

IBM Flex System Fabric CN4093 10Gb Converged Scalable Switch



ISCLI—Industry Standard CLI Command Reference

for IBM Networking OS 7.8

Note: Before using this information and the product it supports, read the general information in the *Safety information and Environmental Notices and User Guide* documents on the IBM *Documentation* CD and the *Warranty Information* document that comes with the product.

First Edition (June 2014)

IBM Flex System Fabric CN4093 10Gb Converged Scalable Switch ISCLI Command Reference

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Preface	xiii
Who Should Use This Book	xiv
How This Book Is Organized	xv
Typographic Conventions	xvi
Chapter 1. ISCLI Basics1
Accessing the ISCLI2
ISCLI Command Modes3
Global Commands7
Command Line Interface Shortcuts9
CLI List and Range Inputs9
Command Abbreviation9
Tab Completion9
User Access Levels	10
Idle Timeout	11
Chapter 2. Information Commands	13
System Information	14
CLI Display Information	15
Error Disable and Recovery Information	16
SNMPv3 System Information	17
SNMPv3 USM User Table Information	18
SNMPv3 View Table Information	19
SNMPv3 Access Table Information	20
SNMPv3 Group Table Information	20
SNMPv3 Community Table Information	21
SNMPv3 Target Address Table Information	21
SNMPv3 Target Parameters Table Information	23
SNMPv3 Notify Table Information	23
SNMPv3 Dump Information	24
General System Information	25
Show Software Version Brief Information	26
Show Specific System Information	26
Show Recent Syslog Messages	27
User Status	28
Stacking Information	29
Stacking Switch Information	30
Attached Switches Information	32
Stack Name Information	32
Stack Backup Switch Information	32
Stack Version Information	32
Stack Packet Path Information	33
Stack Push Status Information	33
Layer 2 Information	35
FDB Information	37
Show All FDB Information	38
Show FDB Multicast Address Information	39
Clearing Entries from the Forwarding Database	39
Link Aggregation Control Protocol Information	40
Link Aggregation Control Protocol	40
Layer 2 Failover Information Commands	41

Layer 2 Failover Information	41
Hot Links Information	43
Edge Control Protocol Information	43
LLDP Information	44
LLDP Remote Device Information	45
Unidirectional Link Detection Information	46
UDLD Port Information	46
OAM Discovery Information	47
OAM Port Information	47
vLAG Information	48
vLAG Trunk Information	48
802.1X Information	49
RSTP/PVRST Information	50
Common Internal Spanning Tree Information	53
Trunk Group Information	54
VLAN Information	56
Layer 3 Information	58
IP Routing Information.	61
Show All IP Route Information	62
ARP Information	63
Show All ARP Entry Information	64
ARP Address List Information	64
BGP Information	65
BGP Peer information	66
BGP Summary Information	66
BGP Aggregation Information	66
Dump BGP Information.	66
OSPF Information	67
OSPF General Information	68
OSPF Interface Loopback Information	69
OSPF Interface Information	69
OSPF Database Information.	70
OSPF Information Route Codes	71
OSPFv3 Information	72
OSPFv3 Information Dump	73
OSPFv3 Interface Information	74
OSPFv3 Database Information.	74
OSPFv3 Route Codes Information	75
Routing Information Protocol	76
RIP Routes Information.	76
RIP Interface Information	76
IPv6 Routing Information.	77
IPv6 Routing Table	77
IPv6 Neighbor Discovery Cache Information	78
IPv6 Neighbor Discovery Cache Information	78
IPv6 Neighbor Discovery Prefix Information	79
ECMP Static Route Information	79
ECMP Hashing Result.	80
IGMP Multicast Group Information	80
IGMP Querier Information.	81
IGMP Group Information	82
IGMP Multicast Router Information	82
IPMC Group Information	83

MLD information	84
VRRP Information	86
Interface Information	87
IPv6 Interface Information	87
IPv6 Path MTU Information	88
IP Information	89
IKEv2 Information	90
IKEv2 Information Dump	91
IPsec Information	92
IPsec Manual Policy Information	93
PIM Information	93
PIM Component Information	95
PIM Interface Information	95
PIM Neighbor Information	96
PIM Multicast Route Information Commands	96
PIM Multicast Route Information	97
Quality of Service Information	98
802.1p Information	98
WRED and ECN Information	99
Access Control List Information Commands	100
Access Control List Information	101
RMON Information Commands	102
RMON History Information	103
RMON Alarm Information	104
RMON Event Information	105
Link Status Information	106
Port Information	108
Port Transceiver Status	110
Virtual Machines Information	112
VM Information	112
VM Check Information	113
VMware Information	113
VMware Host Information	113
EVB Information	115
vNIC Information	116
Virtual NIC (vNIC) Information	116
vNIC Group Information	117
SLP Information	118
UFP Information	118
Port Information	119
CDCP Information	120
QoS Information	120
TLV Status Information	121
Virtual Port Information	121
VLAN Information	122
TLV Information	123
Converged Enhanced Ethernet Information	125
DCBX Information	125
DCBX Control Information	126
DCBX Feature Information	127
DCBX ETS Information	127
DCBX PFC Information	129
DCBX Application Protocol Information	130

ETS Information	132
PFC Information	133
FCoE Information	134
FIP Snooping Information	134
Fibre Channel Information	135
Fabric Login Database Information	137
Fibre Channel Name Server Database Information	138
Fabric Configuration Status Database Information	138
Fibre Channel Forwarding Information	138
NPV Traffic Information	139
Zone Status Information	139
FC Port Information	140
Topology Information	141
Information Dump	142
Chapter 3. Statistics Commands	143
Port Statistics	144
802.1X Authenticator Statistics	146
802.1X Authenticator Diagnostics	147
Bridging Statistics	150
Ethernet Statistics	151
Interface Statistics	154
Interface Protocol Statistics	157
Link Statistics	157
RMON Statistics	158
QoS Queue Statistics	160
Trunk Group Statistics	164
Layer 2 Statistics	165
LACP Statistics	166
Hotlinks Statistics	167
LLDP Port Statistics	168
OAM Statistics	169
vLAG Statistics	169
vLAG ISL Statistics	170
vLAG Statistics	170
Layer 3 Statistics	172
IPv4 Statistics	175
IPv6 Statistics	178
IPv4 Route Statistics	183
IPv6 Route Statistics	184
ARP statistics	184
DNS Statistics	185
ICMP Statistics	186
TCP Statistics	188
UDP Statistics	189
IGMP Statistics	190
MLD Statistics	192
MLD Global Statistics	193
OSPF Statistics	195
OSPF Global Statistics	196
OSPFv3 Statistics	199
OSPFv3 Global Statistics	200
VRRP Statistics	203

PIM Statistics	204
Routing Information Protocol Statistics	205
Management Processor Statistics	206
Packet Statistics	207
MP Packet Statistics.	207
Packet Statistics Log	213
Packet Log example	213
Packet Statistics Last Packet	214
Packet Statistics Dump	214
Logged Packet Statistics	215
TCP Statistics	219
UDP Statistics	220
CPU Statistics	220
CPU Statistics History	223
Access Control List Statistics	224
ACL Statistics	225
VMAP Statistics	225
Fibre Channel over Ethernet Statistics	226
ACL Meter Statistics	227
SNMP Statistics	228
NTP Statistics	232
SLP Statistics	233
Statistics Dump	235
Chapter 4. Configuration Commands	237
Viewing and Saving Changes.	239
System Configuration	240
System Error Disable and Recovery Configuration	243
System Host Log Configuration	244
SSH Server Configuration	246
RADIUS Server Configuration	247
TACACS+ Server Configuration	249
LDAP Server Configuration	252
NTP Server Configuration	254
System SNMP Configuration	257
SNMPv3 Configuration.	259
User Security Model Configuration	261
SNMPv3 View Configuration	262
View-based Access Control Model Configuration	263
SNMPv3 Group Configuration	264
SNMPv3 Community Table Configuration	265
SNMPv3 Target Address Table Configuration	266
SNMPv3 Target Parameters Table Configuration	267
SNMPv3 Notify Table Configuration	268
System Access Configuration.	269
Management Network Configuration	271
User Access Control Configuration	273
System User ID Configuration	274
Strong Password Configuration	275
HTTPS Access Configuration	276
Custom Daylight Saving Time Configuration	277
sFlow Configuration	278
sFlow Port Configuration	278

Port Configuration	279
Port Error Disable and Recovery Configuration	283
Port Link Configuration	283
Temporarily Disabling a Port	284
Unidirectional Link Detection Configuration	285
Port OAM Configuration	286
Port ACL Configuration	286
Port WRED Configuration	287
Port WRED Transmit Queue Configuration	287
Management Port Configuration	288
Stacking Configuration	290
Stacking Switch Configuration.	291
Management Interface Configuration	291
Quality of Service Configuration	293
802.1p Configuration	293
DSCP Configuration	294
Control Plane Protection	295
Weighted Random Early Detection Configuration	296
WRED Transmit Queue Configuration	297
Access Control Configuration	298
Access Control List Configuration	299
Ethernet Filtering Configuration	300
IPv4 Filtering Configuration	301
TCP/UDP Filtering Configuration	302
Packet Format Filtering Configuration.	303
ACL IPv6 Configuration	303
IPv6 Filtering Configuration	304
IPv6 TCP/UDP Filtering Configuration	305
IPv6 Re-Marking Configuration.	306
IPv6 Metering Configuration	307
VMAP Configuration	308
ACL Group Configuration	312
ACL Metering Configuration	313
ACL Re-Mark Configuration	314
Re-Marking In-Profile Configuration	315
Re-Marking Out-of-Profile Configuration	315
IPv6 Re-Marking Configuration	316
IPv6 Re-Marking In-Profile Configuration	317
Port Mirroring	318
Port Mirroring Configuration	319
Layer 2 Configuration.	320
802.1X Configuration	321
802.1X Global Configuration.	321
802.1X Guest VLAN Configuration	323
802.1X Port Configuration.	324
Spanning Tree Configuration	326
MSTP Configuration	329
RSTP/PVRST Configuration.	332
Forwarding Database Configuration	335
Static Multicast MAC Configuration.	336
Static FDB Configuration	337
ECP Configuration	337
LLDP Configuration	338

LLDP Port Configuration	339
LLDP Optional TLV configuration	340
Trunk Configuration	342
IP Trunk Hash Configuration	343
Layer 2 Trunk Hash	343
Layer 3 Trunk Hash	344
Virtual Link Aggregation Control Protocol Configuration	345
vLAG Health Check Configuration	346
vLAG ISL Configuration	347
Link Aggregation Control Protocol Configuration	348
LACP Port Configuration	349
Layer 2 Failover Configuration	350
Failover Trigger Configuration	351
Auto Monitor Configuration	351
Failover Manual Monitor Port Configuration	352
Failover Manual Monitor Control Configuration	353
Hot Links Configuration	354
Hot Links Trigger Configuration	355
Hot Links Master Configuration	356
Hot Links Backup Configuration	357
VLAN Configuration	358
Protocol-Based VLAN Configuration	360
Private VLAN Configuration	362
Layer 3 Configuration	363
IP Interface Configuration	365
Default Gateway Configuration	367
IPv4 Static Route Configuration	368
IP Multicast Route Configuration	369
ARP Configuration	370
ARP Static Configuration	371
IP Forwarding Configuration	372
Network Filter Configuration	373
Routing Map Configuration	374
IP Access List Configuration	376
Autonomous System Filter Path Configuration	377
Routing Information Protocol Configuration	378
Routing Information Protocol Interface Configuration	379
RIP Route Redistribution Configuration	381
Open Shortest Path First Configuration	382
Area Index Configuration	384
OSPF Summary Range Configuration	386
OSPF Interface Configuration	387
OSPF Virtual Link Configuration	389
OSPF Host Entry Configuration	390
OSPF Route Redistribution Configuration	391
OSPF MD5 Key Configuration	391
Border Gateway Protocol Configuration	392
BGP Peer Configuration	394
BGP Redistribution Configuration	397
BGP Aggregation Configuration	398
Multicast Listener Discovery Protocol Configuration	399
IGMP Configuration	401
IGMP Snooping Configuration	402

IGMPv3 Configuration	403
IGMP Relay Configuration	404
IGMP Relay Multicast Router Configuration	405
IGMP Static Multicast Router Configuration	406
IGMP Filtering Configuration	407
IGMP Filter Definition	408
IGMP Filtering Port Configuration	409
IGMP Advanced Configuration	410
IGMP Querier Configuration	410
IKEv2 Configuration	413
IKEv2 Proposal Configuration	413
IKEv2 Preshare Key Configuration	414
IKEv2 Identification Configuration	414
IPsec Configuration	415
IPsec Transform Set Configuration	416
IPsec Traffic Selector Configuration	417
IPsec Dynamic Policy Configuration	418
IPsec Manual Policy Configuration	419
Domain Name System Configuration	421
Bootstrap Protocol Relay Configuration	422
BOOTP Relay Broadcast Domain Configuration	422
VRRP Configuration	424
Virtual Router Configuration	425
Virtual Router Priority Tracking Configuration	427
Virtual Router Group Configuration	428
Virtual Router Group Priority Tracking Configuration	430
VRRP Interface Configuration	431
VRRP Tracking Configuration	432
Protocol Independent Multicast Configuration	433
PIM Component Configuration	433
RP Candidate Configuration	434
RP Static Configuration	434
PIM Interface Configuration	435
IPv6 Default Gateway Configuration	437
IPv6 Static Route Configuration	438
IPv6 Neighbor Discovery Cache Configuration	438
IPv6 Path MTU Configuration	439
IPv6 Neighbor Discovery Prefix Configuration	439
IPv6 Prefix Policy Table Configuration	441
Open Shortest Path First Version 3 Configuration	441
OSPFv3 Area Index Configuration	443
OSPFv3 Summary Range Configuration	445
OSPFv3 AS-External Range Configuration	446
OSPFv3 Interface Configuration	447
OSPFv3 Virtual Link Configuration	451
OSPFv3 Host Entry Configuration	452
OSPFv3 Redist Entry Configuration	453
OSPFv3 Redistribute Configuration	454
IP Loopback Interface Configuration	455
Converged Enhanced Ethernet Configuration	456
ETS Global Configuration	457
ETS Global Priority Group Configuration	457
Priority Flow Control Configuration	458

Port-level 802.1p PFC Configuration458
DCBX Port Configuration459
Fibre Channel Configuration460
FC Port Configuration461
FC VLAN Configuration462
FC Zone Configuration463
FC Zoneset Configuration463
Fibre Channel over Ethernet Configuration465
FIPS Port Configuration466
Remote Monitoring Configuration467
RMON History Configuration467
RMON Event Configuration468
RMON Alarm Configuration469
Virtualization Configuration471
VM Policy Bandwidth Management471
Virtual NIC Configuration472
vNIC Port Configuration473
Virtual NIC Group Configuration473
UFP Configuration475
VM Group Configuration477
VM Check Configuration480
VM Profile Configuration481
VMWare Configuration482
Miscellaneous VMready Configuration483
Edge Virtual Bridge Configuration484
Edge Virtual Bridge Profile Configuration485
Switch Partition (SPAR) Configuration487
Service Location Protocol Configuration488
Configuration Dump490
Saving the Active Switch Configuration491
Restoring the Active Switch Configuration492
Chapter 5. Operations Commands493
Operations-Level Port Commands494
Operations-Level Port 802.1X Commands495
Operations-Level FCoE Commands496
Operations-Level VRRP Commands497
Operations-Level BGP Commands498
Protected Mode Options499
VMware Operations501
VMware Distributed Virtual Switch Operations503
VMware Distributed Port Group Operations504
Edge Virtual Bridge Operations507
Chapter 6. Boot Options509
Stacking Boot Options509
Scheduled Reboot511
Netboot Configuration512
Flexible Port Mapping512
QSFP Port Configuration514
Updating the Switch Software Image515
Loading New Software to Your Switch515
Selecting a Software Image to Run516

Uploading a Software Image from Your Switch	516
Selecting a Configuration Block	518
Resetting the Switch	519
Accessing the IBM Networking OS CLI	520
Changing the Switch Profile	521
Using the Boot Management Menu	522
Recovering from a Failed Software Upgrade	522
Recovering a Failed Boot Image	524
Chapter 7. Maintenance Commands	527
Forwarding Database Maintenance	529
Debugging Commands	531
IP Security Debugging.	532
DCBX Debugging Commands	533
ARP Cache Maintenance	534
IP Route Manipulation	535
LLDP Cache Manipulation	536
IGMP Group Maintenance	537
IGMP Multicast Routers Maintenance	538
IPv6 Neighbor Discovery Cache Manipulation	540
IPv6 Route Maintenance	541
Uuencode Flash Dump	542
TFTP, SFTP or FTP System Dump Put.	543
Clearing Dump Information	544
Unscheduled System Dumps.	545
Appendix A. IBM Networking OS System Log Messages	547
LOG_ALERT	548
LOG_CRIT	550
LOG_ERR	551
LOG_INFO.	552
LOG_NOTICE	555
LOG_WARNING	559
Appendix B. Getting help and technical assistance.	561
Before you call	562
Using the documentation	563
Getting help and information on the World Wide Web	564
Software service and support	565
Hardware service and support	566
IBM Taiwan product service	567
Index	569

Preface

The *IBM Flex System Fabric CN4093 10Gb Converged Scalable Switch ISCLI Command Reference* describes how to configure and use the IBM Networking OS 7.8 software with your IBM Flex System Fabric CN4093 10Gb Converged Scalable Switch. This guide lists each command, together with the complete syntax and a functional description, from the IS Command Line Interface (ISCLI).

For documentation on installing the switches physically, see the *Installation Guide* for your CN4093. For details about the configuration and operation of the CN4093, see the *IBM N/OS 7.8 Application Guide*.

Who Should Use This Book

This book is intended for network installers and system administrators engaged in configuring and maintaining a network. The administrator should be familiar with Ethernet concepts, IP addressing, the Spanning Tree Protocol and SNMP configuration parameters.

How This Book Is Organized

Chapter 1, “ISCLI Basics,” describes how to connect to the switch and access the information and configuration commands. This chapter provides an overview of the command syntax, including command modes, global commands, and shortcuts.

Chapter 2, “Information Commands,” shows how to view switch configuration parameters.

Chapter 3, “Statistics Commands,” shows how to view switch performance statistics.

Chapter 4, “Configuration Commands,” shows how to configure switch system parameters, ports, VLANs, Spanning Tree Protocol, SNMP, Port Mirroring, IP Routing, Port Trunking, and more.

Chapter 5, “Operations Commands,” shows how to use commands which affect switch performance immediately, but do not alter permanent switch configurations (such as temporarily disabling ports). The commands describe how to activate or deactivate optional software features.

Chapter 6, “Boot Options,” describes the use of the primary and alternate switch images, how to load a new software image, and how to reset the software to factory defaults.

Chapter 7, “Maintenance Commands,” shows how to generate and access a dump of critical switch state information, how to clear it, and how to clear part or all of the forwarding database.

Appendix A, “IBM Networking OS System Log Messages,” lists IBM Networking OS System Log Messages.

Appendix B, “Getting help and technical assistance,” contains information on how to get help, service, technical assistance, or more information about IBM products.

“Index” includes pointers to the description of the key words used throughout the book.

Typographic Conventions

The following table describes the typographic styles used in this book.

Table 1. *Typographic Conventions*

Typeface or Symbol	Meaning
plain fixed-width text	<p>This type is used for names of commands, files, and directories used within the text. For example:</p> <p>View the <code>readme.txt</code> file.</p> <p>It also depicts on-screen computer output and prompts.</p>
bold fixed-width text	<p>This bold type appears in command examples. It shows text that must be typed in exactly as shown. For example:</p> <pre>show sys-info</pre>
bold body text	<p>This bold type indicates objects such as window names, dialog box names, and icons, as well as user interface objects such as buttons, and tabs.</p>
<i>italicized body text</i>	<p>This italicized type indicates book titles, special terms, or words to be emphasized.</p>
angle brackets < >	<p>Indicate a variable to enter based on the description inside the brackets. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is</p> <pre>ping <IP address></pre> <p>you enter</p> <pre>ping 192.32.10.12</pre>
braces { }	<p>Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.</p> <p>Example: If the command syntax is</p> <pre>show portchannel {<1-128> hash information}</pre> <p>you enter:</p> <pre>show portchannel <1-128></pre> <p>or</p> <pre>show portchannel hash</pre> <p>or</p> <pre>show portchannel information</pre>

Table 1. Typographic Conventions

Typeface or Symbol	Meaning
brackets []	<p>Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is <code>show interface ip [<125-128>]</code></p> <p>you enter <code>show interface ip</code></p> <p>or <code>show interface ip <125-128></code></p>
vertical line	<p>Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command.</p> <p>Example: If the command syntax is <code>show portchannel {<1-128> hash information}</code></p> <p>you must enter: <code>show portchannel <1-64></code></p> <p>or <code>show portchannel hash</code></p> <p>or <code>show portchannel information</code></p>

Chapter 1. ISCLI Basics

Your CN4093 10Gb Converged Scalable Switch (CN4093) is ready to perform basic switching functions right out of the box. Some of the more advanced features, however, require some administrative configuration before they can be used effectively.

This guide describes the individual ISCLI commands available for the CN4093.

The ISCLI provides a direct method for collecting switch information and performing switch configuration. Using a basic terminal, the ISCLI allows you to view information and statistics about the switch, and to perform any necessary configuration.

This chapter explains how to access the IS Command Line Interface (ISCLI) for the switch.

Accessing the ISCLI

The first time you start the CN4093, it boots into IBM Networking OS CLI. To access the ISCLI, enter the following command and reset the CN4093:

```
Main# boot/mode iscli
```

To access the IBM Networking OS CLI, enter the following command from the ISCLI and reload the CN4093:

```
Router(config)# boot cli-mode ibmnos-cli
```

The switch retains your CLI selection, even when you reset the configuration to factory defaults. The CLI boot mode is not part of the configuration settings.

If you downgrade the switch software to an earlier release, it will boot into IBM Networking OS CLI. However, the switch retains the CLI boot mode, and will restore your CLI choice.

ISCLI Command Modes

The ISCLI has three major command modes listed in order of increasing privileges, as follows:

- **User EXEC mode**

This is the initial mode of access. By default, password checking is disabled for this mode, on console.

- **Privileged EXEC mode**

This mode is accessed from User EXEC mode. This mode can be accessed using the following command: `enable`

- **Global Configuration mode**

This mode allows you to make changes to the running configuration. If you save the configuration, the settings survive a reload of the CN4093. Several sub-modes can be accessed from the Global Configuration mode. For more details, see [Table 1](#).

Each mode provides a specific set of commands. The command set of a higher-privilege mode is a superset of a lower-privilege mode—all lower-privilege mode commands are accessible when using a higher-privilege mode.

[Table 1](#) lists the ISCLI command modes.

Table 1. ISCLI Command Modes

Command Mode/Prompt	Command used to enter or exit
User EXEC Router>	Default mode, entered automatically on console Exit: <code>exit</code> or <code>logout</code>
Privileged EXEC Router#	Enter Privileged EXEC mode, from User EXEC mode: <code>enable</code> Exit to User EXEC mode: <code>disable</code> Quit ISCLI: <code>exit</code> or <code>logout</code>
Global Configuration Router(config)#	Enter Global Configuration mode, from Privileged EXEC mode: <code>configure terminal</code> Exit to Privileged EXEC: <code>end</code> or <code>exit</code>
Interface IP Router(config-ip-if)#	Enter Interface IP Configuration mode, from Global Configuration mode: <code>interface ip <interface number></code> Internal Management IP interface is reachable only by Management Module. Exit to Global Configuration mode: <code>exit</code> Exit to Privileged EXEC mode: <code>end</code>

Table 1. ISCLI Command Modes (continued)

Command Mode/Prompt	Command used to enter or exit
Interface Loopback Router(config-ip-loopback)#	Enter Interface Loopback Configuration mode, from Global Configuration mode: <code>interface loopback <1-5></code> Exit to Global Configuration mode: <code>exit</code> Exit to Privileged EXEC mode: <code>end</code>
Interface Port Router(config-if)#	Enter Port Configuration mode, from Global Configuration mode: <code>interface port <port number or alias></code> Exit to Privileged EXEC mode: <code>exit</code> Exit to Global Configuration mode: <code>end</code>
Interface PortChannel Router(config-PortChannel)#	Enter PortChannel (trunk group) Configuration mode, from Global Configuration mode: <code>interface portchannel {<trunk number> lacp <key>}</code> Exit to Privileged EXEC mode: <code>exit</code> Exit to Global Configuration mode: <code>end</code>
VLAN Router(config-vlan)#	Enter VLAN Configuration mode, from Global Configuration mode: <code>vlan <VLAN number></code> Exit to Global Configuration mode: <code>exit</code> Exit to Privileged EXEC mode: <code>end</code>
Router OSPF Router(config-router-ospf)#	Enter OSPF Configuration mode, from Global Configuration mode: <code>router ospf</code> Exit to Global Configuration mode: <code>exit</code> Exit to Privileged EXEC mode: <code>end</code>
Router BGP Router(config-router-bgp)#	Enter BGP Configuration mode, from Global Configuration mode: <code>router bgp</code> Exit to Global Configuration mode: <code>exit</code> Exit to Privileged EXEC mode: <code>end</code>
Router RIP Router(config-router-rip)#	Enter RIP Configuration mode, from Global Configuration mode: <code>router rip</code> Exit to Global Configuration mode: <code>exit</code> Exit to Privileged EXEC mode: <code>end</code>

Table 1. ISCLI Command Modes (continued)

Command Mode/Prompt	Command used to enter or exit
Route Map Router(config-route-map) #	Enter Route Map Configuration mode, from Global Configuration mode: route-map <1-32> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
Router VRRP Router(config-vrrp) #	Enter VRRP Configuration mode, from Global Configuration mode: router vrrp Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
IKEv2 Proposal Router(config-ikev2-prop) #	Enter IKEv2 Proposal Configuration mode, from Global Configuration mode: ikev2 proposal Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
MLD Configuration Router(config-router-mld) #	Enter Multicast Listener Discovery Protocol Configuration mode, from Global Configuration mode: ipv6 mld Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
MST Configuration	Enter Multiple Spanning Tree Protocol Configuration mode, from Global Configuration mode: spanning-tree mst configuration Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
VSI Database CN4093(conf-vsldb) #	Enter Virtual Station Interface Database Configuration mode, from Global Configuration mode: virt evb vsldb <VSIDB_number> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
EVB Profile CN4093(conf-evbprof) #	Enter Edge Virtual Bridging Profile Configuration mode, from Global Configuration mode: virt evb profile <1-16> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end

Table 1. ISCLI Command Modes (continued)

Command Mode/Prompt	Command used to enter or exit
UFP Virtual Port Configuration CN4093 (config_ufp_vport) #	Enter Unified Fabric Port Virtual Port Configuration mode, from Global Configuration mode: ufp port <port no.> vport <1-4> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
SPAR Configuration CN4093 (config-spar) #	Enter Switch Partition Configuration mode, from Global Configuration mode: spar <1-8> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
FC Port Configuration CN4093 (config-fc) #	Enter Fibre Channel Port Configuration mode, from Global Configuration mode: interface fc <port alias or number> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
FC Zone Configuration CN4093 (config-zone) #	Enter Fibre Channel Zone Configuration mode, from Global Configuration mode: zone name <1-64 characters> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end
FC Zoneset Configuration CN4093 (config-zoneset) #	Enter Fibre Channel Zoneset Configuration mode, from Global Configuration mode: zoneset name <1-64 characters> Exit to Global Configuration mode: exit Exit to Privileged EXEC mode: end

Global Commands

Some basic commands are recognized throughout the ISCLI command modes. These commands are useful for obtaining online help, navigating through the interface, and for saving configuration changes.

For help on a specific command, type the command, followed by `help`.

Table 2. Description of Global Commands

Command	Action
?	Provides more information about a specific command or lists commands available at the current level.
list	Lists the commands available at the current level.
exit	Go up one level in the command mode structure. If already at the top level, exit from the command line interface and log out.
copy running-config startup-config	Write configuration changes to non-volatile flash memory.
logout	Exit from the command line interface and log out.
ping	<p>Use this command to verify station-to-station connectivity across the network. The format is as follows:</p> <pre>ping <host name> <IP address> [-n <tries (0-4294967295)>] [-w <msec delay (0-4294967295)>] [-l <length (0/32-65500/2080)>] [-s <IP source>] [-v <tos (0-255)>] [-f] [-t]</pre> <p>Where:</p> <ul style="list-style-type: none"> - -n: Sets the number of attempts (optional). - -w: Sets the number of milliseconds between attempts (optional). - -l: Sets the ping request payload size (optional). - -s: Sets the IP source address for the IP packet (optional). - -v: Sets the Type Of Service bits in the IP header. - -f: Sets the <i>don't fragment</i> bit in the IP header (only for IPv4 addresses). - -t: Pings continuously (same as -n 0). <p>Where the <i>IP address</i> or <i>hostname</i> specify the target device. Use of a hostname requires DNS parameters to be configured on the switch.</p> <p><i>Tries</i> (optional) is the number of attempts (1-32), and <i>msec delay</i> (optional) is the number of milliseconds between attempts.</p>

Table 2. Description of Global Commands (continued)

Command	Action
tracert	<p>Use this command to identify the route used for station-to-station connectivity across the network. The format is as follows:</p> <pre>tracert {<hostname> <IP address>} [<max-hops (1-32)> [<msec delay>]]</pre> <pre>tracert <hostname> <IP address> [<max-hops (1-32)> [<msec-delay (1-4294967295)>]]</pre> <p>Where <i>hostname/IP address</i> is the hostname or IP address of the target station, <i>max-hops</i> (optional) is the maximum distance to trace (1-32 devices), and <i>msec-delay</i> (optional) is the number of milliseconds to wait for the response.</p> <p>As with <code>ping</code>, the DNS parameters must be configured if specifying hostnames.</p>
telnet	<p>This command is used to form a Telnet session between the switch and another network device. The format is as follows:</p> <pre>telnet {<hostname> <IP address>} [<port>]</pre> <p>Where <i>IP address</i> or <i>hostname</i> specifies the target station. Use of a hostname requires DNS parameters to be configured on the switch.</p> <p><i>Port</i> is the logical Telnet port or service number.</p>
show history	This command displays the last ten issued commands.
show who	Displays a list of users who are currently logged in.
show line	Displays a list of users who are currently logged in, in table format.

Command Line Interface Shortcuts

The following shortcuts allow you to enter commands quickly and easily.

CLI List and Range Inputs

For VLAN and port commands that allow an individual item to be selected from within a numeric range, lists and ranges of items can now be specified. For example, the `vlan` command permits the following options:

<code># vlan 1,3,4095</code>	<i>(access VLANs 1, 3, and 4095)</i>
<code># vlan 1-20</code>	<i>(access VLANs 1 through 20)</i>
<code># vlan 1-5,90-99,4090-4095</code>	<i>(access multiple ranges)</i>
<code># vlan 1-5,19,20,4090-4095</code>	<i>(access a mix of lists and ranges)</i>

The numbers in a range must be separated by a dash: `<start of range> - <end of range>`

Multiple ranges or list items are permitted using a comma: `<range or item 1> , <range or item 2>`

Do not use spaces within list and range specifications.

Ranges can also be used to apply the same command option to multiple items. For example, to access multiple ports with one command:

<code># interface port 1-4</code>	<i>(Access ports 1 through 4)</i>
-----------------------------------	-----------------------------------

Command Abbreviation

Most commands can be abbreviated by entering the first characters which distinguish the command from the others in the same mode. For example, consider the following full command and a valid abbreviation:

<code>Router(config)# spanning-tree stp 2 bridge hello 2</code>
or
<code>Router(config)# sp stp 2 br h 2</code>

Tab Completion

By entering the first letter of a command at any prompt and pressing `<Tab>`, the ISCLI displays all available commands or options that begin with that letter. Entering additional letters further refines the list of commands or options displayed. If only one command fits the input text when `<Tab>` is pressed, that command is supplied on the command line, waiting to be entered.

User Access Levels

To enable better switch management and user accountability, three levels or *classes* of user access have been implemented on the CN4093. Levels of access to CLI, Web management functions, and screens increase as needed to perform various switch management tasks. Conceptually, access classes are defined as follows:

- **user**
Interaction with the switch is completely passive—nothing can be changed on the CN4093. Users may display information that has no security or privacy implications, such as switch statistics and current operational state information.
- **oper**
Operators can make temporary changes on the CN4093. These changes are lost when the switch is rebooted/reset. Operators have access to the switch management features used for daily switch operations. Because any changes an operator makes are undone by a reset of the switch, operators cannot severely impact switch operation.
- **admin**
Administrators are the only ones that may make permanent changes to the switch configuration—changes that are persistent across a reboot or reset of the switch. Administrators can access switch functions to configure and troubleshoot problems on the CN4093. Because administrators can also make temporary (operator-level) changes as well, they must be aware of the interactions between temporary and permanent changes.

Access to switch functions is controlled through the use of unique surnames and passwords. Once you are connected to the switch via local Telnet, remote Telnet, or SSH, you are prompted to enter a password. The default user names/password for each access level are listed in the following table.

Note: It is recommended that you change default switch passwords after initial configuration and as regularly as required under your network security policies.

Table 3. User Access Levels

User Account	Description and Tasks Performed	Password
User	The User has no direct responsibility for switch management. He or she can view all switch status information and statistics, but cannot make any configuration changes to the switch.	user
Operator	The Operator can make temporary changes that are lost when the switch is rebooted/reset. Operators have access to the switch management features used for daily switch operations.	
Administrator	The superuser Administrator has complete access to all command modes, information, and configuration commands on the CN4093 10Gb Converged Scalable Switch, including the ability to change both the user and administrator passwords.	admin

Note: With the exception of the “admin” user, access to each user level can be disabled by setting the password to an empty value.

Idle Timeout

By default, the switch will disconnect your Telnet session after ten minutes of inactivity. This function is controlled by the following command, which can be set from 1 to 60 minutes, or disabled when set to 0:

```
system idle <0-60>
```

Command mode: Global Configuration

Chapter 2. Information Commands

You can view configuration information for the switch in both the user and administrator command modes. This chapter discusses how to use the command line interface to display switch information.

Table 4. Information Commands

Command Syntax and Usage
<pre>show interface status <port alias or number></pre> <p>Displays configuration information about the selected port(s), including:</p> <ul style="list-style-type: none">– Port alias and number– Port speed– Duplex mode (half, full, or auto)– Flow control for transmit and receive (no, yes, or both)– Link status (up, down, or disabled) <p>For details, see page 106.</p> <p>Command mode: All</p>
<pre>show interface trunk <port alias or number></pre> <p>Displays port status information, including:</p> <ul style="list-style-type: none">– Port alias and number– Whether the port uses VLAN Tagging or not– Port VLAN ID (PVID)– Port name– VLAN membership– FDB Learning status– Flooding status <p>For details, see page 108.</p> <p>Command mode: All</p>
<pre>show interface transceiver</pre> <p>Displays the status of the port transceiver module on each external port. For details, see page 110.</p> <p>Command mode: All</p>
<pre>show software-key</pre> <p>Displays the enabled software features.</p> <p>Command mode: All</p>
<pre>show information-dump</pre> <p>Dumps all switch information available (10K or more, depending on your configuration).</p> <p>If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.</p> <p>Command mode: All</p>

System Information

The information provided by each command option is briefly described in [Table 5 on page 14](#), with pointers to where detailed information can be found.

Table 5. System Information Commands

Command Syntax and Usage
<pre>show sys-info</pre> <p>Displays system information, including:</p> <ul style="list-style-type: none">– System date and time– Switch model name and number– Switch name and location– Time of last boot– MAC address of the switch management processor– IP address of management interface– Hardware version and part number– Software image file and version number– Configuration name– Log-in banner, if one is configured– Internal temperatures <p>For details, see page 25.</p> <p>Command mode: All</p>
<pre>show logging [severity <0-7>] [reverse]</pre> <p>Displays the current syslog configuration, followed by the most recent 2000 syslog messages, as displayed by the <code>show logging messages</code> command. For details, see page 27.</p> <p>Command mode: All</p>
<pre>show access user</pre> <p>Displays configured user names and their status.</p> <p>Command mode: Privileged EXEC</p>

CLI Display Information

These commands allow you to display information about the number of lines per screen displayed in the CLI.

Table 6. CLI Display Information Options

Command Syntax and Usage
<pre>show terminal-length</pre> <p>Displays the number of lines per screen displayed in the CLI for the current session. A value of 0 means paging is disabled.</p> <p>Command mode: All</p>
<pre>show line console length</pre> <p>Displays the current line console length setting. For details, see page 240.</p> <p>Command mode: All</p>
<pre>show line vty length</pre> <p>Displays the current line vty length setting. For details, see page 240.</p> <p>Command mode: All</p>

Error Disable and Recovery Information

These commands allow you to display information about the Error Disable and Recovery feature for interface ports.

Table 7. Error Disable Information Commands

Command Syntax and Usage
<pre>show errdisable recovery</pre> <p>Displays a list ports with their Error Recovery status.</p> <p>Command mode: All</p>
<pre>show errdisable timers</pre> <p>Displays a list of active recovery timers, if applicable.</p> <p>Command mode: All</p>
<pre>show errdisable information</pre> <p>Displays all Error Disable and Recovery information.</p> <p>Command mode: All</p>

SNMPv3 System Information

SNMP version 3 (SNMPv3) is an extensible SNMP Framework that supplements the SNMPv2 framework by supporting the following:

- a new SNMP message format
- security for messages
- access control
- remote configuration of SNMP parameters

For more details on the SNMPv3 architecture please refer to RFC2271 to RFC2276.

Table 8. SNMPv3 Commands

Command Syntax and Usage
<pre>show snmp-server v3 user</pre> <p>Displays User Security Model (USM) table information. To view the table, see page 18.</p> <p>Command mode: All</p>
<pre>show snmp-server v3 view</pre> <p>Displays information about view, subtrees, mask and type of view. To view a sample, see page 19.</p> <p>Command mode: All</p>
<pre>show snmp-server v3 access</pre> <p>Displays View-based Access Control information. To view a sample, see page 20.</p> <p>Command mode: All</p>
<pre>show snmp-server v3 group</pre> <p>Displays information about the group, including the security model, user name, and group name. To view a sample, see page 20.</p> <p>Command mode: All</p>
<pre>show snmp-server v3 community</pre> <p>Displays information about the community table information. To view a sample, see page 21.</p> <p>Command mode: All</p>
<pre>show snmp-server v3 target-address</pre> <p>Displays the Target Address table information. To view a sample, see page 21.</p> <p>Command mode: All</p>
<pre>show snmp-server v3 target-parameters</pre> <p>Displays the Target parameters table information. To view a sample, see page 23.</p> <p>Command mode: All</p>

Table 8. SNMPv3 Commands (continued)

Command Syntax and Usage
<pre>show snmp-server v3 notify</pre> <p>Displays the Notify table information. To view a sample, see page 23.</p> <p>Command mode: All</p>
<pre>show snmp-server v3</pre> <p>Displays all the SNMPv3 information. To view a sample, see page 24.</p> <p>Command mode: All</p>

SNMPv3 USM User Table Information

The User-based Security Model (USM) in SNMPv3 provides security services such as authentication and privacy of messages. This security model makes use of a defined set of user identities displayed in the USM user table. The following command displays SNMPv3 user information:

```
show snmp-server v3 user
```

Command mode: All

The USM user table contains the following information:

- the user name
- a security name in the form of a string whose format is independent of the Security Model
- an authentication protocol, which is an indication that the messages sent on behalf of the user can be authenticated
- the privacy protocol

usmUser Table:	
User Name	Protocol
-----	-----
adminmd5	HMAC_MD5, DES PRIVACY
adminsha	HMAC_SHA, DES PRIVACY
v1v2only	NO AUTH, NO PRIVACY

Table 9. USM User Table Information Parameters

Field	Description
User Name	This is a string that represents the name of the user that you can use to access the switch.
Protocol	This indicates whether messages sent on behalf of this user are protected from disclosure using a privacy protocol. IBM Networking OS supports DES algorithm for privacy. The software also supports two authentication algorithms: MD5 and HMAC-SHA.

SNMPv3 View Table Information

The user can control and restrict the access allowed to a group to only a subset of the management information in the management domain that the group can access within each context by specifying the group's rights in terms of a particular MIB view for security reasons.

The following command displays the SNMPv3 View Table:

```
show snmp-server v3 view
```

Command mode: All

View Name	Subtree	Mask	Type
iso	1		included
v1v2only	1		included
v1v2only	1.3.6.1.6.3.15		excluded
v1v2only	1.3.6.1.6.3.16		excluded
v1v2only	1.3.6.1.6.3.18		excluded

Table 10. SNMPv3 View Table Information Parameters

Field	Description
View Name	Displays the name of the view.
Subtree	Displays the MIB subtree as an OID string. A view subtree is the set of all MIB object instances which have a common Object Identifier prefix to their names.
Mask	Displays the bit mask.
Type	Displays whether a family of view subtrees is included or excluded from the MIB view.

SNMPv3 Access Table Information

The access control subsystem provides authorization services.

The vacmAccessTable maps a group name, security information, a context, and a message type, which could be the read or write type of operation or notification into a MIB view.

The View-based Access Control Model defines a set of services that an application can use for checking access rights of a group. This group's access rights are determined by a read-view, a write-view and a notify-view. The read-view represents the set of object instances authorized for the group while reading the objects. The write-view represents the set of object instances authorized for the group when writing objects. The notify-view represents the set of object instances authorized for the group when sending a notification.

The following command displays SNMPv3 access information:

```
show snmp-server v3 access
```

Command mode: All

Group Name	Model	Level	ReadV	WriteV	NotifyV
v1v2grp	snmpv1	noAuthNoPriv	iso	iso	v1v2only
admingrp	usm	authPriv	iso	iso	iso

Table 11. SNMPv3 Access Table Information

Field	Description
Group Name	Displays the name of group.
Model	Displays the security model used, for example, SNMPv1, or SNMPv2 or USM.
Level	Displays the minimum level of security required to gain rights of access. For example, noAuthNoPriv, authNoPriv, or authPriv.
ReadV	Displays the MIB view to which this entry authorizes the read access.
WriteV	Displays the MIB view to which this entry authorizes the write access.
NotifyV	Displays the Notify view to which this entry authorizes the notify access.

SNMPv3 Group Table Information

A group is a combination of security model and security name that defines the access rights assigned to all the security names belonging to that group. The group is identified by a group name.

The following command displays SNMPv3 group information:

```
show snmp-server v3 group
```

Command mode: All

Sec Model	User Name	Group Name
snmpv1	v1v2only	v1v2grp
usm	adminmd5	admingrp
usm	adminsha	admingrp
usm	adminshaaes	admingrp

Table 12. SNMPv3 Group Table Information Parameters

Field	Description
Sec Model	Displays the security model used, which is any one of: USM, SNMPv1, SNMPv2, and SNMPv3.
User Name	Displays the name for the group.
Group Name	Displays the access name of the group.

SNMPv3 Community Table Information

This command displays the community table information stored in the SNMP engine. The following command displays SNMPv3 community information:

```
show snmp-server v3 community
```

Command mode: All

Index	Name	User Name	Tag
trap1	public	v1v2only	v1v2trap

Table 13. SNMPv3 Community Table Information Parameters

Field	Description
Index	Displays the unique index value of a row in this table
Name	Displays the community string, which represents the configuration.
User Name	Displays the User Security Model (USM) user name.
Tag	Displays the community tag. This tag specifies a set of transport endpoints from which a command responder application accepts management requests and to which a command responder application sends an SNMP trap.

SNMPv3 Target Address Table Information

The following command displays SNMPv3 target address information:

```
show snmp-server v3 target-address
```

Command mode: All

This command displays the SNMPv3 target address table information, which is stored in the SNMP engine.

Name	Transport Addr	Port	Taglist	Params
-----	-----	-----	-----	-----
trap1	47.81.25.66	162	v1v2trap	v1v2param

Table 14. SNMPv3 Target Address Table Information Parameters

Field	Description
Name	Displays the locally arbitrary, but unique identifier associated with this <code>snmpTargetAddrEntry</code> .
Transport Addr	Displays the transport addresses.
Port	Displays the SNMP UDP port number.
Taglist	This column contains a list of tag values which are used to select target addresses for a particular SNMP message.
Params	The value of this object identifies an entry in the <code>snmpTargetParamsTable</code> . The identified entry contains SNMP parameters to be used when generating messages to be sent to this transport address.

SNMPv3 Target Parameters Table Information

The following command displays SNMPv3 target parameters information:

```
show snmp-server v3 target-parameters
```

Command mode: All

Name	MP Model	User Name	Sec Model	Sec Level
v1v2param	snmpv2c	v1v2only	snmpv1	noAuthNoPriv

Table 15. SNMPv3 Target Parameters Table Information

Field	Description
Name	Displays the locally arbitrary, but unique identifier associated with this <code>snmpTargetParamsEntry</code> .
MP Model	Displays the Message Processing Model used when generating SNMP messages using this entry.
User Name	Displays the <code>securityName</code> , which identifies the entry on whose behalf SNMP messages will be generated using this entry.
Sec Model	Displays the security model used when generating SNMP messages using this entry. The system may choose to return an <code>inconsistentValue</code> error if an attempt is made to set this variable to a value for a security model which the system does not support.
Sec Level	Displays the level of security used when generating SNMP messages using this entry.

SNMPv3 Notify Table Information

The following command displays the SNMPv3 Notify table:

```
show snmp-server v3 notify
```

Command mode: All

Name	Tag
v1v2trap	v1v2trap

Table 16. SNMPv3 Notify Table Information

Field	Description
Name	The locally arbitrary, but unique identifier associated with this <code>snmpNotifyEntry</code> .
Tag	This represents a single tag value which is used to select entries in the <code>snmpTargetAddrTable</code> . Any entry in the <code>snmpTargetAddrTable</code> that contains a tag value equal to the value of this entry, is selected. If this entry contains a value of zero length, no entries are selected.

SNMPv3 Dump Information

The following command displays SNMPv3 information:

```
show snmp-server v3
```

Command mode: All

```

usmUser Table:
User Name                Protocol
-----
adminmd5                 HMAC_MD5, DES PRIVACY
adminsha                 HMAC_SHA, DES PRIVACY
v1v2only                 NO AUTH, NO PRIVACY

vacmAccess Table:
Group Name Prefix Model  Level      Match  ReadV  WriteV  NotifyV
-----
v1v2grp          snmpv1  noAuthNoPriv  exact  iso    iso    v1v2only
admingrp         usm     authPriv      exact  iso    iso    iso

vacmViewTreeFamily Table:
View Name      Subtree      Mask          Type
-----
iso            1            included
v1v2only      1            included
v1v2only      1.3.6.1.6.3.15  excluded
v1v2only      1.3.6.1.6.3.16  excluded
v1v2only      1.3.6.1.6.3.18  excluded

vacmSecurityToGroup Table:
Sec Model  User Name                Group Name
-----
snmpv1     v1v2only                 v1v2grp
usm        adminmd5                 admingrp
usm        adminsha                 admingrp

snmpCommunity Table:
Index      Name      User Name      Tag
-----

snmpNotify Table:
Name                Tag
-----

snmpTargetAddr Table:
Name      Transport Addr  Port  Taglist  Params
-----

snmpTargetParams Table:
Name                MP Model  User Name                Sec Model  Sec Level
-----

```

General System Information

The following command displays system information:

```
show sys-info
```

Command mode: All

```
System Information at 16:50:45 Wed Nov 16, 2011
Time zone: America/US/Pacific
Daylight Savings Time Status: Disabled

IBM Flex System Fabric CN4093 10Gb Converged Scalable Switch
IBM Flex System Fabric CN4093 10Gb Converged Scalable Switch (BW build)

Switch has been up 5 days, 2 hours, 16 minutes and 42 seconds.
Last boot: 0:00:47 Wed Jan 3, 2010 (reset from console)

MAC address: 00:00:00:00:00:00   IP (If 1) address: 0.0.0.0
Internal Management Port MAC Address: 00:00:00:00:00:ef
Internal Management Port IP Address (if 128): 9.43.95.121
External Management Port MAC Address: 00:00:00:00:00:fe
External Management Port IP Address (if 127):
WARNING: This is UNRELEASED SOFTWARE for LAB TESTING ONLY.
         DO NOT USE IN A PRODUCTION NETWORK.

Software Version 7.9.0.19 (FLASH image2), active configuration.
Boot kernel version 7.9.0.19

Hardware Part Number       : 95Y3315
Hardware Revision         : 05
Serial Number             : Y030CM31B047
Manufacturing Date (WYY)  : 0513

PCBA Part Number          : 00D6224
PCBA Revision             : 0
PCBA Number               : 00
Board Revision            : 05
PLD Firmware Version      : 1.7
Temperature Warning       : 44 C (Warning at 60 C / Recover at 55 C)
Temperature Shutdown     : 43 C (Shutdown at 65 C / Recover at 60 C)
Temperature Inlet        : 38 C
Temperature Exhaust       : 44 C
Temperature Asic Max     : 47 C (Warning at 100 C / Shutdown at 108 C)
```

Note: The display of temperature will come up only if the temperature of any of the sensors exceeds the temperature threshold. There will be a warning from the software if any of the sensors exceeds this temperature threshold. The switch will shut down if the power supply overheats.

System information includes:

- System date and time
- Switch model
- Switch name and location
- Time of last boot
- MAC address of the switch management processor
- Software image file and version number, and configuration name.
- IP address of the management interface
- Hardware version and part number
- Log-in banner, if one is configured
- Internal temperatures

Show Software Version Brief Information

The following command displays brief software version information:

```
show version brief
```

Command mode: All

```
Software Version 7.8.1.0 (FLASH image2), active configuration.
```

Displays the software version number, image file, and configuration name.

Show Specific System Information

[Table 17](#) lists commands used for displaying specific entries from the general system information screen

Table 17. Specific System Information Options

Command Syntax and Usage
<pre>show version brief</pre> <p>Displays the software version number, image file, and configuration name.</p> <p>Command mode: All</p>

Show Recent Syslog Messages

The following command displays system log messages:

```
show logging messages [severity <0-7>] [reverse]
```

Command mode: All

Date	Time	Criticality level	Message
Jul 8	17:25:41	NOTICE	system: link up on port INT1
Jul 8	17:25:41	NOTICE	system: link up on port INT8
Jul 8	17:25:41	NOTICE	system: link up on port INT7
Jul 8	17:25:41	NOTICE	system: link up on port INT2
Jul 8	17:25:41	NOTICE	system: link up on port INT1
Jul 8	17:25:41	NOTICE	system: link up on port INT4
Jul 8	17:25:41	NOTICE	system: link up on port INT3
Jul 8	17:25:41	NOTICE	system: link up on port INT6
Jul 8	17:25:41	NOTICE	system: link up on port INT5
Jul 8	17:25:41	NOTICE	system: link up on port EXT4
Jul 8	17:25:41	NOTICE	system: link up on port EXT1
Jul 8	17:25:41	NOTICE	system: link up on port EXT3
Jul 8	17:25:41	NOTICE	system: link up on port EXT2
Jul 8	17:25:41	NOTICE	system: link up on port INT3
Jul 8	17:25:42	NOTICE	system: link up on port INT2
Jul 8	17:25:42	NOTICE	system: link up on port INT4
Jul 8	17:25:42	NOTICE	system: link up on port INT3
Jul 8	17:25:42	NOTICE	system: link up on port INT6

Each syslog message has a severity level associated with it, included in text form as a prefix to the log message. One of eight different prefixes is used, depending on the condition for which the administrator is being notified.

- EMERG Indicates the system is unusable
- ALERT Indicates action should be taken immediately
- CRIT Indicates critical conditions
- ERR Indicates error conditions or errored operations
- WARNING Indicates warning conditions
- NOTICE Indicates a normal but significant condition
- INFO Indicates an information message
- DEBUG Indicates a debug-level message

The `severity` option filters only syslog messages with a specific severity level between 0 and 7, from EMERG to DEBUG correspondingly.

The `reverse` option displays the output in reverse order, from the newest entry to the oldest.

User Status

The following command displays user status information:

```
show access user
```

Command mode: All except User EXEC

```
Username:
  user   - enabled - offline
  oper   - disabled - offline
  admin  - Always Enabled - online 1 session
Current User ID table:
  1: name paul   , dis, cos user   , password valid, offline
Current strong password settings:
  strong password status: disabled
```

This command displays the status of the configured usernames.

Stacking Information

Table 18 lists the Stacking information options.

Table 18. Stacking Information Commands

Command Syntax and Usage
<pre>show stack switch</pre> <p>Displays information about each switch in the stack, including:</p> <ul style="list-style-type: none">– Configured Switch Number (csnum)– Attached Switch Number (asnum) when run on master switch– MAC address– Stacking state– UUID– Bay number <p>Command mode: All</p>
<pre>show stack attached-switches</pre> <p>Displays information about each attached switch in the stack. Available only on the master switch.</p> <p>Command mode: All</p>
<pre>show stack link</pre> <p>Displays link information for each switch in the stack, listed by attached switch number.</p> <p>Command mode: All</p>
<pre>show stack name</pre> <p>Displays the name of the stack.</p> <p>Command mode: All</p>
<pre>show stack backup</pre> <p>Displays the unit number of the backup switch.</p> <p>Command mode: All</p>
<pre>show stack version</pre> <p>Displays the firmware version number for all attached switches.</p> <p>Command mode: All</p>
<pre>show stack path-map [csnum <1-8>]</pre> <p>Displays the path used to send known unicast packets from one switch of the stack to another.</p> <p>Command mode: All</p>

Table 18. Stacking Information Commands

Command Syntax and Usage
<pre>show stack push-status</pre> <p>Displays the status of the most recent firmware and configuration file push from the master to member switches.</p> <p>Command mode: All</p>
<pre>show stack dynamic</pre> <p>Displays all stacking information.</p> <p>Command mode: All</p>

Stacking Switch Information

The following command displays Stacking switch information:

```
show stack switch
```


Command mode: All

```
Stack name: STK
Local switch is the master.

Local switch:
  csnum           - 1
  MAC             - 74:99:75:21:8d:00
  UUID           - 534c8ca1605846299148305adc9a1f6d
  Bay Number     - 1
  Switch Type    - 14
  Chassis Type   - 6 (Flex Enterprise)
  Switch Mode (cfg) - Master
  Priority       - 250
  Stack MAC     - 74:99:75:21:8d:1f

Master switch:
  csnum           - 1
  MAC             - 74:99:75:21:8d:00
  UUID           - 534c8ca1605846299148305adc9a1f6d
  Bay Number     - 1

Backup switch:
  csnum           - 5
  MAC             - 74:99:75:21:8c:00
  UUID           - 98c587636548429aba5010f8c62d4e27
  Bay Number     - 1

Configured Switches:
-----
csnum           UUID                               Bay      MAC                               asnum
-----
C1  534c8ca1605846299148305adc9a1f6d  1  74:99:75:21:8d:00  A1
C2  534c8ca1605846299148305adc9a1f6d  2  08:17:f4:84:34:00  A3
C3  534c8ca1605846299148305adc9a1f6d  3  08:17:f4:0a:2d:00  A2
C4  534c8ca1605846299148305adc9a1f6d  4  74:99:75:1c:77:00  A4
C5  98c587636548429aba5010f8c62d4e27  1  74:99:75:21:8c:00  A5

Attached Switches in Stack:
-----
asnum           UUID                               Bay      MAC                               csnum  State
-----
A1  534c8ca1605846299148305adc9a1f6d  1  74:99:75:21:8d:00  C1    IN_STACK
A2  534c8ca1605846299148305adc9a1f6d  3  08:17:f4:0a:2d:00  C3    IN_STACK
A3  534c8ca1605846299148305adc9a1f6d  2  08:17:f4:84:34:00  C2    IN_STACK
A4  534c8ca1605846299148305adc9a1f6d  4  74:99:75:1c:77:00  C4    IN_STACK
A5  98c587636548429aba5010f8c62d4e27  1  74:99:75:21:8c:00  C5    IN_STACK
```

Stack switch information includes the following:

- Stack name
- Details about the local switch from which the command was issued
- Configured switch number and MAC of the Stack Master and Stack Backup
- Configured switch numbers and their associated assigned switch numbers
- Attached switch numbers and their associated configured switch numbers

Attached Switches Information

The following command displays information about attached switches, when run on master switch:

```
show stack attached-switches
```

Command mode: All

```
Attached Switches in Stack:
-----
```

asnum	UUID	Bay	MAC	csnum	State
A1	534c8ca1605846299148305adc9a1f6d	1	74:99:75:21:8d:00	C1	IN_STACK
A2	534c8ca1605846299148305adc9a1f6d	3	08:17:f4:0a:2d:00	C3	IN_STACK
A3	534c8ca1605846299148305adc9a1f6d	2	08:17:f4:84:34:00	C2	IN_STACK
A4	534c8ca1605846299148305adc9a1f6d	4	74:99:75:1c:77:00	C4	IN_STACK
A5	98c587636548429aba5010f8c62d4e27	1	74:99:75:21:8c:00	C5	IN_STACK

Stack Name Information

The following command displays the name of the stack:

```
show stack name
```

Command mode: All

```
Stack name: STK
```

Stack Backup Switch Information

The following command displays the unit number for the backup switch:

```
show stack backup
```

Command mode: All

```
Current config Backup unit number = 5
```

Stack Version Information

The following command displays firmware version information for each switch in the stack:

```
show stack version
```

Command mode: All

```
Switch Firmware Versions:
-----
asnum  csnum      MAC          S/W      Version    Serial #
-----
A1     C1    74:99:75:21:8d:00  image1  7.7.1.10   Y250CM28Y653
A2     C3    08:17:f4:0a:2d:00  image1  7.7.1.10   US7049000Y
A3     C2    08:17:f4:84:34:00  image1  7.7.1.10   Y010CM161680
A4     C4    74:99:75:1c:77:00  image1  7.7.1.10   Y010CM28E857
A5     C5    74:99:75:21:8c:00  image1  7.7.1.10   Y250CM28Y639
```

Stack Packet Path Information

The following command displays information about the path used to send known unicast packets between the switches of a stack.

```
show stack path-map
```

Command mode: All

```
Packet path Information:
-----
To-> Swu  1 | Swu  2 | Swu  3 | Swu  4 | Swu  5 | Swu  6 | Swu  7 | Swu  8 |
Swu 1 |    0 | 1:45 | 1:45 | 1:49 | 1:49 |    0 |    0 |
Swu 2 | 2:61 |    0 | 2:61 | 2:57 | 2:57 |    0 |    0 |
Swu 3 | 3:57 | 3:61 |    0 | 3:57 | 3:61 |    0 |    0 |
Swu 4 | 4:57 | 4:61 | 4:57 |    0 | 4:61 |    0 |    0 |
Swu 5 | 5:45 | 5:49 | 5:49 | 5:45 |    0 |    0 |    0 |
Swu 6 |    0 |    0 |    0 |    0 |    0 |    0 |    0 |
Swu 7 |    0 |    0 |    0 |    0 |    0 |    0 |    0 |
Swu 8 |    0 |    0 |    0 |    0 |    0 |    0 |    0 |
```

Stack Push Status Information

The following command displays the status of the most recent firmware and configuration file push from the master to member switches:

```
show stack push-status
```

Command mode: All

```
Image 1 transfer status info:
Switch 08:17:f4:0a:2d:00:
    not received - file not sent or transfer in progress
Switch 08:17:f4:84:34:00:
    not received - file not sent or transfer in progress
Switch 74:99:75:1c:77:00:
    not received - file not sent or transfer in progress
Switch 74:99:75:21:8c:00:
    not received - file not sent or transfer in progress

Image 2 transfer status info:
Switch 08:17:f4:0a:2d:00:
    not received - file not sent or transfer in progress
Switch 08:17:f4:84:34:00:
    not received - file not sent or transfer in progress
Switch 74:99:75:1c:77:00:
    not received - file not sent or transfer in progress
Switch 74:99:75:21:8c:00:
    not received - file not sent or transfer in progress

Boot image transfer status info:
Switch 08:17:f4:0a:2d:00:
    not received - file not sent or transfer in progress
Switch 08:17:f4:84:34:00:
    not received - file not sent or transfer in progress
Switch 74:99:75:1c:77:00:
    not received - file not sent or transfer in progress
Switch 74:99:75:21:8c:00:
    not received - file not sent or transfer in progress

Config file transfer status info:
Switch 08:17:f4:0a:2d:00:
    last receive successful
Switch 08:17:f4:84:34:00:
    last receive successful
Switch 74:99:75:1c:77:00:
    last receive successful
Switch 74:99:75:21:8c:00:
    last receive successful
```

Layer 2 Information

The following commands display Layer 2 information.

Table 19. Layer 2 Information Commands

Command Syntax and Usage
<pre>show dot1x information</pre> <p>Displays 802.1X Information.</p> <p>Command mode: All</p> <p>For details, see page 49.</p>
<pre>show spanning-tree</pre> <p>Displays Spanning Tree information, including the status (on or off), Spanning Tree mode (RSTP, PVRST, or MSTP), and VLAN membership.</p> <p>In addition to seeing if spanning tree groups (STGs) are enabled or disabled, you can view the following STG bridge information:</p> <ul style="list-style-type: none">– Priority– Hello interval– Maximum age value– Forwarding delay– Aging time <p>You can also see the following port-specific STG information:</p> <ul style="list-style-type: none">– Port alias and priority– Cost– State <p>Command mode: All</p>
<pre>show spanning-tree stp <1-128> information</pre> <p>Displays information about a specific Spanning Tree Group.</p> <p>Command mode: All</p> <p>For details, see page 49.</p>

Table 19. Layer 2 Information Commands (continued)

Command Syntax and Usage
<p><code>show spanning-tree mst 0 information</code></p> <p>Displays Common Internal Spanning Tree (CIST) information for the specified instance, including the MSTP digest and VLAN membership.</p> <p>CIST bridge information includes:</p> <ul style="list-style-type: none"> – Priority – Hello interval – Maximum age value – Forwarding delay – Root bridge information (priority, MAC address, path cost, root port) <p>CIST port information includes:</p> <ul style="list-style-type: none"> – Port number and priority – Cost – State <p>For details, see page 53.</p> <p>Command mode: All</p>
<p><code>show spanning-tree mst configuration</code></p> <p>Displays the current MSTP settings.</p>
<p><code>show portchannel information</code></p> <p>Displays the state of each port in the various static or LACP trunk groups. For details, see page 54.</p> <p>Command mode: All</p>
<p><code>show vlan</code></p> <p>Displays VLAN configuration information for all configured VLANs, including:</p> <ul style="list-style-type: none"> – VLAN Number – VLAN Name – Status – Port membership of the VLAN <p>For details, see page 56.</p> <p>Command mode: All</p>
<p><code>show failover trigger <trigger number></code></p> <p>Displays Layer 2 Failover information. For details, see page 41.</p> <p>Command mode: All</p>

Table 19. Layer 2 Information Commands (continued)

Command Syntax and Usage
<pre>show hotlinks information</pre> <p>Displays Hot Links information. For details, see page 43.</p> <p>Command mode: All</p>
<pre>show layer2 information</pre> <p>Dumps all Layer 2 switch information available (10K or more, depending on your configuration).</p> <p>If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.</p> <p>Command mode: All</p>

FDB Information

The forwarding database (FDB) contains information that maps the media access control (MAC) address of each known device to the switch port where the device address was learned. The FDB also shows which other ports have seen frames destined for a particular MAC address.

Note: The master forwarding database supports up to 32K MAC address entries on the MP per switch.

Table 20. FDB Information Commands

Command Syntax and Usage
<pre>show mac-address-table address <MAC address></pre> <p>Displays a single database entry by its MAC address. You are prompted to enter the MAC address of the device. Enter the MAC address using the format, xx:xx:xx:xx:xx:xx. For example, 08:00:20:12:34:56</p> <p>You can also enter the MAC address using the format, xxxxxxxxxxxx. For example, 080020123456</p> <p>Command mode: All</p>
<pre>show mac-address-table interface port <port alias or number></pre> <p>Displays all FDB entries for a particular port.</p> <p>Command mode: All</p>
<pre>show mac-address-table vlan <VLAN number></pre> <p>Displays all FDB entries on a single VLAN.</p> <p>Command mode: All</p>
<pre>show mac-address-table state {unknown forward trunk}</pre> <p>Displays all FDB entries for a particular state.</p> <p>Command mode: All</p>
<pre>show mac-address-table multicast</pre> <p>Displays all Multicast MAC entries in the FDB.</p> <p>Command mode: All</p>

Table 20. FDB Information Commands (continued)

Command Syntax and Usage
<pre>show mac-address-table static</pre> <p>Displays all static MAC entries in the FDB.</p> <p>Command mode: All</p>
<pre>show mac-address-table configured static</pre> <p>Displays all configured static MAC entries in the FDB.</p> <p>Command mode: All</p>
<pre>show mac-address-table</pre> <p>Displays all entries in the Forwarding Database.</p> <p>Command mode: All</p> <p>For more information, see page 38.</p>
<pre>show mac-address-table all</pre> <p>Displays both unicast (static and dynamic) and multicast (static) entries in the Forwarding Database.</p> <p>Command mode: All</p>

Show All FDB Information

The following command displays Forwarding Database information:

```
show mac-address-table
```

Command mode: All

MAC address	VLAN	Port	Trnk	State	Permanent
00:04:38:90:54:18	1	EXT4		FWD	
00:09:6b:9b:01:5f	1	INT13		FWD	
00:09:6b:ca:26:ef	4095	MGT1		FWD	
00:0f:06:ec:3b:00	4095	MGT1		FWD	
00:11:43:c4:79:83	1	EXT4		FWD	P

An address that is in the forwarding (FWD) state, means that it has been learned by the switch. When in the trunking (TRK) state, the port field represents the trunk group number. If the state for the port is listed as unknown (UNK), the MAC address has not yet been learned by the switch, but has only been seen as a destination address.

When an address is in the unknown state, no outbound port is indicated, although ports that reference the address as a destination will be listed under “Reference ports.”

Show FDB Multicast Address Information

The following commands display Multicast Forwarding Database information..

Table 21. Multicast FDB Information Commands

Command Syntax and Usage
<pre>show mac-address-table multicast address <MAC address></pre> <p>Displays a single FDB multicast entry by its MAC address. You are prompted to enter the MAC address of the device. Enter the MAC address using the format, xx:xx:xx:xx:xx:xx. For example, 03:00:20:12:34:56</p> <p>You can also enter the MAC address using the format, xxxxxxxxxxxx. For example, 030020123456</p> <p>Command mode: All</p>
<pre>show mac-address-table multicast interface port <port alias or number></pre> <p>Displays all FDB multicast entries for a particular port.</p> <p>Command mode: All</p>
<pre>show mac-address-table vlan <VLAN number></pre> <p>Displays all FDB multicast entries on a single VLAN.</p> <p>Command mode: All</p>
<pre>show mac-address-table multicast</pre> <p>Displays all Multicast MAC entries in the FDB.</p> <p>Command mode: All</p>

Clearing Entries from the Forwarding Database

To clear the entire FDB, refer to [“Forwarding Database Maintenance” on page 529](#).

Link Aggregation Control Protocol Information

Use these commands to display LACP status information about each port on the CN4093.

Table 22. LACP Information Commands

Command Syntax and Usage
<pre>show lacp aggregator <aggregator ID></pre> <p>Displays detailed information about the LACP aggregator.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> lacp information</pre> <p>Displays LACP information about the selected port.</p> <p>Command mode: All</p>
<pre>show lacp information</pre> <p>Displays a summary of LACP information.</p> <p>Command mode: All</p> <p>For details, see page 40.</p>

Link Aggregation Control Protocol

The following command displays LACP information:

```
show lacp information
```

Command mode: All

port	mode	adminkey	operkey	selected	prio	aggr	trunk	status	minlinks
1	off	1	1	no	32768	--	--	--	1
2	off	2	2	no	32768	--	--	--	1
3	off	3	3	no	32768	--	--	--	1
...									

LACP dump includes the following information for each external port in the CN4093:

- **mode** Displays the port's LACP mode (active, passive, or off).
- **adminkey** Displays the value of the port's *adminkey*.
- **operkey** Shows the value of the port's operational key.
- **selected** Indicates whether the port has been selected to be part of a Link Aggregation Group.
- **prio** Shows the value of the port priority.
- **aggr** Displays the aggregator associated with each port.
- **trunk** This value represents the LACP trunk group number.
- **status** Displays the status of LACP on the port (up, down or standby).
- **minlinks** Displays the minimum number of active links in the LACP trunk.

Layer 2 Failover Information Commands

Table 23. Layer 2 Failover Information Commands

Command Syntax and Usage
<pre>show failover trigger <trigger number></pre> <p>Displays detailed information about the selected Layer 2 Failover trigger.</p> <p>Command mode: All</p>
<pre>show failover trigger</pre> <p>Displays a summary of Layer 2 Failover information. For details, see page 41.</p> <p>Command mode: All</p>

Layer 2 Failover Information

The following command displays Layer 2 Failover information:

```
show failover trigger
```

Command mode: All

```
trunk 1
EXT2      Operational
EXT3      Operational

Control State: Auto Disabled
Member    Status
-----
INT1      Operational
INT2      Operational
INT3      Operational
INT4      Operational

Trigger 2 Manual Monitor: Enabled
Trigger 2 limit: 0
Monitor State: Down
Member    Status
-----
adminkey 62
EXT20     Failed
Control State: Auto Disabled
Member    Status
-----

Physical ports
INTC1     Failed
Virtual ports
INTB1.2   Failed
INTB2.2   Failed
INTB3.2   Failed
INTB4.2   Failed
INTB5.2   Failed
INTB6.2   Failed
INTB7.2   Failed
INTB8.2   Failed
INTB9.2   Failed
INTB10.2  Failed
INTB11.2  Failed
...
```

A monitor port's Failover status is `Operational` only if all the following conditions hold true:

- Port link is up.
- If Spanning-Tree is enabled, the port is in the `Forwarding` state.
- If the port is a member of an LACP trunk group, the port is aggregated.

If any of these conditions are not true, the monitor port is considered to be failed.

A control port is considered to be operational if the monitor trigger state is `Up`. Even if a port's link status is `Down`, Spanning-Tree status is `Blocking`, and the LACP status is `Not Aggregated`, from a teaming perspective the port status is `Operational`, since the trigger is `Up`.

A control port's status is displayed as `Failed` when the monitor trigger state is `Down` or when the controlled port is a vPort which is not properly configured (UFP feature is not enabled in switch, port is not configured as UFP port, vport is not enabled or physical port is not enabled).

Hot Links Information

The following command displays Hot Links information:

```
show hotlinks information
```

Command mode: All

```
Hot Links Info: Trigger

Current global Hot Links setting: ON
Hot Links BPDU flood: disabled
Hot Links FDB update: disabled
FDB update rate (pps): 500

Current Trigger 1 setting: enabled
name "Test", preempt enabled, fdelay 30 sec

Active state: None

Master settings:
    port EXT22
Backup settings:
    port EXT1
```

Hot Links information includes the following:

- Hot Links status (on or off)
- Status of BPDU flood option
- Status of FDB send option
- Status and configuration of each Hot Links trigger

Edge Control Protocol Information

Table 24. ECP Information Options

Command Syntax and Usage
<pre>show ecp channels</pre> <p>Displays all Edge Control Protocol (ECP) channels.</p> <p>Command mode: All</p>
<pre>show ecp upper-layer-protocols</pre> <p>Displays all registered Upper-Level Protocols (ULPs).</p> <p>Command mode: All</p>

LLDP Information

The following commands display LLDP information.

Table 25. LLDP Information Commands

Command Syntax and Usage
<pre>show lldp port</pre> <p>Displays Link Layer Discovery Protocol (LLDP) port information.</p> <p>Command mode: All</p>
<pre>show lldp receive</pre> <p>Displays information about the LLDP receive state machine.</p> <p>Command mode: All</p>
<pre>show lldp transmit</pre> <p>Displays information about the LLDP transmit state machine.</p> <p>Command mode: All</p>
<pre>show lldp remote-device [<I-256> detail]</pre> <p>Displays information received from LLDP-capable devices. To view a sample display, see page 45.</p>
<pre>show lldp port <I-16> tlv evb</pre> <p>Displays Edge Virtual Bridge (EVB) type-length-value (TLV) information.</p> <p>Command mode: All</p>
<pre>show lldp information</pre> <p>Displays all LLDP information.</p> <p>Command mode: All</p>

LLDP Remote Device Information

The following command displays LLDP remote device information:

```
show lldp remote-device [<I-256>|detail]
```

Command mode: All

LLDP Remote Devices Information				
LocalPort	Index	Remote Chassis ID	RemotePort	Remote System Name
MGT	210	00 16 ca ff 7e 00	15	BNT Gb Ethernet Switch...
EXT4	15	00 16 60 f9 3b 00	20	BNT Gb Ethernet Switch...

LLDP remote device information provides a summary of information about remote devices connected to the switch. To view detailed information about a device, as shown below, follow the command with the index number of the remote device. To view detailed information about all devices, use the `detail` option.

Local Port Alias: EXT1	
Remote Device Index	: 15
Remote Device TTL	: 99
Remote Device RxChanges	: false
Chassis Type	: Mac Address
Chassis Id	: 00-18-b1-33-1d-00
Port Type	: Locally Assigned
Port Id	: 23
Port Description	: EXT1
System Name :	
System Description : IBM Networking Operating System IBM Flex System Fabric CN4093 10Gb Converged Scalable Switch, IBM Networking OS: version 7.6.1,0 Boot image: version 7.7.1	
System Capabilities Supported : bridge, router	
System Capabilities Enabled : bridge, router	
Remote Management Address:	
Subtype	: IPv4
Address	: 10.100.120.181
Interface Subtype	: ifIndex
Interface Number	: 128
Object Identifier	:

Unidirectional Link Detection Information

The following commands show unidirectional link detection information.

Table 26. UDLD Information Commands

Command Syntax and Usage
<pre>show interface port <port alias or number> udld</pre> <p>Displays UDLD information about the selected port.</p> <p>Command mode: All</p>
<pre>show udld</pre> <p>Displays all UDLD information.</p> <p>Command mode: All</p>

UDLD Port Information

The following command displays UDLD information for the selected port:

```
show interface port <port alias or number> udld
```

Command mode: All

<pre>UDLD information on port EXT1 Port enable administrative configuration setting: Enabled Port administrative mode: normal Port enable operational state: link up Port operational state: advertisement Port bidirectional status: bidirectional Message interval: 15 Time out interval: 5 Neighbor cache: 1 neighbor detected Entry #1 Expiration time: 31 seconds Device Name: Device ID: 00:da:c0:00:04:00 Port ID: EXT1</pre>

UDLD information includes the following:

- Status (enabled or disabled)
- Mode (normal or aggressive)
- Port state (link up or link down)
- Bi-directional status (unknown, unidirectional, bidirectional, TX-RX loop, neighbor mismatch)

OAM Discovery Information

Table 27. OAM Discovery Information Commands

Command Syntax and Usage
<pre>show interface port <port alias or number> oam</pre> <p>Displays OAM information about the selected port.</p> <p>Command mode: All</p>
<pre>show oam</pre> <p>Displays all OAM information.</p> <p>Command mode: All</p>

OAM Port Information

The following command displays OAM information for the selected port:

```
show interface port <port alias or number> oam
```

Command mode: All

```
OAM information on port EXT1
State enabled
Mode active
Link up
Satisfied Yes
Evaluating No

Remote port information:
Mode active
MAC address 00:da:c0:00:04:00
Stable Yes
State valid Yes
Evaluating No
```

OAM port display shows information about the selected port and the peer to which the link is connected.

vLAG Information

The following table lists the information commands for Virtual Link Aggregation Group (vLAG) protocol.

Table 28. vLAG Information Options

Command Syntax and Usage
<pre>show vlag adminkey <I-65535></pre> <p>Displays vLAG LACP information.</p> <p>Command mode: All</p>
<pre>show vlag portchannel <trunk group number></pre> <p>Displays vLAG static trunk group information.</p> <p>Command mode: All</p>
<pre>show vlag isl</pre> <p>Displays vLAG Inter-Switch Link (ISL) information.</p> <p>Command mode: All</p>
<pre>show vlag information</pre> <p>Displays all vLAG information.</p> <p>Command mode: All</p>

vLAG Trunk Information

The following command displays vLAG information for the trunk group:

```
show vlag portchannel <trunk group number>
```

Command mode: All

<pre>vLAG is enabled on trunk 3 Protocol - Static Current settings: enabled ports: 60 Current L2 trunk hash settings: smac Current L3 trunk hash settings: sip dip Current ingress port hash: disabled Current L4 port hash: disabled</pre>

802.1X Information

The following command displays 802.1X information:

```
show dot1x information
```

Command mode: All

```

System capability : Authenticator
System status    : disabled
Protocol version : 1
Guest VLAN status : disabled
Guest VLAN      : none

```

Port	Auth Mode	Auth Status	Authenticator PAE State	Backend Auth State	Assigned VLAN
*INT1	force-auth	unauthorized	initialize	initialize	none
*INT2	force-auth	unauthorized	initialize	initialize	none
INT3	force-auth	unauthorized	initialize	initialize	none
*INT4	force-auth	unauthorized	initialize	initialize	none
*INT5	force-auth	unauthorized	initialize	initialize	none
*INT6	force-auth	unauthorized	initialize	initialize	none
*INT7	force-auth	unauthorized	initialize	initialize	none
INT8	force-auth	unauthorized	initialize	initialize	none
INT9	force-auth	unauthorized	initialize	initialize	none
*INT10	force-auth	unauthorized	initialize	initialize	none
*INT11	force-auth	unauthorized	initialize	initialize	none
*INT12	force-auth	unauthorized	initialize	initialize	none
EXT1	force-auth	unauthorized	initialize	initialize	none
EXT2	force-auth	unauthorized	initialize	initialize	none
*EXT3	force-auth	unauthorized	initialize	initialize	none
*EXT4	force-auth	unauthorized	initialize	initialize	none
*EXT11	force-auth	unauthorized	initialize	initialize	none

* - Port down or disabled

Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

The following table describes the IEEE 802.1X parameters.

Table 29. 802.1X Parameter Descriptions

Parameter	Description
Port	Displays each port's alias.
Auth Mode	Displays the Access Control authorization mode for the port. The Authorization mode can be one of the following: <ul style="list-style-type: none"> – force-unauth – auto – force-auth
Auth Status	Displays the current authorization status of the port, either authorized or unauthorized.

Table 29. 802.1X Parameter Descriptions (continued)

Parameter	Description
Authenticator PAE State	Displays the Authenticator Port Access Entity State. The PAE state can be one of the following: <ul style="list-style-type: none"> – initialize – disconnected – connecting – authenticating – authenticated – aborting – held – forceAuth
Backend Auth State	Displays the Backend Authorization State. The Backend Authorization state can be one of the following: <ul style="list-style-type: none"> – initialize – request – response – success – fail – timeout – idle

RSTP/PVRST Information

The following command displays RSTP/PVRST information:

```
show spanning-tree stp <1-128> information
```

Command mode: All

```

Spanning Tree Group 1: On (RSTP)
VLANs: 1

Current Root:          Path-Cost  Port Hello MaxAge FwdDel
ffff 00:13:0a:4f:7d:d0      0    EXT4    2    20    15

Parameters:  Priority  Hello  MaxAge  FwdDel  Aging
              61440    2     20     15     300

Port  Prio  Cost    State  Role Designated Bridge      Des Port  Type
-----
INT1  0      0      DSB *
INT2  0      0      DSB *
INT3  0      0      FWD *
INT4  0      0      DSB *
INT5  0      0      DSB *
INT6  0      0      DSB *
INT7  0      0      DSB *
INT8  0      0      DSB *
INT9  0      0      DSB *
INT10 0      0      DSB *
INT11 0      0      DSB *
INT12 0      0      DSB *
INT13 0      0      DSB *
INT14 0      0      DSB *
EXT1  128    2000  FWD  DESG 8000-00:11:58:ae:39:00  8011    P2P
EXT2  128    2000  DISC BKUP 8000-00:11:58:ae:39:00  8011    P2P
EXT3  128    2000  FWD  DESG 8000-00:11:58:ae:39:00  8013    P2P
EXT4  128    20000 DISC BKUP 8000-00:11:58:ae:39:00  8013    Shared
...
* = STP turned off for this port.

```

Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of Flex System unit that you are using and the firmware versions and options that are installed.

You can configure the switch software to use the IEEE 802.1D (2004) Rapid Spanning Tree Protocol (RSTP), Per VLAN Rapid Spanning Tree Protocol (PVRST) or IEEE 802.1Q (2003) Multiple Spanning Tree Protocol (MSTP).

If RSTP/PVRST is turned on, you can view the following bridge information for the Spanning Tree Group:

Table 30. RSTP/PVRST Bridge Parameter Descriptions

Parameter	Description
Current Root	The Current Root shows information about the root bridge for the Spanning Tree. Information includes the priority (in hexadecimal notation) and the MAC address of the root.
Priority (bridge)	The Bridge Priority parameter controls which bridge on the network will become the STP root bridge.
Hello	The Hello Time parameter specifies, in seconds, how often the root bridge transmits a configuration bridge protocol data unit (BPDU). Any bridge that is not the root bridge uses the root bridge hello value.

Table 30. RSTP/PVRST Bridge Parameter Descriptions (continued)

Parameter	Description
MaxAge	The Maximum Age parameter specifies, in seconds, the maximum time the bridge waits without receiving a configuration bridge protocol data unit before it reconfigures the STP network.
FwdDel	The Forward Delay parameter specifies, in seconds, the amount of time that a bridge port has to wait before it changes from listening to learning and from learning state to forwarding state.
Aging	The Aging Time parameter specifies, in seconds, the amount of time the bridge waits without receiving a packet from a station before removing the station from the Forwarding Database.

The following port-specific information is also displayed:

Table 31. RSTP/PVRST Port Parameter Descriptions

Parameter	Description
Prio (port)	The Port Priority parameter helps determine which bridge port becomes the designated port. In a network topology that has multiple bridge ports connected to a single segment, the port with the lowest port priority becomes the designated port for the segment.
Cost	The port Path Cost parameter is used to help determine the designated port for a segment. Generally speaking, the faster the port, the lower the path cost. A setting of 0 indicates that the cost will be set to the appropriate default after the link speed has been auto negotiated.
State	The State field shows the current state of the port. The State field in RSTP mode can be one of the following: Discarding (DISC), Learning (LRN), Forwarding (FWD), or Disabled (DSB).
Role	The Role field shows the current role of this port in the Spanning Tree. The port role can be one of the following: Designated (DESG), Root (ROOT), Alternate (ALTN), Backup (BKUP), Disabled (DSB), Master (MAST).
Designated Bridge	The Designated Bridge shows information about the bridge connected to each port, if applicable. Information includes the priority (in hexadecimal notation) and MAC address of the Designated Bridge.
Designated Port	The port ID of the port on the Designated Bridge to which this port is connected.
Type	Type of link connected to the port, and whether the port is an edge port. Link type values are AUTO, P2P, or SHARED.

Common Internal Spanning Tree Information

The following command displays Common Internal Spanning Tree (CIST) information:

```
show spanning-tree mst 0 information
```

Command mode: All

```
Mstp Digest: 0xac36177f50283cd4b83821d8ab26de62

Common Internal Spanning Tree:

VLANs MAPPED: 1-4094
VLANs: 1 2 4095

Current Root:          Path-Cost  Port MaxAge FwdDel
8000 00:11:58:ae:39:00    2026    0    20    15

Cist Regional Root:    Path-Cost
8000 00:11:58:ae:39:00    0

Parameters:  Priority  MaxAge  FwdDel  Hops
              32768    20     15     20

Port  Prio  Cost    State  Role Designated Bridge      Des Port Hello Type
-----
1     128    2000!   FWD   ROOT fffe-00:13:0a:4f:7d:d0    8011  2   P2P#
23    128    2000!   DISC  ALTN fffe-00:22:00:24:46:00    8012  2   P2P#
MGT   0       0       FWD   *

* = STP turned off for this port.
! = Automatic path cost.
# = PVST Protection enabled for this port.
```

In addition to seeing if Common Internal Spanning Tree (CIST) is enabled or disabled, you can view the following CIST bridge information:

Table 32. CIST Parameter Descriptions

Parameter	Description
CIST Root	The CIST Root shows information about the root bridge for the Common Internal Spanning Tree (CIST). Values on this row of information refer to the CIST root.
CIST Regional Root	The CIST Regional Root shows information about the root bridge for this MSTP region. Values on this row of information refer to the regional root.
Priority (bridge)	The bridge priority parameter controls which bridge on the network will become the STP root bridge.
Hello	The hello time parameter specifies, in seconds, how often the root bridge transmits a configuration bridge protocol data unit (BPDU). Any bridge that is not the root bridge uses the root bridge hello value.

Table 32. CIST Parameter Descriptions (continued)

Parameter	Description
MaxAge	The maximum age parameter specifies, in seconds, the maximum time the bridge waits without receiving a configuration bridge protocol data unit before it reconfigures the STP network.
FwdDel	The forward delay parameter specifies, in seconds, the amount of time that a bridge port has to wait before it changes from learning state to forwarding state.
Hops	The maximum number of bridge hops a packet can traverse before it is dropped. The default value is 20.

The following port-specific CIST information is also displayed:

Table 33. CIST Parameter Descriptions

Parameter	Description
Prio (port)	The port priority parameter helps determine which bridge port becomes the designated port. In a network topology that has multiple bridge ports connected to a single segment, the port with the lowest port priority becomes the designated port for the segment.
Cost	The port path cost parameter is used to help determine the designated port for a segment. Generally speaking, the faster the port, the lower the path cost. A setting of 0 indicates that the cost will be set to the appropriate default after the link speed has been auto negotiated.
State	The state field shows the current state of the port. The state field can be either Discarding (DISC), Learning (LRN), or Forwarding (FWD).
Role	The Role field shows the current role of this port in the Spanning Tree. The port role can be one of the following: Designated (DESG), Root (ROOT), Alternate (ALTN), Backup (BKUP), Disabled (DSB), Master (MAST), or Unknown (UNK).
Designated Bridge	The Designated Bridge shows information about the bridge connected to each port, if applicable. Information includes the priority (in hexadecimal notation) and MAC address of the Designated Bridge.
Designated Port	The port ID of the port on the Designated Bridge to which this port is connected.
Type	Type of link connected to the port, and whether the port is an edge port. Link type values are AUTO, P2P, or SHARED.

Trunk Group Information

The following command displays Trunk Group information:

```
show portchannel information
```


Command mode: All

```
Trunk group 1: Enabled
Protocol - Static
Port state:
  EXT1: STG 1 forwarding
  EXT2: STG 1 forwarding
```

When trunk groups are configured, you can view the state of each port in the various trunk groups.

Note: If Spanning Tree Protocol on any port in the trunk group is set to forwarding, the remaining ports in the trunk group will also be set to forwarding.

VLAN Information

Table 34. VLAN Information Commands

Command Syntax and Usage	
<code>show vlan <VLAN number></code>	Displays general VLAN information.
<code>show protocol-vlan <protocol number></code>	Displays protocol VLAN information. Command mode: All
<code>show vlan private-vlan [type]</code>	Displays private VLAN information. – type lists only the VLAN type for each private VLAN: community, isolated or primary. Command mode: All
<code>show vlan information</code>	Displays information about all VLANs, including: – VLAN number and name – Port membership – VLAN status (enabled or disabled) – Protocol VLAN status – Private VLAN status – Spanning Tree membership – VMAP configuration

The following command displays VLAN information:

```
show vlan <VLAN number>
```

Command mode: All

VLAN	Name	Status	MGT	Ports
1	Default VLAN	ena	dis	INTA1-EXT22
10	VLAN 10	ena	dis	empty
4095	Mgmt VLAN	ena	ena	EXTM MGT1

Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

This information display includes all configured VLANs and all member ports that have an active link state. Port membership is represented in slot/port format.

VLAN information includes:

- VLAN Number
- VLAN Type
- Status
- Management status of the VLAN
- Port membership of the VLAN
- Protocol-based VLAN information
- Private VLAN configuration

Layer 3 Information

Table 35. Layer 3 Information Commands

Command Syntax and Usage
<pre>show ip route</pre> <p>Displays all routes configured on the switch. For details, see page 62.</p> <p>Command mode: All</p>
<pre>show arp</pre> <p>Displays Address Resolution Protocol (ARP) information. For details, see page 63.</p> <p>Command mode: All</p>
<pre>show ip bgp information [IPv4 address] [IPv4 mask]</pre> <p>Displays Border Gateway Protocol (BGP) information. For details, see page 66.</p> <p>Command mode: All</p>
<pre>show ip ospf information</pre> <p>Displays OSPF information. For more OSPF information options, see page 67.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf information</pre> <p>Displays OSPFv3 information. For more OSPFv3 information options, see page 72.</p> <p>Command mode: All</p>
<pre>show ip rip interface</pre> <p>Displays RIP user's configuration. For details, see page 76.</p> <p>Command mode: All</p>
<pre>show ipv6 route</pre> <p>Displays IPv6 routing information. For more information options, see page 77.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors</pre> <p>Displays IPv6 Neighbor Discovery cache information. For more information options, see page 78.</p> <p>Command mode: All</p>
<pre>show ipv6 prefix</pre> <p>Displays IPv6 Neighbor Discovery prefix information. For details, see page 79.</p> <p>Command mode: All</p>
<pre>show ip ecmp</pre> <p>Displays ECMP static route information. For details, see page 79.</p> <p>Command mode: All</p>

Table 35. Layer 3 Information Commands (continued)

Command Syntax and Usage
<p>show ip igmp groups</p> <p>Displays IGMP Information. For more IGMP information options, see page 80.</p> <p>Command mode: All</p>
<p>show ipv6 mld groups</p> <p>Displays Multicast Listener Discovery (MLD) information. For more MLD information options, see page 84.</p> <p>Command mode: All</p>
<p>show ip vrrp information</p> <p>Displays VRRP information. For details, see page 86.</p> <p>Command mode: All</p>
<p>show interface ip</p> <p>Displays IPv4 interface information. For details, see page 87.</p> <p>Command mode: All</p>
<p>show ipv6 interface <interface number></p> <p>Displays IPv6 interface information. For details, see page 87.</p> <p>Command mode: All</p>
<p>show ipv6 pmtu [<destination IPv6 address>]</p> <p>Displays IPv6 Path MTU information. For details, see page 88.</p> <p>Command mode: All</p>
<p>show ip interface brief</p> <p>Displays IP Information. For details, see page 89.</p> <p>IP information, includes:</p> <ul style="list-style-type: none"> – IP interface information: Interface number, IP address, subnet mask, VLAN number, and operational status. – Default gateway information: Metric for selecting which configured gateway to use, gateway number, IP address, and health status – IP forwarding settings, network filter settings, route map settings <p>Command mode: All</p>
<p>show ikev2</p> <p>Displays IKEv2 information. For more information options, see page 90.</p> <p>Command mode: All</p>
<p>show ipsec manual-policy</p> <p>Displays information about manual key management policy for IP security. For more information options, see page 92.</p> <p>Command mode: All</p>

Table 35. Layer 3 Information Commands (continued)

Command Syntax and Usage
<pre>show ip pim component [<I-2>]</pre> <p>Displays Protocol Independent Multicast (PIM) component information. For more PIM information options, see page 93.</p> <p>Command mode: All</p>
<pre>show layer3</pre> <p>Dumps all Layer 3 switch information available (10K or more, depending on your configuration).</p> <p>If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.</p> <p>Command mode: All</p>

IP Routing Information

Using the commands listed below, you can display all or a portion of the IP routes currently held in the switch.

Table 36. Route Information Commands

Command Syntax and Usage
<pre>show ip route address <IP address></pre> <p>Displays a single route by destination IP address.</p> <p>Command mode: All</p>
<pre>show ip route gateway <IP address></pre> <p>Displays routes to a single gateway.</p> <p>Command mode: All</p>
<pre>show ip route type {indirect direct local broadcast martian multicast}</pre> <p>Displays routes of a single type. For a description of IP routing types, see Table 37 on page 62.</p> <p>Command mode: All</p>
<pre>show ip route tag {fixed static addr rip ospf bgp broadcast martian multicast}</pre> <p>Displays routes of a single tag. For a description of IP routing tags, see Table 38 on page 62.</p> <p>Command mode: All</p>
<pre>show ip route interface <interface number></pre> <p>Displays routes on a single interface.</p> <p>Command mode: All</p>
<pre>show ip route ecmphash</pre> <p>Displays the current ECMP hashing mechanism.</p> <p>Command mode: All</p>
<pre>show ip route static</pre> <p>Displays static routes configured on the switch.</p> <p>Command mode: All</p>
<pre>show ip route</pre> <p>Displays all routes configured in the switch.</p> <p>Command mode: All</p> <p>For more information, see page 62.</p>

Show All IP Route Information

The following command displays IP route information:

```
show ip route
```

Command mode: All

Status code: * - best						
Destination	Mask	Gateway	Type	Tag	Metr	If
* 12.0.0.0	255.0.0.0	11.0.0.1	direct	fixed		128
* 12.0.0.1	255.255.255.255	11.0.0.1	local	addr		128
* 12.255.255.255	255.255.255.255	11.255.255.255	broadcast	broadcast		128
* 12.0.0.0	255.0.0.0	12.0.0.1	direct	fixed		12
* 12.0.0.1	255.255.255.255	12.0.0.1	local	addr		12
* 255.255.255.255	255.255.255.255	12.255.255.255	broadcast	broadcast		2
* 224.0.0.0	224.0.0.0	0.0.0.0	martian	martian		
* 224.0.0.5	255.255.255.255	0.0.0.0	multicast	addr		

The following table describes the `Type` parameters.

Table 37. IP Routing Type Parameters

Parameter	Description
indirect	The next hop to the host or subnet destination will be forwarded through a router at the <code>Gateway</code> address.
direct	Packets will be delivered to a destination host or subnet attached to the switch.
local	Indicates a route to one of the switch's IP interfaces.
broadcast	Indicates a broadcast route.
martian	The destination belongs to a host or subnet which is filtered out. Packets to this destination are discarded.
multicast	Indicates a multicast route.

The following table describes the `Tag` parameters.

Table 38. IP Routing Tag Parameters

Parameter	Description
fixed	The address belongs to a host or subnet attached to the switch.
static	The address is a static route which has been configured on the CN4093 10Gb Converged Scalable Switch.
addr	The address belongs to one of the switch's IP interfaces.
rip	The address was learned by the Routing Information Protocol (RIP).
ospf	The address was learned by Open Shortest Path First (OSPF).
bgp	The address was learned via Border Gateway Protocol (BGP)

Table 38. IP Routing Tag Parameters (continued)

Parameter	Description
broadcast	Indicates a broadcast address.
martian	The address belongs to a filtered group.
multicast	Indicates a multicast address.

ARP Information

The ARP information includes IP address and MAC address of each entry, address status flags (see [Table 40 on page 64](#)), VLAN and port for the address, and port referencing information.

Table 39. ARP Information Commands

Command Syntax and Usage
<pre>show arp find <IP address></pre> <p>Displays a single ARP entry by IP address.</p> <p>Command mode: All</p>
<pre>show arp interface port <port alias or number></pre> <p>Displays the ARP entries on a single port.</p> <p>Command mode: All</p>
<pre>show arp vlan <VLAN number></pre> <p>Displays the ARP entries on a single VLAN.</p> <p>Command mode: All</p>
<pre>show arp</pre> <p>Displays all ARP entries. including:</p> <ul style="list-style-type: none"> – IP address and MAC address of each entry – Address status flag (see below) – The VLAN and port to which the address belongs – The ports which have referenced the address (empty if no port has routed traffic to the IP address shown) <p>For more information, see page 64.</p> <p>Command mode: All</p>
<pre>show arp reply</pre> <p>Displays the ARP address list: IP address, IP mask, MAC address, and VLAN flags.</p> <p>Command mode: All</p>

Show All ARP Entry Information

The following command displays ARP information:

```
show arp
```

Command mode: All

IP address	Flags	MAC address	VLAN	Age	Port
12.20.1.1		00:15:40:07:20:42	4095	0	INT8
12.20.20.16		00:30:13:e3:44:14	4095	2	INT8
12.20.20.18		00:30:13:e3:44:14	4095	2	INT6
12.20.23.111		00:1f:29:95:f7:e5	4095	6	INT6

The `Port` field shows the target port of the ARP entry.

The `Flags` field is interpreted as follows:

Table 40. ARP Dump Flag Parameters

Flag	Description
P	Permanent entry created for switch IP interface.
R	Indirect route entry.
U	Unresolved ARP entry. The MAC address has not been learned.

ARP Address List Information

The following command displays owned ARP address list information:

```
show arp reply
```

Command mode: All

IP address	IP mask	MAC address	VLAN	Pass-Up
205.178.18.66	255.255.255.255	00:70:cf:03:20:04		P
205.178.50.1	255.255.255.255	00:70:cf:03:20:06	1	
205.178.18.64	255.255.255.255	00:70:cf:03:20:05	1	

BGP Information

Table 41. BGP Peer Information Commands

Command Syntax and Usage
<pre>show ip bgp neighbor information</pre> <p>Displays BGP peer information.</p> <p>Command mode: All</p> <p>See page 66 for a sample output.</p>
<pre>show ip bgp neighbor summary</pre> <p>Displays peer summary information such as AS, message received, message sent, up/down, state.</p> <p>Command mode: All</p> <p>See page 66 for a sample output.</p>
<pre>show ip bgp aggregate-address</pre> <p>Displays BGP peer routes.</p> <p>Command mode: All</p> <p>See page 66 for a sample output.</p>
<pre>show ip bgp information</pre> <p>Displays the BGP routing table.</p> <p>Command mode: All</p> <p>See page 66 for a sample output.</p>

BGP Peer information

Following is an example of the information provided by the following command:

```
show ip bgp neighbor information
```

Command mode: All

```
BGP Peer Information:

3: 2.1.1.1          , version 4, TTL 225
Remote AS: 100, Local AS: 100, Link type: IBGP
Remote router ID: 3.3.3.3,   Local router ID: 1.1.201.5
BGP status: idle, Old status: idle
Total received packets: 0, Total sent packets: 0
Received updates: 0, Sent updates: 0
Keepalive: 60, Holdtime: 180, MinAdvTime: 60
LastErrorCode: unknown(0), LastErrorSubcode: unspecified(0)
Established state transitions: 1

4: 2.1.1.4          , version 4, TTL 225
Remote AS: 100, Local AS: 100, Link type: IBGP
Remote router ID: 4.4.4.4,   Local router ID: 1.1.201.5
BGP status: idle, Old status: idle
Total received packets: 0, Total sent packets: 0
Received updates: 0, Sent updates: 0
Keepalive: 60, Holdtime: 180, MinAdvTime: 60
LastErrorCode: unknown(0), LastErrorSubcode: unspecified(0)
Established state transitions: 1
```

BGP Summary Information

Following is an example of the information provided by the following command:

```
show ip bgp neighbor summary
```

Command mode: All

```
BGP Peer Summary Information:
Peer      V   AS   MsgRcvd  MsgSent  Up/Down  State
-----
1: 205.178.23.142  4   142    113     121 00:00:28 established
2: 205.178.15.148  0   148     0      0 never connect
```

BGP Aggregation Information

Following is an example of the information provided by the following command:

```
show ip bgp aggregate-address
```

Command mode: All

```
Current BGP aggregation settings:
1: addr 4.2.0.0, mask 255.0.0.0, enabled
2: addr 5.5.0.0, mask 255.255.0.0, enabled
```

Dump BGP Information

Following is an example of the information provided by the following command:

show ip bgp information[<IPv4 network> <IPv4 mask>]

Command mode: All

Network	Mask	Next Hop	Metr	LcPrf	Wght	Path
*> 1.1.1.0	255.255.255.0	0.0.0.0			0	?
*> 10.100.100.0	255.255.255.0	0.0.0.0			0	?
*> 10.100.120.0	255.255.255.0	0.0.0.0			0	?

The 13.0.0.0 is filtered out by rrmapp; or, a loop detected.

The IPv4 network and mask options restrict the output to a specific network in the BGP routing table.

OSPF Information

Table 42. OSPF Information Commands

Command Syntax and Usage
<p>show ip ospf general-information</p> <p>Displays general OSPF information.</p> <p>Command mode: All</p> <p>See page 69 for a sample output.</p>
<p>show ip ospf area information</p> <p>Displays area information for all areas.</p> <p>Command mode: All</p>
<p>show ip ospf area <0-2></p> <p>Displays area information for a particular area index.</p> <p>Command mode: All</p>
<p>show ip ospf interface loopback <1-5></p> <p>Displays loopback information for a particular interface. If no parameter is supplied, it displays loopback information for all the interfaces.</p> <p>Command mode: All</p> <p>See page 69 for a sample output.</p>
<p>show interface ip {<interface number>} ospf</p> <p>Displays interface information for a particular interface. If no parameter is supplied, it displays information for all the interfaces.</p> <p>Command mode: All</p> <p>See page 69 for a sample output.</p>
<p>show ip ospf area-virtual-link information</p> <p>Displays information about all the configured virtual links.</p> <p>Command mode: All</p>

Table 42. OSPF Information Commands (continued)

Command Syntax and Usage
<pre>show ip ospf neighbor</pre> <p>Displays the status of all the current neighbors.</p> <p>Command mode: All</p>
<pre>show ip ospf summary-range <0-2></pre> <p>Displays the list of summary ranges belonging to non-NSSA areas.</p> <p>Command mode: All</p>
<pre>show ip ospf summary-range-nssa <0-2></pre> <p>Displays the list of summary ranges belonging to NSSA areas.</p> <p>Command mode: All</p>
<pre>show ip ospf routes</pre> <p>Displays OSPF routing table.</p> <p>Command mode: All</p> <p>See page 71 for a sample output.</p>
<pre>show ip ospf information</pre> <p>Displays OSPF information.</p> <p>Command mode: All</p>

OSPF General Information

The following command displays general OSPF information:

```
show ip ospf general-information
```

Command mode: All

```
OSPF Version 2
Router ID: 10.10.10.1
Started at 1663 and the process uptime is 4626
Area Border Router: yes, AS Boundary Router: no
LS types supported are 6
External LSA count 0
External LSA checksum sum 0x0
Number of interfaces in this router is 2
Number of virtual links in this router is 1
16 new lsa received and 34 lsa originated from this router
Total number of entries in the LSDB 10
Database checksum sum 0x0
Total neighbors are 1, of which
                                2 are >=INIT state,
                                2 are >=EXCH state,
                                2 are =FULL state
Number of areas is 2, of which 3-transit 0-nssa
  Area Id : 0.0.0.0
  Authentication : none
  Import ASEextern : yes
  Number of times SPF ran : 8
  Area Border Router count : 2
  AS Boundary Router count : 0
  LSA count : 5
  LSA Checksum sum : 0x2237B
  Summary : noSummary
```

OSPF Interface Loopback Information

The following command displays OSPF interface loopback information:

```
show ip ospf interface loopback <interface number>
```

Command mode: All

```
Ip Address 5.5.5.5, Area 0.0.0.1, Passive interface, Admin Status UP
Router ID 1.1.1.2, State Loopback, Priority 1
Designated Router (ID) 0.0.0.0, Ip Address 0.0.0.0
Backup Designated Router (ID) 0.0.0.0, Ip Address 0.0.0.0
Timer intervals, Hello 10, Dead 40, Wait 40, Retransmit 5, Transit delay
1
Neighbor count is 0 If Events 1, Authentication type none
```

OSPF Interface Information

The following command displays OSPF interface information:

```
show ip ospf interface <interface number>
```

Command mode: All

```
Ip Address 10.10.12.1, Area 0.0.0.1, Admin Status UP
Router ID 10.10.10.1, State DR, Priority 1
Designated Router (ID) 10.10.10.1, Ip Address 10.10.12.1
Backup Designated Router (ID) 10.10.14.1, Ip Address 10.10.12.2
Timer intervals, Hello 10, Dead 40, Wait 1663, Retransmit 5,
Neighbor count is 1 If Events 4, Authentication type none
```

OSPF Database Information

Table 43. OSPF Database Information Commands

Command Syntax and Usage
<pre>show ip ospf database advertising-router <router ID></pre> <p>Takes advertising router as a parameter. Displays all the Link State Advertisements (LSAs) in the LS database that have the advertising router with the specified router ID, for example: 20.1.1.1.</p> <p>Command mode: All</p>
<pre>show ip ospf database asbr-summary [advertising-router <router ID> link-state-id <A.B.C.D> self]</pre> <p>Displays ASBR summary LSAs. The use of this command is as follows:</p> <ol style="list-style-type: none"> asbr-summary advertising-router 20.1.1.1 displays ASBR summary LSAs having the advertising router 20.1.1.1. asbr-summary link-state-id 10.1.1.1 displays ASBR summary LSAs having the link state ID 10.1.1.1. asbr-summary self displays the self advertised ASBR summary LSAs. asbr-summary with no parameters displays all the ASBR summary LSAs. <p>Command mode: All</p>
<pre>show ip ospf database database-summary</pre> <p>Displays the following information about the LS database in a table format:</p> <ol style="list-style-type: none"> Number of LSAs of each type in each area. Total number of LSAs for each area. Total number of LSAs for each LSA type for all areas combined. Total number of LSAs for all LSA types for all areas combined. <p>No parameters are required.</p> <p>Command mode: All</p>
<pre>show ip ospf database external [advertising-router <router ID> link-state-id <A.B.C.D> self]</pre> <p>Displays the AS-external (type 5) LSAs with detailed information of each field of the LSAs.</p> <p>Command mode: All</p>
<pre>show ip ospf database network [advertising-router <router ID> link-state-id <A.B.C.D> self]</pre> <p>Displays the network (type 2) LSAs with detailed information of each field of the LSA.network LS database.</p> <p>Command mode: All</p>

Table 43. OSPF Database Information Commands (continued)

Command Syntax and Usage
<pre>show ip ospf database nssa</pre> <p>Displays the NSSA (type 7) LSAs with detailed information of each field of the LSAs.</p> <p>Command mode: All</p>
<pre>show ip ospf database router [advertising-router <router ID> link-state-id <A.B.C.D> self]</pre> <p>Displays the router (type 1) LSAs with detailed information of each field of the LSAs.</p> <p>Command mode: All</p>
<pre>show ip ospf database self</pre> <p>Displays all the self-advertised LSAs. No parameters are required.</p> <p>Command mode: All</p>
<pre>show ip ospf database summary [advertising-router <router ID> link-state-id <A.B.C.D> self]</pre> <p>Displays the network summary (type 3) LSAs with detailed information of each field of the LSAs.</p> <p>Command mode: All</p>
<pre>show ip ospf database</pre> <p>Displays all the LSAs.</p> <p>Command mode: All</p>

OSPF Information Route Codes

The following command displays OSPF route information:

```
show ip ospf routes
```

Command mode: All

```
Codes: IA - OSPF inter area,
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
IA 10.10.0.0/16 via 200.1.1.2
IA 40.1.1.0/28 via 20.1.1.2
IA 80.1.1.0/24 via 200.1.1.2
IA 100.1.1.0/24 via 20.1.1.2
IA 140.1.1.0/27 via 20.1.1.2
IA 150.1.1.0/28 via 200.1.1.2
E2 172.18.1.1/32 via 30.1.1.2
E2 172.18.1.2/32 via 30.1.1.2
E2 172.18.1.3/32 via 30.1.1.2
E2 172.18.1.4/32 via 30.1.1.2
E2 172.18.1.5/32 via 30.1.1.2
E2 172.18.1.6/32 via 30.1.1.2
E2 172.18.1.7/32 via 30.1.1.2
E2 172.18.1.8/32 via 30.1.1.2
```

OSPFv3 Information

Table 44. OSPFv3 Information Options

Command Syntax and Usage
<pre>show ipv6 ospf area <area index (0-2)></pre> <p>Displays the area information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf areas</pre> <p>Displays the OSPFv3 Area Table.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf interface <interface number></pre> <p>Displays interface information for a particular interface. If no parameter is supplied, it displays information for all the interfaces. To view a sample display, see page 74.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf area-virtual-link</pre> <p>Displays information about all the configured virtual links.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf neighbor <nbr router-id (A.B.C.D)></pre> <p>Displays the status of a neighbor with a particular router ID. If no router ID is supplied, it displays the information about all the current neighbors.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf host</pre> <p>Displays OSPFv3 host configuration information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf request-list <nbr router-id (A.B.C.D)></pre> <p>Displays the OSPFv3 request list. If no router ID is supplied, it displays the information about all the current neighbors.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf retrans-list <nbr router-id (A.B.C.D)></pre> <p>Displays the OSPFv3 retransmission list. If no router ID is supplied, it displays the information about all the current neighbors.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf summary-prefix <area index (0-2)></pre> <p>Displays the OSPFv3 external summary-address configuration information.</p> <p>Command mode: All</p>

Table 44. OSPFv3 Information Options

Command Syntax and Usage
<pre>show ipv6 ospf redist-config</pre> <p>Displays OSPFv3 redistribution information to be applied to routes learned from the route table.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf area-range information</pre> <p>Displays OSPFv3 summary ranges.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf routes</pre> <p>Displays OSPFv3 routing table. To view a sample display, see page 75.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf border-routers</pre> <p>Displays OSPFv3 routes to an ABR or ASBR.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf information</pre> <p>Displays all OSPFv3 information. To view a sample display, see page 73.</p> <p>Command mode: All</p>

OSPFv3 Information Dump

Router Id: 1.0.0.1	ABR Type: Standard ABR	
SPF schedule delay: 5 secs	Hold time between two SPF's: 10 secs	
Exit Overflow Interval: 0	Ref BW: 100000	Ext Lsdb Limit: none
Trace Value: 0x00008000	As Scope Lsa: 2	Checksum Sum: 0xfe16
Passive Interface: Disable		
Nssa Asbr Default Route Translation: Disable		
Autonomous System Boundary Router		
Redistributing External Routes from connected, metric 10, metric type asExtType1, no tag set		
Number of Areas in this router 1		
Area 0.0.0.0		
Number of interfaces in this area is 1		
Number of Area Scope Lsa: 7	Checksum Sum: 0x28512	
Number of Indication Lsa: 0	SPF algorithm executed: 2 times	

OSPFv3 Interface Information

The following command displays OSPFv3 interface information:

```
show ipv6 ospf interface
```

Command mode: All

OspfV3 Interface Information		
Interface Id: 1	Instance Id: 0	Area Id: 0.0.0.0
Local Address: fe80::222:ff:fe7d:5d00		Router Id: 1.0.0.1
Network Type: BROADCAST	Cost: 1	State: BACKUP
Designated Router Id: 2.0.0.2 local address: fe80::218:b1ff:feal:6c01		
Backup Designated Router Id: 1.0.0.1 local address: fe80::222:ff:fe7d:5d00		
Transmit Delay: 1 sec	Priority: 1	IfOptions: 0x0
Timer intervals configured:		
Hello: 10, Dead: 40, Retransmit: 5		
Hello due in 6 sec		
Neighbor Count is: 1, Adjacent neighbor count is: 1		
Adjacent with neighbor 2.0.0.2		

OSPFv3 Database Information

Table 45. OSPFv3 Database Information Options

Command Syntax and Usage
<pre>show ipv6 ospf database as-external [detail hex]</pre> <p>Displays AS-External LSAs database information. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf database inter-prefix [detail hex]</pre> <p>Displays Inter-Area Prefix LSAs database information. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf database inter-router [detail hex]</pre> <p>Displays Inter-Area router LSAs database information. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf database intra-prefix [detail hex]</pre> <p>Displays Intra-Area Prefix LSAs database information. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>

Table 45. OSPFv3 Database Information Options

Command Syntax and Usage	
<pre>show ipv6 ospf database link [detail hex]</pre>	<p>Displays Link LSAs database information. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf database network [detail hex]</pre>	<p>Displays Network LSAs database information. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf database router [detail hex]</pre>	<p>Displays the Router LSAs with detailed information of each field of the LSAs. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf database nssa [detail hex]</pre>	<p>Displays Type-7 (NSSA) LSA database information. If no parameter is supplied, it displays condensed information.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf database [detail hex]</pre>	<p>Displays all the LSAs.</p> <p>Command mode: All</p>

OSPFv3 Route Codes Information

The following command displays OSPFv3 route information:

```
show ipv6 ospf routes
```

Command mode: All

Dest/ Prefix-Length	NextHop/ IfIndex	Cost	Rt. Type	Area
3ffe::10:0:0:0 /80	fe80::290:69ff fe90:b4bf /vlan1	30	interArea	0.0.0.0
3ffe::20:0:0:0 /80	fe80::290:69ff fe90:b4bf /vlan1	20	interArea	0.0.0.0
3ffe::30:0:0:0 /80	:: /vlan2	10	intraArea	0.0.0.0
3ffe::60:0:0:6 /128	fe80::211:22ff fe33:4426 /vlan2	10	interArea	0.0.0.0

Routing Information Protocol

Table 46. Routing Information Protocol Commands

Command Syntax and Usage
<pre>show ip rip routes</pre> <p>Displays RIP routes.</p> <p>Command mode: All</p> <p>For more information, see page 76.</p>
<pre>show interface ip <interface number> rip</pre> <p>Displays RIP user's configuration.</p> <p>Command mode: All</p> <p>For more information, see page 76.</p>

RIP Routes Information

The following command displays RIP route information:

```
show ip rip routes
```

Command mode: All

```
>> IP Routing#

30.1.1.0/24 directly connected
3.0.0.0/8 via 30.1.1.11 metric 4
4.0.0.0/16 via 30.1.1.11 metric 16
10.0.0.0/8 via 30.1.1.2 metric 3
20.0.0.0/8 via 30.1.1.2 metric 2
```

This table contains all dynamic routes learned through RIP, including the routes that are undergoing garbage collection with metric = 16. This table does not contain locally configured static routes.

RIP Interface Information

The following command displays RIP user information:

```
show ip rip interface <interface number>
```

Command mode: All

```
RIP USER CONFIGURATION :
  RIP: ON, update 30
  RIP on Interface 49 : 101.1.1.10, enabled
  version 2, listen enabled, supply enabled, default none
  poison disabled, split horizon enabled, trigg enabled, mcast enabled, metric 1
  auth none,key none
```

IPv6 Routing Information

Table 47 describes the IPv6 Routing information options.

Table 47. IPv6 Routing Information Commands

Command Syntax and Usage
<pre>show ipv6 route address <IPv6 address></pre> <p>Displays a single route by destination IP address.</p> <p>Command mode: All</p>
<pre>show ipv6 route gateway <default gateway address></pre> <p>Displays routes to a single gateway.</p> <p>Command mode: All</p>
<pre>show ipv6 route type {connected static ospf}</pre> <p>Displays routes of a single type. For a description of IP routing types, see Table 37 on page 62.</p> <p>Command mode: All</p>
<pre>show ipv6 route interface <interface number></pre> <p>Displays routes on a single interface.</p> <p>Command mode: All</p>
<pre>show ipv6 route summary</pre> <p>Displays a summary of IPv6 routing information, including inactive routes.</p> <p>Command mode: All</p>
<pre>show ipv6 route</pre> <p>Displays all IPv6 routing information. For more information, see page 77.</p> <p>Command mode: All</p>

IPv6 Routing Table

The following command displays IPv6 routing information:

```
show ipv6 route
```

Command mode: All

<pre>IPv6 Routing Table - 3 entries Codes : C - Connected, S - Static O - OSPF M - Management Gateway, E - Ext-Management Gateway S ::/0 [1/20] via 2001:2:3:4::1, Interface 2 C 2001:2:3:4::/64 [1/1] via ::, Interface 2 C fe80::20f:6aff:feec:f701/128 [1/1] via ::, Interface 2</pre>
--

Note: The first number inside the brackets represents the metric and the second number represents the preference for the route.

IPv6 Neighbor Discovery Cache Information

Table 48. IPv6 Neighbor Discovery Cache Information Commands

Command Syntax and Usage
<pre>show ipv6 neighbors find <IPv6 address></pre> <p>Shows a single IPv6 Neighbor Discovery cache entry by IP address.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors interface port <port alias or number></pre> <p>Shows IPv6 Neighbor Discovery cache entries on a single port.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors vlan <VLAN number></pre> <p>Shows IPv6 Neighbor Discovery cache entries on a single VLAN.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors static</pre> <p>Displays static IPv6 Neighbor Discovery cache entries.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors</pre> <p>Shows all IPv6 Neighbor Discovery cache entries. For more information, see page 78.</p> <p>Command mode: All</p>

IPv6 Neighbor Discovery Cache Information

The following command displays a summary of IPv6 Neighbor Discovery cache information:

```
show ipv6 neighbors
```

Command mode: All

IPv6 Address	Age	Link-layer Addr	State	IF	VLAN	Port
2001:2:3:4::1	10	00:50:bf:b7:76:b0	Reachable	2	1	EXT1
fe80::250:bfff:feb7:76b0	0	00:50:bf:b7:76:b0	Stale	2	1	EXT2

IPv6 Neighbor Discovery Prefix Information

The following command displays a summary of IPv6 Neighbor Discovery prefix information:

```
show ipv6 prefix
```

Command mode: All

```
Codes: A - Address , P - Prefix-Advertisement
       D - Default , N - Not Advertised
       [L] - On-link Flag is set
       [A] - Autonomous Flag is set

AD 10:: 64 [LA] Valid lifetime 2592000 , Preferred lifetime 604800
P 20:: 64 [LA] Valid lifetime 200 , Preferred lifetime 100
```

Neighbor Discovery prefix information includes information about all configured prefixes.

The following command displays IPv6 Neighbor Discovery prefix information for an interface:

```
show ipv6 prefix interface <interface number>
```

Command mode: All

ECMP Static Route Information

The following command displays Equal Cost Multi-Path (ECMP) route information:

```
show ip ecmp
```

Command mode: All

```
Current ecmp static routes:
Destination      Mask           Gateway        If    GW Status
-----
10.10.1.1        255.255.255.255 100.10.1.1     1    up
                  200.20.2.2     1    down
10.20.2.2        255.255.255.255 10.233.3.3     1    up
10.20.2.2        255.255.255.255 10.234.4.4     1    up
10.20.2.2        255.255.255.255 10.235.5.5     1    up
```

ECMP route information shows the status of each ECMP route configured on the switch.

ECMP Hashing Result

The following command displays the status of ECMP hashing on each switch:

```
show ip route ecmphash
```

Command mode: All

ECMP Hash Mechanism: dipsip

IGMP Multicast Group Information

Table 49. IGMP Multicast Group Information Commands

Command Syntax and Usage
<pre>show ip igmp querier vlan <VLAN number></pre> <p>Displays IGMP Querier information. For details, see page 81.</p> <p>Command mode: All</p>
<pre>show ip igmp snoop</pre> <p>Displays IGMP Snooping information.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter information</pre> <p>Displays IGMP Multicast Router information. For details, see page 82.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter vlan <VLAN number></pre> <p>Displays IGMP Multicast Router information for the specified VLAN.</p> <p>Command mode: All</p>
<pre>show ip igmp filtering</pre> <p>Displays current IGMP Filtering parameters.</p> <p>Command mode: All</p>
<pre>show ip igmp profile <1-16></pre> <p>Displays information about the current IGMP filter.</p> <p>Command mode: All</p>
<pre>show ip igmp groups address <IP address></pre> <p>Displays a single IGMP multicast group by its IP address.</p> <p>Command mode: All</p>
<pre>show ip igmp groups vlan <VLAN number></pre> <p>Displays all IGMP multicast groups on a single VLAN.</p> <p>Command mode: All</p>

Table 49. IGMP Multicast Group Information Commands (continued)

Command Syntax and Usage
<pre>show ip igmp groups interface port <port alias or number></pre> <p>Displays all IGMP multicast groups on a single port. Command mode: All</p>
<pre>show ip igmp groups portchannel <trunk number></pre> <p>Displays all IGMP multicast groups on a single trunk group. Command mode: All</p>
<pre>show ip igmp groups detail <IP address></pre> <p>Displays details about an IGMP multicast group, including source and timer information. Command mode: All</p>
<pre>show ip igmp groups</pre> <p>Displays information for all multicast groups. For details, see page 82. Command mode: All</p>
<pre>show ip igmp ipmcgrp</pre> <p>Displays information for all IPMC groups. For details, see page 83. Command mode: All</p>
<pre>show ip igmp counters</pre> <p>Displays IGMP counters for all VLANs. Command mode: All</p>
<pre>show ip igmp vlan <VLAN number> counter</pre> <p>Displays IGMP counters for a specific VLAN. Command mode: All</p>

IGMP Querier Information

The following command displays IGMP Querier information:

```
show ip igmp querier vlan <VLAN number>
```

Command mode: All

```
Current IGMP Querier information:
IGMP Querier information for vlan 1:
Other IGMP querier - none
Switch-querier enabled, current state: Querier
Switch-querier type: Ipv4, address 1.1.1.1,
Switch-querier general query interval: 125 secs,
Switch-querier max-response interval: 100 'tenths of secs',
Switch-querier startup interval: 31 secs, count: 2
Switch-querier robustness: 2
IGMP configured version is v3
IGMP Operating version is v3
```

IGMP Querier information includes:

- VLAN number
- Querier status
 - Other IGMP querier—none
 - IGMP querier present, address: (IP or MAC address)
- Querier election type (IPv4 or MAC) and address
- Query interval
- Querier startup interval
- Maximum query response interval
- Querier robustness value
- Other IGMP querier present, interval (minutes:seconds)
- IGMP Querier current state: Querier/Non-Querier
- IGMP version number

IGMP Group Information

The following command displays IGMP Group information:

```
show ip igmp groups
```

Command mode: All

Source	Group	VLAN	Port	Version	Mode	Expires	Fwd
10.1.1.1	232.1.1.1	2	4	V3	INC	4:16	Yes
10.1.1.5	232.1.1.1	2	4	V3	INC	4:16	Yes
*	232.1.1.1	2	4	V3	INC	-	No
10.10.10.43	235.0.0.1	9	1	V3	EXC	2:26	No
*	235.0.0.1	9	1	V3	EXC	-	Yes

IGMP Group information includes:

- IGMP source address
- IGMP Group address
- VLAN and port
- IGMP version
- IGMPv3 filter mode
- Expiration timer value
- IGMP multicast forwarding state

IGMP Multicast Router Information

The following command displays Mrouter information:

```
show ip igmp mrouter information
```

Command mode: All

SrcIP	VLAN	Port	Version	Expires	MRT	QRV	QQIC
10.1.1.1	2	EXT4	V3	4:09	128	2	125
10.1.1.5	2	EXT6	V2	4:09	125	-	-
*	9	EXT7	V2	static	-	-	-

IGMP Mrouter information includes:

- Source IP address
- VLAN and port where the Mrouter is connected
- IGMP version
- Mrouter expiration
- Maximum query response time
- Querier's Robustness Variable (QRV)
- Querier's Query Interval Code (QQIC)

IPMC Group Information

The following command displays IGMP IPMC group information:

```
show ip igmp ipmcgrp
```

Command mode: All

```
Total number of displayed ipmc groups: 4
Legend(possible values in Type column) :
SH - static host      DR - dynamic registered
SP - static primary  DU - dynamic unregistered
SB - static backup   M - mrouter
O - other
-----
```

Source	Group	Vlan	Port	Type	Timeleft
*	232.0.0.1	1	-	DU	6 sec
*	232.0.0.2	1	-	DU	6 sec
*	232.0.0.3	1	-	DU	6 sec
*	232.0.0.4	1	-	DU	6 sec

IGMP IPMC Group information includes:

- IGMPv3 source address
- Multicast group address
- VLAN and port
- Type of IPMC group
- Expiration timer value

MLD information

[Table 50](#) describes the commands used to view Multicast Listener Discovery (MLD) information.

Table 50. MLD Information Commands

Command Syntax and Usage
<pre>show ipv6 mld groups</pre> <p>Displays MLD multicast group information.</p> <p>Command mode: All</p>
<pre>show ipv6 mld groups address <IPv6 address></pre> <p>Displays group information for the specified IPv6 address.</p> <p>Command mode: All</p>
<pre>show ipv6 mld groups interface port <port alias or number></pre> <p>Displays MLD groups on a single interface port.</p> <p>Command mode: All</p>
<pre>show ipv6 mld groups portchannel <trunk group number></pre> <p>Displays groups on a single port channel.</p> <p>Command mode: All</p>
<pre>show ipv6 mld groups vlan <VLAN number></pre> <p>Displays groups on a single VLAN.</p> <p>Command mode: All</p>
<pre>show ipv6 mld mrouter</pre> <p>Displays all MLD Mrouter ports. See page 85 for sample output.</p> <p>Command mode: All</p>

MLD Mrouter Information

The following command displays MLD Mrouter information:

```
show ipv6 mld mrouter
```

Command mode: All

```
Source: fe80:0:0:0:200:14ff:fea8:40c9
Port/Vlan: 26/4
Interface: 3
QRV: 2 QQIC:125
Maximum Response Delay: 1000
Version: MLDv2 Expires:1:02
```

The following table describes the MLD Mrouter information displayed in the output.

Table 51. MLD Mrouter

Statistic	Description
Source	Displays the link-local address of the reporter.
Port/Vlan	Displays the port/vlan on which the general query is received.
Interface	Displays the interface number on which the general query is received.
QRV	Displays the Querier's robustness variable value.
QQIC	Displays the Querier's query interval code.
Maximum Response Delay	Displays the configured maximum query response time.
Version	Displays the MLD version configured on the interface.
Expires	Displays the amount of time that must pass before the multicast router decides that there are no more listeners for a multicast address or a particular source on a link.

VRRP Information

Virtual Router Redundancy Protocol (VRRP) support on CN4093 10Gb Converged Scalable Switch provides redundancy between routers in a LAN. This is accomplished by configuring the same virtual router IP address and ID number on each participating VRRP-capable routing device. One of the virtual routers is then elected as the master, based on a number of priority criteria, and assumes control of the shared virtual router IP address. If the master fails, one of the backup virtual routers will assume routing authority and take control of the virtual router IP address.

The following command displays VRRP information:

```
show ip vrrp information
```

Command mode: All

```
VRRP information:
 1: vrid 2, 205.178.18.210, if 1, renter, prio 100, master
 2: vrid 1, 205.178.18.202, if 1, renter, prio 100, backup
 3: vrid 3, 205.178.18.204, if 1, renter, prio 100, master
```

When virtual routers are configured, you can view the status of each virtual router using this command. VRRP information includes:

- Virtual router number
- Virtual router ID and IP address
- Interface number
- Ownership status
 - `owner` identifies the preferred master virtual router. A virtual router is the owner when the IP address of the virtual router and its IP interface are the same.
 - `renter` identifies virtual routers which are not owned by this device.
- Priority value. During the election process, the virtual router with the highest priority becomes master.
- Activity status
 - `master` identifies the elected master virtual router.
 - `backup` identifies that the virtual router is in backup mode.
 - `holdoff` identifies that the virtual router is in holdoff state.
 - `init` identifies that the virtual router is waiting for a startup event. For example, once it receives a startup event, it transitions to master if its priority is 255, (the IP address owner), or transitions to backup if it is not the IP address owner.

Interface Information

The following command displays interface information:

```
show interface ip
```

Command mode: All

```
Interface information:
 126:   IP6 fd55:faaf:e1ab:1022:7699:75ff:fe91:a6ef/64           , vlan 4095, up
       fe80::7699:75ff:fe91:a6ef
 128:   IP4 9.37.78.51           255.255.252.0   9.37.79.255,   vlan 4095, up
```

For each interface, the following information is displayed:

- IPv4 interface address and subnet mask
- IPv6 address and prefix
- VLAN assignment
- Status (up, down, disabled)

IPv6 Interface Information

The following command displays IPv6 interface information:

```
show ipv6 interface <interface number>
```

Command mode: All

```
Interface information:
 2: IP6 2001:0:0:0:225:3ff:febb:bb15/64           , vlan 1, up
     fe80::225:3ff:febb:bb15
Link local address:
 fe80::225:3ff:febb:bb15
Global unicast address(es):
 2001::225:3ff:febb:bb15/64
Anycast address(es):
 Not Configured.
Joined group address(es):
 ff02::1
 ff02::2
 ff02::1:ffbb:bb15
MTU is 1500
ICMP redirects are enabled
ND DAD is enabled, Number of DAD attempts: 1
ND router advertisement is disabled
```

For each interface, the following information is displayed:

- IPv6 interface address and prefix
- VLAN assignment
- Status (up, down, disabled)
- Path MTU size
- Status of ICMP redirects
- Status of Neighbor Discovery (ND) Duplicate Address Detection (DAD)
- Status of Neighbor Discovery router advertisements

IPv6 Path MTU Information

The following command displays IPv6 Path MTU information:

```
show ipv6 pmtu [<destination IPv6 address>]
```

Command mode: All

Path MTU Discovery info:		
Max Cache Entry Number : 10		
Current Cache Entry Number: 2		
Cache Timeout Interval : 10 minutes		
Destination Address	Since	PMTU
5000:1::3	00:02:26	1400
FE80::203:A0FF:FED6:141D	00:06:55	1280

Path MTU Discovery information provides information about entries in the Path MTU cache. The PMTU field indicates the maximum packet size in octets that can successfully traverse the path from the switch to the destination node. It is equal to the minimum link MTU of all the links in the path to the destination node.

IP Information

The following command displays Layer 3 information:

```
show ip interface brief
```

Command mode: All

```
IP information:
  AS number 0

Interface information:
126: IP6 0:0:0:0:0:0:0:0/0                                , vlan 4095, up
      fe80::200:ff:fe00:ef
128: IP4 9.43.95.121      255.255.255.0    9.43.95.255,      vlan 4095, up

Loopback interface information:

Default gateway information: metric strict
  4: 9.43.95.254,      FAILED

Default IP6 gateway information:

Current BOOTP relay settings: OFF
Global servers:
-----
Server 1 address 0.0.0.0
Server 2 address 0.0.0.0
Server 3 address 0.0.0.0
Server 4 address 0.0.0.0
Server 5 address 0.0.0.0

Current IP forwarding settings: ON, dirbr disabled, icmprd disabled

Current network filter settings:
  none

Current route map settings:
RIP is disabled.

OSPF is disabled.

OSPFv3 is disabled.

BGP is disabled.
```

IP information includes:

- IP interface information: Interface number, IP address, subnet mask, broadcast address, VLAN number, and operational status.
- Default gateway information: Metric for selecting which configured gateway to use, gateway number, IP address, and health status
- BootP relay settings
- IP forwarding settings, including the forwarding status of directed broadcasts, and the status of ICMP re-directs
- Network filter settings, if applicable
- Route map settings, if applicable

IKEv2 Information

The following table lists commands that display information about IKEv2.

Table 52. IKEv2 Information Commands

Command Syntax and Usage
<code>show ikev2</code> Displays all IKEv2 information. See page 91 for sample output. Command mode: All
<code>show ikev2 ca-cert</code> Displays the CA certificate. Command mode: All
<code>show ikev2 host-cert</code> Displays the host certificate. Command mode: All
<code>show ikev2 identity</code> Displays IKEv2 identity information. Command mode: All
<code>show ikev2 preshare-key</code> Displays the IKEv2 preshare key. Command mode: All
<code>show ikev2 proposal</code> Displays the IKEv2 proposal. Command mode: All
<code>show ikev2 retransmit-interval</code> Displays the IKEv2 retransmit interval. Command mode: All
<code>show ikev2 sa</code> Displays the IKEv2 SA. Command mode: All

IKEv2 Information Dump

The following command displays IKEv2 information:

```
show ikev2
```

Command mode: All

```
IKEv2 retransmit time:      20

IKEv2 cookie notification:  disable

IKEv2 authentication method: Pre-shared key

IKEv2 proposal:
Cipher:                     3des
Authentication:             sha1
DH Group:                   dh-2

Local preshare key:         ibm123

IKEv2 choose IPv6 address as ID type
No SAD entries.
```

IKEv2 information includes:

- IKEv2 retransmit time, in seconds.
- Whether IKEv2 cookie notification is enabled.
- The IKEv2 proposal in force. This includes the encryption algorithm (cipher), the authentication algorithm type, and the Diffie-Hellman (DH) group, which determines the strength of the key used in the key exchange process. Higher DH group numbers are more secure but require additional time to compute the key.
- The local preshare key.
- Whether IKEv2 is using IPv4 or IPv6 addresses as the ID type.
- Security Association Database (SAD) entries, if applicable.

IPsec Information

The following table describes the commands used to display information about IPsec.

Table 53. IPsec Information Commands

Command Syntax and Usage
<pre>show ipsec sa</pre> <p>Displays all security association information.</p> <p>Command mode: All</p>
<pre>show ipsec spd</pre> <p>Displays all security policy information.</p> <p>Command mode: All</p>
<pre>show ipsec dynamic-policy <I-10></pre> <p>Displays dynamic policy information.</p> <p>Command mode: All</p>
<pre>show ipsec manual-policy <I-10></pre> <p>Displays manual policy information. See page 93 for sample output.</p> <p>Command mode: All</p>
<pre>show ipsec transform-set <I-10></pre> <p>Displays IPsec transform set information.</p> <p>Command mode: All</p>
<pre>show ipsec traffic-selector <I-10></pre> <p>Displays IPsec traffic selector information.</p> <p>Command mode: All</p>

IPsec Manual Policy Information

The following command displays IPsec manual key management policy information:

```
show ipsec manual-policy
```

Command mode: All

```
IPsec manual policy 1 -----
IP Address:                2002:0:0:0:0:0:151
Associated transform ID:    1
Associated traffic selector ID: 1
IN-ESP SPI:                9900
IN-ESP encryption KEY:     3456789abcdef012
IN-ESP authentication KEY: 23456789abcdef0123456789abcdef0123456789
OUT-ESP SPI:               7700
OUT-ESP encryption KEY:    6789abcdef012345
OUT-ESP authentication KEY: 56789abcdef0123456789abcdef0123456789abc
Applied on interface:
interface 1
```

IPsec manual policy information includes:

- The IP address of the remote peer
- The transform set ID associated with this policy
- Traffic selector ID associated with this policy
- ESP inbound SPI
- ESP inbound encryption key
- ESP inbound authentication key
- ESP outbound SPI
- ESP outbound encryption key
- ESP outbound authentication key
- The interface to which this manual policy has been applied

PIM Information

Table 54. PIM Information Options

Command Syntax and Usage
<pre>show ip pim bsr [<component ID>]</pre> <p>Displays information about the PIM bootstrap router (BSR).</p> <p>Command mode: All</p>
<pre>show ip pim component [<component ID (1-2)>]</pre> <p>Displays PIM component information. For details, see page 95.</p> <p>Command mode: All</p>
<pre>show ip pim interface [<interface number> detail port <port number>]</pre> <p>Displays PIM interface information. To view sample output, see page 95.</p> <p>Command mode: All</p>

Table 54. PIM Information Options (continued)

Command Syntax and Usage
<pre>show ip pim neighbor [<interface number> port <port number>]</pre> <p>Displays PIM neighbor information. To view sample output, see page 96.</p> <p>Command mode: All</p>
<pre>show ip pim neighbor-filters</pre> <p>Displays information about PIM neighbor filters.</p> <p>Command mode: All</p>
<pre>show ip pim mroute [<component ID> count flags group <multicast group address> interface {<interface number> port <port number>} source <multicast source address>]</pre> <p>Displays information about PIM multicast routes. For more information about displaying PIM multicast route information, see page 96.</p> <p>Command mode: All</p>
<pre>show ip pim rp-candidate [<component ID>]</pre> <p>Displays a list of the candidate Rendezvous Points configured.</p> <p>Command mode: All</p>
<pre>show ip pim rp-set [<RP IP address>]</pre> <p>Displays a list of the Rendezvous Points learned.</p> <p>Command mode: All</p>
<pre>show ip pim rp-static [<component ID>]</pre> <p>Displays a list of the static Rendezvous Points configured.</p> <p>Command mode: All</p>
<pre>show ip pim elected-rp [group <multicast group address>]</pre> <p>Displays a list of the elected Rendezvous Points.</p> <p>Command mode: All</p>

PIM Component Information

The following command displays Protocol Independent Multicast (PIM) component information:

```
show ip pim component [<component ID>]
```

Command mode: All

```
PIM Component Information
-----
Component-Id: 1
  PIM Mode: sparse,   PIM Version: 2
  Elected BSR: 1.1.1.1
  Candidate RP Holdtime: 100
```

PIM component information includes the following:

- Component ID
- Mode (sparse, dense)
- PIM Version
- Elected Bootstrap Router (BSR) address
- Candidate Rendezvous Point (RP) hold time, in seconds

PIM Interface Information

The following command displays information about PIM interfaces:

```
show ip pim interface
```

Command mode: All

Address	IfName/IfId	Ver/Mode	Nbr Count	Qry Interval	DR-Address	DR-Prio
40.0.0.3	net4/4	2/Sparse	1	30	40.0.0.3	1
50.0.0.3	net5/5	2/Sparse	0	30	50.0.0.3	1

PIM interface information includes the following for each PIM interface:

- IP address
- Name and ID
- Version and mode
- Neighbor count
- Query interval
- Designated Router address
- Designated Router priority value

PIM Neighbor Information

The following command displays PIM neighbor information:

```
show ip pim neighbor
```

Command mode: All

Neighbour Address	IfName/Idx	Uptime/Expiry	Ver	DRPri/Mode	CompId	Override Interval	Lan Delay
40.0.0.2	net4/4	00:00:37/79	v2	1/S	1	0	0
40.0.0.4	net1/160	00:03:41/92	v2	32/S	2	0	0

PIM neighbor information includes the following:

- Neighbor IP address, interface name, and interface ID
- Name and ID of interface used to reach the PIM neighbor
- Up time (the time since this neighbor became the neighbor of the local router)
- Expiry Time (the minimum time remaining before this PIM neighbor expires)
- Version number
- Designated Router priority and mode
- Component ID
- Override interval
- LAN delay interval

PIM Multicast Route Information Commands

Table 55. PIM Multicast Route Information Options

Command Syntax and Usage
<pre>show ip pim mroute [<component ID>]</pre> <p>Displays PIM multicast routes for the selected component.</p> <p>Command mode: All</p>
<pre>show ip pim mroute flags [s] [r] [w]</pre> <p>Displays PIM multicast routes based on the selected entry flags. Enter flags in any combination:</p> <ul style="list-style-type: none"> – s: Shortest Path Tree (SPT) bit – R: Rendezvous Point Tree (RPT) bit – w: Wildcard bit <p>Command mode: All</p>
<pre>show ip pim mroute group <multicast group IP address></pre> <p>Displays PIM multicast routes for the selected multicast group.</p> <p>Command mode: All</p>
<pre>show ip pim mroute interface <interface number></pre> <p>Displays PIM multicast routes for the selected incoming IP interface.</p> <p>Command mode: All</p>

Table 55. PIM Multicast Route Information Options (continued)

Command Syntax and Usage
<pre>show ip pim mroute source <multicast source IP address></pre> <p>Displays PIM multicast routes for the selected source IP address.</p> <p>Command mode: All</p>
<pre>show ip pim mroute count</pre> <p>Displays a count of PIM multicast routes of each type.</p> <p>Command mode: All</p>
<pre>show ip pim mroute</pre> <p>Displays information about all PIM multicast routes.</p> <p>Command mode: All</p>

PIM Multicast Route Information

The following command displays PIM multicast route information:

```
show ip pim mroute
```

Command mode: All

<pre>IP Multicast Routing Table ----- Route Flags S: SPT Bit W: Wild Card Bit R: RPT Bit Timers: Uptime/Expires (8.8.8.111, 224.2.2.100) ,00:42:03/00:01:11 Incoming Interface : net44 ,RPF nbr : 44.44.44.1 ,Route Flags : S Outgoing InterfaceList : net17, Forwarding/Sparse ,00:42:03/--- (*, 224.2.2.100) ,00:45:15/--- ,RP : 88.88.88.2 Incoming Interface : net5 ,RPF nbr : 5.5.5.2 ,Route Flags : WR Outgoing InterfaceList : net17, Forwarding/Sparse ,00:45:15/--- Total number of (*,G) entries : 1 Total number of (S,G) entries : 1</pre>

Quality of Service Information

Table 56. QoS Information Options

Command Syntax and Usage
<pre>show qos transmit-queue</pre> <p>Displays mapping of 802.1p value to Class of Service queue number, and COS queue weight value.</p> <p>Command mode: All</p>
<pre>show qos transmit-queue information</pre> <p>Displays all 802.1p information.</p> <p>Command mode: All</p> <p>For details, see page 98.</p>
<pre>show qos random-detect</pre> <p>Displays WRED ECN information.</p> <p>Command mode: All</p>

802.1p Information

The following command displays 802.1p information:

```
show qos transmit-queue information
```

Command mode: All

Current priority to COS queue information:			
Priority	COSq	Weight	
-----	----	-----	
0	0	1	
1	1	2	
2	2	3	
3	3	4	
4	4	5	
5	5	7	
6	6	15	
7	7	0	
Current port priority information:			
Port	Priority	COSq	Weight
-----	-----	----	-----
INT1	0	0	1
INT2	0	0	1
...			
MGT1	0	0	1
MGT2	0	0	1
EXT1	0	0	1
EXT2	0	0	1
EXT3	0	0	1
EXT4	0	0	1
...			

The following table describes the IEEE 802.1p priority-to-COS queue information.

Table 57. 802.1p Priority-to-COS Queue Parameter Descriptions

Parameter	Description
Priority	Displays the 802.1p Priority level.
COSq	Displays the Class of Service queue.
Weight	Displays the scheduling weight of the COS queue.

The following table describes the IEEE 802.1p port priority information.

Table 58. 802.1p Port Priority Parameter Descriptions

Parameter	Description
Port	Displays the port alias.
Priority	Displays the 802.1p Priority level.
COSq	Displays the Class of Service queue.
Weight	Displays the scheduling weight.

WRED and ECN Information

The following command displays WRED and ECN information:

```
show qos random-detect
```

Command mode: All

```
Current wred and ecn configuration:
Global ECN: Disable
Global WRED: Disable

--WRED--TcpMinThr--TcpMaxThr--TcpDrate--NonTcpMinThr--NonTcpMaxThr--NonTcpDrate--
0      TQ0:  Dis    0      0      0      0      0
0      TQ1:  Dis    0      0      0      0      0
0      TQ2:  Dis    0      0      0      0      0
0      TQ3:  Dis    0      0      0      0      0
0      TQ4:  Dis    0      0      0      0      0
0      TQ5:  Dis    0      0      0      0      0
0      TQ6:  Dis    0      0      0      0      0
0      TQ7:  Dis    0      0      0      0      0
...
```

Access Control List Information Commands

Table 59. ACL Information Options

Command Syntax and Usage
<pre>show access-control list <ACL number></pre> <p>Displays ACL list information. For details, see page 101.</p> <p>Command mode: All</p>
<pre>show access-control list6 <ACL number></pre> <p>Displays IPv6 ACL list information.</p> <p>Command mode: All</p>
<pre>show access-control group <ACL group number></pre> <p>Displays ACL group information.</p> <p>Command mode: All</p>
<pre>show access-control vmap <VMAP number></pre> <p>Displays VMAP information.</p> <p>Command mode: All</p>

Access Control List Information

The following command displays Access Control List (ACL) information:

```
show access-control list <ACL number>
```

Command mode: All

```
Current ACL information:
-----
Filter 2 profile:
 Ethernet
  - VID      : 2/0xffff
  Actions    : Permit
  Statistics  : enabled
```

Access Control List (ACL) information includes configuration settings for each ACL and ACL Group.

Table 60. ACL Parameter Descriptions

Parameter	Description
Filter <i>x</i> profile	Indicates the ACL number.
Actions	Displays the configured action for the ACL.
Statistics	Displays the status of ACL statistics configuration (enabled or disabled).

RMON Information Commands

The following table describes the Remote Monitoring (RMON) Information commands.

Table 61. RMON Information commands

Command Syntax and Usage
<code>show rmon history</code> Displays RMON History information. For details, see page 103 . Command mode: All
<code>show rmon alarm</code> Displays RMON Alarm information. For details, see page 104 . Command mode: All
<code>show rmon event</code> Displays RMON Event information. For details, see page 105 . Command mode: All
<code>show rmon</code> Displays all RMON information. Command mode: All

RMON History Information

The following command displays RMON History information:

```
show rmon history
```

Command mode: All

```

RMON History group configuration:

Index IFOID                                Interval Rbnum Gbnum
-----
  1  1.3.6.1.2.1.2.2.1.1.24                30     5    5
  2  1.3.6.1.2.1.2.2.1.1.22                30     5    5
  3  1.3.6.1.2.1.2.2.1.1.20                30     5    5
  4  1.3.6.1.2.1.2.2.1.1.19                30     5    5
  5  1.3.6.1.2.1.2.2.1.1.24                1800    5    5

Index                                Owner
-----
  1  dan
  
```

The following table describes the RMON History Information parameters.

Table 62. RMON History Parameter Descriptions

Parameter	Description
Index	Displays the index number that identifies each history instance.
IFOID	Displays the MIB Object Identifier.
Interval	Displays the time interval for each sampling bucket.
Rbnum	Displays the number of requested buckets, which is the number of data slots into which data is to be saved.
Gbnum	Displays the number of granted buckets that may hold sampled data.
Owner	Displays the owner of the history instance.

RMON Alarm Information

The following command displays RMON Alarm information:

```
show rmon alarm
```

Command mode: All

```

RMON Alarm group configuration:

Index  Interval  Sample  Type      rLimit      fLimit      last value
-----  -----  -----  -----  -----  -----  -----
      1      1800     abs     either           0           0          7822

Index  rEvtIdx  fEvtIdx      OID
-----  -----  -----  -----
      1         0         0  1.3.6.1.2.1.2.2.1.10.1

Index      Owner
-----  -----
      1  dan
  
```

The following table describes the RMON Alarm Information parameters.

Table 63. RMON Alarm Parameter Descriptions

Parameter	Description
Index	Displays the index number that identifies each alarm instance.
Interval	Displays the time interval over which data is sampled and compared with the rising and falling thresholds.
Sample	Displays the method of sampling the selected variable and calculating the value to be compared against the thresholds, as follows: <ul style="list-style-type: none"> – <i>abs</i>—absolute value, the value of the selected variable is compared directly with the thresholds at the end of the sampling interval. – <i>delta</i>—delta value, the value of the selected variable at the last sample is subtracted from the current value, and the difference compared with the thresholds.
Type	Displays the type of alarm, as follows: <ul style="list-style-type: none"> – <i>falling</i>—alarm is triggered when a falling threshold is crossed. – <i>rising</i>—alarm is triggered when a rising threshold is crossed. – <i>either</i>—alarm is triggered when either a rising or falling threshold is crossed.
rLimit	Displays the rising threshold for the sampled statistic.
fLimit	Displays the falling threshold for the sampled statistic.
Last value	Displays the last sampled value.

Table 63. RMON Alarm Parameter Descriptions (continued)

Parameter	Description
rEvtIdx	Displays the rising alarm event index that is triggered when a rising threshold is crossed.
fEvtIdx	Displays the falling alarm event index that is triggered when a falling threshold is crossed.
OID	Displays the MIB Object Identifier for each alarm index.
Owner	Displays the owner of the alarm instance.

RMON Event Information

The following command displays RMON Alarm information:

```
show rmon event
```

Command mode: All

```

RMON Event group configuration:

Index Type      Last Sent          Description
-----
  1 both    0D: 0H: 1M:20S   Event_1
  2 none    0D: 0H: 0M: 0S   Event_2
  3 log     0D: 0H: 0M: 0S   Event_3
  4 trap    0D: 0H: 0M: 0S   Event_4
  5 both    0D: 0H: 0M: 0S   Log and trap event for Link Down
 10 both    0D: 0H: 0M: 0S   Log and trap event for Link Up
 11 both    0D: 0H: 0M: 0S   Send log and trap for icmpInMsg
 15 both    0D: 0H: 0M: 0S   Send log and trap for icmpInEchos

Index          Owner
-----
  1 dan
  
```

The following table describes the RMON Event Information parameters.

Table 64. RMON Event Parameter Descriptions

Parameter	Description
Index	Displays the index number that identifies each event instance.
Type	Displays the type of notification provided for this event, as follows: none, log, trap, both.
Last sent	Displays the time that passed since the last switch reboot, when the most recent event was triggered. This value is cleared when the switch reboots.
Description	Displays a text description of the event.
Owner	Displays the owner of the alarm instance.

Link Status Information

The following command displays link information:

```
show interface status [<port alias or number>]
```

Command mode: All

Alias	Port	Speed	Duplex	Flow Ctrl		Link	Name
-----	----	-----	-----	--TX--	---RX---	-----	-----
INTA1	1	1G/10G	full	yes	yes	down	INTA1
INTA2	2	1G/10G	full	yes	yes	down	INTA2
INTA3	3	1G/10G	full	yes	yes	down	INTA3
INTA4	4	1G/10G	full	yes	yes	down	INTA4
...							
INTA14	14	1G/10G	full	yes	yes	down	INTA14
INTB1	15	1G/10G	full	yes	yes	down	INTB1
INTB2	16	1G/10G	full	yes	yes	down	INTB2
INTB3	17	1G/10G	full	yes	yes	down	INTB3
INTB4	18	1G/10G	full	yes	yes	down	INTB4
...							
INTC14	42	1G/10G	full	yes	yes	down	INTC14
EXT1	43	1G/10G	full	no	no	down	EXT1
EXT2	44	1G/10G	full	no	no	down	EXT2
EXT3	45	10000	full	no	no	up	EXT3
EXT4	46	1G/10G	full	no	no	down	EXT4
...							
EXT20	62	10000	full	no	no	disabled	EXT20
EXT21	63	10000	full	no	no	disabled	EXT21
EXT22	64	10000	full	no	no	disabled	EXT22
EXTM	65	1000	full	yes	yes	up	EXTM
MGT1	66	1000	full	no	no	up	MGT1

Alias	Port	Speed	Duplex	Flow Ctrl		Link	Name
-----	----	-----	-----	--TX--	---RX---	-----	-----
INTA1	1	1000	full	yes	yes	down	INTA1
INTA2	2	1000	full	yes	yes	down	INTA2
INTA3	3	1000	full	yes	yes	down	INTA3
INTA4	4	1000	full	no	no	up	INTA4
INTA5	5	1000	full	no	no	up	INTA5
INTA6	6	1000	full	yes	yes	up	INTA6
...							
INTA14	14	1000	full	yes	yes	down	INTA14
EXT1	29	any	any	no	no	down	EXT1
EXT2	30	any	any	no	no	down	EXT2
EXT3	31	1000	full	no	no	up	EXT3
EXT4	32	1000	full	no	no	up	EXT4
...							
EXT21	49	1G/10G	full	no	no	down	EXT21
EXT22	50	1G/10G	full	no	no	down	EXT22
EXT23	51	1G/10G	full	no	no	down	EXT23
EXT24	52	1G/10G	full	no	no	down	EXT24
MGT1	53	1000	full	no	no	up	MGT1

Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

Use this command to display link status information about each port on the CN4093, including:

- Port alias and port number
- Port speed and Duplex mode (half, full, any)
- Flow control for transmit and receive (no, yes, or both)
- Link status (up, down, or disabled)

The following display shows link status when Bridge Module connections are enabled:

Alias	Port	Speed	Duplex	Flow Ctrl		Link
-----	----	-----	-----	--TX----	---RX--	-----
INT1	1	10000	full	yes	yes	down
INT2	2	10000	full	yes	yes	down
INT3	3	10000	full	yes	yes	down
INT4	4	10000	full	yes	yes	down
INT5	5	10000	full	yes	yes	down
INT6	6	10000	full	yes	yes	down
INT7	7	10000	full	yes	yes	down
INT8	8	10000	full	yes	yes	down
INT9	9	10000	full	yes	yes	down
INT10	10	10000	full	yes	yes	down
INT11	11	10000	full	yes	yes	down
INT12	12	10000	full	yes	yes	down
INT13	13	10000	full	yes	yes	down
INT14	14	10000	full	yes	yes	down
MGT1	15	100	full	yes	yes	up
MGT2	16	100	full	yes	yes	disabled
KR 1	17	10000	full	yes	yes	up
KR 2	18	10000	full	yes	yes	up
KR 3	19	10000	full	yes	yes	up
KR 4	20	10000	full	yes	yes	up
EXT5	21	10000	full	yes	yes	down
EXT6	22	10000	full	yes	yes	down
KR 8	23	10000	full	yes	yes	down
KR 7	24	10000	full	yes	yes	down
KR 6	25	10000	full	yes	yes	down
KR 5	26	10000	full	yes	yes	down
EXT11	27	any	any	yes	yes	down

Alias	Speed					
-----	-----					
BM5	40Gbs					
BM3	40Gbs					

Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

This command displays link status information about each port on the CN4093, including:

- Ethernet port alias, number, and configuration
- Link status (up, down, or disabled)
- Bridge Module (KR) port alias, port number, and configuration (if applicable)
- Bridge Module alias and speed setting

Port Information

The following command displays port information:

```
show interface trunk <port alias or number>
```

Command mode: All

Alias	Port	Tag Trk	RMON	Lrn	Fld	PVID NVLAN	DESCRIPTION	VLAN(s)
INTA1	1	n	d	e	e	4081#	INTA1	4081
INTA2	2	n	d	e	e	4081#	INTA2	4081
INTA3	3	n	d	e	e	4081#	INTA3	4081
INTA4	4	n	d	e	e	4081#	INTA4	4081
INTA5	5	n	d	e	e	4081#	INTA5	4081
INTA6	6	n	d	e	e	4081#	INTA6	4081
INTA7	7	n	d	e	e	4081#	INTA7	4081
INTA8	8	n	d	e	e	4081#	INTA8	4081
INTA9	9	n	d	e	e	4081#	INTA9	4081
INTA10	10	n	d	e	e	4081#	INTA10	4081
INTA11	11	n	d	e	e	4081#	INTA11	4081
INTA12	12	n	d	e	e	4081#	INTA12	4081
INTA13	13	n	d	e	e	4081#	INTA13	4081
INTA14	14	n	d	e	e	4081#	INTA14	4081
INTB1	15	n	d	e	e	4082#	INTB1	4082
INTB2	16	n	d	e	e	4082#	INTB2	4082
INTB3	17	n	d	e	e	4082#	INTB3	4082
INTB4	18	n	d	e	e	4082#	INTB4	4082
INTB5	19	n	d	e	e	4082#	INTB5	4082
INTB6	20	n	d	e	e	4082#	INTB6	4082
INTB7	21	n	d	e	e	4082#	INTB7	4082
INTB8	22	n	d	e	e	4082#	INTB8	4082
INTB9	23	n	d	e	e	4082#	INTB9	4082
INTB10	24	n	d	e	e	4082#	INTB10	4082
INTB11	25	n	d	e	e	4082#	INTB11	4082
INTB12	26	n	d	e	e	4082#	INTB12	4082
INTB13	27	n	d	e	e	4082#	INTB13	4082
INTB14	28	n	d	e	e	4082#	INTB14	4082
INTC1	29	n	d	e	e	4083#	INTC1	4083
INTC2	30	n	d	e	e	4083#	INTC2	4083
INTC3	31	n	d	e	e	4083#	INTC3	4083
INTC4	32	n	d	e	e	4083#	INTC4	4083
INTC5	33	n	d	e	e	4083#	INTC5	4083
INTC6	34	n	d	e	e	4083#	INTC6	4083
INTC7	35	n	d	e	e	4083#	INTC7	4083
INTC8	36	n	d	e	e	4083#	INTC8	4083
INTC9	37	n	d	e	e	4083#	INTC9	4083
INTC10	38	n	d	e	e	4083#	INTC10	4083
INTC11	39	n	d	e	e	4083#	INTC11	4083
INTC12	40	n	d	e	e	4083#	INTC12	4083
INTC13	41	n	d	e	e	4083#	INTC13	4083
INTC14	42	n	d	e	e	4083#	INTC14	4083
EXT1	43	n	d	e	e	4081#	EXT1	4081
EXT2	44	n	d	e	e	4081#	EXT2	4081

Note: The sample screens that appear in this document might differ slightly from the screens displayed by your system. Screen content varies based on the type of BladeCenter unit that you are using and the firmware versions and options that are installed.

Port information includes:

- Port alias and number
- Whether the port uses VLAN tagging or not (y or n)
- Whether the port uses PVID/Native-VLAN tagging or not (y or n)
- Whether the port uses PVID ingress tagging or not (y or n)
- Whether the port is internal, external or used for management
- Whether the port has Remote Monitoring (RMON) enabled
- Whether the port has FDB Learning enabled (Lrn)
- Whether the port has Port Flooding enabled (Fld)
- Port VLAN ID (PVID/Native-VLAN)
- Port description
- VLAN membership

Port Transceiver Status

The following command displays the status of the transceiver module on each external port:

```
show interface transceiver
```

Command mode: All

This command displays information about the transceiver module on each port, as follows:

- Port number and media type
- Link status
- Transceiver detail
- Vendor information
- Part number
- Approval state

Use the following command to display extended transceiver information:

```
show interface port <port number> transceiver details
```

Command mode: All

Port		TX	Link	TXFlt	Volts	DegsC	TXuW	RXuW	Transceiver	Approve
55	FLEX	3	Ena	Down	-N/A-	-N/A-	-N/A-	-N/A-	3m ACTX	Accepted
			IBM-Amphenol		Part:46K6183-L36836B	Date:111231	S/N:YL11FY1CY40G			

This command displays detailed information about the transceiver module, as follows:

- Port number and media type
- TX: Transmission status
- TXflt: Transmission fault indicator
- Volts: Power usage, in volts
- DegsC: Temperature, in degrees centigrade
- TXuW: Transmit power, in micro-watts
- RXuW: Receive power, in micro-watts
- Media type (LX, LR, SX, SR)
- Approval status

The optical power levels shown for transmit and receive functions for the transceiver should fall within the expected range defined in the IEEE 802-3-2008 specification for each transceiver type. For convenience, the expected range values are summarized in the following table.

Table 65. Expected Transceiver Optical Power Levels

Transceiver Type	Tx Minimum	Tx Maximum	Rx Minimum	Rx Maximum
SFP SX	112 μ W	1000 μ W	20 μ W	1000 μ W
SFP LX	70.8 μ W	501 μ W	12.6 μ W	501 μ W
SFP+ SR	186 μ W	794 μ W	102 μ W	794 μ W
SFP+ LR	151 μ W	891 μ W	27.5 μ W	891 μ W

Note: Power level values in the IEEE specification are shown in dBm, but have been converted to mW in this table to match the unit of measure shown in the display output.

Virtual Machines Information

The following command display information about Virtual Machines (VMs).

Table 66. Virtual Machines Information Options

Command Syntax and Usage
<pre>show virt port <port alias or number></pre> <p>Displays Virtual Machine information for the selected port.</p> <p>Command mode: All</p>
<pre>show virt vm [-v -r]</pre> <p>Displays all Virtual Machine information.</p> <ul style="list-style-type: none">- -v displays verbose information- -r rescans the data center <p>Command mode: All</p>

VM Information

The following command displays VM information:

```
show virt vm
```

Command mode: All

IP Address	VMAC Address	Index	Port	VM Group (Profile)
*127.31.46.50	00:50:56:4e:62:f5	4	INT3	
*127.31.46.10	00:50:56:4f:f2:85	2	INT4	
+127.31.46.51	00:50:56:72:ec:86	1	INT3	
+127.31.46.11	00:50:56:7c:1c:ca	3	INT4	
127.31.46.25	00:50:56:9c:00:c8	5	INT4	
127.31.46.15	00:50:56:9c:21:2f	0	INT4	
127.31.46.35	00:50:56:9c:29:29	6	INT3	

Number of entries: 8
* indicates VMware ESX Service Console Interface
+ indicates VMware ESX/ESXi VMKernel or Management Interface

VM information includes the following for each Virtual Machine (VM):

- IP address
- MAC address
- Index number assigned to the VM
- Internal port on which the VM was detected
- VM group that contains the VM, if applicable

VM Check Information

The following command displays VM Check information:

```
show virt vmcheck
```

Command mode: All

Action to take for spoofed VMs: Basic: Oper disable the link Advanced: Install ACL to drop traffic
Maximum number of acls that can be used for mac spoofing: 50
Trusted ports by configuration: empty

VMware Information

Use these commands to display information about Virtual Machines (VMs) and VMware hosts in the data center. These commands require the presence of a configured Virtual Center.

Table 67. VMware Information Options

Command Syntax and Usage
<pre>show virt vmware hosts</pre> <p>Displays a list of VMware hosts.</p> <p>Command mode: All</p>
<pre>show virt vmware hello</pre> <p>Displays VMware hello settings.</p> <p>Command mode: All</p>
<pre>show virt vmware showhost <host UUID> <host IP address> <host name></pre> <p>Displays detailed information about a specific VMware host.</p> <p>Command mode: All</p>
<pre>show virt vmware showvm <VM UUID> <VM IP address> <VM name></pre> <p>Displays detailed information about a specific Virtual Machine (VM).</p> <p>Command mode: All</p>
<pre>show virt vmware vms</pre> <p>Displays a list of VMs.</p> <p>Command mode: All</p>

VMware Host Information

The following command displays VM host information:

```
show virt vmware hosts
```

Command mode: All

UUID	Name(s), IP Address
80a42681-d0e5-5910-a0bf-bd23bd3f7803	127.12.41.30
3c2e063c-153c-dd11-8b32-a78dd1909a69	127.12.46.10
64f1fe30-143c-dd11-84f2-a8ba2cd7ae40	127.12.44.50
c818938e-143c-dd11-9f7a-d8defa4b83bf	127.12.46.20
fc719af0-093c-dd11-95be-b0adac1bcf86	127.12.46.30
009a581a-143c-dd11-be4c-c9fb65ff04ec	127.12.46.40

VM host information includes the following:

- UUID associated with the VMware host.
- Name or IP address of the VMware host.

EVB Information

The following commands display Edge Virtual Bridge (EVB) Virtual Station Interface (VSI) discovery and configuration information.

Table 68. EVB Information Options

Command Syntax and Usage
<pre>show virt evb vdp vm</pre> <p>Displays all active Virtual Machines (VMs).</p> <p>Command mode: All</p>
<pre>show virt evb profile [<1-16>]</pre> <p>Displays the current EVB profile parameters.</p> <p>Command mode: All</p>
<pre>show virt evb vdp tlv</pre> <p>Displays all active Virtual Station Interface (VSI) Discovery and Configuration Protocol (VDP) type-length-values (TLVs).</p> <p>Command mode: All</p>
<pre>show virt evb vsidb <VSI_database_number></pre> <p>Displays Virtual Station Interface database information.</p> <p>Command mode: All</p>
<pre>show virt evb vsitypes [mgrid <0-255> typeid <1-16777215> version <0-255>]</pre> <p>Displays the current Virtual Station Interface Type database parameters.</p> <p>Command mode: All</p>

vNIC Information

The following commands display information about Virtual NICs (vNICs).

Table 69. vNIC Information Options

Command Syntax and Usage
<pre>show vnic vnic</pre> <p>Displays information about each vNIC.</p> <p>Command mode: All</p>
<pre>show vnic vnicgroup</pre> <p>Displays information about each vNIC Group, including:</p> <ul style="list-style-type: none"> – Status (enabled or disabled) – VLAN assigned to the vNIC Group – Uplink Failover status (enabled or disabled) – Link status for each vNIC (up, down, or disabled) – Port link status for each port associated with the vNIC Group (up, down, or disabled) <p>Command mode: All</p>
<pre>show vnic information-dump</pre> <p>Displays all vNIC information.</p> <p>Command mode: All</p>

Virtual NIC (vNIC) Information

The following command displays Virtual NIC (vNIC) information:

```
show vnic vnic
```

Command mode: All

vNIC	vNICGroup	Vlan	MaxBandwidth	Type	MACAddress	Link
INT1.1	1	100	25	Default	00:00:c9:c6:d0:2a	up
INT1.2	#	*	0	FCoE	00:00:c9:c6:d0:2b	up
INT1.3	3	300	25	Default	00:00:c9:c6:d0:2c	up
INT1.4	4	400	25	Default	00:00:c9:c6:d0:2d	up
INT2.1	1	100	25	Default	00:00:c9:c6:cf:72	up
INT2.2	#	*	0	FCoE	00:00:c9:c6:cf:73	up
INT2.3	3	300	25	Default	00:00:c9:c6:cf:74	up
INT2.4	4	400	25	Default	00:00:c9:c6:cf:75	up
INT3.1	1	100	25	Default	00:00:c9:e3:09:5c	up
INT3.3	3	300	25	Default	00:00:c9:e3:09:5e	up
INT3.4	4	400	25	Default	00:00:c9:e3:09:5f	up
INT4.2	#	*	0	FCoE	00:00:c9:b2:55:6f	up
INT9.2	#	*	0	FCoE	00:00:c9:c6:cf:33	up
# = Not added to any vNIC group						
* = Not added to any vNIC group or no vlan set for its vNIC group						

vNIC information includes the following for each vNIC:

- vNIC ID
- vNIC Group that contains the vNIC
- VLAN assigned to the vNIC Group
- Maximum bandwidth allocated to the vNIC
- MAC address of the vNIC, if applicable
- Link status (up, down, or disabled)

vNIC Group Information

The following command displays vNIC Group information:

```
show vnic vnicgroup
```

Command mode: All

```
vNIC Group 1: enabled
-----
VLAN          : 100
Failover      : disabled

vNIC          Link
-----
INT1.1       up
INT2.1       up
INT3.1       up

Port          Link
-----

UplinkPort   Link
-----
EXT6         up
```

vNIC Group information includes the following for each vNIC Group:

- Status (enabled or disabled)
- VLAN assigned to the vNIC Group
- Uplink Failover status (enabled or disabled)
- Link status for each vNIC (up, down, or disabled)
- Port link status for each port associated with the vNIC Group (up, down, or disabled)

SLP Information

The following commands display information about Service Location Protocol settings:

Table 70. SLP Information Options

Command Syntax and Usage
<pre>show ip slp information</pre> <p>Displays the SLP version, whether SLP is enabled or disabled and whether DA auto-discovery is enabled or disabled</p> <p>Command mode: All</p>
<pre>show ip slp directory-agents</pre> <p>Lists all detected DAs</p> <p>Command mode: All</p>
<pre>show ip slp user-agents</pre> <p>Lists all detected UAs</p> <p>Command mode: All</p>

UFP Information

The following commands display information about Unified Fabric Port (UFP) settings.

Table 71. UFP Information Options

Command Syntax and Usage
<pre>show ufp [port <port_no.>] [vport <1-4>] [network qos evb]</pre> <p>Displays the UFP network and QoS settings applied on all ports or on specified physical and virtual ports.</p> <ul style="list-style-type: none">– <code>network</code> filters only UFP network settings– <code>qos</code> filters only QoS network settings– <code>evb</code> filters only EVB profile settings <p>Command mode: All</p>
<pre>show ufp information port [<port_no.>]</pre> <p>Displays UFP status for all physical ports or only for a specified physical port. Information includes whether the UFP is enabled on the physical port, how many virtual ports are enabled and the link stats for each virtual port. For details, see page 119.</p> <p>Command mode: All</p>

Table 71. UFP Information Options

Command Syntax and Usage
<pre>show ufp information {cdcp qos tlvstat} [port <port_no.>]</pre> <p>Displays global or port-specific UFP information on:</p> <ul style="list-style-type: none"> – cdcp displays S-Channel Discovery and Configuration Protocol (CDCP) information. CDCP allows hypervisor hosts to create on-demand S-channels with the switch. For details, see page 120. – qos displays bandwidth allocation between virtual ports. For details, see page 120. – tlvstat displays status for Type-Length-Values transmitted on UFP-enabled physical ports. For details, see page 121. <p>Command mode: All</p>
<pre>show ufp information qos [port <port_no.>] [vport <1-4>]</pre> <p>Displays bandwidth allocation between virtual ports for all physical ports or specified physical and virtual ports.</p> <p>Command mode: All</p>
<pre>show ufp information vport [port <port_no.>] [vport <1-4>]</pre> <p>Displays state, operating mode and VLAN related information for all virtual ports, for virtual ports belonging to a specified physical port or for a single virtual port. For details, see page 121.</p> <p>Command mode: All</p>
<pre>show ufp information getvlan <2-4094></pre> <p>Displays state, operating mode and VLAN related information for physical and virtual ports associated to a specified VLAN ID.</p> <p>Command mode: All</p>
<pre>show ufp information vlan [<1-4094>]</pre> <p>Displays ports and vports associated to all configured VLANs or to a specified VLAN ID. For details, see page 122.</p> <p>Command mode: All</p>
<pre>show ufp {receive transmit} {cap cdcp} port <port_no.></pre> <p>Displays received/transmitted Type-Length-Values for the specified ports.</p> <ul style="list-style-type: none"> – cap displays the UFP Capability Discovery TLV – cdcp displays the UFP Channel Discovery and Configuration Protocol TLV <p>For details, see page 123.</p> <p>Command mode: All</p>

Port Information

The following command displays UFP port information:

```
show ufp information port
```

Command mode: All

Alias	Port	state	vPorts	link up	link down	mismatch	disabled
INTA4	4	ena	4	1 3 4		2	

Port information includes the following for each physical port:

- Port alias
- Port number
- UFP state
- Number of virtual ports enabled
- Link status on each channel (up, down or disabled)

CDCP Information

The following command displays S-Channel Discovery and Configuration Protocol information:

```
show ufp information cdcp
```

Command mode: All

INT1	: Channel Request
INT2	: Channel Request
INT3	: TxSVIDs
INT4	: TxSVIDs
INT5	: Disable
INT6	: Disable
INT7	: Disable
INT8	: Disable
INT9	: Disable
INT10	: Disable
INT11	: Disable
INT12	: Disable
INT13	: Disable
INT14	: Disable

CDCP information includes the following for each physical port:

- Whether there is a channel set up
- CDCP communication status for active channels

QoS Information

The following command displays Quality of Service information:

```
show ufp information qos
```

Command mode: All

```
Global UFP QoS mode: UFP QoS BW
```

Port	Vport	Minbw%	Maxbw%
1	1	15	100
	2	25	50
	3	25	100
	4	25	100
2	1	25	100
	2	25	100
	3	25	100
	4	25	100
3	1	25	100
	2	25	100
	3	25	100
	4	25	100
...			

QoS information includes the following:

- Physical port number
- Virtual port number
- Minimum guaranteed bandwidth allocated
- Maximum bandwidth achievable

TLV Status Information

The following command displays Type-Length-Values information:

```
show ufp information tlvstat
```

Command mode: All

```
INT1 : Success
INT2 : Success
INT3 : Disabled
INT4 : Disabled
INT5 : Disabled
INT6 : Disabled
INT7 : Disabled
INT8 : Disabled
INT9 : Disabled
INT10 : Disabled
INT11 : Disabled
INT12 : Disabled
INT13 : Disabled
INT14 : Disabled
```

TLV status information includes the following:

- Physical port alias
- Type-Length-Values status

Virtual Port Information

The following command displays virtual port information:

```
show ufp information vport
```

Command mode: All

vPort	state	mode	svid	defvlan	deftag	evbprof	VLANs
INTA1.1	dis	tunnel	0	0	dis	dis	
INTA1.2	dis	tunnel	0	0	dis	dis	
INTA1.3	dis	tunnel	0	0	dis	dis	
INTA1.4	dis	tunnel	0	0	dis	dis	
...							
INTA14.4	dis	tunnel	0	0	dis	dis	
INTB1.1	dis*	access	4002	100	dis	dis	100
INTB1.2	up	fcoe	2500	2500	dis	dis	2500
INTB1.3	dis*	trunk	4004	300	dis	dis	300 500
INTB1.4	dis	tunnel	0	0	dis	dis	
INTB2.1	dis*	access	4002	100	dis	dis	100
INTB2.2	up	fcoe	2500	2500	dis	dis	2500
INTB2.3	dis*	trunk	4004	300	dis	dis	300 500
INTB2.4	dis	tunnel	0	0	dis	dis	
INTB3.1	dis*	access	4002	100	dis	dis	100
INTB3.2	up	fcoe	2500	2500	dis	dis	2500
INTB3.3	dis*	trunk	4004	300	dis	dis	300 500
INTB3.4	dis	tunnel	0	0	dis	dis	

Virtual port information includes the following for each virtual port:

- Virtual port number
- Channel status
- Operating mode (trunk, access, tunnel, auto or FCoE)
- S-channel VLAN ID
- Default VLAN ID
- Default VLAN ID tagging enforcement
- EVB profile
- VLANs the virtual port is associated with

VLAN Information

The following command displays VLAN information:

```
show ufp information vlan
```

Command mode: All

```
----
VLAN
----
 100

vPort list:
  INTB1.1  INTB2.1  INTB3.1  INTB4.1  INTB5.1  INTB6.1  INTB7.1
INTB8.1  INTB9.1  INTB10.1  INTB11.1  INTB12.1

EXT Port list:
  EXT3     EXT4     EXT8     EXT9

INT Port list:
  INTB13

UFP Port list:
  INTB1  INTB2  INTB3  INTB4  INTB5  INTB6  INTB7  INTB8  INTB9
INTB10  INTB11  INTB12

VMR Port list:
```

VLAN information includes the following for each VLAN:

- VLAN ID
- Associated virtual ports
- Associated external ports
- Associated internal ports
- Associated UFP ports

TLV Information

The following commands display TLV information:

```
show ufp receive cap port <port_no.>
```

Command mode: All

```
UFP Capability Discovery TLV Received on port INT2:
 tlv      : Type 127 Length 7 OUI 00-18-b1 Subtype 1
 version  : Max 1 Oper 1
 cna      : Req 1 Oper 1 Res 0x00
 switch   : Cap 1 Oper 1 Res 0x00
```

UFP Capability Discovery TLV information includes the following:

- TLV type and length
- IBM Organizationally Unique Identifier
- TLV Subtype
- Max Version and Operation Version
- UFP CNA Status which include UFP Request and UFP Operation
- UFP Switch Status which includes UFP Capable and UFP Operation

```
show ufp transmit cdcv port <port_no.>
```

Command mode: All

```
CDCP TLV Transmitted on port INT2:
  tlv      : Type 127 Length 23 OUI 00-80-c2 Subtype 14
  local    : Role 0 SComp 1 Channel Cap 5
  SCID 1   : SVID 1
  SCID 2   : SVID 4002
  SCID 3   : SVID 4003
  SCID 4   : SVID 0
  SCID 5   : SVID 0
```

UFP Channel Discovery and Configuration Protocol TLV includes the following:

- TLV type and length
- IBM Organizationally Unique Identifier
- TLV Subtype
- Role bit
- S-Component bit
- Channel Cap
- Corresponding index/SVID pairs

Converged Enhanced Ethernet Information

[Table 72](#) describes the Converged Enhanced Ethernet (CEE) information options.

Table 72. CEE Information Options

Command Syntax and Usage
<pre>show cee information</pre> <p>Displays all CEE information</p> <p>Command mode: All</p>

DCBX Information

[Table 73](#) describes the Data Center Bridging Capability Exchange (DCBX) protocol information options.

Table 73. DCBX Information Options

Command Syntax and Usage
<pre>show cee information dcbx port <port alias or number> control</pre> <p>Displays information about the DCBX Control state machine for the selected port. For details, see page 126.</p> <p>Command mode: All</p>
<pre>show cee information dcbx port <port alias or number> feature</pre> <p>Displays information about the DCBX Feature state machine for the selected port. For details, see page 127.</p> <p>Command mode: All</p>
<pre>show cee information dcbx port <port alias or number> ets</pre> <p>Displays information about the DCBX ETS state machine. For details, see page 127.</p> <p>Command mode: All</p>
<pre>show cee information dcbx port <port alias or number> pfc</pre> <p>Displays information about the DCBX PFC state machine. For details, see page 129.</p> <p>Command mode: All</p>
<pre>show cee information dcbx port <port alias or number> app_proto</pre> <p>Displays information about the DCBX Application Protocol state machine on the selected port. For details, see page 130.</p> <p>Command mode: All</p>
<pre>show cee information dcbx port <port alias or number></pre> <p>Displays all DCBX information.</p> <p>Command mode: All</p>

DCBX Control Information

The following command displays DCBX control information:

```
show cee information dcbx port <port alias or number> control
```

Command mode: All

```
DCBX Port Control State-machine Info
=====
Alias Port OperStatus OperVer MaxVer SeqNo AckNo
-----
INTA1 1    enabled    0      0      0      0
INTA2 2    enabled    0      0      4      2
INTA3 3    enabled    0      0      0      0
INTA4 4    enabled    0      0      1      1
...
```

DCBX control information includes the following:

- Port alias and number
- DCBX status (enabled or disabled)
- Operating version negotiated with the peer device
- Maximum operating version supported by the system
- Sequence number that changes each time a DCBX parameter in one or more DCB feature TLVs changes
- Sequence number of the most recent DCB feature TLV that has been acknowledged

DCBX Feature Information

The following command displays DCBX feature information:

```
show cee information dcbx port <port alias or number> feature
```

Command mode: All

DCBX Port Feature State-machine Info												
Alias	Port	Type	AdmState	Will	Advrt	OpVer	MxVer	PrWill	SeqNo	Err	OperMode	Syncd
INTA2	2	ETS	enabled	No	Yes	0	0	Yes	1	No	enabled	Yes
INTA2	2	PFC	enabled	No	Yes	0	0	Yes	1	No	enabled	Yes
INTA2	2	AppProt	disabled	No	Yes	0	0	Yes	1	No	disabled	Yes
...												

The following table describes the DCBX feature information.

Table 74. DCBX Feature Information Fields

Parameter	Description
Alias	Displays each port's alias.
Port	Displays each port's number.
Type	Feature type
AdmState	Feature status (Enabled or Disabled)
Will	Willing flag status (Yes/True or No/Untrue)
Advrt	Advertisement flag status (Yes/True or No/Untrue)
OpVer	Operating version negotiated with the peer device
MxVer	Maximum operating version supported by the system
PrWill	Peer's Willing flag status (Yes/True or No/Untrue)
SeqNo	Sequence number that changes each time a DCBX parameter in one or more DCB feature TLVs changes
Err	Error condition flag (Yes or No). Yes indicates that an error occurred during the exchange of configuration data with the peer.
OperMode	Operating status negotiated with the peer device (enabled or disabled)
Syncd	Synchronization status between this port and the peer (Yes or No)

DCBX ETS Information

The following command displays DCBX ETS information:

```
show cee information dcbx port <port alias or number> ets
```

Command mode: All

```

DCBX Port Priority Group - Priority Allocation Table
=====
Alias  Port  Priority  PgIdDes  PgIdOper  PgIdPeer
-----
INTA2  2    0        PGID0    PGID0     PGID0
INTA2  2    1        PGID0    PGID0     PGID0
INTA2  2    2        PGID0    PGID0     PGID0
INTA2  2    3        PGID1    PGID1     PGID1
INTA2  2    4        PGID2    PGID2     PGID0
INTA2  2    5        PGID2    PGID2     PGID0
INTA2  2    6        PGID2    PGID2     PGID0
INTA2  2    7        PGID2    PGID2     PGID0

DCBX Port Priority Group - Bandwidth Allocation Table
=====
Alias  Port  PrioGrp  BwDes  BwOper  BwPeer
-----
INTA2  2    0        10    10     50
INTA2  2    1        50    50     50
INTA2  2    2        40    40     0

```

The following table describes the DCBX ETS information.

Table 75. DCBX Feature Information Fields

Parameter	Description
DCBX Port Priority Group - Priority Allocation Table	
Alias	Displays each port's alias
Port	Displays each port's number
PgldDes	Priority Group ID configured on this switch
PgldOper	Priority Group negotiated with the peer (operating Priority Group).
PgldPeer	Priority Group ID configured on the peer
DCBX Port Priority Group - Bandwidth Allocation Table	
BwDes	Bandwidth allocation configured on this switch
BwOper	Bandwidth allocation negotiated with the peer (operating bandwidth)
BwPeer	Bandwidth allocation configured on the peer

DCBX PFC Information

The following command displays DCBX Priority Flow Control (PFC) information:

```
show cee information dcbx port <port alias or number> pfc
```

Command mode: All

DCBX Port Priority Flow Control Table					
=====					
Alias	Port	Priority	EnableDesr	EnableOper	EnablePeer

INTA2	2	0	disabled	disabled	disabled
INTA2	2	1	disabled	disabled	disabled
INTA2	2	2	disabled	disabled	disabled
INTA2	2	3	enabled	enabled	enabled
INTA2	2	4	disabled	disabled	disabled
INTA2	2	5	disabled	disabled	disabled
INTA2	2	6	disabled	disabled	disabled
INTA2	2	7	disabled	disabled	disabled

DCBX PFC information includes the following:

- Port alias and number
- 802.1p value
- **EnableDesr:** Status configured on this switch
- **EnableOper:** Status negotiated with the peer (operating status)
- **EnablePeer:** Status configured on the peer

DCBX Application Protocol Information

The following command displays DCBX Application Protocol information:

```
show cee information dcbx port <port alias or number> app-PROTO
```

Command mode: All

```

DCBX Application Protocol Table
=====

FCoE Priority Information
=====
Protocol ID           : 0x8906
Selector Field       : 0
Organizationally Unique ID: 0x1b21

Alias  Port  Priority  EnableDesr  EnableOper  EnablePeer
-----
INTA2  2    0        disabled   disabled    disabled
INTA2  2    1        disabled   disabled    disabled
INTA2  2    2        disabled   disabled    disabled
INTA2  2    3        enabled    disabled    enabled
INTA2  2    4        disabled   disabled    disabled
INTA2  2    5        disabled   disabled    disabled
INTA2  2    6        disabled   disabled    disabled
INTA2  2    7        disabled   disabled    disabled

FIP Snooping Priority Information
=====
Protocol ID           : 0x8914
Selector Field       : 0
Organizationally Unique ID: 0x1b21

Alias  Port  Priority  EnableDesr  EnableOper  EnablePeer
-----
INTA2  2    0        disabled   disabled    disabled
INTA2  2    1        disabled   disabled    disabled
INTA2  2    2        disabled   disabled    disabled
INTA2  2    3        enabled    disabled    disabled
INTA2  2    4        disabled   disabled    disabled
INTA2  2    5        disabled   disabled    disabled
INTA2  2    6        disabled   disabled    disabled
INTA2  2    7        disabled   disabled    disabled

```

The following table describes the DCBX Application Protocol information.

Table 76. DCBX Application Protocol Information Fields

Parameter	Description
Protocol ID	Identifies the supported Application Protocol.
Selector Field	Specifies the Application Protocol type, as follows: <ul style="list-style-type: none"> – 0 = Ethernet Type – 1 = TCP socket ID
Organizationally Unique ID	DCBX TLV identifier

Table 76. DCBX Application Protocol Information Fields (continued)

Parameter	Description
Alias	Port alias
Port	Port number
Priority	802.1p value
EnableDesr	Status configured on this switch
EnableOper	Status negotiated with the peer (operating status)
EnablePeer	Status configured on the peer

ETS Information

Table 77 describes the Enhanced Transmission Selection (ETS) information options

Table 77. ETS Information Options

Command Syntax and Usage
<pre>show cee global ets information</pre> <p>Displays global ETS information.</p> <p>Command mode: All</p>

The following command displays ETS information:

```
show cee global ets information
```

Command mode: All

<pre>Global ETS information: Number of COSq: 8 Mapping of 802.1p Priority to Priority Groups: Priority PGID COSq ----- ---- ---- 0 0 0 1 0 0 2 0 0 3 1 1 4 2 2 5 2 2 6 2 2 7 2 2 Bandwidth Allocation to Priority Groups: PGID PG% Description ---- --- - 0 10 1 50 2 40</pre>

Enhanced Transmission Selection (ETS) information includes the following:

- Number of Class of Service queues (COSq) configured
- 802.1p mapping to Priority Groups and Class of Service queues
- Bandwidth allocated to each Priority Group

PFC Information

[Table 78](#) describes the Priority Flow Control (PFC) information options.

Table 78. PFC Information Options

Command Syntax and Usage
<pre>show cee port <port alias or number> pfc information</pre> <p>Displays PFC information.</p>

The following command displays PFC information for a port:

```
show cee port <port alias or number> pfc information
```

Command mode: All

Global PFC Information:		
PFC - ON		
Priority	State	Description
-----	-----	-----
0	Dis	
1	Dis	
2	Dis	
3	Ena	
4	Dis	
5	Dis	
6	Dis	
7	Dis	

State - indicates whether PFC is Enabled/Disabled on a particular priority		

FCoE Information

[Table 79](#) describes the Fibre Channel over Ethernet (FCoE) information options.

Table 79. FCoE Information Options

Command Syntax and Usage
<pre>show fcoe information</pre> <p>Displays all current FCoE information.</p> <p>Command mode: All</p>

FIP Snooping Information

[Table 80](#) describes the Fibre Channel Initialization Protocol (FIP) Snooping information options

Table 80. FIP Snooping Information Options

Command Syntax and Usage
<pre>show fcoe fips port <port alias or number> information</pre> <p>Displays FIP Snooping (FIPS) information for the selected port, including a list of current FIPS ACLs.</p> <p>Command mode: All</p>
<pre>show fcoe fips fcf</pre> <p>Displays FCF information for all FCFs learned.</p> <p>Command mode: All</p>
<pre>show fcoe fips fcoe</pre> <p>Displays FCoE connections established on the switch.</p> <p>Command mode: All</p>
<pre>show fcoe fips vlans</pre> <p>Displays VLAN information.</p> <p>Command mode: All</p>
<pre>show fcoe fips information</pre> <p>Displays FIP Snooping information for all ports.</p> <p>Command mode: All</p>

The following command displays FIP Snooping information for the selected port:

```
show fcoe fips port <port alias or number> information
```

Command mode: All

```
FIP Snooping on port INTA2:
This port has been configured to automatically detect FCF.
It has currently detected to have 0 FCF connecting to it.
FIPS ACLs configured on this port:
SMAC 00:c0:dd:13:9b:6f, action deny.
SMAC 00:c0:dd:13:9b:70, action deny.
SMAC 00:c0:dd:13:9b:6d, action deny.
SMAC 00:c0:dd:13:9b:6e, action deny.
DMAC 00:c0:dd:13:9b:6f, ethertype 0x8914, action permit.
DMAC 00:c0:dd:13:9b:70, ethertype 0x8914, action permit.
DMAC 00:c0:dd:13:9b:6d, ethertype 0x8914, action permit.
DMAC 00:c0:dd:13:9b:6e, ethertype 0x8914, action permit.
SMAC 0e:fc:00:01:0a:00, DMAC 00:c0:dd:13:9b:6d, ethertype 0x8906, vlan 1002, action
permit.
DMAC 01:10:18:01:00:01, Ethertype 0x8914, action permit.
DMAC 01:10:18:01:00:02, Ethertype 0x8914, action permit.
Ethertype 0x8914, action deny.
Ethertype 0x8906, action deny.
SMAC 0e:fc:00:00:00:00, SMAC mask ff:ff:ff:00:00:00, action deny.
```

FIP Snooping port information includes the following:

- Fibre Channel Forwarding (FCF) mode
- Number of FCF links connected to the port
- List of FIP Snooping ACLs assigned to the port

Fibre Channel Information

These commands allow you to display Fibre Channel information.

Table 81. Fibre Channel Information Commands

Command Syntax and Usage
<pre>show flogi database [<switch_number>]</pre> <p>Displays fabric login database information. For details, see page 137.</p> <p>Command mode: All</p>
<pre>show fcalias [<switch_number>]</pre> <p>Displays the current FC alias - PWWN (port World Wide Name) mapping.</p> <p>Command mode: All</p>
<pre>show fcdomain [<switch_number>]</pre> <p>Displays the current configuration of FC domains.</p> <p>Command mode: All</p>
<pre>show fcns database [<switch_number>]</pre> <p>Displays FC name server database information. For details, see page 138.</p> <p>Command mode: All</p>

Table 81. Fibre Channel Information Commands

Command Syntax and Usage
<p><code>show fdmi database [<switch_number>]</code> Displays fibre channel management interface database information. Command mode: All</p>
<p><code>show fcs database [<switch_number>]</code> Displays fabric configuration status database information. For details, see page 138. Command mode: All</p>
<p><code>show fcoe database [<switch_number>]</code> Displays Fibre Channel over Ethernet database information. Command mode: All</p>
<p><code>show fcf [<switch_number>]</code> Displays Fibre Channel forwarding information. For details, see page 138. Command mode: All</p>
<p><code>show npv status [<switch_number>]</code> Displays N_Port Virtualization information. Command mode: All</p>
<p><code>show npv flogi-table [<switch_number>]</code> Displays the contents of the NPV fabric login table. Command mode: All</p>
<p><code>show npv traffic-map [<switch_number>]</code> Displays NPV source-destination traffic mapping. For details, see page 139. Command mode: All</p>
<p><code>show zone [<switch_number>]</code> Lists all FC zones. Command mode: All</p>
<p><code>show zone status [<switch_number>]</code> Displays FC zone status information. For details, see page 139. Command mode: All</p>
<p><code>show zone name <zone name> [<switch_number>]</code> Displays information for the specified FC zone. Command mode: All</p>
<p><code>show zoneset [<switch_number>]</code> Lists all FC zonesets. Command mode: All</p>

Table 81. Fibre Channel Information Commands

Command Syntax and Usage	
show zoneset name <zoneset name> [<switch_number>]	Displays information for the specified FC zoneset. Command mode: All
show zoneset active [<switch_number>]	Displays the currently active FC zoneset. Command mode: All
show interface fc information [<switch_number>]	Displays FC port information. For details, see page 140 . Command mode: All
show interface fc port <port no.> [<switch_number>]	Displays FC information for the specified ports. Command mode: All
show topology [<switch_number>]	Displays port and corresponding node information for each switch member of the fabric or only for a specific switch member. For details, see page 141 . Command mode: All
show steering [<switch_number>]	Displays frame steering information for each switch member of the fabric or only for a specific switch member. Command mode: All
show fabric	Display the FC fabric information. Command mode: All
show lsdb	Display the link state db information of the FC fabric. Command mode: All

Fabric Login Database Information

The following command displays a list of the storage devices present in the FC fabric login database:

```
show flogi database
```

Command mode: All

Port	FCID	Port-WWN	Node-WWN
EXT1	010c00	20:00:00:11:0d:64:f5:00	20:00:00:11:0d:64:f5:00
EXT2	010c01	20:01:00:11:0d:64:f4:00	20:01:00:11:0d:64:f4:00
Total number of entries = 2			

Fibre Channel Name Server Database Information

The following command displays information about the FC name server database:

```
show fcns database
```

Command mode: All

```
-----  
FCID      TYPE  PWWN  
-----  
010100    N    20:02:00:11:0d:8a:10:00  
010400    N    20:3a:00:80:e5:2d:1a:30  
010c00    N    10:00:00:00:27:1a:13:f0  
010c01    N    10:00:00:00:27:1a:13:f7  
010c02    N    10:00:00:00:27:1f:61:5d  
010c03    N    10:00:00:00:27:1f:61:3f  
010c04    N    10:00:00:00:27:1f:61:44  
010c05    N    10:00:00:00:27:1f:61:34  
010c06    N    10:00:00:00:27:1f:61:23  
010c07    N    10:00:00:00:27:1f:8e:18  
...  
01140d    N    10:00:00:00:27:1f:61:4a  
  
Total number of entries = 72
```

Fabric Configuration Status Database Information

The following command displays information about the fabric configuration:

```
show fcs database
```

Command mode: All

```
Fabric Name      : 10:00:74:99:75:22:48:00  
Switch Domain Id : 1  
Switch Mgmt Id   : 010000  
Switch WWN       : 10:00:74:99:75:22:48:00  
Switch Ports:  
  
-----  
Port      PWWN  
-----  
55      20:02:74:99:75:22:48:00  
63      00:00:00:00:00:00:00:00  
64      00:00:00:00:00:00:00:00
```

Fibre Channel Forwarding Information

The following command displays information about Fibre Channel forwarding:

```
show fcf
```

Command mode: All

```
=====
FCF:1 in VLAN: 1002   NPV-Gw
FC-MAP      : 0x0efc00
Priority    : 128
FKA-Adv    : 8

FC Port     : 55 60 63 64
=====
FCF:2 in VLAN: 1003   NPV-Gw
FC-MAP      : 0x0efc01
Priority    : 128
FKA-Adv    : 8

FC Port     : 56 59
=====
FCF:3 in VLAN: 1004   Fabric
FC-MAP      : 0x0efc02
Priority    : 128
FKA-Adv    : 8

FC Port     : 53 54 57 58 61 62
```

NPV Traffic Information

The following command displays information about NPV source-destination traffic mapping:

```
show npv traffic-mapping
```

Command mode: All

VLAN	Source Ports	NP-Uplink Dest Ports
1002		55,60,63,64
1003		56,59

Zone Status Information

The following command displays status information about FC zones:

```
show zone status
```

Command mode: All

```
Default-Zone      : Permit

FC Zoning Limits :--
MAX ZONES per ZONESET : 64
MAX MEMBERS per ZONE  : 20

MAX ZONESETS      : 4
MAX ZONES         : 200
MAX ALIASES       : 200
MAX MEMBERS       : 1000
```

FC Port Information

The following command displays information about FC ports:

```
show interface fc information
```

Command mode: All

Alias	Port	Admin State	Oper State	Login Status	Config Type	Running Type	Link Status	Link Speed
EXT11	53	Online	Online	LoggedIn	F	F	Active	4Gb/s
EXT12	54	Online	Offline	NotLoggedIn	F	F	Active	4Gb/s
EXT13	55	Online	Offline	NotLoggedIn	F	Unknown	Inactive	Unknown
EXT14	56	Online	Offline	NotLoggedIn	F	Unknown	Inactive	Unknown
EXT15	57	Down	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown
EXT16	58	Down	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown
EXT17	59	Down	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown
EXT18	60	Down	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown
EXT19	61	Down	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown
EXT20	62	Down	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown
EXT21	63	Down	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown
EXT22	64	Online	Downed	NotLoggedIn	Eth	Eth	Inactive	Unknown

Fibre Channel port information includes the following:

Table 82. Fibre Channel Port Information Descriptions

Parameter	Description
Alias	Port alias
Port	Port number
Admin State	Configured state of the port (online, offline, or down)
Oper State	Current operational state of the port (online, offline, or downed)
Login Status	Login status of the port on the FC fabric (LoggedIn or NotLoggedIn)
Config Type	Configured FC port type, as follows: <ul style="list-style-type: none"> – E (Expansion port) **not supported – F (Fabric port) – Eth (Ethernet port)
Running Type	Current operational FC port type, as follows: <ul style="list-style-type: none"> – E (Expansion port) **not supported – F (Fabric port) – Eth (Ethernet port) – Unknown
Link Status	Current status of the port link (Active or Inactive)
Link Speed	Current operational link speed.

The following command displays information specific FC ports:

```
show interface fc port <port no.>
```

Command mode: All

```
Port Number: EXT11
-----
AdminState           Online
ConfigType          F
EPortIsolationReason NotApplicable
LinkSpeed            Auto
LinkState            Inactive
LoginStatus          NotLoggedIn
OperationalState     Offline
RunningType          Unkn
Port Number: EXT12
-----
AdminState           Online
ConfigType          F
EPortIsolationReason NotApplicable
LinkSpeed            Auto
LinkState            Inactive
LoginStatus          NotLoggedIn
OperationalState     Offline
RunningType          Unkn
Port Number: EXT13
-----
AdminState           Online
ConfigType          Eth
EPortIsolationReason NotApplicable
LinkSpeed            10000
LinkState            Inactive
LoginStatus          NotLoggedIn
OperationalState     Offline
RunningType          Eth
```

Topology Information

The following command displays a list of the ports and corresponding nodes for each switch member of the fabric:

```
show topology
```

Command mode: All

```
Router(config)#show topology

Information for Switch Unit 1:
(This is the local swunit)
Switch Domain Id   : 1
Switch Mgmt Id     : 010000
Fabric Name        : 10:00:6c:ae:8b:d6:11:c1
Switch WWN         : 10:00:6c:ae:8b:d6:11:c1
Switch Ports Online:
-----
Port      LocalPortWWN          RemoteNodeWWN
-----
EXT1      20:00:00:11:0d:64:f5:00  20:00:00:11:0d:64:f5:00
EXT2      20:01:00:11:0d:64:f4:00  20:01:00:11:0d:64:f4:00
-----
```

Information Dump

The following command dumps switch information:

```
show information-dump
```

Command mode: All

Use the dump command to dump all switch information available (10K or more, depending on your configuration). This data is useful for tuning and debugging switch performance.

If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump commands.

Chapter 3. Statistics Commands

You can use the Statistics Commands to view switch performance statistics in both the user and administrator command modes. This chapter discusses how to use the command line interface to display switch statistics.

Table 83. Statistics Commands

Command Syntax and Usage
<pre>show layer3 counters</pre> <p>Command mode: All Displays Layer 3 statistics.</p>
<pre>show snmp-server counters</pre> <p>Command mode: All Displays SNMP statistics. See page 228 for sample output.</p>
<pre>show ntp counters</pre> <p>Displays Network Time Protocol (NTP) Statistics. Command mode: All See page 232 for a sample output and a description of NTP Statistics.</p>
<pre>show ip slp counter</pre> <p>Displays Service Location Protocol packet counters. See page 233 for a sample output. Command mode: All</p>
<pre>show counters</pre> <p>Dumps all switch statistics. Use this command to gather data for tuning and debugging switch performance. If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump command. Command mode: All For details, see page 235.</p>

Port Statistics

These commands display traffic statistics on a port-by-port basis. Traffic statistics include SNMP Management Information Base (MIB) objects.

Table 84. Port Statistics Commands

Command Syntax and Usage
<pre>show interface port <port alias or number> dot1x counters</pre> <p>Displays IEEE 802.1X statistics for the port. See page 146 for sample output.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> bridging-counters</pre> <p>Displays bridging (“dot1”) statistics for the port. See page 150 for sample output.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> ethernet-counters</pre> <p>Displays Ethernet (“dot3”) statistics for the port. See page 151 for sample output.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> interface-counters</pre> <p>Displays interface statistics for the port. See page 154 for sample output.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> ip-counters</pre> <p>Displays IP statistics for the port. See page 157 for sample output.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> link-counters</pre> <p>Displays link statistics for the port. See page 157 for sample output.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> rmon-counters</pre> <p>Displays Remote Monitoring (RMON) statistics for the port. See page 158 for sample output.</p> <p>Command mode: All</p>
<pre>show interface port <port alias or number> oam counters</pre> <p>Displays Operation, Administrative, and Maintenance (OAM) protocol statistics for the port.</p> <p>Command mode: All</p>

Table 84. Port Statistics Commands

Command Syntax and Usage
<pre>clear interface port <port alias or number> counters</pre> <p>Clears all statistics for the port.</p> <p>Command mode: All except User EXEC</p>
<pre>clear counters</pre> <p>Clears statistics for all ports.</p> <p>Command mode: All except User EXEC</p>

802.1X Authenticator Statistics

Use the following command to display the 802.1X authenticator statistics of the selected port:

```
show interface port <port alias or number> dot1x counters
```

Command mode: All

Authenticator Statistics:	
eapolFramesRx	= 925
eapolFramesTx	= 3201
eapolStartFramesRx	= 2
eapolLogoffFramesRx	= 0
eapolRespIdFramesRx	= 463
eapolRespFramesRx	= 460
eapolReqIdFramesTx	= 1820
eapolReqFramesTx	= 1381
invalidEapolFramesRx	= 0
eapLengthErrorFramesRx	= 0
lastEapolFrameVersion	= 1
lastEapolFrameSource	= 00:01:02:45:ac:51

Table 85. 802.1X Authenticator Statistics of a Port

Statistics	Description
eapolFramesRx	Total number of EAPOL frames received
eapolFramesTx	Total number of EAPOL frames transmitted
eapolStartFramesRx	Total number of EAPOL Start frames received
eapolLogoffFramesRx	Total number of EAPOL Logoff frames received
eapolRespIdFramesRx	Total number of EAPOL Response Identity frames received
eapolRespFramesRx	Total number of Response frames received
eapolReqIdFramesTx	Total number of Request Identity frames transmitted
eapolReqFramesTx	Total number of Request frames transmitted
invalidEapolFramesRx	Total number of invalid EAPOL frames received
eapLengthErrorFramesRx	Total number of EAP length error frames received
lastEapolFrameVersion	The protocol version number carried in the most recently received EAPOL frame.
lastEapolFrameSource	The source MAC address carried in the most recently received EAPOL frame.

802.1X Authenticator Diagnostics

Use the following command to display the 802.1X authenticator diagnostics of the selected port:

```
show interface port <port alias or number> dot1x counters
```

Command mode: All

Authenticator Diagnostics:	
authEntersConnecting	= 1820
authEapLogoffsWhileConnecting	= 0
authEntersAuthenticating	= 463
authSuccessesWhileAuthenticating	= 5
authTimeoutsWhileAuthenticating	= 0
authFailWhileAuthenticating	= 458
authReauthsWhileAuthenticating	= 0
authEapStartsWhileAuthenticating	= 0
authEapLogoffWhileAuthenticating	= 0
authReauthsWhileAuthenticated	= 3
authEapStartsWhileAuthenticated	= 0
authEapLogoffWhileAuthenticated	= 0
backendResponses	= 923
backendAccessChallenges	= 460
backendOtherRequestsToSupplicant	= 460
backendNonNakResponsesFromSupplicant	= 460
backendAuthSuccesses	= 5
backendAuthFails	= 458

Table 86. 802.1X Authenticator Diagnostics of a Port

Statistics	Description
authEntersConnecting	Total number of times that the state machine transitions to the CONNECTING state from any other state.
authEapLogoffsWhileConnecting	Total number of times that the state machine transitions from CONNECTING to DISCONNECTED as a result of receiving an EAPOL-Logoff message.
authEntersAuthenticating	Total number of times that the state machine transitions from CONNECTING to AUTHENTICATING, as a result of an EAP-Response/Identity message being received from the Supplicant.
authSuccessesWhileAuthenticating	Total number of times that the state machine transitions from AUTHENTICATING to AUTHENTICATED, as a result of the Backend Authentication state machine indicating successful authentication of the Supplicant.
authTimeoutsWhileAuthenticating	Total number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of the Backend Authentication state machine indicating authentication timeout.

Table 86. 802.1X Authenticator Diagnostics of a Port (continued)

Statistics	Description
authFailWhile Authenticating	Total number of times that the state machine transitions from AUTHENTICATING to HELD, as a result of the Backend Authentication state machine indicating authentication failure.
authReauthsWhile Authenticating	Total number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of a re-authentication request
authEapStartsWhile Authenticating	Total number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of an EAPOL-Start message being received from the Supplicant.
authEapLogoffWhile Authenticating	Total number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of an EAPOL-Logoff message being received from the Supplicant.
authReauthsWhile Authenticated	Total number of times that the state machine transitions from AUTHENTICATED to CONNECTING, as a result of a re-authentication request.
authEapStartsWhile Authenticated	Total number of times that the state machine transitions from AUTHENTICATED to CONNECTING, as a result of an EAPOL-Start message being received from the Supplicant.
authEapLogoffWhile Authenticated	Total number of times that the state machine transitions from AUTHENTICATED to DISCONNECTED, as a result of an EAPOL-Logoff message being received from the Supplicant.
backendResponses	Total number of times that the state machine sends an initial Access-Request packet to the Authentication server. Indicates that the Authenticator attempted communication with the Authentication Server.
backendAccessChallenges	Total number of times that the state machine receives an initial Access-Challenge packet from the Authentication server. Indicates that the Authentication Server has communication with the Authenticator.
backendOtherRequests ToSupplicant	Total number of times that the state machine sends an EAP-Request packet (other than an Identity, Notification, Failure, or Success message) to the Supplicant. Indicates that the Authenticator chose an EAP-method.

Table 86. 802.1X Authenticator Diagnostics of a Port (continued)

Statistics	Description
backendNonNak ResponsesFromSupplicant	Total number of times that the state machine receives a response from the Supplicant to an initial EAP-Request, and the response is something other than EAP-NAK. Indicates that the Supplicant can respond to the Authenticator.s chosen EAP-method.
backendAuthSuccesses	Total number of times that the state machine receives an Accept message from the Authentication Server. Indicates that the Supplicant has successfully authenticated to the Authentication Server.
backendAuthFails	Total number of times that the state machine receives a Reject message from the Authentication Server. Indicates that the Supplicant has not authenticated to the Authentication Server.

Bridging Statistics

Use the following command to display the bridging statistics of the selected port:

```
show interface port <port alias or number> bridging-counters
```

Command mode: All

Bridging statistics for port INT1:	
dot1PortInFrames:	63242584
dot1PortOutFrames:	63277826
dot1PortInDiscards:	0
dot1TpLearnedEntryDiscards:	0
dot1StpPortForwardTransitions:	0

Table 87. Bridging Statistics of a Port

Statistics	Description
dot1PortInFrames	The number of frames that have been received by this port from its segment. A frame received on the interface corresponding to this port is only counted by this object if and only if it is for a protocol being processed by the local bridging function, including bridge management frames.
dot1PortOutFrames	The number of frames that have been transmitted by this port to its segment. Note that a frame transmitted on the interface corresponding to this port is only counted by this object if and only if it is for a protocol being processed by the local bridging function, including bridge management frames.
dot1PortInDiscards	Count of valid frames received which were discarded (that is, filtered) by the Forwarding Process.
dot1TpLearnedEntry Discards	The total number of Forwarding Database entries, which have been or would have been learnt, but have been discarded due to a lack of space to store them in the Forwarding Database. If this counter is increasing, it indicates that the Forwarding Database is regularly becoming full (a condition which has unpleasant performance effects on the subnetwork). If this counter has a significant value but is not presently increasing, it indicates that the problem has been occurring but is not persistent.
dot1StpPortForward Transitions	The number of times this port has transitioned from the Learning state to the Forwarding state.

Ethernet Statistics

Use the following command to display the ethernet statistics of the selected port:

```
show interface port <port alias or number> ethernet-counters
```

Command mode: All

Ethernet statistics for port INT1:	
dot3StatsAlignmentErrors:	0
dot3StatsFCSErrors:	0
dot3StatsSingleCollisionFrames:	0
dot3StatsMultipleCollisionFrames:	0
dot3StatsLateCollisions:	0
dot3StatsExcessiveCollisions:	0
dot3StatsInternalMacTransmitErrors:	NA
dot3StatsFrameTooLongs:	0
dot3StatsInternalMacReceiveErrors:	0

Table 88. Ethernet Statistics for Port

Statistics	Description
dot3StatsAlignment Errors	<p>A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the Frame Check Sequence (FCS) check.</p> <p>The count represented by an instance of this object is incremented when the <code>alignmentError</code> status is returned by the MAC service to the Logical Link Control (LLC) (or other MAC user). Received frames for which multiple error conditions obtained are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.</p>
dot3StatsFCSErrors	<p>A count of frames received on a particular interface that are an integral number of octets in length but do not pass the Frame Check Sequence (FCS) check.</p> <p>The count represented by an instance of this object is incremented when the <code>frameCheckError</code> status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtained are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.</p>

Table 88. Ethernet Statistics for Port (continued)

Statistics	Description
dot3StatsSingleCollisionFrames	<p>A count of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.</p> <p>A frame that is counted by an instance of this object is also counted by the corresponding instance of either the <code>ifOutUcastPkts</code>, <code>ifOutMulticastPkts</code>, or <code>ifOutBroadcastPkts</code>, and is not counted by the corresponding instance of the <code>dot3StatsMultipleCollisionFrame</code> object.</p>
dot3StatsMultipleCollisionFrames	<p>A count of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.</p> <p>A frame that is counted by an instance of this object is also counted by the corresponding instance of either the <code>ifOutUcastPkts</code>, <code>ifOutMulticastPkts</code>, or <code>ifOutBroadcastPkts</code>, and is not counted by the corresponding instance of the <code>dot3StatsSingleCollisionFrames</code> object.</p>
dot3StatsLateCollisions	<p>The number of times that a collision is detected on a particular interface later than 512 bit-times into the transmission of a packet.</p> <p>Five hundred and twelve bit-times corresponds to 51.2 microseconds on a 10 Mbit/s system. A (late) collision included in a count represented by an instance of this object is also considered as a (generic) collision for purposes of other collision-related statistics.</p>
dot3StatsExcessiveCollisions	<p>A count of frames for which transmission on a particular interface fails due to excessive collisions.</p>
dot3StatsInternalMacTransmitErrors	<p>A count of frames for which transmission on a particular interface fails due to an internal MAC sub layer transmit error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the <code>dot3StatsLateCollisions</code> object, the <code>dot3StatsExcessiveCollisions</code> object, or the <code>dot3StatsCarrierSenseErrors</code> object.</p> <p>The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of transmission errors on a particular interface that are not otherwise counted.</p>

Table 88. Ethernet Statistics for Port (continued)

Statistics	Description
dot3StatsFrameTooLongs	<p>A count of frames received on a particular interface that exceed the maximum permitted frame size.</p> <p>The count represented by an instance of this object is incremented when the <code>frameTooLong</code> status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtained are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.</p>
dot3StatsInternalMac ReceiveErrors	<p>A count of frames for which reception on a particular interface fails due to an internal MAC sub layer receive error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the <code>dot3StatsFrameTooLongs</code> object, the <code>dot3StatsAlignmentErrors</code> object, or the <code>dot3StatsFCSErrors</code> object.</p> <p>The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of received errors on a particular interface that are not otherwise counted.</p>

Interface Statistics

Use the following command to display the interface statistics of the selected port:

```
show interface port <port alias or number> interface-counters
```

Command mode: All

Interface statistics for port EXT1:			
	ifHCIn Counters	ifHCOOut Counters	
Octets:	0	648329	
UcastPkts:	0	0	
BroadcastPkts:	0	271	
MulticastPkts:	0	7654	
FlowCtrlPkts:	0	0	
PriFlowCtrlPkts:	0	0	
Discards:	0	11	
Errors:	0	0	
Ingress Discard reasons:		Egress Discard reasons:	
VLAN Discards:	0	HOL-blocking Discards:	0
Filter Discards:	0	MMU Discards:	0
Policy Discards:	0	Cell Error Discards:	0
Non-Forwarding State:	0	MMU Aging Discards:	0
IBP/CBP Discards:	0	Other Discards:	11

Table 89. Interface Statistics for Port

Statistics	Description
ifInOctets	The total number of octets received on the interface, including framing characters.
ifInUcastPkts	The number of packets, delivered by this sub-layer to a higher sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer.
ifInBroadcastPkts	The number of packets, delivered by this sub-layer to a higher sub-layer, which were addressed to a broadcast address at this sub-layer.
ifInMulticastPkts	The total number of packets that higher-level protocols requested to be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
ifInFlowControlPkts	The total number of flow control pause packets received on the interface.
ifInDiscards	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being delivered to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space.

Table 89. Interface Statistics for Port (continued)

Statistics	Description
ifInErrors	For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being delivered to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol.
ifOutOctets	The total number of octets transmitted out of the interface, including framing characters.
ifOutUcastPkts	The total number of packets that higher-level protocols requested to be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
ifOutBroadcastPkts	The total number of packets that higher-level protocols requested to be transmitted, and which were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent. This object is a 64-bit version of <code>ifOutBroadcastPkts</code> .
ifOutMulticastPkts	The total number of packets that higher-level protocols requested to be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses. This object is a 64-bit version of <code>ifOutMulticastPkts</code> .
ifOutFlowControlPkts	The total number of flow control pause packets transmitted out of the interface.
ifOutDiscards	The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.
ifOutErrors	For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.
VLAN Discards	Discarded because the packet was tagged with a VLAN to which this port is not a member.
Filter Discards	Dropped by the Content Aware Engine (user-configured filter).
Policy Discards	Dropped due to policy setting. For example, due to a user-configured static entry.

Table 89. Interface Statistics for Port (continued)

Statistics	Description
Non-Forwarding State	Discarded because the ingress port is not in the forwarding state.
IBP/CBP Discards	Discarded because of Ingress Back Pressure (flow control), or because the Common Buffer Pool is full (for example, insufficient packet buffering).
HOL-blocking Discards	Discarded because of the Head Of Line (HOL) blocking mechanism. Low-priority packets are placed in a separate queue and can be discarded while applications or the TCP protocol determine whether a retransmission is necessary. HOL blocking forces transmission to stop until the overloaded egress port buffer can receive data again.
MMU Discards	Discarded because of the Memory Management Unit.
Cell Error Discards	
MMU Aging Discards	
Other Discards	Discarded packets not included in any category.
Empty Egress Portmap	Dropped due to an egress port bitmap of zero condition (no ports in the egress mask). This counter increments whenever the switching decision found that there was no port to send out.

Interface Protocol Statistics

Use the following command to display the interface protocol statistics of the selected port:

```
show interface port <port alias or number> ip-counters
```

Command mode: All

GEA IP statistics for port INT1:	
ipInReceives	: 0
ipInHeaderError:	0
ipInDiscards	: 0

Table 90. Interface Protocol Statistics

Statistics	Description
ipInReceives	The total number of input datagrams received from interfaces, including those received in error.
ipInHeaderErrors	The number of input datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this entity (the switch).
ipInDiscards	The number of input IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (for example, for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.

Link Statistics

Use the following command to display the link statistics of the selected port:

```
show interface port <port alias or number> link-counters
```

Command mode: All

Link statistics for port INT1:	
linkStateChange:	1

Table 91. Link Statistics

Statistics	Description
linkStateChange	The total number of link state changes.

RMON Statistics

Use the following command to display the Remote Monitoring (RMON) statistics of the selected port:

```
show interface port <port alias or number> rmon-counters
```

Command mode: All.

RMON statistics for port EXT2:	
etherStatsDropEvents:	NA
etherStatsOctets:	0
etherStatsPkts:	0
etherStatsBroadcastPkts:	0
etherStatsMulticastPkts:	0
etherStatsCRCAlignErrors:	0
etherStatsUndersizePkts:	0
etherStatsOversizePkts:	0
etherStatsFragments:	NA
etherStatsJabbers:	0
etherStatsCollisions:	0
etherStatsPkts64Octets:	0
etherStatsPkts65to127Octets:	0
etherStatsPkts128to255Octets:	0
etherStatsPkts256to511Octets:	0
etherStatsPkts512to1023Octets:	0
etherStatsPkts1024to1518Octets:	0

Table 92. RMON Statistics of a Port

Statistics	Description
etherStatsDropEvents	The total number of packets received that were dropped because of system resource constraints.
etherStatsOctets	The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets).
etherStatsPkts	The total number of packets (including bad packets, broadcast packets, and multicast packets) received.
etherStatsBroadcastPkts	The total number of good packets received that were directed to the broadcast address.
etherStatsMulticastPkts	The total number of good packets received that were directed to a multicast address.
etherStatsCRCAlignErrors	The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).

Table 92. RMON Statistics of a Port (continued)

Statistics	Description
etherStatsUndersizePkts	The total number of packets received that were less than 64 octets long (excluding framing bits but including FCS octets) and were otherwise well formed.
etherStatsOversizePkts	The total number of packets received that were longer than 1518 octets (excluding framing bits but including FCS octets) and were otherwise well formed.
etherStatsFragments	The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
etherStatsJabbers	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). Jabber is defined as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.
etherStatsCollisions	The best estimate of the total number of collisions on this Ethernet segment.
etherStatsPkts64Octets	The total number of packets (including bad packets) received that were less than or equal to 64 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts65to127 Octets	The total number of packets (including bad packets) received that were greater than 64 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts128to255 Octets	The total number of packets (including bad packets) received that were greater than 127 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts256to511 Octets	The total number of packets (including bad packets) received that were greater than 255 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts512to1023 Octets	The total number of packets (including bad packets) received that were greater than 511 octets in length (excluding framing bits but including FCS octets).
etherStatsPkts1024to1518 Octets	The total number of packets (including bad packets) received that were greater than 1023 octets in length (excluding framing bits but including FCS octets).

QoS Queue Statistics

Table 93. QoS Queue Statistics

Command Syntax and Usage
<pre>show interface port <port alias or number> egress-queue-counters [<0-7> drop]</pre> <p>Displays the total number of successfully transmitted or dropped packets and bytes for each QoS queue for the selected port.</p> <ul style="list-style-type: none"> – <0-7> displays statistics only for the specified queue – drop displays statistics only for the dropped packets and bytes <p>Command mode: All</p>
<pre>show interface port <port alias or number> egress-mcast-queue-counters [<8-11> drop]</pre> <p>Displays the total number of successfully transmitted or dropped packets and bytes for each multicast QoS queue for the selected port.</p> <ul style="list-style-type: none"> – <8-11> displays statistics only for the specified queue – drop displays statistics only for the dropped packets and bytes <p>Command mode: All</p>
<pre>show interface port <port alias or number> egress-queue-rate [<0-7> drop]</pre> <p>Displays the number of successfully transmitted or dropped packets and bytes per second for each QoS queue for the selected port.</p> <ul style="list-style-type: none"> – <0-7> displays statistics only for the specified queue – drop displays statistics only for the dropped packets and bytes <p>Command mode: All</p>
<pre>show interface port <port alias or number> egress-mcast-queue-rate [<8-11> drop]</pre> <p>Displays the number of successfully transmitted or dropped packets and bytes per second for each multicast QoS queue for the selected port.</p> <ul style="list-style-type: none"> – <8-11> displays statistics only for the specified queue – drop displays statistics only for the dropped packets and bytes <p>Command mode: All</p>

Use the following command to display the rate-based QoS queue statistics of the selected port:

```
show interface port <port alias or number> egress-queue-rate
```

Command mode: All.

QoS Rate for port INTA14:	
QoS Queue 0:	
Tx Packets:	5
Dropped Packets:	0
Tx Bytes:	363
Dropped Bytes:	0
QoS Queue 1:	
Tx Packets:	0
Dropped Packets:	0
Tx Bytes:	0
Dropped Bytes:	0
QoS Queue 2:	
Tx Packets:	0
Dropped Packets:	0
Tx Bytes:	0
Dropped Bytes:	0
QoS Queue 3:	
Tx Packets:	0
Dropped Packets:	0
Tx Bytes:	0
Dropped Bytes:	0
QoS Queue 4:	
Tx Packets:	0
Dropped Packets:	0
Tx Bytes:	0
Dropped Bytes:	0
QoS Queue 5:	
Tx Packets:	0
Dropped Packets:	0
Tx Bytes:	0
Dropped Bytes:	0
QoS Queue 6:	
Tx Packets:	0
Dropped Packets:	0
Tx Bytes:	0
Dropped Bytes:	0
QoS Queue 7:	
Tx Packets:	0
Dropped Packets:	0
Tx Bytes:	0
Dropped Bytes:	0

Table 94. QoS Queue Rate-Based Statistics of a Port

Statistics	Description
Tx Packets	Number of successfully transmitted packets per second for the QoS queue
Dropped Packets	Number of dropped packets per second for the QoS queue

Table 94. QoS Queue Rate-Based Statistics of a Port (continued)

Statistics	Description
Tx Bytes	Number of successfully transmitted bytes per second for the QoS queue
Dropped Bytes	Number of dropped bytes per second for the QoS queue

Use the following command to display the -based QoS queue statistics of the selected port:

```
show interface port <port alias or number> egress-queue-counters
```

Command mode: All.

```

QoS Rate for port 1:1:
QoS Queue 0:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0
QoS Queue 1:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0
QoS Queue 2:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0
QoS Queue 3:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0
QoS Queue 4:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0
QoS Queue 5:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0
QoS Queue 6:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0
QoS Queue 7:
  Tx Packets:                0
  Dropped Packets:          0
  Tx Bytes:                  0
  Dropped Bytes:            0

```

Table 95. QoS Queue Rate-Based Statistics of a Port

Statistics	Description
Tx Packets	Total number of successfully transmitted packets for the QoS queue
Dropped Packets	Total number of dropped packets for the QoS queue
Tx Bytes	Total number of successfully transmitted bytes for the QoS queue
Dropped Bytes	Total number of dropped bytes for the QoS queue

Trunk Group Statistics

Table 96. Trunk Group Statistics Commands

Command Syntax and Usage
<pre>show interface portchannel <trunk group number> interface-counters</pre> <p>Displays interface statistics for the trunk group.</p> <p>Command mode: All</p>
<pre>clear interface portchannel <trunk group number> counters</pre> <p>Clears all the statistics on the specified trunk group.</p> <p>Command mode: All except User EXEC</p>

Layer 2 Statistics

Table 97. Layer 2 Statistics Commands

Command Syntax and Usage
<pre>show interface port <port alias or number> lacp counters</pre> <p>Displays Link Aggregation Control Protocol (LACP) statistics. See page 166 for sample output.</p> <p>Command mode: All</p>
<pre>clear interface port <port alias or number> lacp counters</pre> <p>Clears Link Aggregation Control Protocol (LACP) statistics.</p> <p>Command mode: All except User EXEC</p>
<pre>show hotlinks counters</pre> <p>Displays Hot Links statistics. See page 167 for sample output.</p> <p>Command mode: All except User EXEC</p>
<pre>clear hotlinks</pre> <p>Clears all Hot Links statistics.</p> <p>Command mode: All except User EXEC</p>
<pre>show interface port <port alias or number> lldp counters</pre> <p>Displays LLDP statistics. See page 168 for sample output.</p> <p>Command mode: All except User EXEC</p>
<pre>show oam counters</pre> <p>Displays OAM statistics. See page 169 for sample output.</p> <p>Command mode: All except User EXEC</p>

LACP Statistics

Use the following command to display Link Aggregation Control Protocol (LACP) statistics:

```
show interface port <port alias or number> lacp counters
```

Command mode: All

Port EXT1:	

Valid LACPDUs received:	- 870
Valid Marker PDUs received:	- 0
Valid Marker Rsp PDUs received:	- 0
Unknown version/TLV type:	- 0
Illegal subtype received:	- 0
LACPDUs transmitted:	- 6031
Marker PDUs transmitted:	- 0
Marker Rsp PDUs transmitted:	- 0

Link Aggregation Control Protocol (LACP) statistics are described in the following table:

Table 98. LACP Statistics

Statistic	Description
Valid LACPDUs received	Total number of valid LACP data units received.
Valid Marker PDUs received	Total number of valid LACP marker data units received.
Valid Marker Rsp PDUs received	Total number of valid LACP marker response data units received.
Unknown version/TLV type	Total number of LACP data units with an unknown version or type, length, and value (TLV) received.
Illegal subtype received	Total number of LACP data units with an illegal subtype received.
LACPDUs transmitted	Total number of LACP data units transmitted.
Marker PDUs transmitted	Total number of LACP marker data units transmitted.
Marker Rsp PDUs transmitted	Total number of LACP marker response data units transmitted.

Hotlinks Statistics

Use the following command to display Hot Links statistics:

```
show hotlinks counters
```

Command mode: All

```
Hot Links Trigger Stats:

Trigger 1 statistics:
  Trigger Name: Trigger 1
  Master active:          0
  Backup active:         0
  FDB update:            0  failed: 0
```

The following table describes the Hotlinks statistics:

Table 99. Hotlinks Statistics

Statistic	Description
Master active	Total number of times the Master interface transitioned to the Active state.
Backup active	Total number of times the Backup interface transitioned to the Active state.
FDB update	Total number of FDB update requests sent.
failed	Total number of FDB update requests that failed.

LLDP Port Statistics

Use the following command to display LLDP statistics:

```
show interface port <port alias or number> lldp counters
```

Command mode: All

```
LLDP Port INT1 Statistics
-----
Frames Transmitted      : 0
Frames Received         : 0
Frames Received in Errors : 0
Frames Discarded        : 0
TLVs Unrecognized      : 0
Neighbors Aged Out     : 0
...
```

The following table describes the LLDP port statistics:

Table 100. LLDP Port Statistics

Statistic	Description
Frames Transmitted	Total number of LLDP frames transmitted.
Frames Received	Total number of LLDP frames received.
Frames Received in Errors	Total number of LLDP frames that had errors.
Frames Discarded	Total number of LLDP frames discarded.
TLVs Unrecognized	Total number of unrecognized TLV (Type, Length, and Value) fields received.
Neighbors Aged Out	Total number of neighbor devices that have had their LLDP information aged out.

OAM Statistics

Use the following command to display OAM statistics:

```
show oam counters
```

Command mode: All

```
OAM statistics on port INT1
-----
Information OAMPDU Tx :      0
Information OAMPDU Rx :      0
Unsupported OAMPDU Tx :      0
Unsupported OAMPDU Rx :      0

Local faults
-----
    0 Link fault records
    0 Critical events
    0 Dying gasps

Remote faults
-----
    0 Link fault records
    0 Critical events
    0 Dying gasps
```

OAM statistics include the following:

- Total number of OAM Protocol Data Units (OAMPDU) transmitted and received.
- Total number of unsupported OAM Protocol Data Units (OAMPDU) transmitted and received.
- Local faults detected
- Remote faults detected

vLAG Statistics

The following table describes the vLAG statistics commands:

Table 101. vLAG Statistics Options

Command Syntax and Usage
<pre>show vlag isl-statistics</pre> <p>Displays vLAG ISL statistics for the selected port. See page 170 for sample output.</p>
<pre>clear vlag statistics</pre> <p>Clears all vLAG statistics.</p>
<pre>show vlag statistics</pre> <p>Displays all vLAG statistics. See page 170 for sample output.</p>

vLAG ISL Statistics

Use the following command to display vLAG statistics:

```
show vlag isl-statistics
```

Command mode: All

	In Counter	Out Counter
Octets:	2755820	2288
Packets:	21044	26

ISL statistics include the total number of octets received/transmitted, and the total number of packets received/transmitted over the Inter-Switch Link (ISL).

vLAG Statistics

Use the following command to display vLAG statistics:

```
show vlag statistics
```

Command mode: All

vLAG PDU sent:			
Role Election:	0	System Info:	0
Peer Instance Enable:	0	Peer Instance Disable:	0
FDB Dynamic Add:	0	FDB Dynamic Del:	0
FDB Inactive Add:	0	FDB Inactive Del:	0
Health Check:	0	ISL Hello:	0
Other:	0	Unknown:	0
vLAG PDU received:			
Role Election:	0	System Info:	0
Peer Instance Enable:	0	Peer Instance Disable:	0
FDB Dynamic Add:	0	FDB Dynamic Del:	0
FDB Inactive Add:	0	FDB Inactive Del:	0
Health Check:	0	ISL Hello:	0
Other:	0	Unknown:	0
vLAG IGMP packets forwarded:			
IGMP Reports:	0		
IGMP Leaves:	0		

The following table describes the vLAG statistics:

Table 102. vLAG Statistics

Statistic	Description
Role Election	Total number of vLAG PDUs sent for role elections.
System Info	Total number of vLAG PDUs sent for getting system information.
Peer Instance Enable	Total number of vLAG PDUs sent for enabling peer instance.
Peer Instance Disable	Total number of vLAG PDUs sent for disabling peer instance.

Table 102. vLAG Statistics (continued)

Statistic	Description
FDB Dynamic Add	Total number of vLAG PDUs sent for addition of FDB dynamic entry.
FDB Dynamic Del	Total number of vLAG PDUs sent for deletion of FDB dynamic entry.
FDB Inactive Add	Total number of vLAG PDUs sent for addition of FDB inactive entry.
FDB Inactive Del	Total number of vLAG PDUs sent for deletion of FDB inactive entry.
Health Check	Total number of vLAG PDUs sent for health checks.
ISL Hello	Total number of vLAG PDUs sent for ISL hello.
Other	Total number of vLAG PDUs sent for other reasons.
Unknown	Total number of vLAG PDUs sent for unknown operations.
	vLAG IGMP packets forwarded
IGMP Reports	Total number of IGMP Reports forwarded over vLAG.
IGMP Leaves	Total number of IGMP Leave messages forwarded over vLAG.

Layer 3 Statistics

Table 103. Layer 3 Statistics Commands

Command Syntax and Usage
<pre>show ip counters</pre> <p>Displays IP statistics. See page 175 for sample output.</p> <p>Command mode: All</p>
<pre>clear ip counters</pre> <p>Clears IPv4 statistics. Use this command with caution as it deletes all the IPv4 statistics.</p> <p>Command mode: All except User EXEC</p>
<pre>show ip route counters</pre> <p>Displays route statistics. See page 183 for sample output.</p> <p>Command mode: All</p>
<pre>show ip arp counters</pre> <p>Displays Address Resolution Protocol (ARP) statistics. See page 184 for sample output.</p> <p>Command mode: All</p>
<pre>show ip dns counters</pre> <p>Displays Domain Name System (DNS) statistics. See page 185 for sample output.</p> <p>Command mode: All</p>
<pre>show ip icmp counters</pre> <p>Displays ICMP statistics. See page 186 for sample output.</p> <p>Command mode: All</p>
<pre>show ip tcp counters</pre> <p>Displays TCP statistics. See page 188 for sample output.</p> <p>Command mode: All</p>
<pre>show ip udp counters</pre> <p>Displays UDP statistics. See page 189 for sample output.</p> <p>Command mode: All</p>
<pre>show ip ospf counters</pre> <p>Displays OSPF statistics. See page 196 for sample output.</p> <p>Command mode: All</p>
<pre>show ipv6 ospf counters</pre> <p>Displays OSPFv3 statistics. See page 200 for sample output.</p> <p>Command mode: All</p>

Table 103. Layer 3 Statistics Commands (continued)

Command Syntax and Usage	
show ip igmp counters	Displays IGMP statistics. See page 190 for sample output. Command mode: All
show ip igmp vlan <vlan number> counters	Displays IGMP statistics for a specific VLAN. See page 190 for sample output. Command mode: All
show layer3 igmp-groups	Displays the total number of IGMP groups that are registered on the switch. Command mode: All
show layer3 ipmc-groups	Displays the total number of current IP multicast groups that are registered on the switch. Command mode: All
show ipv6 mld counters	Displays Multicast Listener Discovery (MLD) statistics. Command mode: All
show ip vrrp counters	When virtual routers are configured, you can display the protocol statistics for VRRP. See page 203 for sample output. Command mode: All
show ip pim counters	Displays PIM statistics for all configured PIM interfaces. See page 204 for sample output. Command mode: All
show ip pim mroute count	Displays statistics of various multicast entry types. Command mode: All
show ip pim interface <interface number> counters	Displays PIM statistics for the selected interface. Command mode: All
show ip rip counters	Displays Routing Information Protocol (RIP) statistics. See page 205 for sample output. Command mode: All
clear ip arp counters	Clears Address Resolution Protocol (ARP) statistics. Command mode: All except User EXEC

Table 103. Layer 3 Statistics Commands (continued)

Command Syntax and Usage
<pre>clear ip dns counters</pre> <p>Clears Domain Name System (DNS) statistics. Command mode: All except User EXEC</p>
<pre>clear ip icmp counters</pre> <p>Clears Internet Control Message Protocol (ICMP) statistics. Command mode: All except User EXEC</p>
<pre>clear ip tcp counters</pre> <p>Clears Transmission Control Protocol (TCP) statistics. Command mode: All except User EXEC</p>
<pre>clear ip udp counters</pre> <p>Clears User Datagram Protocol (UDP) statistics. Command mode: All except User EXEC</p>
<pre>clear ip igmp [<VLAN number>] counters</pre> <p>Clears IGMP statistics for all VLANs or for a specific VLAN. Command mode: All</p>
<pre>clear ip vrrp counters</pre> <p>Clears VRRP statistics. Command mode: All</p>
<pre>clear ip counters</pre> <p>Clears IP statistics. Use this command with caution as it will delete all the IP statistics. Command mode: All</p>
<pre>clear ip rip counters</pre> <p>Clears Routing Information Protocol (RIP) statistics. Command mode: All except User EXEC</p>
<pre>clear ip ospf counters</pre> <p>Clears Open Shortest Path First (OSPF) statistics. Command mode: All except User EXEC</p>
<pre>show layer3 counters</pre> <p>Dumps all Layer 3 statistics. Use this command to gather data for tuning and debugging switch performance. If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump command. Command mode: All</p>

IPv4 Statistics

The following command displays IPv4 statistics:

```
show ip counters
```

Command mode: All

Use the following command to clear IPv4 statistics:

```
clear ip counters
```

IP statistics:			
ipInReceives:	3115873	ipInHdrErrors:	1
ipInAddrErrors:	35447	ipForwDatagrams:	0
ipInUnknownProtos:	500504	ipInDiscards:	0
ipInDelivers:	2334166	ipOutRequests:	1010542
ipOutDiscards:	4	ipOutNoRoutes:	4
ipReasmReqds:	0	ipReasmOKs:	0
ipReasmFails:	0	ipFragOKs:	0
ipFragFails:	0	ipFragCreates:	0
ipRoutingDiscards:	0	ipDefaultTTL:	255
ipReasmTimeout:	5		

Table 104. IP Statistics

Statistic	Description
ipInReceives	The total number of input datagrams received from interfaces, including those received in error.
ipInHdrErrors	The number of input datagrams discarded due to errors in their IP headers, including bad checksums, version number mismatch, other format errors, time-to-live exceeded, errors discovered in processing their IP options, and so forth.
ipInAddrErrors	The number of input datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this entity (the switch). This count includes invalid addresses (for example, 0.0.0.0) and addresses of unsupported Classes (for example, Class E). For entities which are not IP Gateways and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.
ipForwDatagrams	The number of input datagrams for which this entity (the switch) was not their final IP destination, as a result of which an attempt was made to find a route to forward them to that final destination. In entities which do not act as IP Gateways, this counter will include only those packets, which were Source-Routed via this entity (the switch), and the Source-Route option processing was successful.

Table 104. IP Statistics (continued)

Statistic	Description
ipInUnknownProtos	The number of locally addressed datagrams received successfully but discarded because of an unknown or unsupported protocol.
ipInDiscards	The number of input IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (for example, for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.
ipInDelivers	The total number of input datagrams successfully delivered to IP user-protocols (including ICMP).
ipOutRequests	The total number of IP datagrams which local IP user-protocols (including ICMP) supplied to IP in requests for transmission. Note that this counter does not include any datagrams counted in ipForwDatagrams.
ipOutDiscards	The number of output IP datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded (for example, for lack of buffer space). Note that this counter would include datagrams counted in ipForwDatagrams if any such packets met this (discretionary) discard criterion.
ipOutNoRoutes	The number of IP datagrams discarded because no route could be found to transmit them to their destination. Note that this counter includes any packets counted in ipForwDatagrams, which meet this <i>no-route</i> criterion. Note that this includes any datagrams which a host cannot route because all of its default gateways are down.
ipReasmReqds	The number of IP fragments received which needed to be reassembled at this entity (the switch).
ipReasmOKs	The number of IP datagrams successfully re- assembled.
ipReasmFails	The number of failures detected by the IP re- assembly algorithm (for whatever reason: timed out, errors, and so forth). Note that this is not necessarily a count of discarded IP fragments since some algorithms (notably the algorithm in RFC 815) can lose track of the number of fragments by combining them as they are received.
ipFragOKs	The number of IP datagrams that have been successfully fragmented at this entity (the switch).
ipFragFails	The number of IP datagrams that have been discarded because they needed to be fragmented at this entity (the switch) but could not be, for example, because their Don't Fragment flag was set.

Table 104. IP Statistics (continued)

Statistic	Description
ipFragCreates	The number of IP datagram fragments that have been generated as a result of fragmentation at this entity (the switch).
ipRoutingDiscards	The number of routing entries, which were chosen to be discarded even though they are valid. One possible reason for discarding such an entry could be to free-up buffer space for other routing entries.
ipDefaultTTL	The default value inserted into the <code>Time-To-Live (TTL)</code> field of the IP header of datagrams originated at this entity (the switch), whenever a TTL value is not supplied by the transport layer protocol.
ipReasmTimeout	The maximum number of seconds, which received fragments are held while they are awaiting reassembly at this entity (the switch).

IPv6 Statistics

The following command displays IPv6 statistics:

```
show ipv6 counters
```

Command mode: All

Use the following command to clear IPv6 statistics:

```
clear ipv6 counters
```

```
IPv6 Statistics
*****
144 Rcvd          0   HdrErrors      0   TooBigErrors
0   AddrErrors    0   FwdDgrams      0   UnknownProtos
0   Discards      144 Delivers        130 OutRequests
0   OutDiscards   0   OutNoRoutes    0   ReasmReqds
0   ReasmOKs      0   ReasmFails     0
0   FragOKs       0   FragFails      0   FragCreates
7   RcvdMcastPkt 2   SentMcastPkts 0   TruncatedPkts
0   RcvdRedirects 0   SentRedirects

ICMP Statistics
*****
Received :
33 ICMPPkts      0 ICMPErrPkt      0 DestUnreach  0 TimeExcds
0   ParmProbs    0 PktTooBigMsg    9 ICMEchoReq   10 ICMEchoReps
0   RouterSols   0 RouterAdv      5 NeighSols    9 NeighAdv
0   Redirects    0 AdminProhib    0 ICMPBadCode

Sent
19 ICMPMsgs      0 ICMPErrMsgs    0 DstUnReach    0 TimeExcds
0   ParmProbs    0 PktTooBig      10 EchoReq      9 EchoReply
0   RouterSols   0 RouterAdv      11 NeighSols   5 NeighborAdv
0   RedirectMsgs 0 AdminProhibMsgs

UDP statistics
*****
Received :
0 UDPDgrams      0 UDPNoPorts      0 UDPErrPkts

Sent :
0 UDPDgrams
```

Table 105 describes the IPv6 statistics.

Table 105. IPv6 Statistics

Statistic	Description
Rcvd	Number of datagrams received from interfaces, including those received in error.
HdrErrors	Number of datagrams discarded due to errors in their IP headers, including bad checksums, version number mismatch, other format errors, time-to-live exceeded, errors discovered in processing their IP options, and so forth.
TooBigErrors	The number of input datagrams that could not be forwarded because their size exceeded the link MTU of outgoing interface.
AddrErrors	Number of datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this entity (the switch). This count includes invalid addresses. For entities which are not IP Gateways and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.
FwdDgrams	Number of input datagrams for which this entity (the switch) was not their final IP destination, as a result of which an attempt was made to find a route to forward them to that final destination. In entities which do not act as IP Gateways, this counter will include only those packets, which were Source-Routed via this entity (the switch), and the Source-Route option processing was successful.
UnknownProtos	Number of locally addressed datagrams received successfully but discarded because of an unknown or unsupported protocol.
Discards	Number of IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (for example, for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.
Delivers	Number of datagrams successfully delivered to IP user-protocols (including ICMP).
OutRequests	Number of IP datagrams which local IP user-protocols (including ICMP) supplied to IP in requests for transmission.
OutDiscards	Number of output IP datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded (for example, for lack of buffer space).
OutNoRoutes	Number of IP datagrams discarded because no route could be found to transmit them to their destination. Note that this includes any datagrams which a host cannot route because all of its default gateways are down.

Table 105. IPv6 Statistics (continued)

Statistic	Description
ReasmReqds	Number of IP fragments received which needed to be reassembled at this entity (the switch).
ReasmOKs	Number of IP datagrams successfully re- assembled.
ReasmFails	Number of failures detected by the IP re- assembly algorithm (for whatever reason: timed out, errors, and so forth). Note that this is not necessarily a count of discarded IP fragments since some algorithms (notably the algorithm in RFC 815) can lose track of the number of fragments by combining them as they are received.
FragOKs	Number of IP datagrams that have been successfully fragmented at this entity (the switch).
FragFails	Number of IP datagrams that have been discarded because they needed to be fragmented at this entity (the switch) but could not be, for example, because their Don't Fragment flag was set.
FragCreates	Number of IP datagram fragments that have been generated as a result of fragmentation at this entity (the switch).
RcvdMCastPkt	The number of multicast packets received by the interface.
SentMcastPkts	The number of multicast packets transmitted by the interface.
TruncatedPkts	The number of input datagrams discarded because datagram frame didn't carry enough data.
RcvdRedirects	The number of Redirect messages received by the interface.
SentRedirects	The number of Redirect messages sent.

The following table describes the IPv6 ICMP statistics.

Table 106. ICMP Statistics

Statistic	Description
Received	
ICMPPkts	Number of ICMP messages which the entity (the switch) received.
ICMPErrPkt	Number of ICMP messages which the entity (the switch) received but determined as having ICMP-specific errors (bad ICMP checksums, bad length, and so forth).
DestUnreach	Number of ICMP Destination Unreachable messages received.
TimeExcds	Number of ICMP Time Exceeded messages received.
ParmProbs	Number of ICMP Parameter Problem messages received.
PktTooBigMsg	The number of ICMP Packet Too Big messages received by the interface.
ICMPEchoReq	Number of ICMP Echo (request) messages received.
ICMPEchoReps	Number of ICMP Echo Reply messages received.
RouterSols	Number of Router Solicitation messages received by the switch.
RouterAdv	Number of Router Advertisements received by the switch.
NeighSols	Number of Neighbor Solicitations received by the switch.
NeighAdv	Number of Neighbor Advertisements received by the switch.
Redirects	Number of ICMP Redirect messages received.
AdminProhib	The number of ICMP destination unreachable/communication administratively prohibited messages received by the interface.
ICMPBadCode	The number of ICMP Parameter Problem messages received by the interface.
Sent	
ICMPMsgs	Number of ICMP messages which this entity (the switch) attempted to send.
ICMPErrMsgs	Number of ICMP messages which this entity (the switch) did not send due to problems discovered within ICMP such as a lack of buffer. This value should not include errors discovered outside the ICMP layer such as the inability of IP to route the resultant datagram. In some implementations there may be no types of errors that contribute to this counter's value.
DstUnReach	Number of ICMP Destination Unreachable messages sent.
TimeExcds	Number of ICMP Time Exceeded messages sent.

Table 106. ICMP Statistics (continued)

Statistic	Description
ParmProbs	Number of ICMP Parameter Problem messages sent.
PktTooBigs	The number of ICMP Packet Too Big messages sent by the interface.
EchoReq	Number of ICMP Echo (request) messages sent.
EchoReply	Number of ICMP Echo Reply messages sent.
RouterSols	Number of Router Solicitation messages sent by the switch.
RouterAdv	Number of Router Advertisements sent by the switch.
NeighSols	Number of Neighbor Solicitations sent by the switch.
NeighAdv	Number of Neighbor Advertisements sent by the switch.
RedirectMsgs	Number of ICMP Redirect messages sent. For a host, this object will always be zero, since hosts do not send redirects.
AdminProhibMsgs	Number of ICMP destination unreachable/communication administratively prohibited messages sent.

Table 107 describes the UDP statistics.

Table 107. UDP Statistics

Statistic	Description
Received	
UDPDgrams	Number of UDP datagrams received by the switch.
UDPNoPorts	Number of received UDP datagrams for which there was no application at the destination port.
UDPErrPkts	Number of received UDP datagrams that could not be delivered for reasons other than the lack of an application at the destination port.
Sent	
UDPDgrams	Number of UDP datagrams sent from this entity (the switch).

IPv4 Route Statistics

The following command displays IPv4 route statistics:

```
show ip route counters
```

Command mode: All

```

Route statistics:
-----
Current total outstanding routes      :          1
Highest number ever recorded         :          1
Current static routes                 :           0
Current RIP routes                   :           0
Current OSPF routes                   :           0
Current BGP routes                   :           0
Maximum supported routes              :         2048

ECMP statistics (active in ASIC):
-----
Maximum number of ECMP routes        :         2048
Maximum number of static ECMP routes :          128
Number of routes with ECMP paths     :           0
  
```

Table 108. Route Statistics

Statistics	Description
Current total outstanding routes	Total number of outstanding routes in the route table.
Highest number ever recorded	Highest number of routes ever recorded in the route table.
Current static routes	Total number of static routes in the route table.
Current RIP routes	Total number of Routing Information Protocol (RIP) routes in the route table.
Current OSPF routes	Total number of OSPF routes in the route table.
Current BGP routes	Total number of Border Gateway Protocol routes in the route table.
Maximum supported routes	Maximum number of routes that are supported.
Maximum number of ECMP routes	Maximum number of ECMP routes that are supported.
Maximum number of static ECMP routes	Maximum number of static ECMP routes that are supported.
Number of routes with ECMP paths	Current number of routes that contain ECMP paths.

IPv6 Route Statistics

The following command displays IPv6 route statistics:

```
show ipv6 route counters
```

Command mode: All

IPv6 Route statistics:			
ipv6RoutesCur:	4	ipv6RoutesHighWater:	6
ipv6RoutesMax:	1156		
ECMP statistics:			

Maximum number of ECMP routes	:	600	
Max ECMP paths allowed for one route	:	5	

Table 109. IPv6 Route Statistics

Statistics	Description
ipv6RoutesCur	Total number of outstanding routes in the route table.
ipv6RoutesHighWater	Highest number of routes ever recorded in the route table.
ipv6RoutesMax	Maximum number of routes that are supported.
Maximum number of ECMP routes	Maximum number of ECMP routes supported.
Max ECMP paths allowed for one route	Maximum number of ECMP paths supported for each route.

Use the `clear` option to delete all IPv6 route statistics.

ARP statistics

The following command displays Address Resolution Protocol statistics.

```
show ip arp counters
```

Command mode: All

ARP statistics:			
arpEntriesCur:	3	arpEntriesHighWater:	4
arpEntriesMax:	4095		

Table 110. ARP Statistics

Statistic	Description
arpEntriesCur	The total number of outstanding ARP entries in the ARP table.
arpEntriesHighWater	The highest number of ARP entries ever recorded in the ARP table.
arpEntriesMax	The maximum number of ARP entries that are supported.

DNS Statistics

The following command displays Domain Name System statistics.

```
show ip dns counters
```

Command mode: All

DNS statistics:	
dnsInRequests:	0
dnsOutRequests:	0
dnsBadRequests:	0

Table 111. DNS Statistics

Statistics	Description
dnsInRequests	The total number of DNS response packets that have been received.
dnsOutRequests	The total number of DNS response packets that have been transmitted.
dnsBadRequests	The total number of DNS request packets received that were dropped.

ICMP Statistics

The following command displays ICMP statistics:

```
show ip icmp counters
```

Command mode: All

ICMP statistics:			
icmpInMsgs:	245802	icmpInErrors:	1393
icmpInDestUnreachs:	41	icmpInTimeExcds:	0
icmpInParmProbs:	0	icmpInSrcQuenchs:	0
icmpInRedirects:	0	icmpInEchos:	18
icmpInEchoReps:	244350	icmpInTimestamps:	0
icmpInTimestampReps:	0	icmpInAddrMasks:	0
icmpInAddrMaskReps:	0	icmpOutMsgs:	253810
icmpOutErrors:	0	icmpOutDestUnreachs:	15
icmpOutTimeExcds:	0	icmpOutParmProbs:	0
icmpOutSrcQuenchs:	0	icmpOutRedirects:	0
icmpOutEchos:	253777	icmpOutEchoReps:	18
icmpOutTimestamps:	0	icmpOutTimestampReps:	0
icmpOutAddrMasks:	0	icmpOutAddrMaskReps:	0

Table 112. ICMP Statistics

Statistic	Description
icmpInMsgs	The total number of ICMP messages which the entity (the switch) received. Note that this counter includes all those counted by <code>icmpInErrors</code> .
icmpInErrors	The number of ICMP messages which the entity (the switch) received but determined as having ICMP-specific errors (bad ICMP checksums, bad length, and so forth).
icmpInDestUnreachs	The number of ICMP Destination Unreachable messages received.
icmpInTimeExcds	The number of ICMP Time Exceeded messages received.
icmpInParmProbs	The number of ICMP Parameter Problem messages received.
icmpInSrcQuenchs	The number of ICMP Source Quench (buffer almost full, stop sending data) messages received.
icmpInRedirects	The number of ICMP Redirect messages received.
icmpInEchos	The number of ICMP Echo (request) messages received.
icmpInEchoReps	The number of ICMP Echo Reply messages received.
icmpInTimestamps	The number of ICMP Timestamp (request) messages received.
icmpInTimestampReps	The number of ICMP Timestamp Reply messages received.

Table 112. ICMP Statistics

Statistic	Description
icmpInAddrMasks	The number of ICMP Address Mask Request messages received.
icmpInAddrMaskReps	The number of ICMP Address Mask Reply messages received.
icmpOutMsgs	The total number of ICMP messages which this entity (the switch) attempted to send. Note that this counter includes all those counted by <code>icmpOutErrors</code> .
icmpOutErrors	The number of ICMP messages which this entity (the switch) did not send due to problems discovered within ICMP such as a lack of buffer. This value should not include errors discovered outside the ICMP layer such as the inability of IP to route the resultant datagram. In some implementations there may be no types of errors that contribute to this counter's value.
icmpOutDestUnreachs	The number of ICMP Destination Unreachable messages sent.
icmpOutTimeExcds	The number of ICMP Time Exceeded messages sent.
icmpOutParmProbs	The number of ICMP Parameter Problem messages sent.
icmpOutSrcQuenchs	The number of ICMP Source Quench (buffer almost full, stop sending data) messages sent.
icmpOutRedirects	The number of ICMP Redirect messages sent. For a host, this object will always be zero, since hosts do not send redirects.
icmpOutEchos	The number of ICMP Echo (request) messages sent.
icmpOutEchoReps	The number of ICMP Echo Reply messages sent.
icmpOutTimestamps	The number of ICMP Timestamp (request) messages sent.
icmpOutTimestampReps	The number of ICMP Timestamp Reply messages sent.
icmpOutAddrMasks	The number of ICMP Address Mask Request messages sent.
icmpOutAddrMaskReps	The number of ICMP Address Mask Reply messages sent.

TCP Statistics

The following command displays TCP statistics:

```
show ip tcp counters
```

Command mode: All

TCP statistics:			
tcpRtoAlgorithm:	4	tcpRtoMin:	0
tcpRtoMax:	240000	tcpMaxConn:	2048
tcpActiveOpens:	0	tcpPassiveOpens:	16
tcpAttemptFails:	0	tcpEstabResets:	0
tcpInSegs:	2035	tcpOutSegs:	1748
tcpRetransSegs:	21	tcpInErrs:	0
tcpCurrEstab:	1	tcpCurrConn:	5
tcpOutRsts:	0		

Table 113. TCP Statistics

Statistic	Description
tcpRtoAlgorithm	The algorithm used to determine the <code>timeout</code> value used for retransmitting unacknowledged octets.
tcpRtoMin	The minimum value permitted by a TCP implementation for the retransmission <code>timeout</code> , measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission <code>timeout</code> . In particular, when the <code>timeout</code> algorithm is <code>rsre(3)</code> , an object of this type has the semantics of the <code>LBOUND</code> quantity described in RFC 793.
tcpRtoMax	The maximum value permitted by a TCP implementation for the retransmission <code>timeout</code> , measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission <code>timeout</code> . In particular, when the <code>timeout</code> algorithm is <code>rsre(3)</code> , an object of this type has the semantics of the <code>UBOUND</code> quantity described in RFC 793.
tcpMaxConn	The limit on the total number of TCP connections the entity (the switch) can support. In entities where the maximum number of connections is dynamic, this object should contain the value -1.
tcpActiveOpens	The number of times TCP connections have made a direct transition to the <code>SYN-SENT</code> state from the <code>CLOSED</code> state.
tcpPassiveOpens	The number of times TCP connections have made a direct transition to the <code>SYN-RCVD</code> state from the <code>LISTEN</code> state.
tcpAttemptFails	The number of times TCP connections have made a direct transition to the <code>CLOSED</code> state from either the <code>SYN-SENT</code> state or the <code>SYN-RCVD</code> state, plus the number of times TCP connections have made a direct transition to the <code>LISTEN</code> state from the <code>SYN-RCVD</code> state.

Table 113. TCP Statistics (continued)

Statistic	Description
tcpEstabResets	The number of times TCP connections have made a direct transition to the CLOSED state from either the ESTABLISHED state or the CLOSE-WAIT state.
tcpInSegs	The total number of segments received, including those received in error. This count includes segments received on currently established connections.
tcpOutSegs	The total number of segments sent, including those on current connections but excluding those containing only retransmitted octets.
tcpRetransSegs	The total number of segments retransmitted - that is, the number of TCP segments transmitted containing one or more previously transmitted octets.
tcpInErrs	The total number of segments received in error (for example, bad TCP checksums).
tcpCurEstab	The total number of outstanding TCP sessions in the ESTABLISHED state.
tcpCurConn	The total number of outstanding TCP sessions that are currently opened.
tcpOutRsts	The number of TCP segments sent containing the RST flag.

UDP Statistics

The following command displays UDP statistics:

```
show ip udp counters
```

Command mode: All

UDP statistics:			
udpInDatagrams:	54	udpOutDatagrams:	43
udpInErrors:	0	udpNoPorts:	1578077

Table 114. UDP Statistics

Statistic	Description
udpInDatagrams	The total number of UDP datagrams delivered to the switch.
udpOutDatagrams	The total number of UDP datagrams sent from this entity (the switch).
udpInErrors	The number of received UDP datagrams that could not be delivered for reasons other than the lack of an application at the destination port.
udpNoPorts	The total number of received UDP datagrams for which there was no application at the destination port.

IGMP Statistics

The following command displays statistics about IGMP protocol packets for all VLANs:

```
show ip igmp counters
```

Command mode: All

```
IGMP vlan 2 statistics:
-----
rxIgmpValidPkts:          0  rxIgmpInvalidPkts:          0
rxIgmpGenQueries:         0  rxIgmpGrpSpecificQueries:    0
rxIgmpGroupSrcSpecificQueries: 0  rxIgmpDiscardPkts:          0
rxIgmpLeaves:             0  rxIgmpReports:              0
txIgmpReports:            0  txIgmpGrpSpecificQueries:    0
txIgmpLeaves:             0  rxIgmpV3CurrentStateRecords: 0
rxIgmpV3SourceListChangeRecords:0  rxIgmpV3FilterChangeRecords: 0
txIgmpGenQueries:        18  rxPimHellos:                 0
```

The following command displays statistics about IGMP protocol packets for a specific VLAN:

```
show ip igmp vlan <vlan number> counters
```

Command mode: All

```
IGMP vlan 147 statistics:
-----
rxIgmpValidPkts:          0  rxIgmpInvalidPkts:          0
rxIgmpGenQueries:         0  rxIgmpGrpSpecificQueries:    0
rxIgmpGroupSrcSpecificQueries: 0  rxIgmpDiscardPkts:          0
rxIgmpLeaves:             0  rxIgmpReports:              0
txIgmpReports:            0  txIgmpGrpSpecificQueries:    0
txIgmpLeaves:             0  rxIgmpV3CurrentStateRecords: 0
rxIgmpV3SourceListChangeRecords:0  rxIgmpV3FilterChangeRecords: 0
rxPimHellos:              0
```

Table 115. IGMP Statistics

Statistic	Description
rxIgmpValidPkts	Total number of valid IGMP packets received
rxIgmpInvalidPkts	Total number of invalid packets received
rxIgmpGenQueries	Total number of General Membership Query packets received
rxIgmpGrpSpecificQueries	Total number of Membership Query packets received for specific groups
rxIgmpGroupSrcSpecificQueries	Total number of Group Source-Specific Queries (GSSQ) received
rxIgmpDiscardPkts	Total number of IGMP packets discarded
rxIgmpLeaves	Total number of Leave requests received

Table 115. IGMP Statistics

Statistic	Description
rxIgmReports	Total number of Membership Reports received
txIgmReports	Total number of Membership reports transmitted
txIgmGrpSpecificQueries	Total number of Membership Query packets transmitted to specific groups
txIgmLeaves	Total number of Leave messages transmitted
rxIgmV3CurrentStateRecords	Total number of Current State records received
rxIgmV3SourceListChangeRecords	Total number of Source List Change records received.
rxIgmV3FilterChangeRecords	Total number of Filter Change records received.
rxPimHellos	Total number of PIM hello packets received

MLD Statistics

Table 116. MLD Statistics Commands

Command Syntax and Usage
<pre>show ipv6 mld</pre> <p>Displays MLD global statistics. Command mode: All See page 193 for sample output.</p>
<pre>show ipv6 mld counters</pre> <p>Displays MLD area statistics. Command mode: All except User EXEC</p>
<pre>show ipv6 mld interface</pre> <p>Displays information for all MLD interfaces. Command mode: All</p>
<pre>show ipv6 mld interface <interface number></pre> <p>Displays MLD interface statistics for the specified interface. Command mode: All</p>
<pre>show ipv6 mld interface [<interface number>] counters</pre> <p>Displays MLD interface statistics. Command mode: All except User EXE</p>
<pre>show ipv6 mld interface counters</pre> <p>Displays total number of MLD entries. Command mode: All</p>
<pre>clear ipv6 mld counters</pre> <p>Clears MLD counters. Command mode: Privileged EXEC</p>
<pre>clear ipv6 mld dynamic</pre> <p>Clears all dynamic MLD tables. Command mode: Privileged EXEC</p>
<pre>clear ipv6 mld groups</pre> <p>Clears dynamic MLD registered group tables. Command mode: Privileged EXEC</p>
<pre>clear ipv6 mld mrouter</pre> <p>Clears dynamic MLD mrouter group tables. Command mode: Privileged EXEC</p>

MLD Global Statistics

The MLD global statistics displays information for all MLD packets received on all interfaces

```
show ipv6 mld counters
```

Command mode: All.

```
MLD global statistics:
-----
Total L3 IPv6 (S, G, V) entries: 2
Total MLD groups:                2
Bad Length:                      0
Bad Checksum:                    0
Bad Receive If:                  0
Receive non-local:               0
Invalid Packets:                 4

MLD packet statistics for interfaces:

MLD interface packet statistics for interface 1:
MLD msg type      Received      Sent      RxErrors
-----
General Query          0          1067         0
MAS Query             0           0           0
MASSQ Query           0           0           0
MLDv1 Report          0           0           0
MLDv1 Done            0           0           0
MLDv2 Report          1069        1084         0
INC CSRs (v2)         1           0           0
EXC CSRs (v2)        2134        1093         0
TO_INC FMCRs (v2)     1           0           0
TO_EXC FMCRs (v2)     0           15          0
ALLOW SLCRs (v2)     0           0           0
BLOCK SLCRs (v2)     0           0           0

MLD interface packet statistics for interface 2:
MLD msg type      Received      Sent      RxErrors
-----

MLD interface packet statistics for interface 3:
MLD msg type      Received      Sent      RxErrors
-----
General Query          0          2467         0
MAS Query             0           0           0
MASSQ Query           0           0           0
MLDv1 Report          0           0           0
MLDv1 Done            0           0           0
MLDv2 Report          2          2472         0
INC CSRs (v2)         1           0           0
EXC CSRs (v2)         0          2476         0
TO_INC FMCRs (v2)     0           0           0
TO_EXC FMCRs (v2)     0           8           0
ALLOW SLCRs (v2)     0           0           0
BLOCK SLCRs (v2)     1           0           0
```

The following table describes the fields in the MLD global statistics output.

Table 117. MLD Global Statistics

Statistic	Description
Bad Length	Number of messages received with length errors.
Bad Checksum	Number of messages received with an invalid IP checksum.
Bad Receive If	Number of messages received on an interface not enabled for MLD.
Receive non-local	Number of messages received from non-local senders.
Invalid packets	Number of rejected packets.
General Query (v1/v2)	Number of general query packets.
MAS Query(v1/v2)	Number of multicast address specific query packets.
MASSQ Query (v2)	Number of multicast address and source specific query packets.
Listener Report(v1)	Number of packets sent by a multicast listener in response to MLDv1 query.
Listener Done(v1/v2)	Number of packets sent by a host when it wants to stop receiving multicast traffic.
Listener Report(v2)	Number of packets sent by a multicast listener in response to MLDv2 query.
MLDv2 INC mode CSRs	Number of current state records with include filter mode.
MLDv2 EXC mode CSRs	Number of current state records with exclude filter mode.
MLDv2 TO_INC FMCRs	Number of filter mode change records for which the filter mode has changed to include mode.
MLDv2 TO_EXC FMCRs	Number of filter mode change records for which the filter mode has changed to exclude mode.
MLDv2 ALLOW SLCRs	Number of source list change records for which the specified sources from where the data is to be received has changed.
MLDv2 BLOCK SLCRs	Number of source list change records for which the specified sources from where the data is to be received is to be blocked.

OSPF Statistics

Table 118. OSPF Statistics Commands

Command Syntax and Usage
<pre>show ip ospf counters</pre> <p>Displays OSPF statistics.</p> <p>Command mode: All</p> <p>See page 196 for sample output.</p>
<pre>show ip ospf area counters</pre> <p>Displays OSPF area statistics.</p> <p>Command mode: All except User EXEC</p>
<pre>show ip ospf interface [<interface number>] counters</pre> <p>Displays OSPF interface statistics.</p> <p>Command mode: All except User EXEC</p>

OSPF Global Statistics

The following command displays statistics about OSPF packets received on all OSPF areas and interfaces:

```
show ip ospf counters
```

Command mode: All

```

OSPF stats
-----
Rx/Tx Stats:          Rx          Tx
-----
Pkts                  0          0
hello                 23         518
database              4          12
ls requests           3          1
ls acks               7          7
ls updates            9          7

Nbr change stats:    Intf change Stats:
hello                2          up                4
start                0          down              2
n2way                2          loop              0
adjoint ok           2          unloop            0
negotiation done     2          wait timer        2
exchange done        2          backup            0
bad requests         0          nbr change        5
bad sequence         0
loading done         2
nlway                0
rst_ad               0
down                 1

Timers kickoff
hello                514
retransmit           1028
lsa lock              0
lsa ack              0
dbage                 0
summary              0
ase export            0
  
```

Table 119. OSPF General Statistics

Statistic	Description
Rx/Tx Stats:	
Rx Pkts	The sum total of all OSPF packets received on all OSPF areas and interfaces.
Tx Pkts	The sum total of all OSPF packets transmitted on all OSPF areas and interfaces.
Rx Hello	The sum total of all Hello packets received on all OSPF areas and interfaces.
Tx Hello	The sum total of all Hello packets transmitted on all OSPF areas and interfaces.

Table 119. OSPF General Statistics (continued)

Statistic	Description
Rx Database	The sum total of all Database Description packets received on all OSPF areas and interfaces.
Tx Database	The sum total of all Database Description packets transmitted on all OSPF areas and interfaces.
Rx Is Requests	The sum total of all Link State Request packets received on all OSPF areas and interfaces.
Tx Is Requests	The sum total of all Link State Request packets transmitted on all OSPF areas and interfaces.
Rx Is Acks	The sum total of all Link State Acknowledgement packets received on all OSPF areas and interfaces.
Tx Is Acks	The sum total of all Link State Acknowledgement packets transmitted on all OSPF areas and interfaces.
Rx Is Updates	The sum total of all Link State Update packets received on all OSPF areas and interfaces.
Tx Is Updates	The sum total of all Link State Update packets transmitted on all OSPF areas and interfaces.
Nbr Change Stats:	
hello	The sum total of all Hello packets received from neighbors on all OSPF areas and interfaces.
Start	The sum total number of neighbors in this state (that is, an indication that Hello packets must now be sent to the neighbor at intervals of <code>HelloInterval</code> seconds.) across all OSPF areas and interfaces.
n2way	The sum total number of bidirectional communication establishment between this router and other neighboring routers.
adjoint ok	The sum total number of decisions to be made (again) as to whether an adjacency should be established/maintained with the neighbor across all OSPF areas and interfaces.
negotiation done	The sum total number of neighbors in this state wherein the Master/slave relationship has been negotiated, and sequence numbers have been exchanged, across all OSPF areas and interfaces.
exchange done	The sum total number of neighbors in this state (that is, in an adjacency's final state) having transmitted a full sequence of Database Description packets across all OSPF areas and interfaces.
bad requests	The sum total number of Link State Requests which have been received for a link state advertisement not contained in the database across all interfaces and OSPF areas.

Table 119. OSPF General Statistics (continued)

Statistic	Description
bad sequence	The sum total number of Database Description packets which have been received that either: <ul style="list-style-type: none"> a. Has an unexpected DD sequence number b. Unexpectedly has the init bit set c. Has an options field differing from the last Options field received in a Database Description packet. Any of these conditions indicate that some error has occurred during adjacency establishment for all OSPF areas and interfaces.
loading done	The sum total number of link state updates received for all out-of-date portions of the database across all OSPF areas and interfaces.
n1way	The sum total number of Hello packets received from neighbors, in which this router is not mentioned across all OSPF interfaces and areas.
rst_ad	The sum total number of times the Neighbor adjacency has been reset across all OPSF areas and interfaces.
down	The total number of Neighboring routers down (that is, in the initial state of a neighbor conversation) across all OSPF areas and interfaces.
Intf Change Stats:	
up	The sum total number of interfaces up in all OSPF areas.
down	The sum total number of interfaces down in all OSPF areas.
loop	The sum total of interfaces no longer connected to the attached network across all OSPF areas and interfaces.
unloop	The sum total number of interfaces, connected to the attached network in all OSPF areas.
wait timer	The sum total number of times the Wait Timer has been fired, indicating the end of the waiting period that is required before electing a (Backup) Designated Router across all OSPF areas and interfaces.
backup	The sum total number of Backup Designated Routers on the attached network for all OSPF areas and interfaces.
nbr change	The sum total number of changes in the set of bidirectional neighbors associated with any interface across all OSPF areas.

Table 119. OSPF General Statistics (continued)

Statistic	Description
Timers Kickoff:	
hello	The sum total number of times the Hello timer has been fired (which triggers the <code>send</code> of a Hello packet) across all OSPF areas and interfaces.
retransmit	The sum total number of times the Retransmit timer has been fired across all OSPF areas and interfaces.
lsa lock	The sum total number of times the Link State Advertisement (LSA) lock timer has been fired across all OSPF areas and interfaces.
lsa ack	The sum total number of times the LSA <code>Ack</code> timer has been fired across all OSPF areas and interfaces.
dbage	The total number of times the data base age (<code>Dbage</code>) has been fired.
summary	The total number of times the Summary timer has been fired.
ase export	The total number of times the Autonomous System Export (ASE) timer has been fired.

OSPFv3 Statistics

Table 120. OSPFv3 Statistics Commands

Command Syntax and Usage
<pre>show ipv6 ospf counters</pre> <p>Displays OSPFv3 statistics.</p> <p>Command mode: All</p> <p>See page 196 for sample output.</p>
<pre>show ipv6 ospf area counters</pre> <p>Displays OSPFv3 area statistics.</p> <p>Command mode: All except User EXEC</p>
<pre>show ipv6 ospf interface [<interface number>] counters</pre> <p>Displays OSPFv3 interface statistics.</p> <p>Command mode: All except User EXEC</p>

OSPFv3 Global Statistics

The following command displays statistics about OSPFv3 packets received on all OSPFv3 areas and interfaces:

```
show ipv6 ospf counters
```

Command mode: All

```

OSPFv3 stats
-----
Rx/Tx/Disd Stats:      Rx          Tx          Discarded
-----
Pkts                   9695       95933       0
hello                  9097       8994        0
database                39         51          6
ls requests            16         8           0
ls acks                 172        360         0
ls updates             371        180         0

Nbr change stats:      Intf change Stats:
down                   0          down         5
attempt               0          loop         0
init                  1          waiting      6
n2way                 1          ptop         0
exstart               1          dr           4
exchange done         1          backup       6
loading done          1          dr other     0
full                  1          all events   33
all events             6

Timers kickoff
hello                 8988
wait                   6
poll                   0
nbr probe              0

Number of LSAs
originated             180
rcvd newer originations 355
  
```

The OSPFv3 General Statistics contain the sum total of all OSPF packets received on all OSPFv3 areas and interfaces.

Table 121. OSPFv3 General Statistics

Statistics	Description
Rx/Tx Stats:	
Rx Pkts	The sum total of all OSPFv3 packets received on all OSPFv3 interfaces.
Tx Pkts	The sum total of all OSPFv3 packets transmitted on all OSPFv3 interfaces.
Discarded Pkts	The sum total of all OSPFv3 packets discarded.
Rx hello	The sum total of all Hello packets received on all OSPFv3 interfaces.

Table 121. OSPFv3 General Statistics (continued)

Statistics	Description
Tx hello	The sum total of all Hello packets transmitted on all OSPFv3 interfaces.
Discarded hello	The sum total of all Hello packets discarded, including packets for which no associated interface has been found.
Rx database	The sum total of all Database Description packets received on all OSPFv3 interfaces.
Tx database	The sum total of all Database Description packets transmitted on all OSPFv3 interfaces.
Discarded database	The sum total of all Database Description packets discarded.
Rx ls requests	The sum total of all Link State Request packets received on all OSPFv3 interfaces.
Tx ls requests	The sum total of all Link State Request packets transmitted on all OSPFv3 interfaces.
Discarded ls requests	The sum total of all Link State Request packets discarded.
Rx ls acks	The sum total of all Link State Acknowledgement packets received on all OSPFv3 interfaces.
Tx ls acks	The sum total of all Link State Acknowledgement packets transmitted on all OSPFv3 interfaces.
Discarded ls acks	The sum total of all Link State Acknowledgement packets discarded.
Rx ls updates	The sum total of all Link State Update packets received on all OSPFv3 interfaces.
Tx ls updates	The sum total of all Link State Update packets transmitted on all OSPFv3 interfaces.
Discarded ls updates	The sum total of all Link State Update packets discarded.
Nbr Change Stats:	
down	The total number of Neighboring routers down (in the initial state of a neighbor conversation) across all OSPFv3 interfaces.
attempt	The total number of transitions into attempt state of neighboring routers across all OSPFv3 interfaces.
init	The total number of transitions into init state of neighboring routers across all OSPFv3 interfaces.
n2way	The total number of bidirectional communication establishment between this router and other neighboring routers.
exstart	The total number of transitions into exstart state of neighboring routers across all OSPFv3 interfaces

Table 121. OSPFv3 General Statistics (continued)

Statistics	Description
exchange done	The total number of neighbors in this state (that is, in an adjacency's final state) having transmitted a full sequence of Database Description packets, across all OSPFv3 interfaces.
loading done	The total number of link state updates received for all out-of-date portions of the database across all OSPFv3 interfaces.
full	The total number of transitions into full state of neighboring routers across all OSPFv3 interfaces.
all events	The total number of state transitions of neighboring routers across all OSPFv3 interfaces.
Intf Change Stats:	
down	The total number of transitions into down state of all OSPFv3 interfaces.
loop	The total number of transitions into loopback state of all OSPFv3 interfaces.
waiting	The total number of transitions into waiting state of all OSPFv3 interfaces.
ptop	The total number of transitions into point-to-point state of all OSPFv3 interfaces.
dr	The total number of transitions into Designated Router other state of all OSPFv3 interfaces.
backup	The total number of transitions into backup state of all OSPFv3 interfaces.
all events	The total number of changes associated with any OSPFv3 interface, including changes into internal states.
Timers Kickoff:	
hello	The total number of times the Hello timer has been fired (which triggers the send of a Hello packet) across all OSPFv3 interfaces.
wait	The total number of times the wait timer has been fired (which causes an interface to exit waiting state), across all OPSFv3 interfaces.
poll	The total number of times the timer whose firing causes hellos to be sent to inactive NBMA and Demand Circuit neighbors has been fired, across all OPSFv3 interfaces.
nbr probe	The total number of times the neighbor probe timer has been fired, across all OPSFv3 interfaces.
Number of LSAs:	
originated	The number of LSAs originated by this router.
rcvd newer originations	The number of LSAs received that have been determined to be newer originations.

VRRP Statistics

Virtual Router Redundancy Protocol (VRRP) support on the CN4093 provides redundancy between routers in a LAN. This is accomplished by configuring the same virtual router IP address and ID number on each participating VRRP-capable routing device. One of the virtual routers is then elected as the master, based on a number of priority criteria, and assumes control of the shared virtual router IP address. If the master fails, one of the backup virtual routers will assume routing authority and take control of the virtual router IP address.

When virtual routers are configured, you can display the protocol statistics for VRRP. The following command displays VRRP statistics:

```
show ip vrrp counters
```

Command mode: All

VRRP statistics:			
vrrpInAdvers:	0	vrrpBadAdvers:	0
vrrpOutAdvers:	0		
vrrpBadVersion:	0	vrrpBadVrid:	0
vrrpBadAddress:	0	vrrpBadData:	0
vrrpBadPassword:	0	vrrpBadInterval:	0

Table 122. VRRP Statistics

Statistics	Description
vrrpInAdvers	The total number of valid VRRP advertisements that have been received.
vrrpBadAdvers	The total number of VRRP advertisements received that were dropped.
vrrpOutAdvers	The total number of VRRP advertisements that have been sent.
vrrpBadVersion	The total number of VRRP advertisements received that had a bad version number.
vrrpBadVrid	The total number of VRRP advertisements received that had a bad virtual router ID.
vrrpBadAddress	The total number of VRRP advertisements received that had a bad address.
vrrpBadData	The total number of VRRP advertisements received that had bad data.
vrrpBadPassword	The total number of VRRP advertisements received that had a bad password.
vrrpBadInterval	The total number of VRRP advertisements received that had a bad interval.

PIM Statistics

The following command displays Protocol Independent Multicast (PIM) statistics:

```
show ip pim counters
```

Command mode: All

Hello Tx/Rx	: 2595/2596
Join/Prune Tx/Rx	: 0/0
Assert Tx/Rx	: 0/0
Register Tx/Rx	: 0/0
Null-Reg Tx/Rx	: 0/0
RegStop Tx/Rx	: 0/0
CandRPAdv Tx/Rx	: 973/0
BSR Tx/Rx	: 0/1298
Graft Tx/Rx	: 0/0
Graft Ack Tx/Rx	: 0/0
Mcast data Tx/Rx	: 0/0
MDP drop Tx/Rx	: 0/0
CTL drop Tx/Rx	: 0/0
Bad pkts	: 0

Table 123. PIM Statistics

Statistics	Description
Hello Tx/Rx	Number of Hello messages transmitted or received
Join/Prune Tx/Rx	Number of Join/Prune messages transmitted or received
Assert Tx/Rx	Number of Assert messages transmitted or received
Register Tx/Rx	Number of Register messages transmitted or received
Null-Reg Tx/Rx	Number of NULL-register messages transmitted or received
RegStop Tx/Rx	Number of Register Stop messages transmitted or received
CandRPAdv Tx/Rx	Number of Candidate RP Advertisements transmitted or received
BSR Tx/Rx	Number of Bootstrap Router (BSR) messages transmitted or received
Graft Tx/Rx	Number of Graft messages transmitted or received
Graft Ack Tx/Rx	Number of Graft Acknowledgements transmitted or received
Mcast data Tx/Rx	Number of multicast datagrams transmitted or received
MDP drop Tx/Rx	Number of Multicast data packet Tx/Rx dropped
CTL drop Tx/Rx	Number of PIM control packet Tx/Rx dropped
Bad pkts	Number of bad PIM packets received

Routing Information Protocol Statistics

The following command displays RIP statistics:

```
show ip rip counters
```

Command mode: All

```
RIP ALL STATS INFORMATION:
  RIP packets received = 12
  RIP packets sent     = 75
  RIP request received = 0
  RIP response received = 12
  RIP request sent     = 3
  RIP reponse sent     = 72
  RIP route timeout    = 0
  RIP bad size packet received = 0
  RIP bad version received = 0
  RIP bad zeros received = 0
  RIP bad src port received = 0
  RIP bad src IP received = 0
  RIP packets from self received = 0
```

Management Processor Statistics

Table 124. Management Processor Statistics Commands

Command Syntax and Usage
<pre>show mp thread</pre> <p>Displays STEM thread statistics. This command is used by Technical Support personnel.</p> <p>Command mode: All</p>
<pre>show mp packet counters</pre> <p>Displays packet statistics, to check for leads and load. To view a sample output and a description of the statistics, see page 207.</p> <p>Command mode: All</p>
<pre>show mp tcp-block</pre> <p>Displays all TCP control blocks that are in use. To view a sample output and a description of the statistics, see page 219.</p> <p>Command mode: All</p>
<pre>show mp udp-block</pre> <p>Displays all UDP control blocks that are in use. To view a sample output, see page 220.</p> <p>Command mode: All</p>
<pre>show processes cpu</pre> <p>Displays CPU utilization for periods of up to 1, 4, and 64 seconds. To view a sample output and a description of the stats, see page 220.</p> <p>Command mode: All</p>
<pre>show processes cpu history</pre> <p>Displays history of CPU utilization. To view a sample output, see page 223.</p> <p>Command mode: All</p>

Packet Statistics

Table 125. Packet Statistics Commands

Command Syntax and Usage
<pre>show mp packet counters</pre> <p>Displays packet statistics, to check for leads and load. To view a sample output and a description of the stats, see page 207.</p> <p>Command mode: All</p>
<pre>clear mp packet logs</pre> <p>Clears all CPU packet statistics and logs.</p> <p>Command mode: All</p>

MP Packet Statistics

The following command displays MP packet statistics:

```
show mp packet counters
```

Command mode: All except User EXEC

```
CPU packet statistics at 8:21:54 Tue Jan 8, 2013
```

Packet rate:	Incoming	Outgoing
-----	-----	-----
1-second:	8	7
4-seconds:	7	5
64-seconds:	4	3

Packet counters:	Received	Sent
-----	-----	----
Total packets:	109056	148761
Since bootup:	109056	148768
BPDUs:	6415	19214
Cisco packets:	0	0
ARP Requests:	15	10061
ARP Replies:	8545	14
LACP packets:	3414	3420
IPv4 packets:	60130	116101
ICMP Requests:	0	21
ICMP Replies:	21	0
IGMP packets:	0	0
PIM packets:	0	0
VRRP packets:	0	0
TCP packets:	60088	116113
FTP	0	0
HTTP	0	0
SSH	3	3
TACACS	0	0
TELNET	60095	116145
TCP other	0	0
UDP packets:	24	9
DHCP	0	0
NTP	0	0
RADIUS	0	0
SNMP	0	0
TFTP	0	0
UDP other	24	8
RIP packets:	0	1
OSPF packets:	0	0
BGP packets:	0	0
IPv6 packets:	0	0
LLDP PDUs:	3987	6876
FCoE FIP PDUs:	0	0
ECP PDUs:	0	0
Other:	26549	0

...

...

Packet Buffer Statistics:

```
-----  
allocs:      265803  
frees:       265806  
failures:    0  
dropped:     0
```

small packet buffers:

```
-----  
current:          1  
max:              1024  
threshold:        128  
hi-watermark:     3  
hi-water time:    3:39:12 Tue Jan  8, 2013
```

medium packet buffers:

```
-----  
current:          0  
max:              2048  
threshold:        50  
hi-watermark:     1  
hi-water time:    3:37:12 Tue Jan  8, 2013
```

jumbo packet buffers:

```
-----  
current:          0  
max:              16  
hi-watermark:     0
```

pkt_hdr statistics:

```
-----  
current          :          0  
max              :        3072  
hi-watermark    :          180
```

Router(config)#

Problem 11:

page 239/612

output information have error, suggest use the form below.

Router(config)#show mp tcp-block

All TCP allocated control blocks:

```
145c1418:  0.0.0.0                0 <=>  
          0.0.0.0                179 listen  
1458cf48:  0:0:0:0:0:0:0:0            0 <=>  
          0:0:0:0:0:0:0:0            80 listen  
1458cdf8:  0.0.0.0                0 <=>  
          0.0.0.0                80 listen  
145d3610:  192.168.0.4              4130 <=>  
          10.38.5.151              23 established  
145a7658:  0:0:0:0:0:0:0:0            0 <=>  
          0:0:0:0:0:0:0:0            23 listen  
145a74d8:  0.0.0.0                0 <=>  
          0.0.0.0                23 listen
```

Table 126. Packet Statistics

Statistics	Description
Packet Rate	
1-second	The rate of incoming and outgoing packets over 1 second.
4-seconds	The rate of incoming and outgoing packets over 4 seconds.
64-seconds	The rate of incoming and outgoing packets over 64 seconds.
Packets Counters	
Total packets	Total number of packets received
Since bootup	Total number of packets received and sent since the last switch reboot.
BPDUs	Total number of spanning-tree Bridge Protocol Data Units received.
Cisco packets	Total number of UniDirectional Link Detection (UDLD) packets and Cisco Discovery Protocol (CDP) packets received.
ARP packets	Total number of Address Resolution Protocol packets received.
IPv4 packets	Total number of IPv4 packets received and sent. Includes the following packet types: <ul style="list-style-type: none"> – IGMP – PIM – ICMP requests – ICMP replies
TCP packets	Total number of TCP packets received and sent. Includes the following packet types: <ul style="list-style-type: none"> – FTP – HTTP – SSH – TACACS+ – Telnet – Other
UDP packets	Total number of UDP packets received and sent. Includes the following packet types: <ul style="list-style-type: none"> – DHCP – NTP – RADIUS – SNMP – TFTP – Other
RIP packets	Total number of Routing Information Protocol packets received and sent.

Table 126. Packet Statistics (continued)

Statistics	Description
OSPF packets	Total number of Open Shortest Path First packets received and sent.
BGP packets	Total number of Border Gateway Protocol packets received and sent.
IPv6 packets	Total number of IPv6 packets received.
LLDP PDUs	Total number of Link Layer Discovery Protocol data units received.
ECP PDUs	Total number of Edge Control Protocol data units received and sent.
MgmtSock Packets	Total number of packets received and transmitted through the management port.
Other	Total number of other packets received.
Packet Buffer Statistics	
allocs	Total number of packet allocations from the packet buffer pool by the TCP/IP protocol stack.
frees	Total number of times the packet buffers are freed (released) to the packet buffer pool by the TCP/IP protocol stack.
failures	Total number of packet allocation failures from the packet buffer pool by the TCP/IP protocol stack.
dropped	Total number of packets dropped by the packet buffer pool.
small packet buffers	
current	Total number of packet allocations with size less than 128 bytes from the packet buffer pool by the TCP/IP protocol stack.
max	Maximum number of small packet allocations supported.
threshold	Threshold value for small packet allocations, beyond which only high-priority small packets are allowed.
hi-watermark	The highest number of packet allocation with size less than 128 bytes from the packet buffer pool by the TCP/IP protocol stack.
hi-water time	Time stamp that indicates when the hi-watermark was reached.

Table 126. Packet Statistics (continued)

Statistics	Description
medium packet buffers	
current	Total number of packet allocations with size between 128 to 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
max	Maximum number of medium packet allocations supported.
threshold	Threshold value for medium packet allocations, beyond which only high-priority medium packets are allowed.
hi-watermark	The highest number of packet allocation with size between 128 to 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
hi-water time	Time stamp that indicates when the hi-watermark was reached.
jumbo packet buffers	
current	Total number of packet allocations with more than 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
max	Maximum number of jumbo packet allocations supported.
hi-watermark	The highest number of packet allocation with more than 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
pkt_hdr statistics	
current	Total number of packet allocations with more than 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
max	Maximum number of packet allocations with more than 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.
hi-watermark	The highest number of packet allocation with more than 1536 bytes from the packet buffer pool by the TCP/IP protocol stack.

Packet Statistics Log

These commands allow you to display a log of all packets received by CPU. The following table describes the Packet Statistics Log options.

Table 127. Packet Statistics Log Options

Command Syntax and Usage
<pre>show mp packet log all</pre> <p>Displays all packet logs received by and sent from the CPU. To view a sample output and a description of the log entries, see "Packet Log example" on page 213.</p>
<pre>show mp packet log rx</pre> <p>Displays all packets logs received by the CPU.</p>
<pre>show mp packet log tx</pre> <p>Displays all packet logs sent from the CPU.</p>

Packet Log example

```
358. Type: BPDU, sent 1:01:11 Tue Mar 20, 2012
    Port EXT2, VLAN 201, Length 57, Reason 0x0, Flags 0x0
    Dst MAC: 01:80:c2:00:00:00, Src MAC: 08:17:f4:a7:57:2c

357. Type: ICMP ECHO Req, sent 1:01:09 Tue Mar 20, 2012
    Port MGT1, VLAN 4095, Length 16, Reason 0x0, Flags 0x0 FromMgmtSock
    Src IP: 9.43.98.125, Dst IP: 9.43.98.254
```

Each packet log entry includes the following information:

- Entry ID
- Packet type
- Date and time
- Port number
- VLAN number
- Packet length
- Reason code
- Flags
- Source and destination address

Packet Statistics Last Packet

These commands allow you to display a specified number (*N*) of the most recent packet logs received by or sent from the CPU. The following table describes the Packet Statistics Last Packet options.

Table 128. Last Packet Options

Command Syntax and Usage
<pre>show mp packet last both <I-1000></pre> <p>Displays a specified number of recent packet logs received by and sent from the CPU. To view a sample output and a description, see “Packet Log example” on page 213.</p>
<pre>show mp packet last rx <I-1000></pre> <p>Displays a specified number of recent packet logs received by the CPU.</p>
<pre>show mp packet last tx <I-1000></pre> <p>Displays a specified number of recent packet logs sent from the CPU.</p>

Packet Statistics Dump

The following table describes the Packet Statistics Dump options.

Table 129. Packet Statistics Dump Options

Command Syntax and Usage
<pre>show mp packet dump all</pre> <p>Displays all packet statistics and logs received by and sent from the CPU.</p>
<pre>show mp packet dump rx</pre> <p>Displays all packet statistics and logs received by the CPU.</p>
<pre>show mp packet dump tx</pre> <p>Displays all packet statistics and logs sent from the CPU.</p>

Logged Packet Statistics

The following command displays logged packets that have been received or sent, based on the specified filter:

```
show mp packet parse rx|tx < parsing_option >
```

The filter options are described in [Table 130](#).

Table 130. Packet Log Parsing Options

Command Syntax and Usage
<pre>show mp packet parse rx tx arp</pre> <p>Displays only ARP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx rarp</pre> <p>Displays only Reverse-ARP packets.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx bpdu</pre> <p>Displays only BPDUs logged</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx cisco</pre> <p>Displays only Cisco packets (BPDU/CDP/UDLD) logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx lacp</pre> <p>Displays only LACP PDUs logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx fcoe</pre> <p>Displays only FCoE FIP PDUs logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx ipv4</pre> <p>Displays only IPv4 packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx igmp</pre> <p>Displays only IGMP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx pim</pre> <p>Displays only PIM packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx icmp</pre> <p>Displays only ICMP packets logged.</p> <p>Command mode: All</p>

Table 130. Packet Log Parsing Options (continued)

Command Syntax and Usage
<pre>show mp packet parse rx tx tcp</pre> <p>Displays only TCP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx ftp</pre> <p>Displays only FTP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx http</pre> <p>Displays only HTTP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx ssh</pre> <p>Displays only SSH packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx tacacs</pre> <p>Displays only TACACS packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx telnet</pre> <p>Displays only TELNET packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx tcpother</pre> <p>Displays only TCP other-port packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx udp</pre> <p>Displays only UDP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx dhcp</pre> <p>Displays only DHCP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx ntp</pre> <p>Displays only NTP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx radius</pre> <p>Displays only RADIUS packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx snmp</pre> <p>Displays only SNMP packets logged.</p> <p>Command mode: All</p>

Table 130. Packet Log Parsing Options (continued)

Command Syntax and Usage
<pre>show mp packet parse rx tx tftp</pre> <p>Displays only TFTP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx udpother</pre> <p>Displays only UDP other-port packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx ipv6</pre> <p>Displays only IPv6 packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx rip</pre> <p>Displays only RIP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx ospf</pre> <p>Displays only OSPF packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx bgp</pre> <p>Displays only BGP packets logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx lldp</pre> <p>Displays only LLDP PDUs logged.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx vlan <VLAN_number></pre> <p>Displays only logged packets with the specified VLAN.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx port <port_number></pre> <p>Displays only logged packets with the specified port.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx mac <MAC_address></pre> <p>Displays only logged packets with the specified MAC address.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx ip-addr <IPv4_address></pre> <p>Displays only logged packets with the specified IPv4 address.</p> <p>Command mode: All</p>

Table 130. Packet Log Parsing Options (continued)

Command Syntax and Usage
<pre>show mp packet parse rx tx other</pre> <p>Displays logs of all packets not explicitly selectable.</p> <p>Command mode: All</p>
<pre>show mp packet parse rx tx raw</pre> <p>Displays raw packet buffer in addition to headers.</p> <p>Command mode: All</p>

TCP Statistics

The following command displays TCP statistics:

```
show mp tcp-block
```

Command mode: All

```

Data Ports:
-----
All TCP allocated control blocks:
14835bd8:  0.0.0.0                0 <=>
          172.31.38.107          80 listen MGT up
147c6eb8:  0:0:0:0:0:0:0:0              0 <=>
          0:0:0:0:0:0:0:0          80 listen
147c6d68:  0.0.0.0                0 <=>
          0.0.0.0                80 listen
14823918:  172.31.37.42             55866 <=>
          172.31.38.107          23 established 0 ??
11af2394:  0.0.0.0                0 <=>
          172.31.38.107          23 listen MGT up
147e6808:  0.0.0.0                0 <=>
          0.0.0.0                23 listen
147e66b8:  0:0:0:0:0:0:0:0              0 <=>
          0:0:0:0:0:0:0:0          23 listen
147e6568:  0.0.0.0                0 <=>
          0.0.0.0                23 listen

Mgmt Ports:
-----
Active Internet connections (servers and established)
Proto Recv-Q Send-Q Local Address           Foreign Address         State
tcp      0      0 172.31.38.107:http     *:*                     LISTEN
tcp      0      0 172.31.38.107:telnet   *:*                     LISTEN
tcp      0      0 *:11000                 *:*                     LISTEN
tcp      0  1274 172.31.38.107:telnet   172.31.37.42:55866     ESTABLISHED

```

Table 131. MP Specified TCP Statistics

Statistics	Description
14835bd8	Memory
0.0.0.0	Destination IP address
0	Destination port
172.31.38.107	Source IP
80	Source port
listen MGT1 up	State

UDP Statistics

The following command displays UDP statistics:

```
show mp udp-block
```

Command mode: All except User EXEC

```
Data Ports:
-----
All UDP allocated control blocks:
 68: listen
161: listen
500: listen
546: listen

Mgmt Ports:
-----
Active Internet connections (servers and established)
Proto Recv-Q Send-Q Local Address           Foreign Address         State
udp      0      0 9.43.95.121:snmp       *.*
0.0.0.0          0 <=> 9.43.95.121          161 accept MGT1 up
```

CPU Statistics

The following commands display CPU utilization statistics:

```
show mp cpu
```

Command mode: All

```
      CPU utilization           Highest      Thread           Time
-----
cpuUtil1Second:              3%          83%          58 (I2C )       12:02:14 Fri Oct 14, 2011
cpuUtil4Seconds:             5%
cpuUtil64Seconds:            5%
```

Table 132. CPU Statistics

Statistics	Description
cpuUtil1Second	The use of MP CPU over 1 second. It shows the percentage, highest rate, thread, and time the highest utilization occurred.
cpuUtil4Seconds	The use of MP CPU over 4 seconds. It shows the percentage.
cpuUtil64Seconds	The use of MP CPU over 64 seconds. It shows the percentage.
Highest	The highest percent of CPU use.

Table 132. CPU Statistics

Statistics	Description
Thread	The thread ID and name of the thread that caused the highest CPU use.
Time	The time when the highest CPU use was reached.

show processes cpu

Command mode: All

```

-----
CPU Utilization at  8:25:55 Tue Jan  8, 2013

Total CPU Utilization: For 1 second: 2.92%
                      For 5 second: 3.38%
                      For 1 minute: 7.88%
                      For 5 minute: 8.93%

Highest CPU Utilization: thread  2 (STP ) at  6:44:56 Tue Jan  8, 2013

-----
Thread  Thread      Utilization      Status
  ID     Name         1sec      5sec      1Min      5Min
-----
  1     STEM         0.00%     0.00%     0.00%     0.00%     idle
  2     STP           0.00%     0.05%     0.10%     0.10%     idle
  3     MFDB          0.00%     0.00%     5.06%     5.22%     idle
  4     TND            0.00%     0.00%     0.00%     0.00%     idle
  5     CONS           0.00%     0.00%     0.00%     0.15%     suspended
  6     TNET           0.11%     0.58%     0.17%     0.27%     running
  7     TNET           0.00%     0.00%     0.00%     0.00%     idle
  8     TNET           0.00%     0.00%     0.00%     0.00%     idle
  9     TNET           0.00%     0.00%     0.00%     0.00%     idle
 10     LOG            0.00%     0.00%     0.00%     0.00%     idle
 11     TRAP           0.00%     0.00%     0.00%     0.00%     idle
 13     NTP            0.00%     0.00%     0.00%     0.00%     idle
 14     IP             0.04%     0.04%     0.06%     0.06%     idle
 17     IP             0.01%     0.08%     0.04%     0.04%     idle
 18     RIP            0.00%     0.00%     0.00%     0.00%     idle
 19     AGR            0.00%     0.00%     0.00%     0.00%     idle
 20     EPI            0.16%     0.27%     0.12%     0.10%     runnable
 22     PORT           0.00%     0.00%     0.00%     0.00%     idle
 24     BGP            0.18%     0.04%     0.00%     0.00%     idle
 32     SCAN           0.00%     0.00%     0.00%     0.00%     idle
 34     OSPF           0.20%     0.04%     0.02%     0.01%     idle
 36     SNMP           0.00%     0.00%     0.00%     0.00%     idle
 37     SNMP           0.00%     0.00%     0.00%     0.00%     idle
 38     SNMP           0.00%     0.00%     0.00%     0.00%     idle
 40     SSHD           0.00%     0.00%     0.00%     0.00%     idle
...
 120    VDPT           0.00%     0.00%     0.00%     0.00%     idle
 124    HIST           0.00%     0.00%     0.00%     0.00%     runnable
 128    NORM           0.00%     0.00%     0.00%     0.00%     idle
 129    NORM           0.00%     0.00%     0.00%     0.00%     idle
 130    DONE           0.00%     0.00%     0.00%     0.00%     idle
-----

```

Table 133. CPU Statistics

Statistics	Description
Thread ID	The thread ID number.
Thread Name	The name of the thread.
1sec	The percent of CPU use over 1 second.
5sec	The percent of CPU use over 5 seconds.
1Min	The percent of CPU use over 1 minute.
5Min	The percent of CPU use over 5 minutes.
Status	The status of the process.

CPU Statistics History

The following command display a history of CPU use statistics:

```
show processes cpu history
```

Command mode: All

```
-----  
CPU Utilization History  
-----  
 17 (IP ) 98% at 22:17:24 Mon Feb 20, 2012  
 59 (LACP) 9% at 22:17:33 Mon Feb 20, 2012  
110 (ETMR) 12% at 22:17:34 Mon Feb 20, 2012  
110 (ETMR) 12% at 22:17:36 Mon Feb 20, 2012  
110 (ETMR) 12% at 22:17:40 Mon Feb 20, 2012  
110 (ETMR) 12% at 22:17:45 Mon Feb 20, 2012  
110 (ETMR) 17% at 22:17:47 Mon Feb 20, 2012  
110 (ETMR) 18% at 22:17:49 Mon Feb 20, 2012  
110 (ETMR) 25% at 22:20:28 Mon Feb 20, 2012  
110 (ETMR) 26% at 22:39:08 Mon Feb 20, 2012  
 37 (SNMP) 28% at 22:46:20 Mon Feb 20, 2012  
 94 (PROX) 57% at 23:29:36 Mon Feb 20, 2012  
 94 (PROX) 63% at 23:29:37 Mon Feb 20, 2012  
 94 (PROX) 63% at 23:29:39 Mon Feb 20, 2012  
 58 (I2C ) 64% at 16:21:54 Tue Feb 21, 2012  
 5 (CONS) 86% at 18:41:54 Tue Feb 21, 2012  
 58 (I2C ) 88% at 18:41:55 Tue Feb 21, 2012  
 58 (I2C ) 88% at 21:29:41 Sat Feb 25, 2012  
 58 (I2C ) 98% at 12:04:59 Tue Feb 28, 2012  
 58 (I2C ) 100% at 11:31:32 Sat Mar 10, 2012  
-----
```

Access Control List Statistics

The following commands display and change ACL statistics.

Table 134. ACL Statistics Commands

Command Syntax and Usage
<pre>show access-control list <ACL number> counters</pre> <p>Displays the Access Control List Statistics for a specific ACL.</p> <p>Command mode: All</p>
<pre>show access-control list6 <ACL number> counters</pre> <p>Displays the IPv6 ACL statistics for a specific ACL.</p> <p>Command mode: All</p>
<pre>show access-control macl <MACL number> counters</pre> <p>Displays the ACL statistics for a specific management ACL (MACL).</p> <p>Command mode: All</p>
<pre>show access-control counters</pre> <p>Displays all ACL statistics.</p> <p>Command mode: All</p>
<pre>clear access-control list {<ACL number> all} counters</pre> <p>Clears ACL statistics.</p> <p>Command mode: Privileged EXEC</p>
<pre>clear access-control list6 {<ACL number> all}</pre> <p>Clears IPv6 ACL statistics.</p> <p>Command mode: Privileged EXEC</p>
<pre>show access-control meter <meter number> counters</pre> <p>Displays ACL meter statistics.</p> <p>Command mode: All</p>
<pre>clear access-control meter <meter number> counters</pre> <p>Clears ACL meter statistics.</p> <p>Command mode: Privileged EXEC</p>

ACL Statistics

The following command displays ACL statistics.

```
show access-control counters
```

Command mode: All

Hits for ACL 1:	26057515
Hits for ACL 2:	26057497

VMAP Statistics

The following command displays VLAN Map statistics.

```
show access-control vmap {<vmap number>} counters
```

Command mode: All

Hits for VMAP 1:	57515
------------------	-------

Fibre Channel over Ethernet Statistics

The following command displays Fibre Channel over Ethernet (FCoE) statistics:

```
show fcoe counters
```

Command mode: All

FCF-keepalives statistics:			
FCF 54:7f:ee:8f:d4:2a keepalives received : 62			
FCOE statistics:			
FCFAdded:	5	FCFRemoved:	1
FCOEAdded:	81	FCOERemoved:	24

Fibre Channel over Ethernet (FCoE) statistics are described in the following table:

Table 135. FCoE Statistics

Statistic	Description
FCFAdded	Total number of FCoE Forwarders (FCF) added.
FCFRemoved	Total number of FCoE Forwarders (FCF) removed.
FCOEAdded	Total number of FCoE connections added.
FCOERemoved	Total number of FCoE connections removed.

The total can accumulate over several FCoE sessions, until the statistics are cleared.

The following command clears Fibre Channel over Ethernet (FCoE) statistics:

```
clear fcoe counters
```

Command mode: All

ACL Meter Statistics

This option displays ACL meter statistics.

```
show access-control meter <meter number> counters
```

Command mode: All

```
Out of profile hits for Meter 1, Port EXT1: 0
Out of profile hits for Meter 2, Port EXT1: 0
```

SNMP Statistics

The following command displays SNMP statistics:

```
show snmp-server counters
```

Command mode: All except User EXEC

SNMP statistics:			
snmpInPkts:	150097	snmpInBadVersions:	0
snmpInBadC'tyNames:	0	snmpInBadC'tyUses:	0
snmpInASNParseErrs:	0	snmpEnableAuthTraps:	0
snmpOutPkts:	150097	snmpInBadTypes:	0
snmpInTooBig:	0	snmpInNoSuchNames:	0
snmpInBadValues:	0	snmpInReadOnlys:	0
snmpInGenErrs:	0	snmpInTotalReqVars:	798464
snmpInTotalSetVars:	2731	snmpInGetRequests:	17593
snmpInGetNexts:	131389	snmpInSetRequests:	615
snmpInGetResponses:	0	snmpInTraps:	0
snmpOutTooBig:	0	snmpOutNoSuchNames:	1
snmpOutBadValues:	0	snmpOutReadOnlys:	0
snmpOutGenErrs:	1	snmpOutGetRequests:	0
snmpOutGetNexts:	0	snmpOutSetRequests:	0
snmpOutGetResponses:	150093	snmpOutTraps:	4
snmpSilentDrops:	0	snmpProxyDrops:	0

Table 136. SNMP Statistics

Statistic	Description
snmpInPkts	The total number of Messages delivered to the SNMP entity from the transport service.
snmpInBadVersions	The total number of SNMP Messages, which were delivered to the SNMP protocol entity and were for an unsupported SNMP version.
snmpInBadC'tyNames	The total number of SNMP Messages delivered to the SNMP entity which used an SNMP community name not known to the said entity (the switch).
snmpInBadC'tyUses	The total number of SNMP Messages delivered to the SNMP protocol entity which represented an SNMP operation which was not allowed by the SNMP community named in the Message.

Table 136. SNMP Statistics (continued)

Statistic	Description
snmpInASNParseErrs	<p>The total number of ASN.1 or BER errors encountered by the SNMP protocol entity when decoding SNMP Messages received.</p> <p>Note: OSI's method of specifying abstract objects is called ASN.1 (Abstract Syntax Notation One, defined in X.208), and one set of rules for representing such objects as strings of ones and zeros is called the BER (Basic Encoding Rules, defined in X.209). ASN.1 is a flexible notation that allows one to define a variety of data types, from simple types such as integers and bit strings to structured types such as sets and sequences. BER describes how to represent or encode values of each ASN.1 type as a string of eight-bit octets.</p>
snmpEnableAuthTraps	An object to enable or disable the authentication traps generated by this entity (the switch).
snmpOutPkts	The total number of SNMP Messages which were passed from the SNMP protocol entity to the transport service.
snmpInBadTypes	The total number of SNMP Messages which failed ASN parsing.
snmpInTooBig	The total number of SNMP Protocol Data Units (PDUs) which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>too big</i> .
snmpInNoSuchNames	The total number of SNMP Protocol Data Units (PDUs) which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>noSuchName</i> .
snmpInBadValues	The total number of SNMP Protocol Data Units (PDUs) which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>badValue</i> .
snmpInReadOnly	The total number of valid SNMP Protocol Data Units (PDUs), which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>read-Only</i> . It should be noted that it is a protocol error to generate an SNMP PDU, which contains the value <i>read-Only</i> in the error-status field. As such, this object is provided as a means of detecting incorrect implementations of the SNMP.
snmpInGenErrs	The total number of SNMP Protocol Data Units (PDUs), which were delivered to the SNMP protocol entity and for which the value of the error-status field is <i>genErr</i> .

Table 136. SNMP Statistics (continued)

Statistic	Description
snmpInTotalReqVars	The total number of MIB objects which have been retrieved successfully by the SNMP protocol entity as a result of receiving valid SNMP Get-Request and Get-Next Protocol Data Units (PDUs).
snmpInTotalSetVars	The total number of MIB objects, which have been altered successfully by the SNMP protocol entity as a result of receiving valid SNMP Set-Request Protocol Data Units (PDUs).
snmpInGetRequests	The total number of SNMP Get-Request Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpInGetNexts	The total number of SNMP Get-Next Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpInSetRequests	The total number of SNMP Set-Request Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpInGetResponses	The total number of SNMP Get-Response Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpInTraps	The total number of SNMP Trap Protocol Data Units (PDUs), which have been accepted and processed by the SNMP protocol entity.
snmpOutTooBig	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status field is <i>too big</i> .
snmpOutNoSuchNames	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status is <i>noSuchName</i> .
snmpOutBadValues	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status field is <i>badValue</i> .
snmpOutReadOnly	Not in use.
snmpOutGenErrs	The total number of SNMP Protocol Data Units (PDUs), which were generated by the SNMP protocol entity and for which the value of the error-status field is <i>genErr</i> .
snmpOutGetRequests	The total number of SNMP Get-Request Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.

Table 136. SNMP Statistics (continued)

Statistic	Description
snmpOutGetNexts	The total number of SNMP Get-Next Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpOutSetRequests	The total number of SNMP Set-Request Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpOutGetResponses	The total number of SNMP Get-Response Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpOutTraps	The total number of SNMP Trap Protocol Data Units (PDUs), which have been generated by the SNMP protocol entity.
snmpSilentDrops	The total number of GetRequest-PDUs, GetNextRequest-PDUs, GetBulkRequest-PDUs, SetRequest-PDUs, and InformRequest-PDUs delivered to the SNMPv2 entity which were silently dropped because the size of a reply containing an alternate Response-PDU with an empty variable bindings field was greater than either a local constraint or the maximum message size associated with the originator of the request.
snmpProxyDrops	The total number of GetRequest-PDUs, GetNextRequest-PDUs, GetBulkRequest-PDUs, SetRequest-PDUs, and InformRequest-PDUs delivered to the SNMP entity which were silently dropped because the transmission of the message to a proxy target failed in a manner such that no Response-PDU could be returned.

NTP Statistics

IBM Networking OS uses NTP (Network Timing Protocol) version 3 to synchronize the switch's internal clock with an atomic time calibrated NTP server. With NTP enabled, the switch can accurately update its internal clock to be consistent with other devices on the network and generates accurate syslogs.

The following command displays NTP statistics:

```
show ntp counters
```

Command mode: All

NTP statistics:	
Primary Server:	
Requests Sent:	17
Responses Received:	17
Updates:	1
Secondary Server:	
Requests Sent:	0
Responses Received:	0
Updates:	0
Last update based on response from primary/secondary server.	
Last update time: 18:04:16 Tue Jul 13, 2010	
Current system time: 18:55:49 Tue Jul 13, 2010	

Table 137. NTP Statistics

Field	Description
Primary Server	<ul style="list-style-type: none">• Requests Sent: The total number of NTP requests the switch sent to the primary NTP server to synchronize time.• Responses Received: The total number of NTP responses received from the primary NTP server.• Updates: The total number of times the switch updated its time based on the NTP responses received from the primary NTP server.
Secondary Server	<ul style="list-style-type: none">• Requests Sent: The total number of NTP requests the switch sent to the secondary NTP server to synchronize time.• Responses Received: The total number of NTP responses received from the secondary NTP server.• Updates: The total number of times the switch updated its time based on the NTP responses received from the secondary NTP server.
Last update based on response from primary server	Last update of time on the switch based on either primary or secondary NTP response received.

Table 137. NTP Statistics (continued)

Field	Description
Last update time	The time stamp showing the time when the switch was last updated.
Current system time	The switch system time when the following command was issued: show ntp counters

The following command displays information about NTP associated peers:

```
show ntp associations
```

Command mode: All

address	ref clock	st	when(s)	offset(s)
*12.200.151.18	198.72.72.10	3	35316	-2
*synced, #unsynched				

Table 138. NTP Associations

Field	Description
address	Peer address
ref clock	Peer reference clock address
st	Peer stratum
when(s)	Time in seconds since the latest NTP packet was received from the peer
offset(s)	Offset in seconds between the peer clock and local clock

SLP Statistics

Table 139. SLP Statistics Commands

Command Syntax and Usage
<pre>show ip slp counter</pre> <p>Displays SLP packet counters.</p> <p>Command mode: All</p>
<pre>clear ip slp counter</pre> <p>Clears SLP packet counters.</p> <p>Command mode: Privileged EXEC</p>

Use the following command to display SLP packet counters:

```
show ip slp counter
```

Command mode: All

```
SLP Send Counters:
  SLP DAAdvert           : 0
  SLP SrvRqst           : 0
  SLP SrvRply           : 0
  SLP SrvAck            : 0
  SLP AttrRqst          : 0
  SLP AttrRply          : 0
  SLP SrvTypeRqst       : 0
  SLP SrvReg            : 0
  SLP SrvDeReg          : 0
  SLP SrvTypeRply       : 0
  SLP SAAdvert          : 0
  SLP Unknown           : 0

SLP Receive Counters:
  SLP DAAdvert           : 0
  SLP SrvRqst           : 0
  SLP SrvRply           : 0
  SLP SrvAck            : 0
  SLP AttrRqst          : 0
  SLP AttrRply          : 0
  SLP SrvTypeRqst       : 0
  SLP SrvReg            : 0
  SLP SrvDeReg          : 0
  SLP SrvTypeRply       : 0
  SLP SAAdvert          : 0
  SLP Dropped            : 0
    Incorect pkt/dest    : 0
    Scopes mismatch      : 0
    Others                : 0
```

Statistics Dump

The following command dumps switch statistics:

```
show counters
```

Use the dump command to dump all switch statistics (40K or more, depending on your configuration). This data can be used to tune or debug switch performance.

If you want to capture dump data to a file, set your communication software on your workstation to capture session data prior to issuing the dump command.

Chapter 4. Configuration Commands

This chapter discusses how to use the Command Line Interface (CLI) for making, viewing, and saving switch configuration changes. Many of the commands, although not new, display more or different information than in the previous version. Important differences are called out in the text.

Table 140. General Configuration Commands

Command Syntax and Usage
<pre>show running-config</pre> <p>Dumps current configuration to a script file.</p> <p>Command mode: Privileged EXEC</p> <p>For details, see page 490.</p>
<pre>show running-config diff</pre> <p>Displays running configuration changes that have been applied but not saved to flash memory.</p> <p>Command mode: Privileged EXEC</p>
<pre>copy running-config backup-config</pre> <p>Copy the current (running) configuration from switch memory to the backup-config partition.</p> <p>Command mode: Privileged EXEC</p> <p>For details, see page 491.</p>
<pre>copy running-config startup-config</pre> <p>Copy the current (running) configuration from switch memory to the startup-config partition.</p> <p>Command mode: Privileged EXEC</p>
<pre>copy running-config {ftp tftp sftp} [data-port extm-port mgt-port]</pre> <p>Backs up current configuration to a file on the selected FTP/TFTP/SFTP server. Select a management port, or press Enter to use the default (management) port.</p> <p>Command mode: Privileged EXEC</p>

Table 140. General Configuration Commands

Command Syntax and Usage
<pre>copy {ftp tftp sftp} running-config [data-port extm-port mgt-port]</pre> <p>Restores current configuration from a FTP/TFTP/SFTP server. Select a management port, or press Enter to use the default (management) port.</p> <p>Command mode: Privileged EXEC</p> <p>For details, see page 492.</p>
<pre>copy {tftp sftp} {ca-cert host-key host-cert}</pre> <p>Import interface used by NIST certified test laboratories for USGv6 (NIST SP 500-267) certification purposes. Required for RSA digital signature authentication verification during IKEv2 interoperability testing. Uses TFTP or SFTP to import:</p> <ul style="list-style-type: none">– ca-cert: Certificate Authority root certificate– host-key: host private key– host-cert: host public key <p>Command mode: Privileged EXEC</p>

Viewing and Saving Changes

As you use the configuration commands to set switch parameters, the changes you make take effect immediately. You do not need to apply them. Configuration changes are lost the next time the switch boots, unless you save the changes.

You can view all running configuration changes that have been applied but not saved to flash memory using the `show running-config diff` command in Privileged EXEC mode.

Note: Some operations can override the settings of the Configuration commands. Therefore, settings you view using the Configuration commands (for example, port status) might differ from run-time information that you view using the Information commands. The Information commands display current run-time information of switch parameters.

Saving the Configuration

You must save configuration settings to flash memory, so the CN4093 reloads the settings after a reset.

Note: If you do not save the changes, they will be lost the next time the system is rebooted.

To save the new configuration, enter the following command:

```
Router# copy running-config startup-config
```

When you save configuration changes, the changes are saved to the *active* configuration block. For instructions on selecting the configuration to run at the next system reset, see [“Selecting a Configuration Block” on page 518](#).

System Configuration

These commands provide configuration of switch management parameters such as user and administrator privilege mode passwords, Web-based management settings, and management access lists.

Table 141. System Configuration Commands

Command Syntax and Usage
<pre>system date <yyy> <mm> <dd></pre> <p>Prompts the user for the system date. The date retains its value when the switch is reset.</p> <p>Command mode: Global configuration</p>
<pre>system time <hh>:<mm>:<ss></pre> <p>Configures the system time using a 24-hour clock format. The time retains its value when the switch is reset.</p> <p>Command mode: Global configuration</p>
<pre>system timezone</pre> <p>Configures the time zone where the switch resides. You are prompted to select your location (continent, country, region) by the timezone wizard. Once a region is selected, the switch updates the time to reflect local changes to Daylight Saving Time, etc.</p> <p>Command mode: Global configuration</p>
<pre>[no] system daylight</pre> <p>Disables or enables daylight saving time in the system clock. When enabled, the switch will add an extra hour to the system clock so that it is consistent with the local clock. By default, this option is disabled.</p> <p>Command mode: Global configuration</p>
<pre>terminal-length <0-300></pre> <p>Configures the number of lines per screen displayed in the CLI for the current session. A value of 0 disables paging. By default, it is set to the corresponding <code>line vty length</code> or <code>line console length</code> value in effect at login.</p> <p>Command mode: All</p>
<pre>line console length <0-300></pre> <p>Configures the number of lines per screen displayed in the CLI by default for console sessions. Setting it to 0 disables paging. The default value is 28.</p> <p>Command mode: Global configuration</p>
<pre>no line console</pre> <p>Sets <code>line console length</code> to the default value of 28.</p> <p>Command mode: Global configuration</p>
<pre>line vty length <0-300></pre> <p>Sets the default number of lines per screen displayed for Telnet and SSH sessions. A value of 0 disables paging. The default value is 28.</p> <p>Command mode: Global configuration</p>

Table 141. System Configuration Commands (continued)

Command Syntax and Usage	
no line vty	<p>Sets line vty length to the default value of 28.</p> <p>Command mode: Global configuration</p>
system idle <0-60>	<p>Sets the idle timeout for CLI sessions in minutes. The default value is 10 minutes. A value of 0 disables system idle.</p> <p>Command mode: Global configuration</p>
system linkscan {fast normal slow}	<p>Configures the link scan interval used to poll the status of ports.</p> <p>Command mode: Global configuration</p>
system notice <maximum 1024 character multi-line login notice> <'.' to end>	<p>Displays a login notice immediately before the "Enter password:" prompt. This notice can contain up to 1024 characters and new lines.</p> <p>Command mode: Global configuration</p>
[no] banner <1-80 characters>	<p>Configures a login banner of up to 80 characters. When a user or administrator logs into the switch, the login banner is displayed. It is also displayed as part of the output from the <code>show sys-info</code> command.</p> <p>Command mode: Global configuration</p>
[no] hostname <character string>	<p>Enables or disables displaying of the host name (system administrator's name) in the Command Line Interface (CLI).</p> <p>Command mode: Global configuration</p>
[no] system dhcp [extm mgt]	<p>Enables or disables Dynamic Host Control Protocol for setting the IP address on the selected interface. When enabled, the IP address obtained from the DHCP server overrides the static IP address. The default setting is enabled.</p> <p>Command mode: Global configuration</p>
[no] system reset-control	<p>Enables or disables the reset control flag. When enabled, the switch continues to function after a crash of the main processor, using the last known Layer 2/3 information.</p> <p>Command mode: Global configuration</p>
[no] system packet-logging	<p>Enables or disables logging of packets that come to the CPU. The default setting is enabled.</p> <p>Command mode: Global configuration</p>

Table 141. System Configuration Commands (continued)

Command Syntax and Usage
<pre>[no] boot strict enable</pre> <p>Enables or disables switch operation in security strict mode. When enabled, the authentication and privacy protocols and algorithms of the device are compliant with NIST SP-800-131A, with non-compliant protocols and algorithms disabled.</p> <p>Setting will be applied and device will be reset to default factory configuration after reboot.</p> <p>The default setting is disabled.</p> <p>Command mode: Global configuration</p>
<pre>show boot strict</pre> <p>Displays the current security strict mode status.</p> <p>Command mode: Global configuration</p>
<pre>show system</pre> <p>Displays the current system parameters.</p> <p>Command mode: All</p>

System Error Disable and Recovery Configuration

The Error Disable and Recovery feature allows the switch to automatically disable a port if an error condition is detected on the port. The port remains in the error-disabled state until it is re-enabled manually, or re-enabled automatically by the switch after a timeout period has elapsed. The error-disabled state of a port does not persist across a system reboot.

Table 142. Error Disable Configuration Commands

Command Syntax and Usage
<pre>errdisable timeout <30 - 86400></pre> <p>Configures the error-recovery timeout, in seconds. After the timer expires, the switch attempts to re-enable the port. The default value is 300.</p> <p>Note: When you change the timeout value, all current error-recovery timers are reset.</p> <p>Command mode: Global configuration</p>
<pre>errdisable recovery</pre> <p>Globally enables automatic error-recovery for error-disabled ports. The default setting is disabled.</p> <p>Note: Each port must have error-recovery enabled to participate in automatic error recovery.</p> <p>Command mode: Global configuration</p>
<pre>no errdisable recovery</pre> <p>Globally disables error-recovery for error-disabled ports; <code>errdisable recovery</code> is disabled globally by default.</p> <p>Command mode: All</p>
<pre>show errdisable</pre> <p>Displays the current system Error Disable configuration.</p> <p>Command mode: All</p>

System Host Log Configuration

Table 143. Host Log Configuration Commands

Command Syntax and Usage
<pre>[no] logging host <1-2> address <IP address> [data-port extm-port mgt-port]</pre> <p>Sets the IPv4 address of the first or second syslog host.</p> <p>Command mode: Global configuration</p>
<pre>[no] logging host <1-2> address6 <IP address> [data-port extm-port mgt-port]</pre> <p>Sets the IPv6 address of the first or second syslog host.</p> <p>Command mode: Global configuration</p>
<pre>logging host <1-2> severity <0-7></pre> <p>This option sets the severity level of the first or second syslog host displayed. The default is 7, which means log all severity levels.</p> <p>Command mode: Global configuration</p>
<pre>logging host <1-2> facility <0-7></pre> <p>This option sets the facility level of the first or second syslog host displayed. The default is 0.</p> <p>Command mode: Global configuration</p>
<pre>logging source-interface <1-5></pre> <p>Sets the loopback interface number for syslogs.</p> <p>Command mode: Global configuration</p>
<pre>logging console</pre> <p>Enables delivering syslog messages to the console. It is enabled by default.</p> <p>Command mode: Global configuration</p>
<pre>no logging console</pre> <p>Disables delivering syslog messages to the console. When necessary, disabling <code>console</code> ensures the switch is not affected by syslog messages. It is enabled by default.</p> <p>Command mode: Global configuration</p>
<pre>[no] logging synchronous [level <0-7> all]</pre> <p>Enables or disables synchronous logging messages. When enabled, logging messages are displayed asynchronously.</p> <p>The <code>level</code> parameter sets the message severity level. Messages with a severity level equal to or higher than this value are displayed asynchronously. Low numbers indicate greater severity. <code>All</code> displays all messages asynchronously, regardless the severity level. The default setting is 2.</p> <p>Command mode: Global configuration</p>

Table 143. Host Log Configuration Commands

Command Syntax and Usage	
logging console severity <0-7>	<p>Sets the severity level of system log messages to display via the console, Telnet, and SSH. The system displays only messages with the selected severity level and above. For example, if you set the console severity to 2, only messages with severity level of 1 and 2 are displayed. The default is 7, which means log all severity levels.</p> <p>Command mode: Global configuration</p>
no logging console severity	<p>Disables delivering syslog messages to the console based on severity.</p> <p>Command mode: Global configuration</p>
[no] logging buffer severity <0-7>	<p>Sets the severity level of system log messages that are written to flash buffer. The system saves only messages with the selected severity level and above. For example, if you set the buffer severity to 2, only messages with severity level of 1 and 2 are saved.</p> <p>Command mode: Global configuration</p>
[no] logging log [<feature>]	<p>Displays a list of features for which syslog messages can be generated. You can choose to enable/disable specific features (such as vlans, stg, or ssh), or enable/disable syslog on all available features.</p> <p>Command mode: Global configuration</p>
[no] logging pdrop enable	<p>Enables or disables packet drop logging. By default, the switch generates these messages once every 30 minutes.</p> <p>Command mode: Global configuration</p>
logging pdrop interval <0-30>	<p>Sets the packet drop logging interval. The default value is 30.</p> <p>Command mode: Global configuration</p>
show logging [severity <severity level>] [reverse]	<p>Displays the current syslog settings, followed by the most recent 2000 syslog messages, as displayed by the show logging messages command. For details, see page 27.</p> <p>The reverse option displays the output in reverse order, from the newest entry to the oldest.</p> <p>Command mode: All</p>

SSH Server Configuration

For the CN4093 10Gb Converged Scalable Switch, these commands enable Secure Shell access from any SSH client.

Table 144. SSH Server Configuration Commands

Command Syntax and Usage
<pre>ssh scp-password</pre> <p>Set the administration password for SCP access. Command mode: Global configuration</p>
<pre>ssh generate-host-key</pre> <p>Generate the RSA host key. Command mode: Global configuration</p>
<pre>ssh port <TCP port number></pre> <p>Sets the SSH server port number. Command mode: Global configuration</p>
<pre>ssh scp-enable</pre> <p>Enables the SCP apply and save. Command mode: Global configuration</p>
<pre>no ssh scp-enable</pre> <p>Disables the SCP apply and save. Command mode: Global configuration</p>
<pre>ssh enable</pre> <p>Enables the SSH server. Command mode: Global configuration</p>
<pre>no ssh enable</pre> <p>Disables the SSH server. Command mode: Global configuration</p>
<pre>show ssh</pre> <p>Displays the current SSH server configuration. Command mode: All</p>

RADIUS Server Configuration

Table 145. RADIUS Server Configuration Commands

Command Syntax and Usage	
[no] radius-server primary-host <IP address>	<p>Sets the primary RADIUS server address.</p> <p>Command mode: Global configuration</p>
[no] radius-server secondary-host <IP address>	<p>Sets the secondary RADIUS server address.</p> <p>Command mode: Global configuration</p>
radius-server primary-host <IP address> key <1-32 characters>	<p>This is the primary shared secret between the switch and the RADIUS server(s).</p> <p>Command mode: Global configuration</p>
radius-server secondary-host <IP address> key <1-32 characters>	<p>This is the secondary shared secret between the switch and the RADIUS server(s).</p> <p>Command mode: Global configuration</p>
[default] radius-server port <UDP port number>	<p>Enter the number of the UDP port to be configured, between 1500 - 3000. The default is 1645.</p> <p>Command mode: Global configuration</p>
radius-server retransmit <1-3>	<p>Sets the number of failed authentication requests before switching to a different RADIUS server. The default is 3 requests.</p> <p>Command mode: Global configuration</p>
radius-server timeout <1-10>	<p>Sets the amount of time, in seconds, before a RADIUS server authentication attempt is considered to have failed. The default is 3 seconds.</p> <p>Command mode: Global configuration</p>
ip radius source-interface loopback <1-5>	<p>Sets the RADIUS source loopback interface.</p> <p>Command mode: Global configuration</p>
[no] radius-server backdoor	<p>Enables or disables the RADIUS backdoor for Telnet/SSH/HTTP/HTTPS. The default value is disabled.</p> <p>To obtain the RADIUS backdoor password for your switch, contact your Service and Support line.</p> <p>Command mode: Global configuration</p>

Table 145. RADIUS Server Configuration Commands

Command Syntax and Usage	
[no] radius-server secure-backdoor	<p>Enables or disables the RADIUS backdoor using secure password for Telnet/SSH/HTTP/HTTPS. This command does not apply when RADIUS backdoor is enabled.</p> <p>Command mode: Global configuration</p>
radius-server enable	<p>Enables the RADIUS server.</p> <p>Command mode: Global configuration</p>
no radius-server enable	<p>Disables the RADIUS server.</p> <p>Command mode: Global configuration</p>
show radius-server	<p>Displays the current RADIUS server parameters.</p> <p>Command mode: All</p>

TACACS+ Server Configuration

TACACS (Terminal Access Controller Access Control system) is an authentication protocol that allows a remote access server to forward a user's logon password to an authentication server to determine whether access can be allowed to a given system. TACACS is not an encryption protocol, and therefore less secure than TACACS+ and Remote Authentication Dial-In User Service (RADIUS) protocols. Both TACACS and TACACS+ are described in RFC 1492.

TACACS+ protocol is more reliable than RADIUS, as TACACS+ uses the Transmission Control Protocol (TCP) whereas RADIUS uses the User Datagram Protocol (UDP). Also, RADIUS combines authentication and authorization in a user profile, whereas TACACS+ separates the two operations.

TACACS+ offers the following advantages over RADIUS as the authentication device:

- TACACS+ is TCP-based, so it facilitates connection-oriented traffic.
- It supports full-packet encryption, as opposed to password-only in authentication requests.
- It supports de-coupled authentication, authorization, and accounting.

Table 146. TACACS+ Server Configuration Commands

Command Syntax and Usage	
[no] tacacs primary-host <IP address>	Defines the primary TACACS+ server address. Command mode: Global configuration
[no] tacacs secondary-host <IP address>	Defines the secondary TACACS+ server address. Command mode: Global configuration
[no] tacacs primary-host <IP address> key <1-32 characters>	This is the primary shared secret between the switch and the TACACS+ server(s). Command mode: Global configuration
[no] tacacs secondary-host <IP address> key <1-32 characters>	This is the secondary shared secret between the switch and the TACACS+ server(s). Command mode: Global configuration
[default] tacacs port <TCP port number>	Enter the number of the TCP port to be configured, between 1 and 65000. The default is 49. Command mode: Global configuration
tacacs retransmit <1-3>	Sets the number of failed authentication requests before switching to a different TACACS+ server. The default is 3 requests. Command mode: Global configuration

Table 146. TACACS+ Server Configuration Commands (continued)

Command Syntax and Usage	
<code>tacacs attempts <1-10></code>	<p>Sets the number of failed login attempts before disconnecting the user. The default is 2 attempts.</p> <p>Command mode: Global configuration</p>
<code>tacacs timeout <4-15></code>	<p>Sets the amount of time, in seconds, before a TACACS+ server authentication attempt is considered to have failed. The default is 5 seconds.</p> <p>Command mode: Global configuration</p>
<code>ip tacacs source-interface loopback <1-5></code>	<p>Sets the TACACS+ source loopback interface.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs user-mapping {<0-15> user oper admin}</code>	<p>Maps a TACACS+ authorization level to a switch user level. Enter a TACACS+ authorization level (0-15), followed by the corresponding switch user level.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs backdoor</code>	<p>Enables or disables the TACACS+ back door for Telnet, SSH/SCP, or HTTP/HTTPS.</p> <p>Enabling this feature allows you to bypass the TACACS+ servers. It is recommended that you use Secure Backdoor to ensure the switch is secured, because Secure Backdoor disallows access through the back door when the TACACS+ servers are responding.</p> <p>The default setting is disabled.</p> <p>To obtain the TACACS+ backdoor password for your CN4093, contact your Service and Support line.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs secure-backdoor</code>	<p>Enables or disables TACACS+ secure back door access through Telnet, SSH/SCP, or HTTP/HTTPS only when the TACACS+ servers are not responding.</p> <p>This feature is recommended to permit access to the switch when the TACACS+ servers become unresponsive. If no back door is enabled, the only way to gain access when TACACS+ servers are unresponsive is to use the back door via the console port.</p> <p>The default is disabled.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs privilege-mapping</code>	<p>Enables or disables TACACS+ privilege-level mapping.</p> <p>The default value is disabled.</p> <p>Command mode: Global configuration</p>

Table 146. TACACS+ Server Configuration Commands (continued)

Command Syntax and Usage	
<code>[no] tacacs-server password-change</code>	<p>Enables or disables TACACS+ password change. The default value is <code>disabled</code>.</p> <p>Command mode: Global configuration</p>
<code>primary-password</code>	<p>Configures the password for the primary TACACS+ server. The CLI will prompt you for input.</p> <p>Command mode: Global configuration</p>
<code>secondary-password</code>	<p>Configures the password for the secondary TACACS+ server. The CLI will prompt you for input.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs-server command-authorization</code>	<p>Enables or disables TACACS+ command authorization.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs-server command-logging</code>	<p>Enables or disables TACACS+ command logging.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs-server directed-request [restricted no-truncate]</code>	<p>Enables or disables TACACS+ directed request, which uses a specified TACACS+ server for authentication, authorization, accounting. When enabled, When directed-request is enabled, each user must add a configured TACACS+ server hostname to the username (for example, <code>username@hostname</code>) during login.</p> <p>This command allows the following options:</p> <ul style="list-style-type: none"> – Restricted: Only the username is sent to the specified TACACS+ server. – No-truncate: The entire login string is sent to the TACACS+ server. <p>Command mode: Global configuration</p>
<code>[no] tacacs-server enable</code>	<p>Enables or disables the TACACS+ server. By default, the server is disabled.</p> <p>Command mode: Global configuration</p>
<code>[no] tacacs-server accounting-enable</code>	<p>Enables or disables TACACS+ accounting.</p> <p>Command mode: Global configuration</p>
<code>show tacacs-server</code>	<p>Displays current TACACS+ configuration parameters.</p> <p>Command mode: All</p>

LDAP Server Configuration

LDAP (Lightweight Directory Access Protocol) is an authentication protocol that allows a remote access server to forward a user's logon password to an authentication server to determine whether access can be allowed to a given system.

Table 147. LDAP Server Configuration Commands

Command Syntax and Usage	
[no] ldap-server primary-host <IP address>	<p>Sets the primary LDAP server address.</p> <p>Command mode: Global configuration</p>
[no] ldap-server secondary-host <IP address>	<p>Sets the secondary LDAP server address.</p> <p>Command mode: Global configuration</p>
[default] ldap-server port <UDP port number>	<p>Enter the number of the UDP port to be configured, between 1 - 65000. The default is 389.</p> <p>Command mode: Global configuration</p>
ldap-server retransmit <1-3>	<p>Sets the number of failed authentication requests before switching to a different LDAP server. The default is 3 requests.</p> <p>Command mode: Global configuration</p>
ldap-server timeout <4-15>	<p>Sets the amount of time, in seconds, before a LDAP server authentication attempt is considered to have failed. The default is 5 seconds.</p> <p>Command mode: Global configuration</p>
ldap-server domain [<1-128 characters> none]	<p>Sets the domain name for the LDAP server. Enter the full path for your organization. For example:</p> <p>ou=people,dc=mydomain,dc=com</p> <p>Command mode: Global configuration</p>
[no] ldap-server backdoor	<p>Enables or disables the LDAP back door for Telnet, SSH/SCP, or HTTP/HTTPS. The default setting is disabled.</p> <p>To obtain the LDAP back door password for your CN4093, contact your Service and Support line.</p> <p>Command mode: Global configuration</p>

Table 147. LDAP Server Configuration Commands (continued)

Command Syntax and Usage	
<code>ldap-server enable</code>	Enables the LDAP server. Command mode: Global configuration
<code>no ldap-server enable</code>	Disables the LDAP server. Command mode: Global configuration
<code>show ldap-server</code>	Displays the current LDAP server parameters. Command mode: All

NTP Server Configuration

These commands allow you to synchronize the switch clock to a Network Time Protocol (NTP) server. By default, this option is disabled.

Table 148. NTP Server Configuration Commands

Command Syntax and Usage
<p><code>[no] ntp primary-server <IP address>[data-port extm-port mgt-port]</code></p> <p>Prompts for the IP addresses of the primary NTP server to which you want to synchronize the switch clock. Select the port to use for data transfer:</p> <ul style="list-style-type: none"> – internal management port (mgt) – data port (data) – external management port (extm) <p>Command mode: Global configuration</p>
<p><code>[no] ntp secondary-server <IP address>[data-port extm-port mgt-port]</code></p> <p>Prompts for the IP addresses of the secondary NTP server to which you want to synchronize the switch clock. Select the port to use for data transfer:</p> <ul style="list-style-type: none"> – internal management port (mgt) – data port (data) – external management port (extm) <p>Command mode: Global configuration</p>
<p><code>[no] ntp ipv6 primary-server <IPv6 address>[data-port extm-port mgt-port]</code></p> <p>Prompts for the IPv6 addresses of the primary NTP server to which you want to synchronize the switch clock. Select the port to use for data transfer:</p> <ul style="list-style-type: none"> – internal management port (mgt) – data port (data) – external management port (extm) <p>Note: To delete the IPv6 primary server, use the following command: <code>no ntp ipv6 primary-server <IPv6 address></code></p> <p>Command mode: Global configuration</p>
<p><code>[no] ntp ipv6 secondary-server <IPv6 address>[data-port extm-port mgt-port]</code></p> <p>Prompts for the IPv6 addresses of the secondary NTP server to which you want to synchronize the switch clock. Select the port to use for data transfer:</p> <ul style="list-style-type: none"> – internal management port (mgt) – data port (data) – external management port (extm) <p>Note: To delete the IPv6 secondary server, use the following command: <code>no ntp ipv6 secondary-server <IPv6 address></code></p> <p>Command mode: Global configuration</p>

Table 148. NTP Server Configuration Commands

Command Syntax and Usage	
[no] ntp sync-logs	<p>Enables or disables informational logs for NTP synchronization failures. Default setting is enabled.</p> <p>Command mode: Global configuration</p>
ntp offset <0-86400>	<p>Configures the minimum offset in seconds between the switch clock and the NTP server that triggers a system log message.</p> <p>The default value is 300.</p> <p>Command mode: Global configuration</p>
no ntp offset	<p>Resets the NTP offset to the default 300 seconds value.</p> <p>Command mode: Global configuration</p>
ntp interval <5-44640>	<p>Specifies the interval, that is, how often, in minutes, to re-synchronize the switch clock with the NTP server.</p> <p>The default value is 1440.</p> <p>Command mode: Global configuration</p>
ntp source loopback <1-5>	<p>Sets the NTP source loopback interface.</p> <p>Command mode: Global configuration</p>
[no] ntp authenticate	<p>Enables or disables NTP authentication. The default setting is disabled. When authentication is enabled, the switch transmits NTP packets with the MAC address appended.</p> <p>Command mode: Global configuration</p>
ntp primary-key <1-65534>	<p>Adds the NTP primary server key, which specifies which MD5 key is used by the primary server.</p> <p>Command mode: Global configuration</p>
ntp secondary-key <1-65534>	<p>Adds the NTP secondary server key, which specifies which MD5 key is used by the secondary server.</p> <p>Command mode: Global configuration</p>
ntp trusted-key <1-65534> 0	<p>Adds an MD5 key code to the list of trusted keys. Enter 0 (zero) to remove the selected key code.</p> <p>Command mode: Global configuration</p>

Table 148. NTP Server Configuration Commands

Command Syntax and Usage
<pre>ntp enable</pre> <p>Enables the NTP synchronization service. Command mode: Global configuration</p>
<pre>no ntp enable</pre> <p>Disables the NTP synchronization service. Command mode: Global configuration</p>
<pre>show ntp</pre> <p>Displays the current NTP service settings. Command mode: All</p>

NTP MD5 Key Commands

Table 149. NTP MD5 KEy Configuration Options

Command Syntax and Usage
<pre>ntp message-digest-key <1-65534> md5-key <1-16 characters></pre> <p>Configures the selected MD5 key code. Command mode: Global configuration</p>
<pre>no ntp message-digest-key <1-65534></pre> <p>Deletes the selected MD5 key code. Command mode: Global configuration</p>

System SNMP Configuration

IBM Networking OS supports SNMP-based network management. In SNMP model of network management, a management station (client/manager) accesses a set of variables known as MIBs (Management Information Base) provided by the managed device (agent). If you are running an SNMP network management station on your network, you can manage the switch using the following standard SNMP MIBs:

- MIB II (RFC 1213)
- Ethernet MIB (RFC 1643)
- Bridge MIB (RFC 1493)

An SNMP agent is a software process on the managed device that listens on UDP port 161 for SNMP messages. Each SNMP message sent to the agent contains a list of management objects to retrieve or to modify.

SNMP parameters that can be modified include:

- System name
- System location
- System contact
- Use of the SNMP system authentication trap function
- Read community string
- Write community string
- Trap community strings

Table 150. System SNMP Commands

Command Syntax and Usage
<pre>snmp-server name <1-64 characters></pre> <p>Configures the name for the system. The name can have a maximum of 64 characters.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server location <1-64 characters></pre> <p>Configures the name of the system location. The location can have a maximum of 64 characters.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server contact <1-64 characters></pre> <p>Configures the name of the system contact. The contact can have a maximum of 64 characters.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server read-community <1-32 characters></pre> <p>Configures the SNMP read community string. The read community string controls SNMP “get” access to the switch. It can have a maximum of 32 characters. The default read community string is <i>public</i>.</p> <p>Command mode: Global configuration</p>

Table 150. System SNMP Commands

Command Syntax and Usage	
<code>snmp-server write-community <1-32 characters></code>	<p>Configures the SNMP write community string. The write community string controls SNMP “set” and “get” access to the switch. It can have a maximum of 32 characters. The default write community string is <i>private</i>.</p> <p>Command mode: Global configuration</p>
<code>[no] snmp-server read-community-additional <1-32 characters></code>	<p>Adds or removes an additional SNMP read community string. Up to 7 additional read community strings are supported.</p> <p>Command mode: Global configuration</p>
<code>[no] snmp-server write-community-additional <1-32 characters></code>	<p>Adds or removes an additional SNMP write community string. Up to 7 additional write community strings are supported.</p> <p>Command mode: Global configuration</p>
<code>snmp-server trap-source { <interface number> loopback <1-5> }</code>	<p>Configures the source interface for SNMP traps.</p> <p>To send traps through the management ports, specify interface 128.</p> <p>Command mode: Global configuration</p>
<code>snmp-server host <trap host IP address> <trap host community string></code>	<p>Adds a trap host server.</p> <p>Command mode: Global configuration</p>
<code>no snmp-server host <trap host IP address></code>	<p>Removes the trap host server.</p> <p>Command mode: Global configuration</p>
<code>snmp-server timeout <1-30></code>	<p>Sets the timeout value for the SNMP state machine, in minutes.</p> <p>Command mode: Global configuration</p>
<code>[no] snmp-server authentication-trap</code>	<p>Enables or disables the use of the system authentication trap facility. The default setting is disabled.</p> <p>Command mode: Global configuration</p>
<code>[no] snmp-server link-trap <port alias or number></code>	<p>Enables or disables the sending of SNMP link up and link down traps for the specified port. The default setting is enabled.</p> <p>Command mode: Global configuration</p>
<code>show snmp-server</code>	<p>Displays the current SNMP configuration.</p> <p>Command mode: All</p>

SNMPv3 Configuration

SNMP version 3 (SNMPv3) is an extensible SNMP Framework that supplements the SNMPv2 Framework by supporting the following:

- a new SNMP message format
- security for messages
- access control
- remote configuration of SNMP parameters

For more details on the SNMPv3 architecture please refer to RFC3411 to RFC3418.

Table 151. SNMPv3 Configuration Commands

Command Syntax and Usage
<pre>snmp-server user <I-16></pre> <p>This command allows you to create a user security model (USM) entry for an authorized user. You can also configure this entry through SNMP.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 261.</p>
<pre>snmp-server view <I-128></pre> <p>This command allows you to create different MIB views.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 262.</p>
<pre>snmp-server access <I-32></pre> <p>This command allows you to specify access rights. The View-based Access Control Model defines a set of services that an application can use for checking access rights of the user. You need access control when you have to process retrieval or modification request from an SNMP entity.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 263.</p>
<pre>snmp-server group <I-16></pre> <p>A group maps the user name to the access group names and their access rights needed to access SNMP management objects. A group defines the access rights assigned to all names that belong to a particular group.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 264.</p>
<pre>snmp-server community <I-16></pre> <p>The community table contains objects for mapping community strings and version-independent SNMP message parameters.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 265.</p>

Table 151. SNMPv3 Configuration Commands (continued)

<pre>snmp-server target-address <I-16></pre> <p>This command allows you to configure destination information, consisting of a transport domain and a transport address. This is also termed as transport endpoint. The SNMP MIB provides a mechanism for performing source address validation on incoming requests, and for selecting community strings based on target addresses for outgoing notifications.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 266.</p>
<pre>snmp-server target-parameters <I-16></pre> <p>This command allows you to configure SNMP parameters, consisting of message processing model, security model, security level, and security name information. There may be multiple transport endpoints associated with a particular set of SNMP parameters, or a particular transport endpoint may be associated with several sets of SNMP parameters.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 267.</p>
<pre>snmp-server notify <I-16></pre> <p>A notification application typically monitors a system for particular events or conditions, and generates Notification-Class messages based on these events or conditions.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 268.</p>
<pre>snmp-server version {v1v2v3 v3only}</pre> <p>This command allows you to enable or disable the access to SNMP versions 1, 2 or 3. The default value is v1v2v3.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3</pre> <p>Displays the current SNMPv3 configuration.</p> <p>Command mode: All</p>

User Security Model Configuration

You can make use of a defined set of user identities using this Security Model. An SNMP engine must have the knowledge of applicable attributes of a user.

These commands help you create a user security model entry for an authorized user. You need to provide a security name to create the USM entry.

Table 152. User Security Model Configuration Commands

Command Syntax and Usage
<pre>snmp-server user <1-16> name <1-32 characters></pre> <p>This command allows you to configure a string that represents the name of the user. This is the login name that you need in order to access the switch.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server user <1-16> authentication-protocol {md5 sha none} authentication-password <password value></pre> <p>This command allows you to configure the authentication protocol and password.</p> <p>The authentication protocol can be HMAC-MD5-96 or HMAC-SHA-96 for compatibility mode, HMAC-SHA-96 for security strict mode, or none. The default algorithm is none.</p> <p>MD5 authentication protocol is not available in security strict mode if you do not select SNMPv3 account backward compatibility.</p> <p>When you configure an authentication algorithm, you must provide a password, otherwise you will get an error message during validation. This command allows you to create or change your password for authentication.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server user <1-16> privacy-protocol {aes des none} privacy-password <password value></pre> <p>This command allows you to configure the type of privacy protocol and the privacy password.</p> <p>The privacy protocol protects messages from disclosure. The options are <code>des</code> (CBC-DES Symmetric Encryption Protocol), <code>aes</code> (AES-128 Advanced Encryption Standard Protocol) or <code>none</code>. If you specify <code>des</code> as the privacy protocol, then make sure that you have selected one of the authentication protocols (MD5 or HMAC-SHA-96). In security strict mode, if you do not select SNMPv3 account backward compatibility, make sure to disable <code>des</code> privacy protocol. If you specify <code>aes</code> as the privacy protocol, make sure that you have selected HMAC-SHA-256 authentication protocol. If you select <code>none</code> as the authentication protocol, you will get an error message.</p> <p>You can create or change the privacy password.</p> <p>Command mode: Global configuration</p>

Table 152. User Security Model Configuration Commands

Command Syntax and Usage
<pre>no snmp-server user <1-16></pre> <p>Deletes the USM user entries.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 user <1-16></pre> <p>Displays the USM user entries.</p> <p>Command mode: All</p>

SNMPv3 View Configuration

Note that the first five default `vacmViewTreeFamily` entries cannot be removed, and their names cannot be changed.

Table 153. SNMPv3 View Configuration Commands

Command Syntax and Usage
<pre>snmp-server view <1-128> name <1-32 characters></pre> <p>This command defines the name for a family of view subtrees.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server view <1-128> tree <1-64 characters></pre> <p>This command defines MIB tree, which when combined with the corresponding mask defines a family of view subtrees.</p> <p>Command mode: Global configuration</p>
<pre>[no] snmp-server view <1-128> mask <1-32 characters></pre> <p>This command defines the bit mask, which in combination with the corresponding tree defines a family of view subtrees.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server view <1-128> type {included excluded}</pre> <p>This command indicates whether the corresponding instances of <code>vacmViewTreeFamilySubtree</code> and <code>vacmViewTreeFamilyMask</code> define a family of view subtrees, which is included in or excluded from the MIB view.</p> <p>Command mode: Global configuration</p>
<pre>no snmp-server view <1-128></pre> <p>Deletes the <code>vacmViewTreeFamily</code> group entry.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 view <1-128></pre> <p>Displays the current <code>vacmViewTreeFamily</code> configuration.</p> <p>Command mode: All</p>

View-based Access Control Model Configuration

The view-based Access Control Model defines a set of services that an application can use for checking access rights of the user. Access control is needed when the user has to process SNMP retrieval or modification request from an SNMP entity.

Table 154. View-based Access Control Model Commands

Command Syntax and Usage	
<code>snmp-server access <1-32> name <1-32 characters></code>	<p>Defines the name of the group.</p> <p>Command mode: Global configuration</p>
<code>snmp-server access <1-32> prefix <1-32 characters></code>	<p>Defines the name of the context. An SNMP context is a collection of management information that an SNMP entity can access. An SNMP entity has access to many contexts. For more information on naming the management information, see RFC2571, the SNMP Architecture document. The view-based Access Control Model defines a table that lists the locally available contexts by contextName.</p> <p>Command mode: Global configuration</p>
<code>snmp-server access <1-32> security {usm snmpv1 snmpv2}</code>	<p>Allows you to select the security model to be used.</p> <p>Command mode: Global configuration</p>
<code>snmp-server access <1-32> level {noAuthNoPriv authNoPriv authPriv}</code>	<p>Defines the minimum level of security required to gain access rights. The level <code>noAuthNoPriv</code> means that the SNMP message will be sent without authentication and without using a privacy protocol. The level <code>authNoPriv</code> means that the SNMP message will be sent with authentication but without using a privacy protocol. The <code>authPriv</code> means that the SNMP message will be sent both with authentication and using a privacy protocol.</p> <p>Command mode: Global configuration</p>
<code>snmp-server access <1-32> match {exact prefix}</code>	<p>If the value is set to <code>exact</code>, then all the rows whose contextName exactly matches the prefix are selected. If the value is set to <code>prefix</code> then the all the rows where the starting octets of the contextName exactly match the prefix are selected.</p> <p>Command mode: Global configuration</p>
<code>snmp-server access <1-32> read-view <1-32 characters></code>	<p>Defines a read view name that allows you read access to a particular MIB view. If the value is empty or if there is no active MIB view having this value then no access is granted.</p> <p>Command mode: Global configuration</p>

Table 154. View-based Access Control Model Commands (continued)

Command Syntax and Usage
<pre>snmp-server access <1-32> write-view <1-32 characters></pre> <p>Defines a write view name that allows you write access to the MIB view. If the value is empty or if there is no active MIB view having this value then no access is granted.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server access <1-32> notify-view <1-32 characters></pre> <p>Defines a notify view name that allows you notify access to the MIB view.</p> <p>Command mode: Global configuration</p>
<pre>no snmp-server access <1-32></pre> <p>Deletes the View-based Access Control entry.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 access <1-32></pre> <p>Displays the View-based Access Control configuration.</p> <p>Command mode: All</p>

SNMPv3 Group Configuration

Table 155. SNMPv3 Group Configuration Commands

Command Syntax and Usage
<pre>snmp-server group <1-16> security {usm snmpv1 snmpv2}</pre> <p>Defines the security model.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server group <1-16> user-name <1-32 characters></pre> <p>Sets the user name as defined in the following command on page 261: <pre>snmp-server user <1-16> name <1-32 characters></pre></p> <p>Command mode: Global configuration</p>
<pre>snmp-server group <1-16> group-name <1-32 characters></pre> <p>The name for the access group as defined in the following command: <pre>snmp-server access <1-32> name <1-32 characters></pre> on page 261.</p> <p>Command mode: Global configuration</p>
<pre>no snmp-server group <1-16></pre> <p>Deletes the vacmSecurityToGroup entry.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 group <1-16></pre> <p>Displays the current vacmSecurityToGroup configuration.</p> <p>Command mode: All</p>

SNMPv3 Community Table Configuration

These commands are used for configuring the community table entry. The configured entry is stored in the community table list in the SNMP engine. This table is used to configure community strings in the Local Configuration Datastore (LCD) of SNMP engine.

Table 156. SNMPv3 Community Table Configuration Commands

Command Syntax and Usage
<pre>snmp-server community <1-16> index <1-32 characters></pre> <p>Allows you to configure the unique index value of a row in this table.</p> <p>Command string: Global configuration</p>
<pre>snmp-server community <1-16> name <1-32 characters></pre> <p>Defines the user name as defined in the following command on page 261:</p> <pre>snmp-server user <1-16> name <1-32 characters></pre> <p>Command string: Global configuration</p>
<pre>snmp-server community <1-16> user-name <1-32 characters></pre> <p>Defines a readable string that represents the corresponding value of an SNMP community name in a security model.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server community <1-16> tag <1-255 characters></pre> <p>Allows you to configure a tag. This tag specifies a set of transport endpoints to which a command responder application sends an SNMP trap.</p> <p>Command mode: Global configuration</p>
<pre>no snmp-server community <1-16></pre> <p>Deletes the community table entry.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 community <1-16></pre> <p>Displays the community table configuration.</p> <p>Command mode: All</p>

SNMPv3 Target Address Table Configuration

These commands are used to configure the target transport entry. The configured entry is stored in the target address table list in the SNMP engine. This table of transport addresses is used in the generation of SNMP messages.

Table 157. Target Address Table Configuration Commands

Command Syntax and Usage
<pre>snmp-server target-address <1-16> address <IP address> name <1-32 characters></pre> <p>Allows you to configure the locally arbitrary, but unique identifier, target address name associated with this entry.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-address <1-16> name <1-32 characters> address <transport IP address></pre> <p>Configures a transport IPv4 address that can be used in the generation of SNMP traps.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-address <1-16> port <port number></pre> <p>Allows you to configure a transport address port that can be used in the generation of SNMP traps.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-address <1-16> taglist <1-255 characters></pre> <p>Allows you to configure a list of tags that are used to select target addresses for a particular operation.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-address <1-16> parameters-name <1-32 characters></pre> <p>Defines the name as defined in the following command on page 267: <pre>snmp-server target-parameters <1-16> name <1-32 characters></pre></p> <p>Command mode: Global configuration</p>
<pre>no snmp-server target-address <1-16></pre> <p>Deletes the Target Address Table entry.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 target-address <1-16></pre> <p>Displays the current Target Address Table configuration.</p> <p>Command mode: All</p>

SNMPv3 Target Parameters Table Configuration

You can configure the target parameters entry and store it in the target parameters table in the SNMP engine. This table contains parameters that are used to generate a message. The parameters include the message processing model (for example: SNMPv3, SNMPv2c, SNMPv1), the security model (for example: USM), the security name, and the security level (`noAuthNoPriv`, `authNoPriv`, or `authPriv`).

Table 158. Target Parameters Table Configuration Commands

Command Syntax and Usage	
<pre>snmp-server target-parameters <1-16> name <1-32 characters></pre>	<p>Allows you to configure the locally arbitrary, but unique, identifier that is associated with this entry.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-parameters <1-16> message {snmpv1 snmpv2c snmpv3}</pre>	<p>Allows you to configure the message processing model that is used to generate SNMP messages.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-parameters <1-16> security {usm snmpv1 snmpv2}</pre>	<p>Allows you to select the security model to be used when generating the SNMP messages.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-parameters <1-16> user-name <1-32 characters></pre>	<p>Defines the name that identifies the user in the USM table (page 261) on whose behalf the SNMP messages are generated using this entry.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server target-parameters <1-16> level {noAuthNoPriv authNoPriv authPriv}</pre>	<p>Allows you to select the level of security to be used when generating the SNMP messages using this entry. The level <code>noAuthNoPriv</code> means that the SNMP message will be sent without authentication and without using a privacy protocol. The level <code>authNoPriv</code> means that the SNMP message will be sent with authentication but without using a privacy protocol. The <code>authPriv</code> means that the SNMP message will be sent both with authentication and using a privacy protocol.</p> <p>Command mode: Global configuration</p>
<pre>no snmp-server target-parameters <1-16></pre>	<p>Deletes the <code>targetParamsTable</code> entry.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 target-parameters <1-16></pre>	<p>Displays the current <code>targetParamsTable</code> configuration.</p> <p>Command mode: All</p>

SNMPv3 Notify Table Configuration

SNMPv3 uses Notification Originator to send out traps. A notification typically monitors a system for particular events or conditions, and generates Notification-Class messages based on these events or conditions.

Table 159. Notify Table Commands

Command Syntax and Usage
<pre>snmp-server notify <1-16> name <1-32 characters></pre> <p>Defines a locally arbitrary, but unique, identifier associated with this SNMP notify entry.</p> <p>Command mode: Global configuration</p>
<pre>snmp-server notify <1-16> tag <1-255 characters></pre> <p>Allows you to configure a tag that contains a tag value which is used to select entries in the Target Address Table. Any entry in the <code>snmpTargetAddrTable</code>, that matches the value of this tag, is selected.</p> <p>Command mode: Global configuration</p>
<pre>no snmp-server notify <1-16></pre> <p>Deletes the notify table entry.</p> <p>Command mode: Global configuration</p>
<pre>show snmp-server v3 notify <1-16></pre> <p>Displays the current notify table configuration.</p> <p>Command mode: All</p>

System Access Configuration

The following table describes system access configuration commands.

Table 160. System Access Configuration Commands

Command Syntax and Usage	
<pre>access user user-password</pre>	<p>Sets the user (<code>user</code>) password. The user has no direct responsibility for switch management. The user view switch status information and statistics, but cannot make any configuration changes.</p> <p>This command will prompt for required information: current admin password, new password (up to 128 characters) and confirmation of the new password.</p> <p>Note: To disable the user account, set the password to null (no password).</p> <p>Command Mode: Global configuration</p>
<pre>access user operator-password</pre>	<p>Sets the operator (<code>oper</code>) password. The operator manages all functions of the switch. The operator can view all switch information and statistics and can reset ports.</p> <p>This command will prompt for required information: current admin password, new password (up to 128 characters) and confirmation of the new password.</p> <p>Note: To disable the operator account, set the password to null (no password). The default setting is disabled (no password).</p> <p>Command Mode: Global configuration</p>
<pre>access user administrator-password</pre>	<p>Sets the administrator (<code>admin</code>) password. The administrator has complete access to all menus, information, and configuration commands on the CN4093, including the ability to change both the user and administrator passwords.</p> <p>This command will prompt for required information: current admin password, new password (up to 128 characters) and confirmation of the new password.</p> <p>Access includes “oper” functions.</p> <p>Note: You cannot disable the administrator password.</p> <p>Command Mode: Global configuration</p>
<pre>[no] access http enable</pre>	<p>Enables or disables HTTP (Web) access to the Browser-Based Interface. It is disabled by default.</p> <p>Command mode: Global configuration</p>
<pre>[default] access http port [<i><port number></i>]</pre>	<p>Sets the switch port used for serving switch Web content. The default is HTTP port 80.</p> <p>Command mode: Global configuration</p>

Table 160. System Access Configuration Commands (continued)

Command Syntax and Usage
<pre>[no] access snmp {read-only read-write}</pre> <p>Disables or provides read-only/write-read SNMP access.</p> <p>Command mode: Global configuration</p>
<pre>[no] access telnet enable</pre> <p>Enables or disables Telnet access. This command is disabled by default.</p> <p>Command mode: Global configuration</p>
<pre>[default] access telnet port [<1-65535>]</pre> <p>Sets an optional Telnet server port number for cases where the server listens for Telnet sessions on a non-standard port.</p> <p>Command mode: Global configuration</p>
<pre>[default] access tftp-port [<1-65535>]</pre> <p>Sets the TFTP port for the switch. The default is port 69.</p> <p>Command mode: Global configuration</p>
<pre>[no] access tsbbi enable</pre> <p>Enables or disables Telnet/SSH configuration through the Browser-Based Interface (BBI).</p> <p>Command mode: Global configuration</p>
<pre>[no] access userbbi enable</pre> <p>Enables or disables user configuration access through the Browser-Based Interface (BBI).</p> <p>Command mode: Global configuration</p>
<pre>show access</pre> <p>Displays the current system access parameters.</p> <p>Command mode: All</p>

Management Network Configuration

These commands are used to define IP address ranges which are allowed to access the switch for management purposes.

Table 161. Management Network Configuration Commands

Command Syntax and Usage
<p><code>access management-network <mgmt network IPv4 or IPv6 address> <mgmt network mask or prefix length></code></p> <p>Adds a defined network through which switch access is allowed through Telnet, SNMP, RIP, or the IBM Networking OS browser-based interface. A range of IP addresses is produced when used with a network mask address. Specify an IP address and mask address in dotted-decimal notation.</p> <p>Note: If you configure the management network without including the switch interfaces, the configuration causes the Firewall Load Balancing health checks to fail and creates a “Network Down” state on the network.</p> <p>Command mode: Global configuration</p>
<p><code>no access management-network <mgmt network IPv4 or IPv6 address> <mgmt network mask or prefix length></code></p> <p>Removes a defined network, which consists of a management network address and a management network mask address.</p> <p>Command mode: Global configuration</p>
<p><code>access management-network <mgmt network IPv4 address> <mgmt network mask> {snmp-ro snmp-rw}</code></p> <p>Adds a defined IPv4 network through which SNMP read-only or SNMP read/write switch access is allowed. Specify an IP address and mask address in dotted-decimal notation.</p> <p>Command mode: Global configuration</p>
<p><code>access management-network6 <mgmt network IPv6 address> <IPv6 prefix length> {snmp-ro snmp-rw}</code></p> <p>Adds a defined IPv6 network through which SNMP read-only or SNMP read/write switch access is allowed.</p> <p>Command mode: Global configuration</p>
<p><code>no access management-network {snmp-ro snmp-rw}</code></p> <p>Clears the IPv4 SNMP read-only or SNMP read/write access control list for management purposes.</p> <p>Command mode: Global configuration</p>
<p><code>no access management-network6 {snmp-ro snmp-rw}</code></p> <p>Clears the IPv6 SNMP read-only or SNMP read/write access control list for management purposes.</p> <p>Command mode: Global configuration</p>

Table 161. Management Network Configuration Commands

Command Syntax and Usage
<pre>show access management-network</pre> <p>Displays the current management network configuration and SNMP access management IP list.</p> <p>Command mode: All</p>
<pre>clear access management-network</pre> <p>Removes all defined management networks.</p> <p>Command mode: All except User EXEC</p>

User Access Control Configuration

The following table describes user-access control commands.

Passwords can be a maximum of 128 characters.

Table 162. User Access Control Configuration Commands

Command Syntax and Usage
<pre>access user <1-20></pre> <p>Configures the User ID.</p> <p>Command mode: Global configuration</p>
<pre>access user eject {<user name> <session ID>}</pre> <p>Ejects the specified user from the CN4093.</p> <p>Command mode: Global configuration</p>
<pre>clear line <1-12></pre> <p>Ejects the user with the corresponding session ID from the CN4093.</p> <p>Command mode: Privileged EXEC</p>
<pre>[no] access user administrator-enable</pre> <p>Enables or disables the default administrator account.</p> <p>Command mode: Global configuration</p>
<pre>access user user-password <1-128 characters></pre> <p>Sets the user (<code>user</code>) password. The user has no direct responsibility for switch management. He or she can view switch status information and statistics, but cannot make any configuration changes.</p> <p>Command mode: Global configuration</p>
<pre>access user operator-password <1-128 characters></pre> <p>Sets the operator (<code>oper</code>) password. The operator manages all functions of the switch. He or she can view all switch information and statistics and can reset ports.</p> <p>Command mode: Global configuration</p>
<pre>access user administrator-password <1-128 characters></pre> <p>Sets the administrator (<code>admin</code>) password. The super user administrator has complete access to all information and configuration commands on the CN4093, including the ability to change both the user and administrator passwords.</p> <p>Access includes “oper” functions.</p> <p>Command mode: Global configuration</p>
<pre>show access user</pre> <p>Displays the current user status.</p> <p>Command mode: All</p>

System User ID Configuration

The following table describes user ID configuration commands.

Table 163. User ID Configuration Commands

Command Syntax and Usage
<pre>access user <1-20> level {user operator administrator}</pre> <p>Sets the Class-of-Service to define the user's authority level. IBM Networking OS defines these levels as: User, Operator, and Administrator, with User being the most restricted level.</p> <p>Command mode: Global configuration</p>
<pre>access user <1-20> name <1-8 characters></pre> <p>Defines the user name of maximum eight characters.</p> <p>Command mode: Global configuration</p>
<pre>access user <1-20> password</pre> <p>Sets the user (user) password. This command will prompt for required information: current admin password, new password (up to 128 characters) and confirmation of the new password.</p> <p>Command mode: Global configuration</p>
<pre>access user <1-20> enable</pre> <p>Enables the user ID.</p> <p>Command mode: Global configuration</p>
<pre>no access user <1-20> enable</pre> <p>Disables the user ID.</p> <p>Command mode: Global configuration</p>
<pre>no access user <1-20></pre> <p>Deletes the user ID.</p> <p>Command mode: Global configuration</p>
<pre>show access user</pre> <p>Displays the current user ID configuration.</p> <p>Command mode: All</p>

Strong Password Configuration

The following table describes strong password configuration commands.

Table 164. Strong Password Configuration Commands

Command Syntax and Usage
<pre>access user strong-password enable</pre> <p>Enables Strong Password requirement. Command mode: Global configuration</p>
<pre>no access user strong-password enable</pre> <p>Disables Strong Password requirement. Command mode: Global configuration</p>
<pre>access user strong-password expiry <I-365></pre> <p>Configures the number of days allowed before the password must be changed. The default value is 60 days. Command mode: Global configuration</p>
<pre>access user strong-password warning <I-365></pre> <p>Configures the number of days before password expiration, that a warning is issued to users. The default value is 15 days. Command mode: Global configuration</p>
<pre>access user strong-password faillog <I-255></pre> <p>Configures the number of failed login attempts allowed before a security notification is logged. The default value is 3 login attempts. Command mode: Global configuration</p>
<pre>[no] access user strong-password lockout</pre> <p>Enables or disables account lockout after a specified number of failed login attempts. Default setting is disabled. Command mode: Global configuration</p>
<pre>access user strong-password faillock <I-10></pre> <p>Configures the number of failed login attempts that trigger the account lockout. Default value is 6. Command mode: Global configuration</p>
<pre>access user strong-password clear local user {lockout fail-attempts} {<username> all}</pre> <p>Enables locked out accounts or resets failed login counters for all users or for a specific user. Command mode: Global configuration</p>
<pre>show access user strong-password</pre> <p>Displays the current Strong Password configuration. Command mode: All</p>

HTTPS Access Configuration

The following table describes HTTPS access configuration commands.

Table 165. HTTPS Access Configuration Commands

Command Syntax and Usage
<pre>[no] access https enable</pre> <p>Enables or disables BBI access (Web access) using HTTPS. This is enabled by default.</p> <p>Command mode: Global configuration</p>
<pre>[default] access https port [<TCP port number>]</pre> <p>Defines the HTTPS Web server port number. The default port is 443.</p> <p>Command mode: Global configuration</p>
<pre>access https generate-certificate</pre> <p>Allows you to generate a certificate to connect to the SSL to be used during the key exchange. A default certificate is created when HTTPS is enabled for the first time. The user can create a new certificate defining the information that they want to be used in the various fields. For example:</p> <ul style="list-style-type: none"> – Country Name (2 letter code): CA – State or Province Name (full name): Ontario – Locality Name (for example, city): Ottawa – Organization Name (for example, company): IBM – Organizational Unit Name (for example, section): Operations – Common Name (for example, user's name): Mr Smith – Email (for example, email address): info@ibm.com <p>You will be asked to confirm if you want to generate the certificate. It will take approximately 30 seconds to generate the certificate. Then the switch will restart SSL agent.</p> <p>Command mode: Global configuration</p>
<pre>access https save-certificate</pre> <p>Allows the client, or the Web browser, to accept the certificate and save the certificate to Flash to be used when the switch is rebooted.</p> <p>Command mode: Global configuration</p>
<pre>show access</pre> <p>Displays the current SSL Web Access configuration.</p> <p>Command mode: All</p>

Custom Daylight Saving Time Configuration

Use these commands to configure custom Daylight Saving Time. The DST is defined by two rules, the start rule and end rule. The rules specify the dates when the DST starts and finishes. These dates are represented as specific calendar dates or as relative offsets in a month (for example, 'the second Sunday of September').

Relative offset example:

2070901 = Second Sunday of September, at 1:00 a.m.

Calendar date example:

0070901 = September 7, at 1:00 a.m.

Table 166. Custom DST Configuration Commands

Command Syntax and Usage
<pre>system custom-dst start-rule <WDDMMhh></pre> <p>Configures the start date for custom DST, as follows:</p> <p>WDDMMhh</p> <p>W = week (0-5, where 0 means use the calendar date) D = day of the week (01-07, where 01 is Monday) MM = month (1-12) hh = hour (0-23)</p> <p>Note: Week 5 is always considered to be the last week of the month.</p> <p>Command mode: Global configuration</p>
<pre>system custom-dst end-rule <WDDMMhh></pre> <p>Configures the end date for custom DST, as follows:</p> <p>WDDMMhh</p> <p>W = week (0-5, where 0 means use the calendar date) D = day of the week (01-07, where 01 is Monday) MM = month (1-12) hh = hour (0-23)</p> <p>Note: Week 5 is always considered to be the last week of the month.</p> <p>Command mode: Global configuration</p>
<pre>system custom-dst enable</pre> <p>Enables the Custom Daylight Saving Time settings.</p> <p>Command mode: Global configuration</p>
<pre>no system custom-dst enable</pre> <p>Disables the Custom Daylight Savings Time settings.</p> <p>Command mode: Global configuration</p>
<pre>show custom-dst</pre> <p>Displays the current Custom DST configuration.</p> <p>Command mode: All</p>

sFlow Configuration

IBM Networking OS supports sFlow version 5. sFlow is a sampling method used for monitoring high speed switched networks. Use these commands to configure the sFlow agent on the switch.

Table 167. sFlow Configuration Commands

Command Syntax and Usage
<code>sflow enable</code> Enables the sFlow agent. Command mode: Global configuration
<code>no sflow enable</code> Disables the sFlow agent. Command mode: Global configuration
<code>sflow server <IP address></code> Defines the sFlow server address. Command mode: Global configuration
<code>sflow port <1-65535></code> Configures the UDP port for the sFlow server. The default value is 6343. Command mode: Global configuration
<code>show sflow</code> Displays sFlow configuration parameters. Command mode: All

sFlow Port Configuration

Use the following commands to configure the sFlow port on the switch.

Table 168. sFlow Port Configuration Commands

Command Syntax and Usage
<code>[no] sflow polling <5-60></code> Configures the sFlow polling interval, in seconds. The default setting is disabled. Command mode: Interface port
<code>[no] sflow sampling <256-65536></code> Configures the sFlow sampling rate, in packets per sample. The default setting is disabled. Command mode: Interface port

Port Configuration

Use the Port Configuration commands to configure settings for switch ports (INT_x) and (EXT_x). If you are configuring management ports (MGT1), see ["Management Port Configuration" on page 288](#).

Table 169. Port Configuration Commands

Command Syntax and Usage
<pre>interface port <port alias or number></pre> <p>Enter Interface port mode.</p> <p>Command mode: Global configuration</p>
<pre>dot1p <0-7></pre> <p>Configures the port's 802.1p priority level.</p> <p>Command mode: Interface port</p>
<pre>unicast-bandwidth <10-100></pre> <p>Configures the allocated bandwidth percentage for unicast traffic on the port. The remaining bandwidth is automatically allocated to multicast traffic. The default value is 50.</p> <p>Command mode: Interface port</p>
<pre>unicast-bandwidth global <10-100></pre> <p>Configures the allocated bandwidth percentage for unicast traffic on the egress ports. The remaining bandwidth is automatically allocated to multicast traffic. The default value is 50. This applies to all ports.</p> <p>Command mode: Interface port</p>
<pre>description <1-64 characters></pre> <p>Sets a description for the port. The assigned port name appears next to the port description on some information and statistics screens. The default is set to the port number.</p> <p>Command mode: Interface port</p>
<pre>[no] bpdu-guard</pre> <p>Enables or disables BPDU guard, to avoid spanning-tree loops on ports with Port Fast Forwarding enabled.</p> <p>Command mode: Interface port</p>
<pre>[no] dscp-marking</pre> <p>Enables or disables DSCP re-marking on a port.</p> <p>Command mode: Interface port</p>
<pre>[no] reflective-relay force</pre> <p>Enables or disables constraint to always keep reflective relay active. Default setting is disabled.</p> <p>Command mode: Interface port</p>

Table 169. Port Configuration Commands (continued)

Command Syntax and Usage	
<pre>switchport mode {access trunk private-vlan}</pre>	<p>Configures the port's trunking mode:</p> <ul style="list-style-type: none"> – <code>access</code> allows association to a single VLAN – <code>trunk</code> allows association to multiple VLANs – <code>private-vlan</code> allows association to a private VLAN <p>Default mode is <code>access</code>.</p> <p>Note: When switching from <code>access</code> to <code>trunk</code> mode, the port inherits the access VLAN as the trunk Native-VLAN.</p> <p>Note: When switching from <code>trunk</code> to <code>access</code> mode, the port inherits the trunk Native-VLAN as the access VLAN.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>switchport access vlan <1-4094></pre>	<p>Configures the associated VLAN used in access mode. If the VLAN does not exist, it will be created and enabled automatically. Default value is 1 for data ports and 4095 for the management port.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>no switchport access vlan</pre>	<p>Resets the access VLAN to its default value.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>switchport trunk native vlan <1-4094></pre>	<p>Configures the Port VLAN ID (PVID) or Native-VLAN used to carry untagged traffic in trunk mode. If the VLAN does not exist, it will be created and enabled automatically. Default value is 1 for data ports and 4095 for the management port.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>switchport trunk allowed vlan [add remove] <VLAN ID range></pre>	<p>Updates the associated VLANs in trunk mode. If any VLAN in the range does not exist, it will be created and enabled automatically.</p> <ul style="list-style-type: none"> – <code>add</code> enables the VLAN range in addition to the current configuration – <code>remove</code> eliminates the VLAN range from the current configuration <p>Command mode: Interface port/Interface portchannel</p>
<pre>switchport trunk allowed vlan {all none}</pre>	<ul style="list-style-type: none"> – <code>all</code> associates all existing and enabled VLANs to the port. This is an operational command applicable only to VLANs currently configured at the moment of execution. VLANs created afterward will not be associated automatically. Also, as an operational command, it will not be dumped into the configuration file. – <code>none</code> removes the port from all currently associated VLANs except the default VLAN <p>Command mode: Interface port/Interface portchannel</p>

Table 169. Port Configuration Commands (continued)

Command Syntax and Usage	
[no] switchport private-vlan mapping <primary VLAN>	<p>Enables or disables a private VLAN promiscuous port to/from a primary VLAN.</p> <p>Command mode: Interface port/Interface portchannel</p>
[no] switchport private-vlan host-association <primary VLAN> <secondary VLAN>	<p>Adds or removes a private VLAN host port to/from a secondary VLAN.</p> <p>Command mode: Interface port/Interface portchannel</p>
[no] rmon	<p>Enables or disables Remote Monitoring for the port. RMON must be enabled for any RMON configurations to function.</p> <p>Command mode: Interface port</p>
[no] vlan dot1q tag native	<p>Disables or enables VLAN tag persistence. When disabled, the VLAN tag is removed at egress from packets whose VLAN tag matches the port PVID/Native-vlan. The default setting is disabled.</p> <p>Note: In global configuration mode, this is an operational command used to set the VLAN tag persistence on all ports currently tagged at the moment of execution. VLAN tag persistence will not be set automatically for ports tagged afterward. Also, as an operational command, it will not be dumped into the configuration file.</p> <p>Command mode: Global configuration/Interface port/Interface portchannel</p>
[no] tagpvid-ingress	<p>Enables or disables tagging the ingress frames with the port's VLAN ID. When enabled, the PVID tag is inserted into untagged and 802.1Q single-tagged ingress frames as outer VLAN ID. The default setting is disabled.</p> <p>Command mode: Interface port/Interface portchannel</p>
[no] flood-blocking	<p>Enables or disables port Flood Blocking. When enabled, unicast and multicast packets with unknown destination MAC addresses are blocked from the port.</p> <p>Command mode: Interface port</p>
[no] mac-address-table mac-notification	<p>Enables or disables MAC Address Notification. With MAC Address Notification enabled, the switch generates a syslog message when a MAC address is added or removed from the MAC address table.</p> <p>Command mode: Global configuration</p>
[no] learning	<p>Enables or disables FDB learning on the port.</p> <p>Command mode: Interface port</p>

Table 169. Port Configuration Commands (continued)

Command Syntax and Usage	
port-channel min-links <1-16>	<p>Set the minimum number of links for this port. If the specified minimum number of ports are not available, the trunk is placed in the down state.</p> <p>Command mode: Interface port</p>
[no] storm-control broadcast level pps <0-2097151>	<p>Limits the number of broadcast packets per second to the specified value. If disabled, the port forwards all broadcast packets.</p> <p>Command mode: Interface port</p>
[no] storm-control multicast level pps <0-2097151>	<p>Limits the number of multicast packets per second to the specified value. If disabled, the port forwards all multicast packets.</p> <p>Command mode: Interface port</p>
[no] storm-control unicast level pps <0-2097151>	<p>Limits the number of unknown unicast packets per second to the specified value. If disabled, the port forwards all unknown unicast packets.</p> <p>Command mode: Interface port</p>
no shutdown	<p>Enables the port.</p> <p>Command mode: Interface port</p>
shutdown	<p>Disables the port. (To temporarily disable a port without changing its configuration attributes, refer to “Temporarily Disabling a Port” on page 284.)</p> <p>Command mode: Interface port</p>
show interface port <port alias or number>	<p>Displays current port parameters.</p> <p>Command mode: All</p>

Port Error Disable and Recovery Configuration

The Error Disable and Recovery feature allows the switch to automatically disable a port if an error condition is detected on the port. The port remains in the error-disabled state until it is re-enabled manually, or re-enabled automatically by the switch after a timeout period has elapsed. The error-disabled state of a port does not persist across a system reboot.

Table 170. Port Error Disable Commands

Command Syntax and Usage
<pre>errdisable recovery</pre> <p>Enables automatic error-recovery for the port. The default setting is enabled.</p> <p>Note: Error-recovery must be enabled globally before port-level commands become active.</p> <p>Command mode: Interface port</p>
<pre>no errdisable recovery</pre> <p>Enables automatic error-recovery for the port.</p> <p>Command mode: Interface port</p>
<pre>show interface port <port alias or number> errdisable</pre> <p>Displays current port Error Disable parameters.</p> <p>Command mode: All</p>

Port Link Configuration

Use these commands to set flow control for the port link.

Table 171. Port Link Configuration Commands

Command Syntax and Usage
<pre>speed {1000 10000 auto}</pre> <p>Sets the link speed. Some options are not valid on all ports. The choices include:</p> <ul style="list-style-type: none"> – 1000 Mbps – 10000 Mps – any (auto negotiate port speed) <p>Command mode: Interface port</p>
<pre>duplex {full half auto}</pre> <p>Sets the operating mode. The choices include:</p> <ul style="list-style-type: none"> – Auto negotiation (default) – Half-duplex – Full-duplex <p>Command mode: Interface port</p>

Table 171. Port Link Configuration Commands

Command Syntax and Usage
<pre>flowcontrol receive {on off}</pre> <p>Enables or disables flow control receive.</p> <p>Note: For external ports (EXTx) the default setting is no flow control, and for internal ports (INTx) the default setting is both receive and transmit.</p> <p>Command mode: Interface port</p>
<pre>flowcontrol send {on off}</pre> <p>Enables or disables flow control transmit.</p> <p>Note: For external ports (EXTx) the default setting is no flow control, and for internal ports (INTx) the default setting is both receive and transmit.</p> <p>Command mode: Interface port</p>
<pre>[no] auto</pre> <p>Turns auto-negotiation on or off.</p> <p>Command mode: Interface port</p>
<pre>show interface port <port alias or number></pre> <p>Displays current port parameters.</p> <p>Command mode: All</p>

Temporarily Disabling a Port

To temporarily disable a port without changing its stored configuration attributes, enter the following command at any prompt:

```
Router# interface port <port alias or number> shutdown
```

Because this configuration sets a temporary state for the port, you do not need to use a save operation. The port state will revert to its original configuration when the CN4093 10Gb Converged Scalable Switch is reset. See the [“Operations Commands” on page 493](#) for other operations-level commands.

Unidirectional Link Detection Configuration

UDLD commands are described in the following table.

Table 172. Port UDLD Configuration Commands

Command Syntax and Usage
<pre>[no] udld</pre> <p>Enables or disables UDLD on the port.</p> <p>Command mode: Interface port</p>
<pre>[no] udld aggressive</pre> <p>Configures the UDLD mode for the selected port, as follows:</p> <ul style="list-style-type: none">– Normal: Detect unidirectional links that have mis-connected interfaces. The port is disabled if UDLD determines that the port is mis-connected. Use the “no” form to select normal operation.– Aggressive: In addition to the normal mode, the aggressive mode disables the port if the neighbor stops sending UDLD probes for 7 seconds. <p>Command mode: Interface port</p>
<pre>show interface port <port number> udld</pre> <p>Displays current port UDLD parameters.</p> <p>Command mode: All</p>

Port OAM Configuration

Operation, Administration, and Maintenance (OAM) protocol allows the switch to detect faults on the physical port links. OAM is described in the IEEE 802.3ah standard. OAM Discovery commands are described in the following table.

Table 173. Port OAM Configuration Commands

Command Syntax and Usage
<pre>oam passive</pre> <p>Configures the OAM discovery mode, as follows:</p> <ul style="list-style-type: none">– Passive: This port allows its peer link to initiate OAM discovery. <p>If OAM determines that the port is in an anomalous condition, the port is disabled.</p> <p>Command mode: Interface port</p>
<pre>no oam passive</pre> <p>Disables OAM discovery on the port.</p> <p>Command mode: Interface port</p>
<pre>show interface port <port number> oam</pre> <p>Displays current port OAM parameters.</p> <p>Command mode: All</p>

Port ACL Configuration

The following table describes port ACL configuration commands

Table 174. Port ACL/QoS Configuration Commands

Command Syntax and Usage
<pre>[no] access-control list <ACL number></pre> <p>Adds or removes the specified ACL. You can add multiple ACLs to a port.</p> <p>Command mode: Interface port</p>
<pre>[no] access-control list6 <ACL number></pre> <p>Adds or removes the specified IPv6 ACL. You can add multiple ACLs to a port.</p> <p>Command mode: Interface port</p>
<pre>[no] access-control group <ACL group number></pre> <p>Adds or removes the specified ACL group. You can add multiple ACL groups to a port.</p> <p>Command mode: Interface port</p>
<pre>show interface port <port alias or number> access-control</pre> <p>Displays current ACL QoS parameters.</p> <p>Command mode: All</p>

Port WRED Configuration

These commands allow you to configure Weighted Random Early Detection (WRED) parameters for a selected port. For global WRED configuration, see [“Weighted Random Early Detection Configuration” on page 296](#).

Table 175. Port WRED Options

Command Syntax and Usage	
<code>[no] random-detect ecn enable</code>	<p>Enables or disables Explicit Congestion Notification (ECN). When ECN is on, the switch marks the ECN bit of the packet (if applicable) instead of dropping the packet. ECN-aware devices are notified of the congestion and those devices can take corrective actions.</p> <p>Note: ECN functions only on TCP traffic.</p> <p>Command mode: Interface port</p>
<code>random-detect enable</code>	<p>Turns on Random Detection and avoidance.</p> <p>Command mode: Interface port</p>
<code>no random-detect enable</code>	<p>Turns off Random Detection and avoidance.</p> <p>Command mode: Interface port</p>
<code>show interface port <port alias or number> random-detect</code>	<p>Displays current Random Detection and avoidance parameters.</p> <p>Command mode: All</p>

Port WRED Transmit Queue Configuration

Use this menu to define WRED thresholds for the port's transmit queues. Set each threshold between 1% and 100%. When the average queue size grows beyond the minimum threshold, packets begin to be dropped. When the average queue size reaches the maximum threshold, all packets are dropped. The probability of packet-drop between the thresholds is defined by the drop rate.

Table 176. Port WRED Transmit Queue Options

Command Syntax and Usage	
<code>[no] random-detect transmit-queue <0-7> tcp <min. threshold (1-100)> <max. threshold (1-100)> <drop rate (1-100)></code>	<p>Configures the WRED thresholds for TCP traffic. Use the <code>no</code> form to clear the WRED threshold value.</p> <p>Command mode: Interface port</p>
<code>[no] random-detect transmit-queue <0-7> non-tcp <min. threshold (1-100)> <max. threshold (1-100)> <drop rate (1-100)></code>	<p>Configures the WRED thresholds for non-TCP traffic. Use the <code>no</code> form to clear the WRED threshold value.</p> <p>Command mode: Interface port</p>

Table 176. Port WRED Transmit Queue Options

Command Syntax and Usage
<pre>random-detect transmit-queue <0-7> enable</pre> <p>Sets the WRED transmit queue configuration to <code>on</code>.</p> <p>Command mode: Interface port</p>
<pre>no random-detect transmit-queue <0-7> enable</pre> <p>Sets the WRED transmit queue configuration to <code>off</code>.</p> <p>Command mode: Interface port</p>

Management Port Configuration

You can use these commands to set port parameters for management ports (MGT1 and EXTM). Use these commands to set port parameters for the port link. For MGT1, the values for speed, duplex, and flow control are fixed, and cannot be configured.

Table 177. Management Port Configuration Commands

Command Syntax and Usage
<pre>speed {10 100 1000 auto}</pre> <p>Sets the link speed. The choices include:</p> <ul style="list-style-type: none"> – 10 Mbps – 100 Mbps – 1000 Mbps – Auto — for auto negotiation <p>Command mode: Interface port</p>
<pre>duplex {full half auto}</pre> <p>Sets the operating mode. The choices include:</p> <ul style="list-style-type: none"> – Full-duplex – Half-duplex – Auto — for auto negotiation (default) <p>Command mode: Interface port</p>
<pre>flowcontrol {receive send} {on off}</pre> <p>Activates or deactivates one type of flow control. The choices include:</p> <ul style="list-style-type: none"> – Receive flow control – Transmit flow control <p>Command mode: Interface port</p>
<pre>no flowcontrol</pre> <p>Deactivates flow control globally.</p>
<pre>no shutdown</pre> <p>Enables the port.</p> <p>Command mode: Interface port</p>

Table 177. Management Port Configuration Commands (continued)

Command Syntax and Usage
shutdown Disables the port. Command mode: Interface port
show interface port <i><port alias or number></i> Displays current port parameters. Command mode: All

Stacking Configuration

A *stack* is a group of switches that work together as a unified system. The network views a stack of switches as a single entity, identified by a single network IP address. The Stacking Configuration menu is used to configure a stack, and to define the Backup switch.

The Stacking Configuration menu is available only after Stacking is enabled and the switch is reset. For more information, see [“Stacking Boot Options” on page 509](#).

Table 178. Stacking Commands

Command Syntax and Usage
<pre>[no] stack name <1-63 characters></pre> <p>Defines a name for the stack.</p> <p>Command mode: Global configuration</p>
<pre>[no] stack backup <csnum (1-8)></pre> <p>Defines the backup switch in the stack, based on its configured switch number (csnum).</p> <p>Command mode: Global configuration</p>
<pre>show stack switch-number <csnum (1-8)></pre> <p>Displays UUID and slot ID for all the configured switches from the stack.</p> <p>Command mode: All</p>

Stacking Switch Configuration

The following table describes stacking switch configuration commands

Table 179. Stacking Switch Commands

Command Syntax and Usage
<pre>stack switch-number <csnum (1-8)> universal-unic-id <UUID></pre> <p>Binds the selected switch to the stack, based on the UUID of the chassis in which the switch resides. You also must enter the bay number to specify a switch within the chassis. Following is an example UUID:</p> <pre>uuid 49407441b1a511d7b95df58f4b6f99fe</pre> <p>Command mode: Global configuration</p>
<pre>stack switch-number <csnum (1-8)> bay <1-4></pre> <p>Binds the selected switch to the stack, based on its bay number in the chassis. You also must enter the UUID to specify the chassis in which the switch resides.</p> <p>Command mode: Global configuration</p>
<pre>stack switch-number <csnum (1-8)> bind <asnum (1-16)></pre> <p>Binds the selected switch to the stack, based on its attached switch number (asnum).</p> <p>Command mode: Global configuration</p>
<pre>stack switch-number <csnum (1-8)> description <1-63 characters></pre> <p>Defines a description for each configured switch number of the stack.</p> <p>Command mode: Global configuration</p>
<pre>no stack switch-number <csnum (1-8)></pre> <p>Deletes the selected switch from the stack.</p> <p>Command mode: Global configuration</p>

Management Interface Configuration

Table 180. Management Interface Options

Command Syntax and Usage
<pre>floating ip {address netmask}</pre> <p>Configures additional IPv4 address or netmask.</p> <p>Command mode: Interface IP</p>

Table 180. Management Interface Options

Command Syntax and Usage
<pre>no floating</pre> <p>Removes all floating IP addresses.</p> <p>Command mode: Interface IP</p>
<pre>show interface ip</pre> <p>Displays current IP address floating information.</p> <p>Command mode: Global configuration</p>

Quality of Service Configuration

Quality of Service (QoS) commands configure the 802.1p priority value and DiffServ Code Point value of incoming packets. This allows you to differentiate between various types of traffic, and provide different priority levels.

802.1p Configuration

This feature provides the CN4093 the capability to filter IP packets based on the 802.1p bits in the packet's VLAN header. The 802.1p bits specify the priority that you should give to the packets while forwarding them. The packets with a higher (non-zero) priority bits are given forwarding preference over packets with numerically lower priority bits value.

Table 181. 802.1p Configuration Commands

Command Syntax and Usage
<pre>qos transmit-queue mapping <priority (0-7)> <COSq number></pre> <p>Maps the 802.1p priority of to the Class of Service queue (COSq) priority. Enter the 802.1p priority value (0-7), followed by the Class of Service queue that handles the matching traffic.</p> <p>Command mode: Global configuration</p>
<pre>qos transmit-queue weight-cos <COSq number> <weight (0-15)></pre> <p>Configures the weight of the selected Class of Service queue (COSq). Enter the queue number (0-1), followed by the scheduling weight (0-15).</p> <p>Command mode: Global configuration</p>
<pre>show qos transmit-queue</pre> <p>Displays the current 802.1p parameters.</p> <p>Command mode: All</p>
<pre>qos unicast-bandwidth <10-100></pre> <p>Configures the allocated bandwidth percentage for unicast traffic on the egress ports. The remaining bandwidth is automatically allocated to multicast traffic. The default value is 50. This applies to all ports.</p> <p>Command mode: All</p>

DSCP Configuration

These commands map the DiffServ Code Point (DSCP) value of incoming packets to a new value or to an 802.1p priority value.

Table 182. DSCP Configuration Commands

Command Syntax and Usage
<pre>qos dscp dscp-mapping <DSCP (0-63)> <new DSCP (0-63)></pre> <p>Maps the initial DiffServ Code Point (DSCP) value to a new value. Enter the DSCP value (0-63) of incoming packets, followed by the new value.</p> <p>Command mode: Global configuration</p>
<pre>qos dscp dot1p-mapping <DSCP (0-63)> <priority (0-7)></pre> <p>Maps the DiffServ Code point value to an 802.1p priority value. Enter the DSCP value, followed by the corresponding 802.1p value.</p> <p>Command mode: Global configuration</p>
<pre>qos dscp re-marking</pre> <p>Turns on DSCP re-marking globally.</p> <p>Command mode: Global configuration</p>
<pre>no qos dscp re-marking</pre> <p>Turns off DSCP re-marking globally.</p> <p>Command mode: Global configuration</p>
<pre>show qos dscp</pre> <p>Displays the current DSCP parameters.</p> <p>Command mode: All</p>

Control Plane Protection

To prevent switch instability if the switch is unable to process a high rate of control-plane traffic, the switch now supports CoPP. CoPP, allows you to assign control-plane traffic protocols to one of 48 queues, and can set bandwidth limits for each queue.

Table 183. CoPP Commands

Command Syntax and Usage
<pre> qos protocol-packet-control packet-queue-map <packet queue number (0-47)> <packet type> </pre> <p>Configures a packet type to associate with each packet queue number. Enter a queue number, followed by the packet type. You may map multiple packet types to a single queue. The following packet types are allowed:</p> <ul style="list-style-type: none"> – 802.1x (IEEE 802.1x packets) – application-cri-packets (critical packets of various applications, such as Telnet, SSH) – arp-bcast (ARP broadcast packets) – arp-ucast (ARP unicast reply packets) – bgp (BGP packets) – bpdu (Spanning Tree Protocol packets) – cisco-bpdu (Cisco STP packets) – dest-unknown (packets with destination not yet learned) – dhcp (DHCP packets) – icmp (ICMP packets) – igmp (IGMP packets) – ipv4-miscellaneous (IPv4 packets with IP options and TTL exception) – ipv6-nd (IPv6 Neighbor Discovery packets) – lacp (LACP/Link Aggregation protocol packets) – lldp (LLDP packets) – ospf (OSPF packets) – ospf3 (OSPF3 Packets) – pim (PIM packets) – rip (RIP packets) – system (system protocols, such as tftp, ftp, telnet, ssh) – udld (UDLD packets) – vlag (vLAG packets) – vrrp (VRRP packets) <p>Command mode: Global configuration</p>
<pre> qos protocol-packet-control rate-limit-packet- queue <packet queue number (0-47)> <1-10000> </pre> <p>Configures the number of packets per second allowed for each packet queue.</p> <p>Command mode: Global configuration</p>

Table 183. CoPP Commands

Command Syntax and Usage
<pre>no qos protocol-packet-control packet-queue-map <packet type></pre> <p>Clears the selected packet type from its associated packet queue. Command mode: Global configuration</p>
<pre>no qos protocol-packet-control rate-limit-packet-queue <packet queue number (0-47)></pre> <p>Clears the packet rate configured for the selected packet queue. Command mode: Global configuration</p>
<pre>show qos protocol-packet-control information protocol</pre> <p>Displays of mapping of protocol packet types to each packet queue number. The status indicates whether the protocol is running or not running. Command mode: All</p>
<pre>show qos protocol-packet-control information queue</pre> <p>Displays the packet rate configured for each packet queue. Command mode: All</p>

Weighted Random Early Detection Configuration

Weighted Random Early Detection (WRED) provides congestion avoidance by pre-emptively dropping packets before a queue becomes full. CN4093 implementation of WRED defines TCP and non-TCP traffic profiles on a per-port, per COS queue basis. For each port, you can define a transmit-queue profile with thresholds that define packet-drop probability.

These commands allow you to configure global WRED parameters. For port WRED commands, see [“Port WRED Configuration” on page 287](#).

Table 184. WRED Configuration Options

Command Syntax and Usage
<pre>qos random-detect ecn</pre> <p>Enables or disables Explicit Congestion Notification (ECN). When ECN is on, the switch marks the ECN bit of the packet (if applicable) instead of dropping the packet. ECN-aware devices are notified of the congestion and those devices can take corrective actions. Note: ECN functions only on TCP traffic. Command mode: Global configuration</p>
<pre>qos random-detect enable</pre> <p>Turns on Random Detection and avoidance. Command mode: Global configuration</p>

Table 184. WRED Configuration Options

Command Syntax and Usage
<pre>no qos random-detect enable</pre> <p>Turns off Random Detection and avoidance.</p> <p>Command mode: Global configuration</p>
<pre>show qos random-detect</pre> <p>Displays current Random Detection and avoidance parameters.</p> <p>Command mode: All</p>

WRED Transmit Queue Configuration

Table 185. WRED Transmit Queue Options

Command Syntax and Usage
<pre>[no] qos random-detect transmit-queue <0-7> tcp <min. threshold (1-100)> <max. threshold (1-100)> <drop rate (1-100)></pre> <p>Configures the WRED thresholds for TCP traffic. Use the <code>no</code> form to clear the WRED threshold value.</p> <p>Command mode: Global configuration</p>
<pre>[no] qos random-detect transmit-queue <0-7> non-tcp <min. threshold (1-100)> <max. threshold (1-100)> <drop rate (1-100)></pre> <p>Configures the WRED thresholds for non-TCP traffic. Use the <code>no</code> form to clear the WRED threshold value.</p> <p>Command mode: Global configuration</p>
<pre>qos random-detect transmit-queue <0-7> enable</pre> <p>Sets the WRED transmit queue configuration to <code>on</code>.</p> <p>Command mode: Global configuration</p>
<pre>no qos random-detect transmit-queue <0-7> enable</pre> <p>Sets the WRED transmit queue configuration to <code>off</code>.</p> <p>Command mode: Global configuration</p>

Access Control Configuration

Use these commands to create Access Control Lists and ACL Groups. ACLs define matching criteria used for IP filtering and Quality of Service functions.

For information about assigning ACLs to ports, see [“Port ACL Configuration” on page 286](#).

Table 186. General ACL Configuration Commands

Command Syntax and Usage
<pre>[no] access-control list <1-256></pre> <p>Configures an Access Control List.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 299.</p>
<pre>[no] access-control group <1-256></pre> <p>Configures an ACL Group.</p> <p>Command mode: Global configuration</p> <p>To view command options, see page 312.</p>
<pre>show access-control</pre> <p>Displays the current ACL parameters.</p> <p>Command mode: All</p>

Access Control List Configuration

These commands allow you to define filtering criteria for each Access Control List (ACL).

Table 187. ACL Configuration Commands

Command Syntax and Usage
<pre>[no] access-control list <1-256> egress-port port <port alias or number></pre> <p>Configures the ACL to function on egress packets.</p> <p>Command mode: Global configuration</p>
<pre>access-control list <1-256> action {permit deny set-priority <0-7>}</pre> <p>Configures a filter action for packets that match the ACL definitions. You can choose to permit (pass) or deny (drop) packets, or set the 802.1p priority level (0-7).</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <1-256> statistics</pre> <p>Enables or disables the statistics collection for the Access Control List.</p> <p>Command mode: Global configuration</p>
<pre>default access-control list <1-256></pre> <p>Resets the ACL parameters to their default values.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list <1-256></pre> <p>Displays the current ACL parameters.</p> <p>Command mode: All</p>
<pre>[no] access-control list6 <1-128></pre> <p>Configures an IPv6 Access Control List. To view command options, see page 303.</p> <p>Command mode: Global configuration</p>

Ethernet Filtering Configuration

These commands allow you to define Ethernet matching criteria for an ACL.

Table 188. Ethernet Filtering Configuration Commands

Command Syntax and Usage
<pre>[no] access-control list <I-256> ethernet source-mac-address <MAC address> <MAC mask></pre> <p>Defines the source MAC address for this ACL.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <I-256> ethernet destination-mac-address <MAC address> <MAC mask></pre> <p>Defines the destination MAC address for this ACL.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <I-256> ethernet vlan <VLAN ID> <VLAN mask></pre> <p>Defines a VLAN number and mask for this ACL.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <I-256> ethernet ethernet-type {arp ip ipv6 mpls rarp any <other (0x600-0xFFFF)>}</pre> <p>Defines the Ethernet type for this ACL.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <I-256> ethernet priority <0-7></pre> <p>Defines the Ethernet priority value for the ACL.</p> <p>Command mode: Global configuration</p>
<pre>default access-control list <I-256> ethernet</pre> <p>Resets Ethernet parameters for the ACL to their default values.</p> <p>Command mode: Global configuration</p>
<pre>no access-control list <I-256> ethernet</pre> <p>Removes Ethernet parameters for the ACL.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list <I-256> ethernet</pre> <p>Displays the current Ethernet parameters for the ACL.</p> <p>Command mode: All</p>

IPv4 Filtering Configuration

These commands allow you to define IPv4 matching criteria for an ACL.

Table 189. IP version 4 Filtering Configuration Commands

Command Syntax and Usage															
[no] access-control list <1-256> ipv4 source-ip-address <IP address> <IP mask>	<p>Defines a source IP address for the ACL. If defined, traffic with this source IP address will match this ACL. Specify an IP address in dotted decimal notation.</p> <p>Command mode: Global configuration</p>														
[no] access-control list <1-256> ipv4 destination-ip-address <IP address> <IP mask>	<p>Defines a destination IP address for the ACL. If defined, traffic with this destination IP address will match this ACL.</p> <p>Command mode: Global configuration</p>														
[no] access-control list <1-256> ipv4 protocol <0-255>	<p>Defines an IP protocol for the ACL. If defined, traffic from the specified protocol matches this filter. Specify the protocol number. Listed below are some of the well-known protocols.</p> <table border="1"> <thead> <tr> <th>Number</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>icmp</td> </tr> <tr> <td>2</td> <td>igmp</td> </tr> <tr> <td>6</td> <td>tcp</td> </tr> <tr> <td>17</td> <td>udp</td> </tr> <tr> <td>89</td> <td>ospf</td> </tr> <tr> <td>112</td> <td>vrrp</td> </tr> </tbody> </table> <p>Command mode: Global configuration</p>	Number	Name	1	icmp	2	igmp	6	tcp	17	udp	89	ospf	112	vrrp
Number	Name														
1	icmp														
2	igmp														
6	tcp														
17	udp														
89	ospf														
112	vrrp														
[no] access-control list <1-256> ipv4 type-of-service <0-255>	<p>Defines a Type of Service (ToS) value for the ACL. For more information on ToS, refer to RFC 1340 and 1349.</p> <p>Command mode: Global configuration</p>														
default access-control list <1-256> ipv4	<p>Resets the IPv4 parameters for the ACL to their default values.</p> <p>Command mode: Global configuration</p>														
show access-control list <1-256> ipv4	<p>Displays the current IPv4 parameters.</p> <p>Command mode: All</p>														

TCP/UDP Filtering Configuration

These commands allow you to define TCP/UDP matching criteria for an ACL.

Table 190. TCP/UDP Filtering Configuration Commands

Command Syntax and Usage																													
<pre>[no] access-control list <1-256> tcp-udp source-port <1-65535> <mask (0xFFFF)></pre>	<p>Defines a source port for the ACL. If defined, traffic with the specified TCP or UDP source port will match this ACL. Specify the port number. Listed below are some of the well-known ports:</p> <table border="1"> <thead> <tr> <th>Number</th> <th>Name</th> </tr> </thead> <tbody> <tr><td>20</td><td>ftp-data</td></tr> <tr><td>21</td><td>ftp</td></tr> <tr><td>22</td><td>ssh</td></tr> <tr><td>23</td><td>telnet</td></tr> <tr><td>25</td><td>smtp</td></tr> <tr><td>37</td><td>time</td></tr> <tr><td>42</td><td>name</td></tr> <tr><td>43</td><td>whois</td></tr> <tr><td>53</td><td>domain</td></tr> <tr><td>69</td><td>tftp</td></tr> <tr><td>70</td><td>gopher</td></tr> <tr><td>79</td><td>finger</td></tr> <tr><td>80</td><td>http</td></tr> </tbody> </table> <p>Command mode: Global configuration</p>	Number	Name	20	ftp-data	21	ftp	22	ssh	23	telnet	25	smtp	37	time	42	name	43	whois	53	domain	69	tftp	70	gopher	79	finger	80	http
Number	Name																												
20	ftp-data																												
21	ftp																												
22	ssh																												
23	telnet																												
25	smtp																												
37	time																												
42	name																												
43	whois																												
53	domain																												
69	tftp																												
70	gopher																												
79	finger																												
80	http																												
<pre>[no] access-control list <1-256> tcp-udp destination-port <1-65535> <mask (0xFFFF)></pre>	<p>Defines a destination port for the ACL. If defined, traffic with the specified TCP or UDP destination port will match this ACL. Specify the port number, just as with <code>sport</code> above.</p> <p>Command mode: Global configuration</p>																												
<pre>[no] access-control list <1-256> tcp-udp flags <value (0x0-0x3f)> <mask (0x0-0x3f)></pre>	<p>Defines a TCP/UDP flag for the ACL.</p> <p>Command mode: Global configuration</p>																												
<pre>default access-control list <1-256> tcp-udp</pre>	<p>Resets the TCP/UDP parameters for the ACL to their default values.</p> <p>Command mode: Global configuration</p>																												
<pre>show access-control list <1-256> tcp-udp</pre>	<p>Displays the current TCP/UDP Filtering parameters.</p> <p>Command mode: All</p>																												

Packet Format Filtering Configuration

These commands allow you to define Packet Format matching criteria for an ACL.

Table 191. Packet Format Filtering Configuration Commands

Command Syntax and Usage
<pre>[no] access-control list <1-256> packet-format ethernet {ethertype2 snap llc}</pre> <p>Defines the Ethernet format for the ACL. Command mode: Global configuration</p>
<pre>[no] access-control list <1-256> packet-format tagging {any none tagged}</pre> <p>Defines the tagging format for the ACL. Command mode: Global configuration</p>
<pre>[no] access-control list <1-256> packet-format ip {ipv4 ipv6}</pre> <p>Defines the IP format for the ACL. Command mode: Global configuration</p>
<pre>default access-control list <1-256> packet-format</pre> <p>Resets Packet Format parameters for the ACL to their default values. Command mode: Global configuration</p>
<pre>show access-control list <1-256> packet-format</pre> <p>Displays the current Packet Format parameters for the ACL. Command mode: All</p>

ACL IPv6 Configuration

These commands allow you to define filtering criteria for each IPv6 Access Control List (ACL).

Table 192. IPv6 ACL Options

Command Syntax and Usage
<pre>[no] access-control list6 <1-128> egress-port port <port alias or number></pre> <p>Configures the ACL to function on egress packets. Command mode: Global configuration</p>
<pre>access-control list6 <1-128> action {permit deny set-priority <0-7>}</pre> <p>Configures a filter action for packets that match the ACL definitions. You can choose to permit (pass) or deny (drop) packets, or set the 802.1p priority level (0-7). Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-128> statistics</pre> <p>Enables or disables the statistics collection for the Access Control List. Command mode: Global configuration</p>

Table 192. IPv6 ACL Options

Command Syntax and Usage
<pre>default access-control list6 <1-128></pre> <p>Resets the ACL parameters to their default values. Command mode: Global configuration</p>
<pre>show access-control list <1-128></pre> <p>Displays the current ACL parameters. Command mode: All</p>

IPv6 Filtering Configuration

These commands allow you to define IPv6 matching criteria for an ACL.

Table 193. IP version 6 Filtering Options

Command Syntax and Usage
<pre>[no] access-control list6 <1-128> ipv6 source-address <IPv6 address> <prefix length (1-128)></pre> <p>Defines a source IPv6 address for the ACL. If defined, traffic with this source address will match this ACL. Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-128> ipv6 destination-address <IPv6 address> <prefix length (1-128)></pre> <p>Defines a destination IPv6 address for the ACL. If defined, traffic with this destination address will match this ACL. Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-128> ipv6 next-header <0-255></pre> <p>Defines the next header value for the ACL. If defined, traffic with this next header value will match this ACL. Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-128> ipv6 flow-label <0-1048575></pre> <p>Defines the flow label for the ACL. If defined, traffic with this flow label will match this ACL. Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-128> ipv6 traffic-class <0-255></pre> <p>Defines the traffic class for the ACL. If defined, traffic with this traffic class will match this ACL. Command mode: Global configuration</p>

Table 193. IP version 6 Filtering Options

Command Syntax and Usage
<pre>default access-control list6 <I-128> ipv6</pre> <p>Resets the IPv6 parameters for the ACL to their default values.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list6 <I-128> ipv6</pre> <p>Displays the current IPv6 parameters.</p> <p>Command mode: All</p>

IPv6 TCP/UDP Filtering Configuration

These commands allow you to define TCP/UDP matching criteria for an ACL.

Table 194. IPv6 ACL TCP/UDP Filtering Options

Command Syntax and Usage																												
<pre>[no] access-control list6 <I-128> tcp-udp source-port <I-65535> <mask (0xFFFF)></pre> <p>Defines a source port for the ACL. If defined, traffic with the specified TCP or UDP source port will match this ACL. Specify the port number. Listed here are some of the well-known ports:</p> <table border="1"> <thead> <tr> <th>Number</th> <th>Name</th> </tr> </thead> <tbody> <tr><td>20</td><td>ftp-data</td></tr> <tr><td>21</td><td>ftp</td></tr> <tr><td>22</td><td>ssh</td></tr> <tr><td>23</td><td>telnet</td></tr> <tr><td>25</td><td>smtp</td></tr> <tr><td>37</td><td>time</td></tr> <tr><td>42</td><td>name</td></tr> <tr><td>43</td><td>whois</td></tr> <tr><td>53</td><td>domain</td></tr> <tr><td>69</td><td>tftp</td></tr> <tr><td>70</td><td>gopher</td></tr> <tr><td>79</td><td>finger</td></tr> <tr><td>80</td><td>http</td></tr> </tbody> </table> <p>Command mode: Global configuration</p>	Number	Name	20	ftp-data	21	ftp	22	ssh	23	telnet	25	smtp	37	time	42	name	43	whois	53	domain	69	tftp	70	gopher	79	finger	80	http
Number	Name																											
20	ftp-data																											
21	ftp																											
22	ssh																											
23	telnet																											
25	smtp																											
37	time																											
42	name																											
43	whois																											
53	domain																											
69	tftp																											
70	gopher																											
79	finger																											
80	http																											
<pre>[no] access-control list6 <I-128> tcp-udp destination-port <I-65535> <mask (0xFFFF)></pre> <p>Defines a destination port for the ACL. If defined, traffic with the specified TCP or UDP destination port will match this ACL. Specify the port number, just as with <code>sport</code> above.</p> <p>Command mode: Global configuration</p>																												
<pre>[no] access-control list6 <I-128> tcp-udp flags <value (0x0-0x3f)> <mask (0x0-0x3f)></pre> <p>Defines a TCP/UDP flag for the ACL.</p> <p>Command mode: Global configuration</p>																												

Table 194. IPv6 ACL TCP/UDP Filtering Options

Command Syntax and Usage
<pre>default access-control list6 <1-128> tcp-udp</pre> <p>Resets the TCP/UDP parameters for the ACL to their default values.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list6 <1-128> tcp-udp</pre> <p>Displays the current TCP/UDP Filtering parameters.</p> <p>Command mode: All</p>

IPv6 Re-Marking Configuration

You can choose to re-mark IP header data for the selected ACL. You can configure different re-mark values, based on whether packets fall within the ACL metering profile, or out of the ACL metering profile.

IPv6 Re-Mark In-Profile Configuration

Table 195. IPv6 Re-Marking In-Profile Options

Command Syntax and Usage
<pre>[no] access-control list6 <1-128> re-mark dot1p <0-7></pre> <p>Re-marks the 802.1p value. The value is the priority bits information in the packet structure.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-128> re-mark in-profile dscp <0-63></pre> <p>Re-marks the DSCP value for in-profile traffic.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-128> re-mark use-tos-precedence</pre> <p>Enables or disables mapping of TOS (Type of Service) priority to 802.1p priority for in-profile packets. When enabled, the TOS value is used to set the 802.1p value.</p> <p>Command mode: Global configuration</p>
<pre>default access-control list6 <1-128> re-mark</pre> <p>Sets the ACL re-mark parameters to their default values.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list6 <1-128> re-mark</pre> <p>Displays current re-mark parameters.</p> <p>Command mode: All</p>

IPv6 Metering Configuration

These commands define the Access Control profile for the selected ACL.

IPv6 Metering Configuration

Table 196. IPv6 Metering Options

Command Syntax and Usage
<pre>access-control list6 <1-256> meter committed-rate <64-40000000></pre> <p>Configures the committed rate, in kilobits per second. The committed rate must be a multiple of 64.</p> <p>Command mode: Global configuration</p>
<pre>access-control list6 <1-256> meter maximum-burst-size <32-4096></pre> <p>Configures the maximum burst size, in kilobits. Enter one of the following values for mbsize: 32, 64, 128, 256, 512, 1024, 2048, 4096.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list6 <1-256> meter enable</pre> <p>Enables or disables ACL Metering.</p> <p>Command mode: Global configuration</p>
<pre>access-control list6 <1-256> meter action {drop pass}</pre> <p>Configures the ACL Meter to either drop or pass out-of-profile traffic.</p> <p>Command mode: Global configuration</p>
<pre>default access-control list6 <1-256> meter</pre> <p>Sets the ACL meter configuration to its default values.</p> <p>Command mode: Global configuration</p>
<pre>no access-control list6 <1-256> meter</pre> <p>Deletes the selected ACL meter.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list6 <1-256> meter</pre> <p>Displays current ACL Metering parameters.</p> <p>Command mode: All</p>

VMAP Configuration

A VLAN Map is an Access Control List (ACL) that can be assigned to a VLAN or a VM group instead of a port. In a virtualized environment where Virtual Machines move between physical servers, VLAN Maps allow you to create traffic filtering and metering policies associated with a VM's VLAN.

For more information about VLAN Map configuration commands, see [“Access Control List Configuration” on page 299](#).

For more information about assigning VLAN Maps to a VLAN, see [“VLAN Configuration” on page 358](#).

For more information about assigning VLAN Maps to a VM group, see [“VM Group Configuration” on page 477](#).

[Table 197](#) lists the general VMAP configuration commands.

Table 197. VMAP Configuration Commands

Command Syntax and Usage
<pre>[no] access-control vmap <1-128> egress-port <port alias or number></pre> <p>Configures the VMAP to function on egress packets.</p> <p>Command mode: Global configuration</p>
<pre>access-control vmap <1-128> action {permit deny set-priority <0-7>}</pre> <p>Configures a filter action for packets that match the VMAP definitions. You can choose to permit (pass) or deny (drop) packets, or set the 802.1p priority level (0-7).</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <1-128> ethernet source-mac-address <MAC address> <MAC mask></pre> <p>Enables or disables filtering of VMAP statistics collection based on source MAC.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <1-128> ethernet destination-mac-address <MAC address> <MAC mask></pre> <p>Enables or disables filtering of VMAP statistics collection based on destination MAC.</p> <p>Command mode: Global configuration</p>

Table 197. VMAP Configuration Commands (continued)

Command Syntax and Usage	
<pre>[no] access-control vmap <I-128> ethernet ethernet-type {<0x600-0xFFF> arp rarp ip ipv6 mpls any}</pre>	<p>Enables or disables filtering of VMAP statistics collection based on the encapsulated protocol:</p> <ul style="list-style-type: none"> – <0x600-0xFFF> filters Ethernet frames with the specified EtherType – arp filters Address Resolution Protocol frames – rarp filters Reverse Address Resolution Protocol frames – ip filters Internet Protocol version 4 frames – ipv6 filters Internet Protocol version 6 frames – mpls filters Multiprotocol Label Switching frames – all filters all frames <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> ethernet priority <0-7></pre>	<p>Enables or disables filtering of VMAP statistics collection based on the IEEE 802.1Q priority code point value.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> ethernet vlan <I-4094></pre>	<p>Enables or disables filtering of VMAP statistics collection based on VLAN ID.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> ipv4 source-ip-address <IPv4 address> <IPv4 mask></pre>	<p>Enables or disables filtering of VMAP statistics collection based on source IP address.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> ipv4 destination-ip-address <IPv4 address> <IPv4 mask></pre>	<p>Enables or disables filtering of VMAP statistics collection based on destination IP address.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> ipv4 protocol <0-255></pre>	<p>Enables or disables filtering of VMAP statistics collection based on protocol.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> ipv4 type-of-service <0-255></pre>	<p>Enables or disables filtering of VMAP statistics collection based on type of service.</p> <p>Command mode: Global configuration</p>
<pre>access-control vmap <I-128> meter enable</pre>	<p>Enables ACL port metering.</p> <p>Command mode: All except User EXEC</p>

Table 197. VMAP Configuration Commands (continued)

Command Syntax and Usage
<p>access-control vmap <1-128> meter action drop pass</p> <p>Sets ACL port metering to drop or pass out-of-profile traffic.</p> <p>Command mode: Global configuration</p>
<p>access-control vmap <1-128> meter committed-rate <64-10000000></p> <p>Sets the ACL port metering control rate in kilobits per second.</p> <p>Command mode: Global configuration</p>
<p>access-control vmap <1-128> meter maximum-burst-size <32-4096></p> <p>Sets the ACL port metering maximum burst size in kilobytes. The following eight values are allowed:</p> <ul style="list-style-type: none"> – 32 – 64 – 128 – 256 – 512 – 1024 – 2048 – 4096 <p>Command mode: Global configuration</p>
<p>no access-control vmap <1-128> meter enable</p> <p>Disables ACL port metering.</p> <p>Command mode: Global configuration</p>
<p>access-control vmap <1-128> mirror port <port></p> <p>Sets the specified port as the mirror target.</p> <p>Command mode: Global configuration</p>
<p>no access-control vmap <1-128> mirror</p> <p>Turns off ACL mirroring.</p> <p>Command mode: Global configuration</p>
<p>access-control vmap <1-128> packet-format ethernet ethernet-type2 llc snap</p> <p>Sets to filter the specified ethernet packet format type.</p> <p>Command mode: Global configuration</p>
<p>access-control vmap <1-128> packet-format ip ipv4 ipv6</p> <p>Sets to filter the specified IP packet format type.</p> <p>Command mode: Global configuration</p>

Table 197. VMAP Configuration Commands (continued)

Command Syntax and Usage	
<pre>access-control vmap <I-128> packet-format tagging any none tagged</pre>	<p>Sets filtering based on packet tagging. The options are:</p> <ul style="list-style-type: none"> – any: Filter tagged & untagged packets – none: Filter only untagged packets – tagged: Filter only tagged packets <p>Command mode: Global configuration</p>
<pre>no access-control vmap <I-128> packet-format ethernet ip tagging</pre>	<p>Disables filtering based on the specified packet format.</p> <p>Command mode: Global configuration</p>
<pre>access-control vmap <I-128> re-mark dot1p <0-7></pre>	<p>Sets the ACL re-mark configuration user update priority.</p> <p>Command mode: Global configuration</p>
<pre>no access-control vmap <I-128> re-mark dot1p</pre>	<p>Disables the use of dot1p for in-profile traffic ACL re-mark configuration.</p> <p>Command mode: Global configuration</p>
<pre>access-control vmap <I-128> re-mark in-profile out-profile dscp <0-63></pre>	<p>Sets the ACL re-mark configuration user update priority.</p> <p>Command mode: Global configuration</p>
<pre>no access-control vmap <I-128> re-mark in-profile out-profile</pre>	<p>Removes all re-mark in-profile or out-profile settings.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> re-mark use-tos-precedence</pre>	<p>Enables or disables the use of the TOS precedence for in-profile traffic.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control vmap <I-128> statistics</pre>	<p>Enables or disables the statistics collection for the VMAP.</p> <p>Command mode: Global configuration</p>
<pre>access-control vmap <I-128> tcp-udp source-port destination-port <I-65535> <port mask (0x0001 - 0xFFFF)></pre>	<p>Sets the TCP/UDP filtering source port or destination port and port mask for this ACL.</p> <p>Command mode: Global configuration</p>
<pre>access-control vmap <I-128> tcp-udp flags [<flags mask (0x0-0x3F)>]</pre>	<p>Sets the TCP flags for this ACL.</p> <p>Command mode: Global configuration</p>

Table 197. VMAP Configuration Commands (continued)

Command Syntax and Usage
<pre>no access-control vmap <I-128> tcp-udp</pre> <p>Removes TCP/UDP filtering for this ACL. Command mode: Global configuration</p>
<pre>default access-control vmap <I-128></pre> <p>Resets the VMAP parameters to their default values. Command mode: Global configuration</p>
<pre>show access-control vmap <I-128></pre> <p>Displays the current VMAP parameters. Command mode: All</p>

ACL Group Configuration

These commands allow you to compile one or more ACLs into an ACL group. Once you create an ACL group, you can assign the ACL group to one or more ports.

Table 198. ACL Group Configuration Commands

Command Syntax and Usage
<pre>access-control group <I-256> list <I-256></pre> <p>Adds the selected ACL to the ACL group. Command mode: Global configuration</p>
<pre>no access-control group <I-256> list <I-256></pre> <p>Removes the selected ACL from the ACL group. Command mode: Global configuration</p>
<pre>show access-control group <I-256></pre> <p>Displays the current ACL group parameters. Command mode: All</p>

ACL Metering Configuration

These commands define the Access Control profile for the selected ACL or ACL Group.

Table 199. ACL Metering Configuration Commands

Command Syntax and Usage
<pre>access-control list <1-256> meter committed-rate <64-1000000></pre> <p>Configures the committed rate, in Kilobits per second. The committed rate must be a multiple of 64.</p> <p>Command mode: Global configuration</p>
<pre>access-control list <1-256> meter maximum-burst-size <32-4096></pre> <p>Configures the maximum burst size, in Kilobits. Enter one of the following values for <code>mbsize</code>: 32, 64, 128, 256, 512, 1024, 2048, 4096</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <1-256> meter enable</pre> <p>Enables or disables ACL Metering.</p> <p>Command mode: Global configuration</p>
<pre>access-control list <1-256> meter action {drop pass}</pre> <p>Configures the ACL meter to either drop or pass out-of-profile traffic.</p> <p>Command mode: Global configuration</p>
<pre>default access-control list <1-256> meter</pre> <p>Sets the ACL meter configuration to its default values.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <1-256> meter log</pre> <p>Configures the ACL meter to log out-of-profile notifications.</p> <p>Command mode: Global configuration</p>
<pre>no access-control list <1-256> meter</pre> <p>Deletes the selected ACL meter.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list <1-256> meter</pre> <p>Displays current ACL Metering parameters.</p> <p>Command mode: All</p>

ACL Re-Mark Configuration

You can choose to re-mark IP header data for the selected ACL or ACL group. You can configure different re-mark values, based on whether packets fall within the ACL metering profile, or out of the ACL metering profile.

Table 200. ACL Re-Marking Configuration Commands

Command Syntax and Usage
<pre>access-control list <I-256> re-mark dot1p <0-7></pre> <p>Defines 802.1p value. The value is the priority bits information in the packet structure.</p> <p>Command mode: Global configuration</p>
<pre>no access-control list <I-256> re-mark dot1p</pre> <p>Disables use of 802.1p value for re-marked packets.</p> <p>Command mode: Global configuration</p>
<pre>[no] access-control list <I-256> re-mark use-tos-precedence</pre> <p>Enable or disable mapping of TOS (Type of Service) priority to 802.1p priority for In-Profile packets. When enabled, the TOS value is used to set the 802.1p value.</p> <p>Command mode: Global configuration</p>
<pre>default access-control list <I-256> re-mark</pre> <p>Sets the ACL Re-mark configuration to its default values.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list <I-256> re-mark</pre> <p>Displays current Re-mark parameters.</p> <p>Command mode: All</p>

Re-Marking In-Profile Configuration

Table 201. ACL Re-Mark In-Profile Commands

Command Syntax and Usage
<pre>access-control list <1-256> re-mark in-profile dscp <0-63></pre> <p>Sets the DiffServ Code Point (DSCP) of in-profile packets to the selected value.</p> <p>Command mode: Global configuration</p>
<pre>no access-control list <1-256> re-mark in-profile dscp</pre> <p>Disables use of DSCP value for in-profile traffic.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list <1-256> re-mark</pre> <p>Displays current re-mark parameters.</p> <p>Command mode: All</p>

Re-Marking Out-of-Profile Configuration

Table 202. ACL Re-Mark Out-of-Profile Commands

Command Syntax and Usage
<pre>access-control list <1-256> re-mark out-profile dscp <0-63></pre> <p>Sets the DiffServ Code Point (DSCP) of out-of-profile packets to the selected value. The switch sets the DSCP value on Out-of-Profile packets.</p> <p>Command mode: Global configuration</p>
<pre>no access-control list <1-256> re-mark out-profile dscp</pre> <p>Disables use of DSCP value for out-of-profile traffic.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list <1-256> re-mark</pre> <p>Displays current re-mark parameters.</p> <p>Command mode: All</p>

IPv6 Re-Marking Configuration

You can choose to re-mark IP header data for the selected ACL. You can configure different re-mark values, based on whether packets fall within or outside the ACL metering profile.

Table 203. IPv6 General Re-Mark Options

Command Syntax and Usage
<pre>[no] access-control list6 <1-128> re-mark dot1p <0-7></pre> <p>Re-marks the 802.1p value. The value is the priority bits information in the packet structure.</p> <p>Command mode: Global configuration</p>
<pre>[no] no access-control list6 <1-128> re-mark use-tos-precedence</pre> <p>Enables or disables mapping of TOS (Type of Service) priority to 802.1p priority for in-profile packets. When enabled, the TOS value is used to set the 802.1p value.</p> <p>Command mode: Global configuration</p>
<pre>default access-control list6 <1-128> re-mark</pre> <p>Sets the ACL re-mark parameters to their default values.</p> <p>Command mode: Global configuration</p>
<pre>show access-control list6 <1-128> re-mark</pre> <p>Displays current re-mark parameters.</p> <p>Command mode: All</p>

IPv6 Re-Marking In-Profile Configuration

Table 204. IPv6 Re-Mark In-Profile Options

Command Syntax and Usage
<pre>[no] access-control list6 <1-128> re-mark in-profile dscp <0-63></pre> <p>Re-marks the DSCP value for in-profile traffic. Command mode: Global configuration</p>
<pre>default access-control list6 <1-128> re-mark</pre> <p>Sets the ACL re-mark parameters to their default values. Command mode: Global configuration</p>
<pre>show access-control list6 <1-128> re-mark</pre> <p>Displays current re-mark parameters. Command mode: All</p>

Port Mirroring

Port mirroring is disabled by default. For more information about port mirroring on the CN4093, see “Appendix A: Troubleshooting” in the *IBM Networking OS 7.8 Application Guide*.

Note: Traffic on VLAN 4095 is not mirrored to the external ports.

Port Mirroring commands are used to configure, enable, and disable the monitor port. When enabled, network packets being sent and/or received on a target port are duplicated and sent to a monitor port. By attaching a network analyzer to the monitor port, you can collect detailed information about your network performance and usage.

Table 205. Port Mirroring Configuration Commands

Command Syntax and Usage
<pre>[no] port-mirroring enable</pre> <p>Enables or disables port mirroring.</p> <p>Command mode: Global configuration</p>
<pre>show port-mirroring</pre> <p>Displays current settings of the mirrored and monitoring ports.</p> <p>Command mode: All</p>

Port Mirroring Configuration

Table 206. Port-Based Port Mirroring Configuration Commands

Command Syntax and Usage
<pre>port-mirroring monitor-port <port alias or number> mirroring-port <port alias or number> {in out both}</pre> <p>Adds the port to be mirrored. This command also allows you to enter the direction of the traffic. It is necessary to specify the direction because:</p> <p>If the source port of the frame matches the mirrored port and the mirrored direction is ingress or both (ingress and egress), the frame is sent to the monitoring port.</p> <p>If the destination port of the frame matches the mirrored port and the mirrored direction is egress or both, the frame is sent to the monitoring port.</p> <p>Note: Up to two monitor ports with 2-way mirroring or four monitor ports with 1-way mirroring are supported in stand-alone mode. In stacking mode, the switch supports one monitor port with 2-way mirroring or two monitor ports with 1-way mirroring.</p> <p>Command mode: Global configuration</p>
<pre>no port-mirroring monitor-port <port alias or number> mirroring-port <port alias or number></pre> <p>Removes the mirrored port.</p> <p>Command mode: Global configuration</p>
<pre>show port-mirroring</pre> <p>Displays the current settings of the monitoring port.</p> <p>Command mode: All</p>

Layer 2 Configuration

The following table describes basic Layer 2 Configuration commands. The following sections provide more detailed information and commands.

Table 207. Layer 2 Configuration Commands

Command Syntax and Usage
<pre>vlan <VLAN number></pre> <p>Enter VLAN configuration mode. To view command options, see page 358.</p> <p>Command mode: Global configuration</p>
<pre>spanning-tree mode disable</pre> <p>When enabled, globally turns Spanning Tree <code>off</code> (selects Spanning-Tree mode “disable”). All ports are placed into forwarding state. Any BPDU’s received are flooded. BPDU Guard is not affected by this command.</p> <p>To enable Spanning-Tree, select another Spanning-Tree mode.</p> <p>Command mode: Global configuration</p>
<pre>[no] spanning-tree stg-auto</pre> <p>Enables or disables VLAN Automatic STG Assignment (VASA). When enabled, each time a new VLAN is configured, the switch will automatically assign the new VLAN its own STG. Conversely, when a VLAN is deleted, if its STG is not associated with any other VLAN, the STG is returned to the available pool.</p> <p>Note: VASA applies only to PVRST mode.</p> <p>Command mode: Global configuration</p>
<pre>[no] spanning-tree pvst-compatibility</pre> <p>Enables or disables VLAN tagging of Spanning Tree BPDUs. The default setting is <code>enabled</code>.</p> <p>Command mode: Global configuration</p>
<pre>[no] spanning-tree loopguard</pre> <p>Enables or disables Spanning Tree Loop Guard.</p> <p>Command mode: Global configuration</p>
<pre>show layer2</pre> <p>Displays current Layer 2 parameters.</p> <p>Command mode: All</p>

802.1X Configuration

These commands allow you to configure the CN4093 as an IEEE 802.1X Authenticator, to provide port-based network access control.

Table 208. 802.1X Configuration Commands

Command Syntax and Usage
<pre>dot1x enable</pre> <p>Globally enables 802.1X.</p> <p>Command mode: Global configuration</p>
<pre>no dot1x enable</pre> <p>Globally disables 802.1X.</p> <p>Command mode: Global configuration</p>
<pre>show dot1x</pre> <p>Displays current 802.1X parameters.</p> <p>Command mode: All</p>

802.1X Global Configuration

The global 802.1X commands allow you to configure parameters that affect all ports in the CN4093.

Table 209. 802.1X Global Configuration Commands

Command Syntax and Usage
<pre>dot1x mode [force-unauthorized auto force-authorized]</pre> <p>Sets the type of access control for all ports:</p> <ul style="list-style-type: none">– force-unauthorized - the port is unauthorized unconditionally.– auto - the port is unauthorized until it is successfully authorized by the RADIUS server.– force-authorized - the port is authorized unconditionally, allowing all traffic. <p>The default value is force-authorized.</p> <p>Command mode: Global configuration</p>
<pre>dot1x quiet-time <0-65535></pre> <p>Sets the time, in seconds, the authenticator waits before transmitting an EAP-Request/ Identity frame to the supplicant (client) after an authentication failure in the previous round of authentication. The default value is 60 seconds.</p> <p>Command mode: Global configuration</p>
<pre>dot1x transmit-interval <1-65535></pre> <p>Sets the time, in seconds, the authenticator waits for an EAP-Response/Identity frame from the supplicant (client) before retransmitting an EAP-Request/Identity frame. The default value is 30 seconds.</p> <p>Command mode: Global configuration</p>

Table 209. 802.1X Global Configuration Commands (continued)

Command Syntax and Usage	
dot1x supplicant-timeout <1-65535>	<p>Sets the time, in seconds, the authenticator waits for an EAP-Response packet from the supplicant (client) before retransmitting the EAP-Request packet from the authentication server. The default value is 30 seconds.</p> <p>Command mode: Global configuration</p>
dot1x server-timeout <1-65535>	<p>Sets the time, in seconds, the authenticator waits for a response from the RADIUS server before declaring an authentication timeout. The default value is 30 seconds.</p> <p>The time interval between transmissions of the RADIUS Access-Request packet containing the supplicant's (client's) EAP-Response packet is determined by the current setting of radius-server timeout <timeout-value> (default is 3 seconds).</p> <p>Command mode: Global configuration</p>
dot1x max-request <1-10>	<p>Sets the maximum number of times the authenticator retransmits an EAP-Request packet to the supplicant (client). The default value is 2.</p> <p>Command mode: Global configuration</p>
dot1x re-authentication-interval <1-604800>	<p>Sets the time, in seconds, the authenticator waits before re-authenticating a supplicant (client) when periodic re-authentication is enabled. The default value is 3600 seconds.</p> <p>Command mode: Global configuration</p>
dot1x re-authenticate	<p>Sets the re-authentication status to on. The default value is off.</p> <p>Command mode: Global configuration</p>
[no] dot1x re-authenticate	<p>Sets the re-authentication status to off. The default value is off.</p> <p>Command mode: Global configuration</p>
[no] dot1x vlan-assign	<p>Sets the dynamic VLAN assignment status to on or off. The default value is off.</p> <p>Command mode: Global configuration</p>
default dot1x	<p>Resets the global 802.1X parameters to their default values.</p> <p>Command mode: Global configuration</p>
show dot1x	<p>Displays current global 802.1X parameters.</p> <p>Command mode: All</p>

802.1X Guest VLAN Configuration

The 802.1X Guest VLAN commands allow you to configure a Guest VLAN for unauthenticated ports. The Guest VLAN provides limited access to switch functions.

Table 210. 802.1X Guest VLAN Configuration Commands

Command Syntax and Usage
<pre>[no] dot1x guest-vlan vlan <VLAN number></pre> <p>Configures the Guest VLAN number. Command mode: Global configuration</p>
<pre>dot1x guest-vlan enable</pre> <p>Enables the 802.1X Guest VLAN. Command mode: Global configuration</p>
<pre>no dot1x guest-vlan enable</pre> <p>Disables the 802.1X Guest VLAN. Command mode: Global configuration</p>
<pre>show dot1x</pre> <p>Displays current 802.1X parameters. Command mode: All</p>

802.1X Port Configuration

The 802.1X port commands allows you to configure parameters that affect the selected port in the CN4093. These settings override the global 802.1X parameters.

Table 211. 802.1X Port Commands

Command Syntax and Usage
<pre>dot1x mode force-unauthorized auto force-authorized</pre> <p>Sets the type of access control for the port:</p> <ul style="list-style-type: none"> – force-unauthorized - the port is unauthorized unconditionally. – auto - the port is unauthorized until it is successfully authorized by the RADIUS server. – force-authorized - the port is authorized unconditionally, allowing all traffic. <p>The default value is force-authorized.</p> <p>Command mode: Interface port</p>
<pre>dot1x quiet-time <0-65535></pre> <p>Sets the time, in seconds, the authenticator waits before transmitting an EAP-Request/ Identity frame to the supplicant (client) after an authentication failure in the previous round of authentication. The default value is 60 seconds.</p> <p>Command mode: Interface port</p>
<pre>dot1x transmit-interval <1-65535></pre> <p>Sets the time, in seconds, the authenticator waits for an EAP-Response/Identity frame from the supplicant (client) before retransmitting an EAP-Request/Identity frame. The default value is 30 seconds.</p> <p>Command mode: Interface port</p>
<pre>dot1x supplicant-timeout <1-65535></pre> <p>Sets the time, in seconds, the authenticator waits for an EAP-Response packet from the supplicant (client) before retransmitting the EAP-Request packet from the authentication server. The default value is 30 seconds.</p> <p>Command mode: Interface port</p>
<pre>dot1x server-timeout <1-65535></pre> <p>Sets the time, in seconds, the authenticator waits for a response from the RADIUS server before declaring an authentication timeout. The default value is 30 seconds.</p> <p>The time interval between transmissions of the RADIUS Access-Request packet containing the supplicant's (client's) EAP-Response packet is determined by the current setting of the radius-server timeout command.</p> <p>Command mode: Interface port</p>
<pre>dot1x max-request <1-10></pre> <p>Sets the maximum number of times the authenticator retransmits an EAP-Request packet to the supplicant (client). The default value is 2.</p> <p>Command mode: Interface port</p>

Table 211. 802.1X Port Commands (continued)

Command Syntax and Usage	
dot1x re-authentication-interval <1-604800>	<p>Sets the time, in seconds, the authenticator waits before re-authenticating a supplicant (client) when periodic re-authentication is enabled. The default value is 3600 seconds.</p> <p>Command mode: Interface port</p>
dot1x re-authenticate	<p>Sets the re-authentication status to <code>on</code>. The default value is <code>off</code>.</p> <p>Command mode: Interface port</p>
[no] dot1x re-authenticate	<p>Sets the re-authentication status <code>off</code>. The default value is <code>off</code>.</p> <p>Command mode: Interface port</p>
[no] dot1x vlan-assign	<p>Sets the dynamic VLAN assignment status to <code>on</code> or <code>off</code>. The default value is <code>off</code>.</p> <p>Command mode: Interface port</p>
default dot1x	<p>Resets the 802.1X port parameters to their default values.</p> <p>Command mode: Interface port</p>
dot1x apply-global	<p>Applies current global 802.1X configuration parameters to the port.</p> <p>Command mode: Interface port</p>
show interface port <port alias or number> dot1x	<p>Displays current 802.1X port parameters.</p> <p>Command mode: All</p>

Spanning Tree Configuration

IBM Networking OS supports the IEEE 802.1D (2004) Rapid Spanning Tree Protocol (RSTP), the IEEE 802.1Q (2003) Multiple Spanning Tree Protocol (MSTP), and Per VLAN Rapid Spanning Tree Protocol (PVRST+). STP is used to prevent loops in the network topology. Up to 128 Spanning Tree Groups can be configured on the switch (STG 128 is reserved for management).

Note: When VRRP is used for active/active redundancy, STG must be enabled.

Table 212. Spanning Tree Configuration Options

Command Syntax and Usage	
<pre>spanning-tree mode [disable mst pvrst rstp]</pre>	<p>Selects and enables Multiple Spanning Tree mode (<code>mst</code>), Per VLAN Rapid Spanning Tree mode (<code>pvrst</code>), or Rapid Spanning Tree mode (<code>rstp</code>).</p> <p>The default mode is PVRST+.</p> <p>When you select <code>spanning-tree mode disable</code>, the switch globally turns Spanning Tree <code>off</code>. All ports are placed into forwarding state. Any BPDU's received are flooded. BPDU Guard is not affected by this command.</p> <p>Command mode: Global configuration</p>
<pre>[no] spanning-tree stg-auto</pre>	<p>Enables or disables VLAN Automatic STG Assignment (VASA). When enabled, each time a new VLAN is configured, the switch will automatically assign the new VLAN its own STG. Conversely, when a VLAN is deleted, if its STG is not associated with any other VLAN, the STG is returned to the available pool.</p> <p>Note: When using VASA, a maximum number of automatically assigned STGs is supported.</p> <p>Note: VASA applies only to PVRST mode.</p> <p>Command mode: Global configuration</p>
<pre>[no] spanning-tree pvst-compatibility</pre>	<p>Enables or disables VLAN tagging of Spanning Tree BPDUs. The default setting is enabled.</p> <p>Command mode: Global configuration</p>
<pre>[no] spanning-tree portfast</pre>	<p>Enables or disables this port as portfast or edge port. An edge port is not connected to a bridge, and can begin forwarding traffic as soon as the link is up. Configure server ports as edge ports (<code>enabled</code>).</p> <p>Note: After you configure the port as an edge port, you must disable the port and then re-enable the port for the change to take effect.</p> <p>Command mode: Interface port/Interface portchannel</p>

Table 212. Spanning Tree Configuration Options (continued)

Command Syntax and Usage	
[no] spanning-tree link-type {p2p shared auto}	<p>Defines the type of link connected to the port, as follows:</p> <ul style="list-style-type: none"> – auto: Configures the port to detect the link type, and automatically match its settings. – p2p: Configures the port for Point-To-Point protocol. – shared: Configures the port to connect to a shared medium (usually a hub). <p>The default link type is auto.</p> <p>Command mode: Interface port/Interface portchannel</p>
[no] spanning-tree pvst-protection	<p>Enables or disables PVST Protection on the selected port. If the port receives any PVST+/PVRST+ BPDUs, it is error disabled. The default setting for this feature is disabled (no protection).</p> <p>Command mode: Interface port/Interface portchannel</p>
spanning-tree guard loop	<p>Enables STP loop guard. STP loop guard prevents the port from forwarding traffic if no BPDUs are received. The port is placed into a loop-inconsistent blocking state until a BPDU is received.</p> <p>Command mode: Interface port/Interface portchannel</p>
spanning-tree guard root	<p>Enables STP root guard. STP root guard enforces the position of the root bridge. If the bridge receives a superior BPDU, the port is placed into a root-inconsistent state (listening).</p> <p>Command mode: Interface port/Interface portchannel</p>
spanning-tree guard none	<p>Disables STP loop guard and root guard.</p> <p>Command mode: Interface port/Interface portchannel</p>
no spanning-tree guard	<p>Sets the Spanning Tree guard parameters to their default values.</p> <p>Command mode: Interface port/Interface portchannel</p>

Table 212. Spanning Tree Configuration Options (continued)

Command Syntax and Usage	
<pre>show spanning-tree</pre>	<p>Displays Spanning Tree information, including the status (on or off), Spanning Tree mode (RSTP, PVRST, or MSTP), and VLAN membership.</p> <p>In addition to seeing if STG is enabled or disabled, you can view the following STG bridge information:</p> <ul style="list-style-type: none"> – Priority – Hello interval – Maximum age value – Forwarding delay – Aging time <p>You can also see the following port-specific STG information:</p> <ul style="list-style-type: none"> – Port alias and priority – Cost – State <p>Command mode: All</p>
<pre>show spanning-tree root</pre>	<p>Displays the Spanning Tree configuration on the root bridge for each STP instance. For details, see page 54.</p> <p>Command mode: All</p>
<pre>show spanning-tree blockedports</pre>	<p>Lists the ports blocked by each STP instance.</p> <p>Command mode: All</p>
<pre>show spanning-tree [vlan <VLAN ID>] bridge</pre>	<p>Displays Spanning Tree bridge information. For details, see page 53.</p> <p>Command mode: All</p>

MSTP Configuration

Up to 32 Spanning Tree Groups can be configured in MSTP mode. MSTP is turned off by default and the default STP mode is PVRST+.

Note: When Multiple Spanning Tree is turned on, VLAN 4095 is moved from Spanning Tree Group 128 to the Common Internal Spanning Tree (CIST). When Multiple Spanning Tree is turned off, VLAN 4095 is moved back to Spanning Tree Group 128.

Table 213. Multiple Spanning Tree Configuration Options

Command Syntax and Usage
<p>spanning-tree mst configuration</p> <p>Enables MSTP configuration mode.</p> <p>Command mode: Global configuration</p>
<p>[no] name <1-32 characters></p> <p>Configures a name for the MSTP region. All devices within an MSTP region must have the same region name.</p> <p>Command mode: MST configuration</p>
<p>[no] revision <0-65535></p> <p>Configures a revision number for the MSTP region. The revision is used as a numerical identifier for the region. All devices within an MSTP region must have the same revision number.</p> <p>Command mode: MST configuration</p>
<p>spanning-tree mst max-hops <4-60></p> <p>Configures the maximum number of bridge hops a packet may traverse before it is dropped. The default value is 20.</p> <p>Command mode: Global configuration</p>
<p>[no] spanning-tree mst <0-32> enable</p> <p>Enables or disables the specified MSTP instance.</p> <p>Command mode: Global configuration</p>
<p>spanning-tree mst forward-time <4-30></p> <p>Configures the forward delay time in seconds. The forward delay parameter specifies the amount of time that a bridge port has to wait before it changes from the listening state to the learning state and from the learning state to the forwarding state. Default value is 15.</p> <p>Command mode: Global configuration</p>
<p>spanning-tree mst max-age <6-40></p> <p>Configures the maximum age interval in seconds. The maximum age parameter specifies the maximum time the bridge waits without receiving a configuration bridge protocol data unit before it reconfigures the MSTP network. Default value is 20.</p> <p>Command mode: Global configuration</p>

Table 213. Multiple Spanning Tree Configuration Options (continued)

Command Syntax and Usage	
default spanning-tree mst <0-32>	Restores the Spanning Tree instance to its default configuration. Command mode: Global configuration
instance <0-32> vlan <VLAN numbers>	Map the specified VLANs to the Spanning Tree instance. If a VLAN does not exist, it will be created automatically, but it will not be enabled by default. Command mode: MST configuration
no instance <1-32> vlan <VLAN numbers>	Remove the specified VLAN from the Spanning Tree instance. Command mode: MST configuration
spanning-tree mst <0-32> priority <0-65535>	Configures the CIST bridge priority for the specified MSTP instance. The bridge priority parameter controls which bridge on the network is the MSTP root bridge. To make this switch the root bridge, configure the bridge priority lower than all other switches and bridges on your network. The lower the value, the higher the bridge priority. The range is 0 to 65535, in steps of 4096 (0, 4096, 8192...); the default value is 61440. Command mode: Global configuration
no spanning-tree mst configuration	Returns the MST region to its default values: no VLAN is mapped to any MST instance. Revision number is reset to 0. Command mode: Global configuration
show spanning-tree mst <0-32> information	Displays the current CIST configuration for the specified instance. Command mode: All
show spanning-tree mst configuration	Displays the current MSTP settings. Command mode: All

MSTP Port Configuration

MSTP port parameters are used to modify MSTP operation on an individual port basis. MSTP parameters do not affect operation of RSTP/PVRST..

Table 214. MSTP Port Configuration Options

Command Syntax and Usage	
<pre>spanning-tree mst <0-32> port-priority <0-240></pre>	<p>Configures the port priority for the specified MSTP instance. The port priority helps determine which bridge port becomes the designated port. In a network topology that has multiple bridge ports connected to a single segment, the port with the lowest port priority becomes the designated port for the segment.</p> <p>The range is 0 to 240, in steps of 16 (0, 16, 32...), and the default is 128.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>spanning-tree mst <0-32> cost <0-200000000></pre>	<p>Configures the port path cost for the specified MSTP instance. The port path cost is used to help determine the designated port for a segment. Port path cost is based on the port speed, and is calculated as follows:</p> <ul style="list-style-type: none"> – 1Gbps = 20000 – 10Gbps = 2000 <p>The default value of 0 (zero) indicates that the default path cost will be computed for an auto negotiated link speed.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>spanning-tree mst hello-time <1-10></pre>	<p>Configures the port Hello time. The Hello time specifies how often the root bridge transmits a configuration bridge protocol data unit (BPDU). Any bridge that is not the root bridge uses the root bridge Hello value. The range is 1 to 10 seconds, and the default is 2 seconds.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>[no] spanning-tree pvst-protection</pre>	<p>Configures PVST Protection on the selected port. If the port receives any PVST+/PVRST+ BPDUs, it error disabled. PVST Protection works only in MSTP mode. The default setting is <i>disabled</i>.</p> <p>Note: Not available in stacking.</p> <p>Command mode: Interface port</p>
<pre>[no] spanning-tree mst <0-32> enable</pre>	<p>Enables or disables the specified MSTP instance on the port.</p> <p>Command mode: Interface port/Interface portchannel</p>
<pre>show interface port <port alias or number> spanning-tree mstp cist</pre>	<p>Displays the current CIST port configuration.</p> <p>Command mode: All</p>

RSTP/PVRST Configuration

[Table 215](#) describes the commands used to configure the Rapid Spanning Tree (RSTP) and Per VLAN Rapid Spanning Tree Protocol (PVRST+) protocols.

Table 215. RSTP/PVRST Configuration Options

Command Syntax and Usage	
<pre>spanning-tree stp <STG number> vlan <VLAN number></pre>	<p>Associates a VLAN with a Spanning Tree Group and requires a VLAN ID as a parameter. If the VLAN does not exist, it will be created automatically, but it will not be enabled by default.</p> <p>Command mode: Global configuration</p>
<pre>no spanning-tree stp <STG number> vlan <VLAN number></pre>	<p>Breaks the association between a VLAN and a Spanning Tree Group and requires a VLAN ID as a parameter.</p> <p>Command mode: Global configuration</p>
<pre>no spanning-tree stp <STG number> vlan all</pre>	<p>Removes all VLANs from a Spanning Tree Group.</p> <p>Command mode: Global configuration</p>
<pre>spanning-tree stp <STG number> enable</pre>	<p>Enables Spanning Tree instance. STG is turned on by default.</p> <p>Command mode: Global configuration</p>
<pre>no spanning-tree stp <STG number> enable</pre>	<p>Disables Spanning Tree instance. STG is turned on by default.</p> <p>Command mode: Global configuration</p>
<pre>default spanning-tree <STG number></pre>	<p>Restores a Spanning Tree instance to its default configuration.</p> <p>Command mode: Global configuration</p>
<pre>show spanning-tree stp <STG number> [information]</pre>	<p>Displays current Spanning Tree Protocol parameters for the specified Spanning Tree Group. See page 49 for details about the <code>information</code> parameter.</p> <p>Command mode: All</p>

Bridge RSTP/PVRST Configuration

Spanning Tree bridge parameters affect the global STG operation of the switch. STG bridge parameters include:

- Bridge priority
- Bridge hello time
- Bridge maximum age
- Forwarding delay

Table 216. Bridge Spanning Tree Configuration Options

Command Syntax and Usage
<pre>spanning-tree stp <STG number> bridge priority <0-65535></pre> <p>Configures the bridge priority. The bridge priority parameter controls which bridge on the network is the STG root bridge. To make this switch the root bridge, configure the bridge priority lower than all other switches and bridges on your network. The lower the value, the higher the bridge priority. The range is 0 to 65535, in steps of 4096 (0, 4096, 8192...); the default value is 61440.</p> <p>Command mode: Global configuration</p>
<pre>spanning-tree stp <STG number> bridge hello-time <1-10></pre> <p>Configures the bridge Hello time. The Hello time specifies how often the root bridge transmits a configuration bridge protocol data unit (BPDU). Any bridge that is not the root bridge uses the root bridge Hello value. The range is 1 to 10 seconds, and the default is 2 seconds.</p> <p>This command does not apply to MSTP.</p> <p>Command mode: Global configuration</p>
<pre>spanning-tree stp <STG number> bridge maximum-age <6-40></pre> <p>Configures the bridge maximum age. The maximum age parameter specifies the maximum time the bridge waits without receiving a configuration bridge protocol data unit before it re configures the STG network. The range is 6 to 40 seconds, and the default is 20 seconds.</p> <p>This command does not apply to MSTP.</p> <p>Command mode: Global configuration</p>
<pre>spanning-tree stp <STG number> bridge forward-delay <4-30></pre> <p>Configures the bridge forward delay parameter. The forward delay parameter specifies the amount of time that a bridge port has to wait before it changes from the listening state to the learning state and from the learning state to the forwarding state. The range is 4 to 30 seconds, and the default is 15 seconds.</p> <p>This command does not apply to MSTP.</p> <p>Command mode: Global configuration</p>
<pre>show spanning-tree [vlan <VLAN ID>] bridge</pre> <p>Displays the current Spanning Tree parameters either globally or for a specific VLAN. See page 53 for sample output.</p> <p>Command mode: All</p>

When configuring STG bridge parameters, the following formulas must be used:

- $2^{*(fwd-1)} \geq mxage$

- $2*(hello+1) \leq mxage$

RSTP/PVRST Port Configuration

By default, Spanning Tree is turned `off` for management ports, and turned `on` for data ports. STG port parameters include:

- Port priority
- Port path cost

Table 217. Spanning Tree Port Options

Command Syntax and Usage
<pre>spanning-tree stp <STG number> priority <0-240></pre> <p>Configures the port priority. The port priority helps determine which bridge port becomes the designated port. In a network topology that has multiple bridge ports connected to a single segment, the port with the lowest port priority becomes the designated port for the segment. The range is 0 to 240, in steps of 16 (0, 16, 32...) and the default is 128.</p> <p>Command mode: Interface port</p>
<pre>spanning-tree stp <STG number> path-cost <1-200000000, 0 for default></pre> <p>Configures the port path cost. The port path cost is used to help determine the designated port for a segment. Port path cost is based on the port speed, and is calculated as follows:</p> <ul style="list-style-type: none"> – 1Gbps = 20000 – 10Gbps = 2000 <p>The default value of 0 (zero) indicates that the default path cost will be computed for an auto negotiated link speed.</p> <p>Command mode: Interface port</p>
<pre>spanning-tree stp link-type {auto p2p shared}</pre> <p>Defines the type of link connected to the port, as follows:</p> <ul style="list-style-type: none"> – <code>auto</code>: Configures the port to detect the link type, and automatically match its settings. – <code>p2p</code>: Configures the port for Point-To-Point protocol. – <code>shared</code>: Configures the port to connect to a shared medium (usually a hub). <p>Command mode: Interface port</p>
<pre>spanning-tree stp <STG number> enable</pre> <p>Enables STG on the port.</p> <p>Command mode: Interface port</p>

Table 217. Spanning Tree Port Options (continued)

Command Syntax and Usage
<pre>no spanning-tree stp <STG number> enable</pre> <p>Disables STG on the port. Command mode: Interface port</p>
<pre>show interface port <port alias or number> spanning-tree stp <STG number></pre> <p>Displays the current STG port parameters. Command mode: All</p>

Forwarding Database Configuration

Use the following commands to configure the Forwarding Database (FDB).

Table 218. FDB Configuration Commands

Command Syntax and Usage
<pre>mac-address-table aging <0-65535></pre> <p>Configures the aging value for FDB entries, in seconds. The default value is 300. Command mode: Global configuration</p>
<pre>[no] mac-address-table mac-notification</pre> <p>Enables or disables MAC address notification. This is applicable for internal ports only. Command mode: Global configuration</p>
<pre>show mac-address-table</pre> <p>Display current FDB configuration. Command mode: All</p>

Static Multicast MAC Configuration

The following options are available to control the forwarding of known and unknown multicast packets:

- All multicast packets are flooded to the entire VLAN. This is the default switch behavior.
- Known multicast packets are forwarded only to those ports specified. Unknown multicast packets are flooded to the entire VLAN. To configure this option, define the Multicast MAC address for the VLAN and specify ports that are to receive multicast packets (`mac-address-table multicast`).
- Known multicast packets are forwarded only to those ports specified. Unknown multicast packets are dropped. To configure this option:
 - Define the Multicast MAC address for the VLAN and specify ports that are to receive multicast packets (`mac-address-table multicast`).
 - Enable Flood Blocking on ports that are not to receive multicast packets (`interface port x`) (`flood-blocking`).

Use the following commands to configure static Multicast MAC entries in the Forwarding Database (FDB).

Table 219. Static Multicast MAC Configuration Commands

Command Syntax and Usage
<pre>mac-address-table multicast <MAC address> <VLAN number> <port alias or number></pre> <p>Adds a static multicast entry. You can list ports separated by a space, or enter a range of ports separated by a hyphen (-). For example:</p> <pre>mac-address-table multicast 01:00:00:23:3f:01 200 int1-int4</pre> <p>Command mode: Global configuration</p>
<pre>no mac-address-table multicast <MAC address> <VLAN number> <port alias or number></pre> <p>Deletes a static multicast entry.</p> <p>Command mode: Global configuration</p>
<pre>show mac-address-table multicast</pre> <p>Display the current static multicast entries.</p> <p>Command mode: All</p>

Static FDB Configuration

Use the following commands to configure static entries in the Forwarding Database (FDB).

Table 220. FDB Configuration Commands

Command Syntax and Usage
<pre>mac-address-table static <MAC address> vlan <VLAN number> {port <port alias or number> portchannel <trunk number> adminkey <1-65535>}</pre> <p>Adds a permanent FDB entry. Enter the MAC address using the following format, xx:xx:xx:xx:xx:xx</p> <p>For example, 08:00:20:12:34:56</p> <p>You can also enter the MAC address as follows: xxxxxxxxxxxx</p> <p>For example, 080020123456</p> <p>Command mode: Global configuration</p>
<pre>no mac-address-table static <MAC address> <VLAN number></pre> <p>Deletes a permanent FDB entry.</p> <p>Command mode: Global configuration</p>
<pre>show mac-address-table</pre> <p>Display current FDB configuration.</p> <p>Command mode: All</p>

ECP Configuration

Use the following commands to configure Edge Control Protocol (ECP).

Table 221. ECP Configuration Options

Command Syntax and Usage
<pre>ecp retransmit-interval <100-9000></pre> <p>Configures ECP retransmit interval in milliseconds. Default value is 1000.</p> <p>Command mode: Global configuration</p>
<pre>default ecp retransmit-interval</pre> <p>Resets the ECP retransmit interval to the default 1000 milliseconds.</p> <p>Command mode: Global configuration</p>
<pre>show ecp [channels upper-layer-protocols]</pre> <p>Displays settings for all ECP channels or registered ULPs.</p> <p>Command mode: All</p>

LLDP Configuration

Use the following commands to configure Link Layer Detection Protocol (LLDP).

Table 222. LLDP Configuration Commands

Command Syntax and Usage
<pre>lldp refresh-interval <5-32768></pre> <p>Configures the message transmission interval, in seconds. The default value is 30.</p> <p>Command mode: Global configuration</p>
<pre>lldp holdtime-multiplier <2-10></pre> <p>Configures the message hold time multiplier. The hold time is configured as a multiple of the message transmission interval.</p> <p>The default value is 4.</p> <p>Command mode: Global configuration</p>
<pre>lldp trap-notification-interval <1-3600></pre> <p>Configures the trap notification interval, in seconds. The default value is 5.</p> <p>Command mode: Global configuration</p>
<pre>lldp transmission-delay <1-8192></pre> <p>Configures the transmission delay interval. The transmit delay timer represents the minimum time permitted between successive LLDP transmissions on a port.</p> <p>The default value is 2.</p> <p>Command mode: Global configuration</p>
<pre>lldp reinit-delay <1-10></pre> <p>Configures the re-initialization delay interval, in seconds. The re-initialization delay allows the port LLDP information to stabilize before transmitting LLDP messages.</p> <p>The default value is 2.</p> <p>Command mode: Global configuration</p>
<pre>lldp enable</pre> <p>Globally turns LLDP on. The default setting is on.</p> <p>Command mode: Global configuration</p>
<pre>no lldp enable</pre> <p>Globally turns LLDP off.</p> <p>Command mode: Global configuration</p>
<pre>show lldp</pre> <p>Display current LLDP configuration.</p> <p>Command mode: All</p>

LLDP Port Configuration

Use the following commands to configure LLDP port options.

Table 223. LLDP Port Commands

Command Syntax and Usage
<pre>lldp admin-status {disabled tx_only rx_only tx_rx}</pre> <p>Configures the LLDP transmission type for the port, as follows:</p> <ul style="list-style-type: none">– Transmit only– Receive only– Transmit and receive– Disabled <p>The default setting is <code>tx_rx</code>.</p> <p>Command mode: Interface port</p>
<pre>[no] lldp trap-notification</pre> <p>Enables or disables SNMP trap notification for LLDP messages.</p> <p>Command mode: Interface port</p>
<pre>show interface port <port alias or number> lldp</pre> <p>Display current LLDP port configuration.</p> <p>Command mode: All</p>

LLDP Optional TLV configuration

Use the following commands to configure LLDP port TLV (Type, Length, Value) options for the selected port.

Table 224. Optional TLV Commands

Command Syntax and Usage
[no] lldp tlv portdesc Enables or disables the Port Description information type. Command mode: Interface port
[no] lldp tlv sysname Enables or disables the System Name information type. Command mode: Interface port
[no] lldp tlv sysdescr Enables or disables the System Description information type. Command mode: Interface port
[no] lldp tlv syscap Enables or disables the System Capabilities information type. Command mode: Interface port
[no] lldp tlv mgmtaddr Enables or disables the Management Address information type. Command mode: Interface port
[no] lldp tlv portvid Enables or disables the Port VLAN ID information type. Command mode: Interface port
[no] lldp tlv portprot Enables or disables the Port and VLAN Protocol ID information type. Command mode: Interface port
[no] lldp tlv vlanname Enables or disables the VLAN Name information type. Command mode: Interface port
[no] lldp tlv protid Enables or disables the Protocol ID information type. Command mode: Interface port
[no] lldp tlv macphy Enables or disables the MAC/Phy Configuration information type. Command mode: Interface port

Table 224. Optional TLV Commands (continued)

Command Syntax and Usage	
[no] lldp tlv powermdi	Enables or disables the Power via MDI information type. Command mode: Interface port
[no] lldp tlv linkaggr	Enables or disables the Link Aggregation information type. Command mode: Interface port
[no] lldp tlv framesz	Enables or disables the Maximum Frame Size information type. Command mode: Interface port
[no] lldp tlv dcbx	Enables or disables the Data Center Bridging Capability Exchange (DCBX) information type. Command mode: Interface port
[no] lldp tlv all	Enables or disables all optional TLV information types. Command mode: Interface port
show interface port <port alias or number> lldp	Display current LLDP port configuration. Command mode: All

Trunk Configuration

Trunk groups can provide super-bandwidth connections between CN4093 or other trunk capable devices. A *trunk* is a group of ports that act together, combining their bandwidth to create a single, larger port. Up to 64 trunk groups can be configured on the CN4093, with the following restrictions:

- Any physical switch port can belong to no more than one trunk group.
- Up to 16 ports can belong to the same trunk group.
- Configure all ports in a trunk group with the same properties (speed, duplex, flow control, STG, VLAN, and so on).
- Trunking from non-IBM devices must comply with Cisco® EtherChannel® technology and exclude the PAgP networking protocol.

By default, each trunk group is empty and disabled.

Table 225. Trunk Configuration Commands

Command Syntax and Usage
<pre>portchannel <1-64> port <port alias or number></pre> <p>Adds a physical port or ports to the current trunk group. You can add several ports, with each port separated by a comma (,) or a range of ports, separated by a dash (-).</p> <p>Command mode: Global configuration</p>
<pre>no portchannel <1-64> port <port alias or number></pre> <p>Removes a physical port or ports from the current trunk group.</p> <p>Command mode: Global configuration</p>
<pre>[no] portchannel <1-64> enable</pre> <p>Enables or Disables the current trunk group.</p> <p>Command mode: Global configuration</p>
<pre>no portchannel <1-64></pre> <p>Removes the current trunk group configuration.</p> <p>Command mode: Global configuration</p>
<pre>show portchannel <1-64></pre> <p>Displays current trunk group parameters.</p> <p>Command mode: All</p>

IP Trunk Hash Configuration

Use the following commands to configure IP trunk hash settings for the CN4093. Trunk hash parameters are set globally for the CN4093. The trunk hash settings affect both static trunks and LACP trunks.

To achieve the most even traffic distribution, select options that exhibit a wide range of values for your particular network. You may use the configuration settings listed in [Table 226](#) combined with the hash parameters listed in [Table 227](#).

Table 226. Trunk Hash Settings

Command Syntax and Usage
<pre>[no] portchannel hash ingress</pre> <p>Enables or disables use of the ingress port to compute the trunk hash value. The default setting is disabled.</p> <p>Command mode: Global configuration</p>
<pre>[no] portchannel hash L4port</pre> <p>Enables or disables use of Layer 4 service ports (TCP, UDP, etc.) to compute the hash value. The default setting is disabled.</p> <p>Command mode: Global configuration</p>
<pre>show portchannel hash</pre> <p>Display current trunk hash configuration.</p> <p>Command mode: All</p>

Layer 2 Trunk Hash

Layer 2 trunk hash parameters are set globally. You can enable one or both parameters, to configure any of the following valid combinations:

- SMAC (source MAC only)
- DMAC (destination MAC only)
- SMAC and DMAC

Use the following commands to configure Layer 2 trunk hash parameters for the switch.

Table 227. Layer 2 Trunk Hash Options

Command Syntax and Usage
<pre>[no] portchannel thash l2hash l2-source-mac-address</pre> <p>Enables or disables Layer 2 trunk hashing on the source MAC.</p> <p>Command mode: Global configuration</p>
<pre>[no] portchannel thash l2hash l2-destination-mac-address</pre> <p>Enables or disables Layer 2 trunk hashing on the destination MAC.</p> <p>Command mode: Global configuration</p>

Table 227. Layer 2 Trunk Hash Options (continued)

Command Syntax and Usage
<pre>[no] portchannel thash l2hash l2-source-destination-mac</pre> <p>Enables or disables Layer 2 trunk hashing on both the source and destination MAC.</p> <p>Command mode: Global configuration</p>
<pre>show portchannel hash</pre> <p>Displays the current trunk hash settings.</p> <p>Command mode: All</p>

Layer 3 Trunk Hash

Layer 3 trunk hash parameters are set globally. You can enable one or both parameters, to configure any of the following valid combinations:

- SIP (source IP only)
- DIP (destination IP only)
- SIP and DIP

Use the following commands to configure Layer 3 trunk hash parameters for the switch.

Table 228. Layer 3 Trunk Hash Options

Command Syntax and Usage
<pre>[no] portchannel thash l3thash l3-use-l2-hash</pre> <p>Enables or disables use of Layer 2 hash parameters only. When enabled, Layer 3 hashing parameters are cleared.</p> <p>Command mode: Global configuration</p>
<pre>[no] portchannel thash l3thash l3-source-ip-address</pre> <p>Enables or disables Layer 3 trunk hashing on the source IP address.</p> <p>Command mode: Global configuration</p>
<pre>[no] portchannel thash l3thash l3-destination-ip-address</pre> <p>Enables or disables Layer 3 trunk hashing on the destination IP address.</p> <p>Command mode: Global configuration</p>
<pre>[no] portchannel thash l3thash l3-source-destination-ip</pre> <p>Enables or disables Layer 3 trunk hashing on both the source and the destination IP address.</p> <p>Command mode: Global configuration</p>
<pre>show portchannel hash</pre> <p>Displays the current trunk hash settings.</p> <p>Command mode: All</p>

Virtual Link Aggregation Control Protocol Configuration

Use the following commands to configure Virtual Link Aggregation Control Protocol (vLAG) for the CN4093.

Table 229. Virtual Link Aggregation Control Protocol Commands

Command Syntax and Usage
<pre>[no] vlag portchannel <1-64> enable</pre> <p>Enables or disables the vLAG underlying trunk.</p> <p>Command mode: Global configuration</p>
<pre>[no] vlag adminkey <1-65535> enable</pre> <p>Enables or disables vLAG on the selected LACP <i>admin key</i>. LACP trunks formed with this <i>admin key</i> will be included in the vLAG configuration.</p> <p>Command mode: Global configuration</p>
<pre>[no] vlag enable</pre> <p>Enables or disables vLAG globally.</p> <p>Command mode: Global configuration</p>
<pre>[no] vlag tier-id <1-512></pre> <p>Sets the vLAG peer ID.</p> <p>Command mode: Global configuration</p>
<pre>vlag priority <0-65535></pre> <p>Configures the vLAG priority for the switch, used for election of Primary and Secondary vLAG switches. The switch with lower priority is elected to the role of Primary vLAG switch.</p> <p>Command mode: Global configuration</p>
<pre>vlag auto-recovery <240-3600></pre> <p>Sets the duration in seconds of the auto-recovery timer. This timer configures how long after boot-up configuration load, the switch can assume the Primary role from an unresponsive ISL peer and bring up the vLAG ports.</p> <p>The default value is 300.</p> <p>Command mode: Global configuration</p>
<pre>no vlag auto-recovery</pre> <p>Sets the auto-recovery timer to the default 300 seconds duration.</p> <p>Command mode: Global configuration</p>

Table 229. Virtual Link Aggregation Control Protocol Commands (continued)

Command Syntax and Usage
<pre>[no] vlag startup-delay <1-3600></pre> <p>Sets the vLAG startup-delay value in seconds to the specified value. No command sets the default to 120 seconds.</p> <p>Note: Startup delay gives vLAG the ability to prevent traffic loss after a reboot. When a vLAG switch reboots, the vLAG ports are in an errdisabled state. After ISL is up, the vLAG ports are started one by one after the specified startup delay time. This specified time allows the switch to get BGP/OSFP ready through the uplinks so when the vLAG port starts up, all the traffic through those links flows smoothly. Admin status of the ports is honored by the vlag startup delay. For example, if the admin status of the vLAG port is down, those ports will be kept down even after the vLAG start-up delay.</p> <p>Command mode: Global configuration</p>
<pre>show vlag</pre> <p>Display current vLAG configuration.</p> <p>Command mode: All</p>

vLAG Health Check Configuration

These commands allow you to configure a health check of synchronization between vLAG peers.

Table 230. vLAG Health Check Configuration Options

Command Syntax and Usage
<pre>vlag hlthchk peer-ip {<IP address> <IPv6 address>}</pre> <p>Configures the IP address of the vLAG peer.</p> <p>Command mode: Global configuration</p>
<pre>[no] vlag hlthchk connect-retry-interval <1-300></pre> <p>Sets in seconds the vLAG health check connect retry interval, in seconds. The default value is 30.</p> <p>Command mode: Global configuration</p>
<pre>[no] vlag hlthchk keepalive-attempts <1-24></pre> <p>Sets the number of vLAG keep alive attempts. The default value is 3.</p> <p>Command mode: Global configuration</p>
<pre>[no] vlag hlthchk keepalive-interval <2-300></pre> <p>Sets the time between vLAG keep alive attempts, in seconds. The default value is 5.</p> <p>Command mode: Global configuration</p>

vLAG ISL Configuration

These commands allow you to configure a dedicated inter-switch link (ISL) for synchronization between vLAG peers.

Table 231. vLAG ISL Configuration Options

Command Syntax and Usage
<pre>[no] vlag isl portchannel <1-64></pre> <p>Enables or disables vLAG Inter-Switch Link (ISL) on the selected trunk group. Command mode: Global configuration</p>
<pre>[no] vlag isl adminkey <1-65535></pre> <p>Enables or disables vLAG Inter-Switch Link (ISL) on the selected LACP <i>admin key</i>. LACP trunks formed with this <i>admin key</i> will be included in the ISL. Command mode: Global configuration</p>
<pre>show vlag information</pre> <p>Displays current vLAG parameters. Command mode: All</p>

Link Aggregation Control Protocol Configuration

Use the following commands to configure Link Aggregation Control Protocol (LACP) for the CN4093.

Table 232. Link Aggregation Control Protocol Commands

Command Syntax and Usage
<pre>lacp system-priority <I-65535></pre> <p>Defines the priority value for the CN4093. Lower numbers provide higher priority. The default value is 32768.</p> <p>Command mode: Global configuration</p>
<pre>lacp timeout {short long}</pre> <p>Defines the timeout period before invalidating LACP data from a remote partner. Choose <i>short</i> (3 seconds) or <i>long</i> (90 seconds). The default value is <i>long</i>.</p> <p>Note: It is recommended that you use a timeout value of <i>long</i>, to reduce LACPDU processing. If your CN4093's CPU utilization rate remains at 100% for periods of 90 seconds or more, consider using static trunks instead of LACP.</p> <p>Command mode: Global configuration</p>
<pre>default lacp [system-priority timeout]</pre> <p>Restores either the VFSM priority value, timeout period or both to their default values.</p> <p>Command mode: Global configuration</p>
<pre>no lacp <I-65535></pre> <p>Deletes a selected LACP trunk, based on its <i>admin key</i>. This command is equivalent to disabling LACP on each of the ports configured with the same <i>admin key</i>.</p> <p>Command mode: Global configuration</p>
<pre>portchannel <trunk ID> lacp key <I-65535></pre> <p>Enables a static LACP trunk. In this mode, ports sharing the same LACP admin key can form a single trunk, with the specified <i>trunk ID</i>. The active trunk is picked based on the ports which occupy first the trunk ID. Member ports that cannot join this trunk are prohibited from forming secondary LACP groups. Instead, they are set in a suspend state where they discard all non-LACP traffic.</p> <p>Command mode: Global configuration</p>
<pre>no portchannel <trunk ID></pre> <p>Disables a static LACP trunk.</p> <p>Command mode: Global configuration</p>
<pre>show lacp</pre> <p>Display current LACP configuration.</p> <p>Command mode: All</p>

LACP Port Configuration

Use the following commands to configure Link Aggregation Control Protocol (LACP) for the selected port.

Table 233. Link Aggregation Control Protocol Commands

Command Syntax and Usage
<pre>lacp mode {off active passive}</pre> <p>Set the LACP mode for this port, as follows:</p> <ul style="list-style-type: none">– off Turn LACP off for this port. You can use this port to manually configure a static trunk. The default value is <i>off</i>.– active Turn LACP on and set this port to active. Active ports initiate LACPDU's.– passive Turn LACP on and set this port to passive. Passive ports do not initiate LACPDU's, but respond to LACPDU's from active ports. <p>Command mode: Interface port</p>
<pre>lacp priority <1-65535></pre> <p>Sets the priority value for the selected port. Lower numbers provide higher priority. The default value is 32768.</p> <p>Command mode: Interface port</p>
<pre>lacp key <1-65535></pre> <p>Set the admin key for this port. Only ports with the same <i>admin key</i> and <i>oper key</i> (operational state generated internally) can form a LACP trunk group.</p> <p>Command mode: Interface port</p>
<pre>port-channel min-links <1-16></pre> <p>Set the minimum number of links for this port. If the specified minimum number of ports are not available, the trunk is placed in the <i>down</i> state.</p> <p>Command mode: Interface port</p>
<pre>default lacp [key mode priority]</pre> <p>Restores the selected parameters to their default values.</p> <p>Command mode: Interface port</p>
<pre>show interface port <port alias or number> lacp</pre> <p>Displays the current LACP configuration for this port.</p> <p>Command mode: All</p>

Layer 2 Failover Configuration

Use these commands to configure Layer 2 Failover. For more information about Layer 2 Failover, see “High Availability” in the *IBM Networking OS Application Guide*.

Table 234. Layer 2 Failover Configuration Commands

Command Syntax and Usage	
<code>failover vlan</code>	<p>Globally turns VLAN monitor <code>on</code>. When the VLAN Monitor is <code>on</code>, the switch automatically disables only internal ports that belong to the same VLAN as ports in the failover trigger. The default value is <code>off</code>.</p> <p>Command mode: Global configuration</p>
<code>no failover vlan</code>	<p>Globally turns VLAN monitor <code>off</code>. When the VLAN Monitor is <code>off</code>, the switch automatically disables all of the internal ports. When the VLAN Monitor is <code>on</code>, the switch automatically disables only internal ports that belong to the same VLAN as ports in the failover trigger. The default value is <code>off</code>.</p> <p>Command mode: Global configuration</p>
<code>failover enable</code>	<p>Globally turns Layer 2 Failover <code>on</code>.</p> <p>Command mode: Global configuration</p>
<code>no failover enable</code>	<p>Globally turns Layer 2 Failover <code>off</code>.</p> <p>Command mode: Global configuration</p>
<code>show failover trigger</code>	<p>Displays current Layer 2 Failover parameters.</p> <p>Command mode: All</p>

Failover Trigger Configuration

Table 235. Failover Trigger Configuration Commands

Command Syntax and Usage
<pre>[no] failover trigger <1-8> enable</pre> <p>Enables or disables the Failover trigger. Command mode: Global configuration</p>
<pre>no failover trigger <1-8></pre> <p>Deletes the Failover trigger. Command mode: Global configuration</p>
<pre>failover trigger <1-8> limit <0-1024></pre> <p>Configures the minimum number of operational links allowed within each trigger before the trigger initiates a failover event. If you enter a value of zero (0), the switch triggers a failover event only when no links in the trigger are operational. Command mode: Global configuration</p>
<pre>show failover trigger <1-8></pre> <p>Displays the current failover trigger settings. Command mode: All</p>

Auto Monitor Configuration

Table 236. Auto Monitor Configuration Commands

Command Syntax and Usage
<pre>failover trigger <1-8> amon portchannel <trunk group number></pre> <p>Adds a trunk group to the Auto Monitor. Command mode: Global configuration</p>
<pre>no failover trigger <1-8> amon portchannel <trunk group number></pre> <p>Removes a trunk group from the Auto Monitor. Command mode: Global configuration</p>
<pre>failover trigger <1-8> amon adminkey <1-65535></pre> <p>Adds an LACP <i>admin key</i> to the Auto Monitor. LACP trunks formed with this <i>admin key</i> will be included in the Auto Monitor. Command mode: Global configuration</p>
<pre>no failover trigger <1-8> amon adminkey <1-65535></pre> <p>Removes an LACP <i>admin key</i> from the Auto Monitor. Command mode: Global configuration</p>

Failover Manual Monitor Port Configuration

Use these commands to define the port link(s) to monitor. The Manual Monitor Port configuration accepts only external uplink ports.

Note: AMON and MMON configurations are mutually exclusive.

Table 237. Failover Manual Monitor Port Commands

Command Syntax and Usage
<pre>failover trigger <1-8> mmon monitor member <port alias or number></pre> <p>Adds the selected port to the Manual Monitor Port configuration.</p> <p>Command mode: Global configuration</p>
<pre>no failover trigger <1-8> mmon monitor member <port alias or number></pre> <p>Removes the selected port from the Manual Monitor Port configuration.</p> <p>Command mode: Global configuration</p>
<pre>failover trigger <1-8> mmon monitor portchannel <trunk number></pre> <p>Adds the selected trunk group to the Manual Monitor Port configuration.</p> <p>Command mode: Global configuration</p>
<pre>no failover trigger <1-8> mmon monitor portchannel <trunk number></pre> <p>Removes the selected trunk group to the Manual Monitor Port configuration.</p> <p>Command mode: Global configuration</p>
<pre>failover trigger <1-8> mmon monitor adminkey <1-65535></pre> <p>Adds an LACP <i>admin key</i> to the Manual Monitor Port configuration. LACP trunks formed with this <i>admin key</i> will be included in the Manual Monitor Port configuration.</p> <p>Command mode: Global configuration</p>
<pre>no failover trigger <1-8> mmon monitor adminkey <1-65535></pre> <p>Removes an LACP admin key from the Manual Monitor Port configuration.</p> <p>Command mode: Global configuration</p>
<pre>show failover trigger <1-8></pre> <p>Displays the current Failover settings.</p> <p>Command mode: All</p>

Failover Manual Monitor Control Configuration

Use these commands to define the port link(s) to control. The Manual Monitor Control configuration accepts internal and external ports, but not management ports.

Table 238. Failover Manual Monitor Control Commands

Command Syntax and Usage
<pre>failover trigger <I-8> mmon control member <port alias or number></pre> <p>Adds the selected port to the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>no failover trigger <I-8> mmon control member <port alias or number></pre> <p>Removes the selected port from the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>failover trigger <I-8> mmon control portchannel <trunk number></pre> <p>Adds the selected trunk group to the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>no failover trigger <I-8> mmon control portchannel <trunk number></pre> <p>Removes the selected trunk group to the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>failover trigger <I-8> mmon control adminkey <I-65535></pre> <p>Adds an LACP <i>admin key</i> to the Manual Monitor Control configuration. LACP trunks formed with this <i>admin key</i> will be included in the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>no failover trigger <I-8> mmon control adminkey <I-65535></pre> <p>Removes an LACP admin key from the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>failover trigger <I-8> mmon control vmember <UFP vport(s)></pre> <p>Adds the selected Unified Fabric Port virtual port(s) to the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>no failover trigger <I-8> mmon control vmember <UFP vport(s)></pre> <p>Removes the selected Unified Fabric Port virtual port(s) from the Manual Monitor Control configuration.</p> <p>Command mode: Global configuration</p>
<pre>show failover trigger <I-8></pre> <p>Displays the current Failover settings.</p> <p>Command mode: All</p>

Hot Links Configuration

Use these commands to configure Hot Links. For more information about Hot Links, see “Hot Links” in the *IBM Networking OS 7.8 Application Guide*.

Table 239. Hot Links Configuration Commands

Command Syntax and Usage	
[no] hotlinks bpdu	<p>Enables or disables flooding of Spanning-Tree BPDUs on the active Hot Links interface when the interface belongs to a Spanning Tree group that is globally turned off. This feature can prevent unintentional loop scenarios (for example, if two uplinks come up at the same time).</p> <p>The default setting is disabled.</p> <p>Command mode: Global configuration</p>
[no] hotlinks fdb-update	<p>Enables or disables FDB Update, which allows the switch to send FDB and MAC update packets over the active interface.</p> <p>The default value is disabled.</p> <p>Command mode: Global configuration</p>
hotlinks fdb-update-rate <10-200>	<p>Configures the FDB Update rate, in packets per second.</p> <p>Command mode: Global configuration</p>
hotlinks enable	<p>Globally enables Hot Links.</p> <p>Command mode: Global configuration</p>
no hotlinks enable	<p>Globally disables Hot Links.</p> <p>Command mode: Global configuration</p>
show hotlinks	<p>Displays current Hot Links parameters.</p> <p>Command mode: All</p>

Hot Links Trigger Configuration

Table 240. Hot Links Trigger Configuration Commands

Command Syntax and Usage
<pre>hotlinks trigger <1-200> forward-delay <0-3600></pre> <p>Configures the Forward Delay interval, in seconds. The default value is 1.</p> <p>Command mode: Global configuration</p>
<pre>[no] hotlinks trigger <1-200> name <1-32 characters></pre> <p>Defines a name for the Hot Links trigger.</p> <p>Command mode: Global configuration</p>
<pre>[no] hotlinks trigger <1-200> preemption</pre> <p>Enables or disables pre-emption, which allows the Master interface to transition to the Active state whenever it becomes available.</p> <p>The default setting is enabled.</p> <p>Command mode: Global configuration</p>
<pre>[no] hotlinks trigger <1-200> enable</pre> <p>Enables or disables the Hot Links trigger.</p> <p>Command mode: Global configuration</p>
<pre>no hotlinks trigger <1-200></pre> <p>Deletes the Hot Links trigger.</p> <p>Command mode: Global configuration</p>
<pre>show hotlinks trigger <1-200></pre> <p>Displays the current Hot Links trigger settings.</p> <p>Command mode: All</p>

Hot Links Master Configuration

Use the following commands to configure the Hot Links Master interface.

Table 241. Hot Links Master Configuration Commands

Command Syntax and Usage
<pre>[no] hotlinks trigger <I-200> master port <port alias or number></pre> <p>Adds or removes the selected port to the Hot Links Master interface.</p> <p>Command mode: Global configuration</p>
<pre>[no] hotlinks trigger <I-200> master portchannel <trunk group number></pre> <p>Adds or removes the selected trunk group to the Master interface.</p> <p>Command mode: Global configuration</p>
<pre>[no] hotlinks trigger <I-200> master adminkey <0-65535></pre> <p>Adds or removes an LACP <i>admin key</i> to the Master interface. LACP trunks formed with this <i>admin key</i> will be included in the Master interface.</p> <p>Command mode: Global configuration</p>
<pre>show hotlinks trigger <I-200></pre> <p>Displays the current Hot Links trigger settings.</p> <p>Command mode: All</p>

Hot Links Backup Configuration

Use the following commands to configure the Hot Links Backup interface.

Table 242. Hot Links Backup Configuration Commands

Command Syntax and Usage
<pre>[no] hotlinks trigger <1-200> backup port <port alias or number></pre> <p>Adds or removes the selected port to the Hot Links Backup interface.</p> <p>Command mode: Global configuration</p>
<pre>[no] hotlinks trigger <1-200> backup portchannel <trunk group number></pre> <p>Adds or removes the selected trunk group to the Backup interface.</p> <p>Command mode: Global configuration</p>
<pre>[no] hotlinks trigger <1-200> backup adminkey <0-65535></pre> <p>Adds or removes an LACP <i>admin key</i> to the Backup interface. LACP trunks formed with this <i>admin key</i> will be included in the Backup interface.</p> <p>Command mode: Global configuration</p>
<pre>show hotlinks trigger <1-200></pre> <p>Displays the current Hot Links trigger settings.</p> <p>Command mode: All</p>

VLAN Configuration

These commands configure VLAN attributes, change the status of each VLAN, change the port membership of each VLAN, and delete VLANs.

Internal server ports and external uplink ports are members of SPAR VLAN 4081-4083 by default. Up to 4094 VLANs can be configured on the CN4093.

VLANs can be assigned any number between 1 and 4094, except the reserved VLANs.

Table 243. VLAN Configuration Commands

Command Syntax and Usage	
<code>vlan <VLAN number></code>	Enter VLAN configuration mode. Command mode: Global configuration
<code>protocol-vlan <1-8></code>	Configures the Protocol-based VLAN (PVLAN). Command mode: VLAN
<code>name <1-32 characters></code>	Assigns a name to the VLAN or changes the existing name. The default VLAN name is the first one. Command mode: VLAN
<code>[no] shutdown</code>	Disables or enables local traffic on the specified VLAN. Default setting is enabled (<code>no shutdown</code>) Command mode: VLAN
<code>stg <STG number></code>	Assigns a VLAN to a Spanning Tree Group. Note: For MST, no VLAN assignment is required. VLANs are mapped from CIST. Command mode: VLAN
<code>[no] vmap <1-128> [extports intports]</code>	Adds or removes a VLAN Map to the VLAN membership. You can choose to limit operation of the VLAN Map to internal ports only or external ports only. If you do not select a port type, the VMAP is applied to the entire VLAN. Command mode: VLAN
<code>[no] management</code>	Configures this VLAN as a management VLAN. You must have at least one internal port in each new management VLAN. Management port (MGT1) is automatically added to management VLAN. Command mode: VLAN

Table 243. VLAN Configuration Commands (continued)

Command Syntax and Usage	
<pre>[no] flood</pre>	<p>Configures the switch to flood unregistered IP multicast traffic to all ports. The default setting is <i>enabled</i>.</p> <p>Note: If none of the IGMP hosts reside on the VLAN of the streaming server for a IPMC group, you must disable IGMP flooding to ensure that multicast data is forwarded across the VLANs for that IPMC group.</p> <p>Command mode: VLAN</p>
<pre>[no] cpu</pre>	<p>Configures the switch to forward unregistered IP multicast traffic to the MP, which adds an entry in the IPMC table, as follows:</p> <ul style="list-style-type: none"> – If no Mrouter is present, drop subsequent packets with same IPMC. – If an Mrouter is present, forward subsequent packets to the Mrouter(s) on the ingress VLAN. <p>The default setting is <i>enabled</i>.</p> <p>Note: If both <code>flood</code> and <code>cpu</code> are disabled, then the switch drops all unregistered IPMC traffic.</p> <p>Command mode: VLAN</p>
<pre>[no] optflood</pre>	<p>Enables or disables optimized flooding. When enabled, optimized flooding avoids packet loss during the learning period. The default setting is <i>disabled</i>.</p> <p>Command mode: VLAN</p>
<pre>show vlan information</pre>	<p>Displays the current VLAN configuration.</p> <p>Command mode: All</p>

Note: All ports must belong to at least one VLAN. Any port which is removed from a VLAN and which is not a member of any other VLAN is automatically added to default VLAN 1. You cannot add a port to more than one VLAN unless the port has VLAN tagging turned *on*.

Protocol-Based VLAN Configuration

Use the following commands to configure Protocol-based VLAN for the selected VLAN.

Table 244. Protocol VLAN Configuration Commands

Command Syntax and Usage
<pre>protocol-vlan <1-8> frame-type {ether2 llc snap} <Ethernet type></pre> <p>Configures the frame type and the Ethernet type for the selected protocol. Ethernet type consists of a 4-digit (16 bit) hex code, such as 0080 (IPv4).</p> <p>Command mode: VLAN</p>
<pre>protocol-vlan <1-8> protocol <protocol type></pre> <p>Selects a pre-defined protocol, as follows:</p> <ul style="list-style-type: none"> - decEther2:DEC Local Area Transport - ipv4Ether2:Internet IP (IPv4) - ipv6Ether2:IPv6 - ipx802.2:Novell IPX 802.2 - ipx802.3:Novell IPX 802.3 - ipxEther2:Novell IPX - ipxSnap:Novell IPX SNAP - netbios:NetBIOS 802.2 - rarpEther2:Reverse ARP - sna802.2:SNA 802.2 - snaEther2:IBM SNA Service on Ethernet - vinesEther2:Banyan VINES - xnsEther2:XNS Compatibility <p>Command mode: VLAN</p>
<pre>protocol-vlan <1-8> priority <0-7></pre> <p>Configures the priority value for this PVLAN.</p> <p>Command mode: VLAN</p>
<pre>protocol-vlan <1-8> member <port alias or number></pre> <p>Adds a port to the selected PVLAN.</p> <p>Command mode: VLAN</p>
<pre>no protocol-vlan <1-8> member <port alias or number></pre> <p>Removes a port from the selected PVLAN.</p> <p>Command mode: VLAN</p>
<pre>[no] protocol-vlan <1-8> tag-pvlan <port alias or number></pre> <p>Defines a port that will be tagged by the selected protocol on this VLAN.</p> <p>Command mode: VLAN</p>

Table 244. Protocol VLAN Configuration Commands (continued)

Command Syntax and Usage
<pre>protocol-vlan <1-8> enable</pre> <p>Enables the selected protocol on the VLAN. Command mode: VLAN</p>
<pre>no protocol-vlan <1-8> enable</pre> <p>Disables the selected protocol on the VLAN. Command mode: VLAN</p>
<pre>no protocol-vlan <1-8></pre> <p>Deletes the selected protocol configuration from the VLAN. Command mode: VLAN</p>
<pre>show protocol-vlan <1-8></pre> <p>Displays current parameters for the selected PVLAN. Command mode: All</p>

Private VLAN Configuration

Use the following commands to configure Private VLAN.

Table 245. Private VLAN Configuration Commands

Command Syntax and Usage
<pre>[no] private-vlan primary</pre> <p>Enables or disables the VLAN type as a Primary VLAN.</p> <p>A Private VLAN must have only one primary VLAN. The primary VLAN carries unidirectional traffic to ports on the isolated VLAN or to community VLAN.</p> <p>Command mode: VLAN</p>
<pre>[no] private-vlan community</pre> <p>Enables or disables the VLAN type as a community VLAN.</p> <p>Community VLANs carry upstream traffic from host ports. A Private VLAN may have multiple community VLANs.</p> <p>Command mode: VLAN</p>
<pre>[no] private-vlan isolated</pre> <p>Enables or disables the VLAN type as an isolated VLAN.</p> <p>The isolated VLAN carries unidirectional traffic from host ports. A Private VLAN may have only one isolated VLAN.</p> <p>Command mode: VLAN</p>
<pre>private-vlan association [add remove] <secondary VLAN list></pre> <p>Configures Private VLAN mapping between a primary VLAN and secondary VLANs. Enter the primary VLAN ID. If no optional parameter is specified, the list of secondary VLANs, replaces the currently associated secondary VLANs. Otherwise:</p> <ul style="list-style-type: none">– <code>add</code> appends the secondary VLANs to the ones currently associated– <code>remove</code> excludes the secondary VLANs from the ones currently associated <p>Command mode: VLAN</p>
<pre>show vlan private-vlan [<2-4094>]</pre> <p>Displays current parameters for the selected Private VLAN(s).</p> <p>Command mode: VLAN</p>

Layer 3 Configuration

The following table describes basic Layer 3 Configuration commands. The following sections provide more detailed information and commands.

Table 246. Layer 3 Configuration Commands

Command Syntax and Usage
<pre>interface ip <interface number></pre> <p>Configures the IP Interface. The CN4093 supports up to 128 IP interfaces. To view command options, see page 365.</p> <p>Command mode: Global configuration</p>
<pre>route-map {<I-32>}</pre> <p>Enter IP Route Map mode. To view command options, see page 374.</p> <p>Command mode: Global configuration</p>
<pre>router rip</pre> <p>Configures the Routing Interface Protocol. To view command options, see page 378.</p> <p>Command mode: Global configuration</p>
<pre>router ospf</pre> <p>Configures OSPF. To view command options, see page 382.</p> <p>Command mode: Global configuration</p>
<pre>ipv6 router ospf</pre> <p>Enters OSPFv3 configuration mode. To view command options, see page 441.</p> <p>Command mode: Global configuration</p>
<pre>router bgp</pre> <p>Configures Border Gateway Protocol. To view command options, see page 392.</p> <p>Command mode: Global configuration</p>
<pre>router vrrp</pre> <p>Configures Virtual Router Redundancy. To view command options, see page 424.</p> <p>Command mode: Global configuration</p>
<pre>ip pim component <I-2></pre> <p>Enters Protocol Independent Multicast (PIM) component configuration mode. To view command options, see page 437.</p> <p>Command mode: Global configuration</p>

Table 246. Layer 3 Configuration Commands

Command Syntax and Usage
<pre>ip router-id <IP address></pre> <p>Sets the router ID.</p> <p>Command mode: Global configuration</p>
<pre>show layer3</pre> <p>Displays the current IP configuration.</p> <p>Command mode: All</p>

IP Interface Configuration

The CN4093 supports up to 128 IP interfaces. Each IP interface represents the CN4093 on an IP subnet on your network. The Interface option is disabled by default.

IP Interfaces 127 and 128 are reserved for switch management. If the IPv6 feature is enabled on the switch, IP Interface 125 and 126 are also reserved.

Note: To maintain connectivity between the management module and the CN4093, use the management module interface to change the IP address of the switch.

Table 247. IP Interface Configuration Commands

Command Syntax and Usage	
interface ip <interface number>	Enter IP interface mode. Command mode: Global configuration
ip address <IP address> [<IP netmask>]	Configures the IP address of the switch interface, using dotted decimal notation. Command mode: Interface IP
ip netmask <IP netmask>	Configures the IP subnet address mask for the interface, using dotted decimal notation. Command mode: Interface IP
ipv6 address <IP address (such as 3001:0:0:0:0:abcd:12)> [<IPv6 prefix length (1-128)>] [enable anycast]	Configures the IPv6 address of the switch interface, using hexadecimal format with colons. Command mode: Interface IP
ipv6 secaddr6 address <IP address (such as 3001:0:0:0:0:abcd:12)> <prefix length> [anycast]	Configures the secondary IPv6 address of the switch interface, using hexadecimal format with colons. Command mode: Interface IP
ipv6 prefixlen <IPv6 prefix length (1-128)>	Configures the subnet IPv6 prefix length. The default value is 0 (zero). Command mode: Interface IP
vlan <VLAN number>	Configures the VLAN number for this interface. Each interface can belong to one VLAN. Command mode: Interface IP

Table 247. IP Interface Configuration Commands (continued)

Command Syntax and Usage	
[no] relay	<p>Enables or disables the BOOTP relay on this interface. The default setting is enabled.</p> <p>Command mode: Interface IP</p>
[no] ipv6host	<p>Enables or disables the IPv6 Host Mode on this interface. The default setting is disabled for data interfaces, and enabled for the management interface.</p> <p>Command mode: Interface IP</p>
[no] ipv6 unreachable	<p>Enables or disables sending of ICMP Unreachable messages. The default setting is enabled.</p> <p>Command mode: Interface IP</p>
enable	<p>Enables this IP interface.</p> <p>Command mode: Interface IP</p>
no enable	<p>Disables this IP interface.</p> <p>Command mode: Interface IP</p>
no interface ip <interface number>	<p>Removes this IP interface.</p> <p>Command mode: Interface IP</p>
show interface ip <interface number>	<p>Displays the current interface settings.</p> <p>Command mode: All</p>

Default Gateway Configuration

The switch can be configured with up to 4 IPv4 gateways. Gateways 1–4 are reserved for default gateways. Gateway 4 is reserved for switch management. Default gateway indices are:

- 1-2: Data gateways
- 3: External management gateway
- 4: Internal management gateway

This option is disabled by default.

Table 248. Default Gateway Configuration Commands

Command Syntax and Usage	
ip gateway <1-4> address <IP address>	Configures the IP address of the default IP gateway using dotted decimal notation. Default gateway indices are: Command mode: Global configuration
ip gateway <1-4> interval <0-60>	The switch pings the default gateway to verify that it's up. This command sets the time between health checks. The range is from 0 to 60 seconds. The default is 2 seconds. Command mode: Global configuration
ip gateway <1-4> retry <1-120>	Sets the number of failed health check attempts required before declaring this default gateway inoperative. The range is from 1 to 120 attempts. The default is 8 attempts. Command mode: Global configuration
[no] ip gateway <1-4> arp-health-check	Enables or disables Address Resolution Protocol (ARP) health checks. The default setting is disabled. The arp option does not apply to management gateways. Command mode: Global configuration
ip gateway <1-4> enable	Enables the gateway for use. Command mode: Global configuration
no ip gateway <1-4> enable	Disables the gateway. Command mode: Global configuration

Table 248. Default Gateway Configuration Commands (continued)

Command Syntax and Usage
<pre>no ip gateway <1-4></pre> <p>Deletes the gateway from the configuration.</p> <p>Command mode: Global configuration</p>
<pre>show ip gateway <1-4></pre> <p>Displays the current gateway settings.</p> <p>Command mode: All</p>

IPv4 Static Route Configuration

Up to 128 IPv4 static routes can be configured.

Table 249. IPv4 Static Route Configuration Commands

Command Syntax and Usage
<pre>ip route <IP subnet> <IP netmask> <IP nexthop> [<interface number>]</pre> <p>Adds a static route. You will be prompted to enter a destination IP address, destination subnet mask, and gateway address. Enter all addresses using dotted decimal notation.</p> <p>Command mode: Global configuration</p>
<pre>no ip route <IP subnet> <IP netmask> [<interface number>]</pre> <p>Removes a static route. The destination address of the route to remove must be specified using dotted decimal notation.</p> <p>Command mode: Global configuration</p>
<pre>no ip route destination-address <IP address></pre> <p>Clears all IP static routes with this destination.</p> <p>Command mode: Global configuration</p>
<pre>no ip route gateway <IP address></pre> <p>Clears all IP static routes that use this gateway.</p> <p>Command mode: Global configuration</p>
<pre>ip route interval <1-60></pre> <p>Configures the ping interval for ECMP health checks, in seconds. The default value is one second.</p> <p>Command mode: Global configuration</p>
<pre>ip route retries <1-60></pre> <p>Configures the number of health check retries allowed before the switch declares that the gateway is down. The default value is 3.</p> <p>Command mode: Global configuration</p>
<pre>show ip route static</pre> <p>Displays the current IP static routes.</p> <p>Command mode: All</p>

IP Multicast Route Configuration

The following table describes the IP Multicast (IPMC) route commands.

Note: Before you can add an IPMC route, IGMP must be turned on, IGMP Snooping/Relay must be enabled, and the required VLANs must be added to IGMP Snooping/Relay.

Table 250. IP Multicast Route Configuration Commands

Command Syntax and Usage	
<pre>ip mroute <IPMC destination> <VLAN number> <port alias or number> {primary backup host} [<virtual router ID> none]</pre>	<p>Adds a static multicast route. The destination address, VLAN, member port of the route and route type (primary, backup or host) must be specified.</p> <p>Command mode: Global configuration</p>
<pre>no ip mroute <IPMC destination> <VLAN number> <port alias or number> {primary backup host} [<virtual router ID> none]</pre>	<p>Removes a static multicast route. The destination address, VLAN, member port of the route and route type (primary, backup or host) must be specified.</p> <p>Command mode: Global configuration</p>
<pre>ip mroute <IP address> <VLAN number> portchannel <trunk group number> {primary backup host} [<virtual router ID> none]</pre>	<p>Adds a static multicast route. The destination address, VLAN, and member trunk group of the route must be specified. Indicate whether the route is used for a primary, backup, or host multicast router.</p> <p>Command mode: Global configuration</p>
<pre>no ip mroute <IP address> <VLAN number> portchannel <trunk group number> {primary backup host} [<virtual router ID> none]</pre>	<p>Removes a static multicast route. The destination address, VLAN, member port of the route and route type (primary, backup or host) must be specified.</p> <p>Command mode: Global configuration</p>
<pre>ip mroute <IP address> <VLAN number> adminkey <I-65535> {primary backup host} [<virtual router ID> none]</pre>	<p>Adds a static multicast route. The destination address, VLAN, member port of the route and route type (primary, backup or host) must be specified.</p> <p>Command mode: Global configuration</p>
<pre>no ip mroute <IP address> <VLAN number> adminkey <I-65535> {primary backup host} [<virtual router ID> none]</pre>	<p>Removes a static multicast route. The destination address, VLAN, member port of the route and route type (primary, backup or host) must be specified.</p> <p>Command mode: Global configuration</p>

Table 250. IP Multicast Route Configuration Commands (continued)

Command Syntax and Usage
<pre>no ip mroute all</pre> <p>Removes all the static multicast routes configured.</p> <p>Command mode: Global configuration</p>
<pre>show ip mroute</pre> <p>Displays the current IP multicast routes.</p> <p>Command mode: All</p>

ARP Configuration

Address Resolution Protocol (ARP) is the TCP/IP protocol that resides within the Internet layer. ARP resolves a physical address from an IP address. ARP queries machines on the local network for their physical addresses. ARP also maintains IP to physical address pairs in its cache memory. In any IP communication, the ARP cache is consulted to see if the IP address of the computer or the router is present in the ARP cache. Then the corresponding physical address is used to send a packet.

Table 251. ARP Configuration Commands

Command Syntax and Usage
<pre>ip arp rearp <2-120></pre> <p>Defines re-ARP period, in minutes, for entries in the switch arp table. When ARP entries reach this value the switch will re-ARP for the address to attempt to refresh the ARP cache.</p> <p>The default value is 5 minutes.</p> <p>Command mode: Global configuration</p>
<pre>show ip arp</pre> <p>Displays the current ARP configurations.</p> <p>Command mode: All</p>

ARP Static Configuration

Static ARP entries are permanent in the ARP cache and do not age out like the ARP entries that are learned dynamically. Static ARP entries enable the switch to reach the hosts without sending an ARP broadcast request to the network. Static ARPs are also useful to communicate with devices that do not respond to ARP requests. Static ARPs can also be configured on some gateways as a protection against malicious ARP Cache corruption and possible DOS attacks.

Table 252. ARP Static Configuration Commands

Command Syntax and Usage
<pre>ip arp <IP address> <MAC address> vlan <vlan number> port <port alias or number></pre> <p>Adds a permanent ARP entry.</p> <p>Command mode: Global configuration</p>
<pre>ip arp <destination unicast IP address> <destination multicast MAC address> vlan <cluster vlan number></pre> <p>Adds a static multicast ARP entry for Network Load Balancing (NLB).</p> <p>Command mode: Global configuration</p>
<pre>no ip arp <IP address></pre> <p>Deletes a permanent ARP entry.</p> <p>Command mode: Global configuration</p>
<pre>no ip arp all</pre> <p>Deletes all static ARP entries.</p> <p>Command mode: Global configuration</p>
<pre>show ip arp static</pre> <p>Displays current static ARP configuration.</p> <p>Command mode: All</p>

IP Forwarding Configuration

Table 253. IP Forwarding Configuration Commands

Command Syntax and Usage
<pre>[no] ip routing directed-broadcasts</pre> <p>Enables or disables forwarding directed broadcasts. The default setting is disabled.</p> <p>Command mode: Global configuration</p>
<pre>[no] ip routing no-icmp-redirect</pre> <p>Enables or disables ICMP re-directs. The default setting is disabled.</p> <p>Command mode: Global configuration</p>
<pre>[no] ip routing icmp6-redirect</pre> <p>Enables or disables IPv6 ICMP re-directs. The default setting is disabled.</p> <p>Command mode: Global configuration</p>
<pre>ip routing</pre> <p>Enables IP forwarding (routing) on the CN4093. Forwarding is turned on by default.</p> <p>Command mode: Global configuration</p>
<pre>no ip routing</pre> <p>Disables IP forwarding (routing) on the CN4093.</p> <p>Command mode: Global configuration</p>
<pre>show ip routing</pre> <p>Displays the current IP forwarding settings.</p> <p>Command mode: All</p>

Network Filter Configuration

Table 254. IP Network Filter Configuration Commands

Command Syntax and Usage	
<pre>ip match-address <1-256> <IP address> <IP netmask></pre>	<p>Sets the starting IP address and IP Netmask for this filter to define the range of IP addresses that will be accepted by the peer when the filter is enabled. The default address is 0.0.0.0 0.0.0.0</p> <p>For Border Gateway Protocol (BGP), assign the network filter to an access-list in a route map, then assign the route map to the peer.</p> <p>Command mode: Global configuration.</p>
<pre>ip match-address <1-256> enable</pre>	<p>Enables the Network Filter configuration.</p> <p>Command mode: Global configuration</p>
<pre>no ip match-address <1-256> enable</pre>	<p>Disables the Network Filter configuration.</p> <p>Command mode: Global configuration</p>
<pre>no ip match-address <1-256></pre>	<p>Deletes the Network Filter configuration.</p> <p>Command mode: Global configuration</p>
<pre>show ip match-address [<1-256>]</pre>	<p>Displays the current the Network Filter configuration.</p> <p>Command mode: All</p>

Routing Map Configuration

Note: The *map number* (1-32) represents the routing map you wish to configure.

Routing maps control and modify routing information.

Table 255. Routing Map Configuration Commands

Command Syntax and Usage	
route-map <1-32>	Enter route map configuration mode. Command mode: Route map
[no] access-list <1-8>	Configures the Access List. For more information, see page 376 . Command mode: Route map
[no] as-path-list <1-8>	Configures the Autonomous System (AS) Filter. For more information, see page 377 . Command mode: Route map
[no] as-path-preference <1-65535>	Sets the AS path preference of the matched route. You can configure up to three path preferences. Command mode: Route map
[no] local-preference <0-4294967294>	Sets the local preference of the matched route, which affects both inbound and outbound directions. The path with the higher preference is preferred. Command mode: Route map
[no] metric <1-4294967294>	Sets the metric of the matched route. Command mode: Route map
[no] metric-type {1 2}	Assigns the type of OSPF metric. The default is type 1. <ul style="list-style-type: none"> – Type 1—External routes are calculated using both internal and external metrics. – Type 2—External routes are calculated using only the external metrics. Type 1 routes have more cost than Type 2. – none—Removes the OSPF metric. Command mode: Route map
precedence <1-255>	Sets the precedence of the route map. The smaller the value, the higher the precedence. Default value is 10. Command mode: Route map

Table 255. Routing Map Configuration Commands (continued)

Command Syntax and Usage	
[no] weight <0-65534>	Sets the weight of the route map. Command mode: Route map
enable	Enables the route map. Command mode: Route map
no enable	Disables the route map. Command mode: Route map
no route-map <1-32>	Deletes the route map. Command mode: Route map
show route-map [<1-32>]	Displays the current route configuration. Command mode: All

IP Access List Configuration

Note: The *route map number* (1-32) and the *access list number* (1-8) represent the IP access list you wish to configure.

Table 256. IP Access List Configuration Commands

Command Syntax and Usage
<pre>[no] access-list <1-8> match-address <1-256></pre> <p>Sets the network filter number. See “Network Filter Configuration” on page 373 for details.</p> <p>Command mode: Route map</p>
<pre>[no] access-list <1-8> metric <1-4294967294></pre> <p>Sets the metric value in the AS-External (ASE) LSA.</p> <p>Command mode: Route map</p>
<pre>access-list <1-8> action {permit deny}</pre> <p>Permits or denies action for the access list.</p> <p>Command mode: Route map</p>
<pre>access-list <1-8> enable</pre> <p>Enables the access list.</p> <p>Command mode: Route map</p>
<pre>no access-list <1-8> enable</pre> <p>Disables the access list.</p> <p>Command mode: Route map</p>
<pre>no access-list <1-8></pre> <p>Deletes the access list.</p> <p>Command mode: Route map</p>
<pre>show route-map <1-32> access-list <1-8></pre> <p>Displays the current Access List configuration.</p> <p>Command mode: All</p>

Autonomous System Filter Path Configuration

Note: The *rmap number* and the *path number* represent the AS path you wish to configure.

Table 257. AS Filter Configuration Commands

Command Syntax and Usage
<pre>as-path-list <1-8> as-path <1-65535></pre> <p>Sets the Autonomous System filter's path number. Command mode: Route map</p>
<pre>as-path-list <1-8> action {permit deny}</pre> <p>Permits or denies Autonomous System filter action. Command mode: Route map</p>
<pre>as-path-list <1-8> enable</pre> <p>Enables the Autonomous System filter. Command mode: Route map</p>
<pre>no as-path-list <1-8> enable</pre> <p>Disables the Autonomous System filter. Command mode: Route map</p>
<pre>no as-path-list <1-8></pre> <p>Deletes the Autonomous System filter. Command mode: Route map</p>
<pre>show route-map <1-32> as-path-list <1-8></pre> <p>Displays the current Autonomous System filter configuration. Command mode: All</p>

Routing Information Protocol Configuration

RIP commands are used for configuring Routing Information Protocol parameters. This option is turned off by default.

Table 258. Routing Information Protocol Commands

Command Syntax and Usage
<pre>router rip</pre> <p>Enter Router RIP configuration mode. Command mode: Global Configuration</p>
<pre>timers update <1-120></pre> <p>Configures the time interval for sending for RIP table updates, in seconds. The default value is 30 seconds. Command mode: Router RIP</p>
<pre>enable</pre> <p>Globally turns RIP on. Command mode: Router RIP</p>
<pre>no enable</pre> <p>Globally turns RIP off. Command mode: Router RIP</p>
<pre>show ip rip</pre> <p>Displays the current RIP configuration. Command mode: All</p>

Routing Information Protocol Interface Configuration

The RIP Interface commands are used for configuring Routing Information Protocol parameters for the selected interface.

Note: Do not configure RIP version 1 parameters if your routing equipment uses RIP version 2.

Table 259. RIP Interface Commands

Command Syntax and Usage	
<code>ip rip version {1 2 both}</code>	Configures the RIP version used by this interface. The default value is version 2. Command mode: Interface IP
<code>[no] ip rip supply</code>	When enabled, the switch supplies routes to other routers. The default value is enabled. Command mode: Interface IP
<code>[no] ip rip listen</code>	When enabled, the switch learns routes from other routers. The default value is enabled. Command mode: Interface IP
<code>[no] ip rip poison</code>	When enabled, the switch uses split horizon with poisoned reverse. When disabled, the switch uses only split horizon. The default value is disabled. Command mode: Interface IP
<code>[no] ip rip split-horizon</code>	Enables or disables split horizon. The default value is enabled. Command mode: Interface IP
<code>[no] ip rip triggered</code>	Enables or disables Triggered Updates. Triggered Updates are used to speed convergence. When enabled, Triggered Updates force a router to send update messages immediately, even if it is not yet time for the update message. The default value is enabled. Command mode: Interface IP
<code>[no] ip rip multicast-updates</code>	Enables or disables multicast updates of the routing table (using address 224.0.0.9). The default value is enabled. Command mode: Interface IP
<code>[no] ip rip default-action {listen supply both}</code>	When enabled, the switch accepts RIP default routes from other routers, but gives them lower priority than configured default gateways. When disabled, the switch rejects RIP default routes. The default value is none. Command mode: Interface IP

Table 259. RIP Interface Commands (continued)

Command Syntax and Usage	
[no] ip rip metric [<i><1-15></i>]	Configures the route metric, which indicates the relative distance to the destination. The default value is 1. Command mode: Interface IP
[no] ip rip authentication type [<i><password></i>]	Configures the authentication type. The default is none. Command mode: Interface IP
[no] ip rip authentication key <i><password></i>	Configures the authentication key password. Command mode: Interface IP
ip rip enable	Enables this RIP interface. Command mode: Interface IP
no ip rip enable	Disables this RIP interface. Command mode: Interface IP
show interface ip <i><interface number></i> rip	Displays the current RIP configuration. Command mode: All

RIP Route Redistribution Configuration

The following table describes the RIP Route Redistribution commands.

Table 260. RIP Redistribution Commands

Command Syntax and Usage	
<pre>redistribute {fixed static ospf eospf ebgp ibgp} <1-32></pre>	<p>Adds selected routing maps to the RIP route redistribution list. To add specific route maps, enter routing map numbers, separated by a comma (,). To add all 32 route maps, type <code>all</code>.</p> <p>The routes of the redistribution protocol matched by the route maps in the route redistribution list will be redistributed.</p> <p>Command mode: Router RIP</p>
<pre>no redistribute {fixed static ospf eospf ebgp ibgp} <1-32></pre>	<p>Removes the route map from the RIP route redistribution list.</p> <p>To remove specific route maps, enter routing map numbers, separated by a comma (,). To remove all 32 route maps, type <code>all</code>.</p> <p>Command mode: Router RIP</p>
<pre>redistribute {fixed static ospf eospf ebgp ibgp} export <1-15></pre>	<p>Exports the routes of this protocol in which the metric and metric type are specified. To remove a previous configuration and stop exporting the routes of the protocol, enter <code>none</code>.</p> <p>Command mode: Router RIP</p>
<pre>show ip rip redistribute</pre>	<p>Displays the current RIP route redistribute configuration.</p> <p>Command mode: All</p>

Open Shortest Path First Configuration

Table 261. OSPF Configuration Commands

Command Syntax and Usage
<p>router ospf</p> <p>Enter Router OSPF configuration mode.</p> <p>Command mode: Global configuration</p>
<p>area-range <1-16></p> <p>Configures summary routes for up to 16 IP addresses. See page 386 to view command options.</p> <p>Command mode: Router OSPF</p>
<p>ip ospf <interface number></p> <p>Configures the OSPF interface. See page 387 to view command options.</p> <p>Command mode: Interface IP</p>
<p>area-virtual-link <1-3></p> <p>Configures the Virtual Links used to configure OSPF for a Virtual Link. See page 389 to view command options.</p> <p>Command mode: Router OSPF</p>
<p>message-digest-key <1-255> md5-key <text string></p> <p>Assigns a string to MD5 authentication key.</p> <p>Command mode: Router OSPF</p>
<p>host <1-128></p> <p>Configures OSPF for the host routes. Up to 128 host routes can be configured. Host routes are used for advertising network device IP addresses to external networks to perform server load balancing within OSPF. It also makes Area Border Route (ABR) load sharing and ABR failover possible.</p> <p>See page 390 to view command options.</p> <p>Command mode: Router OSPF</p>
<p>lsdb-limit <LSDB limit (0-2048, 0 for no limit)></p> <p>Sets the link state database limit.</p> <p>Command mode: Router OSPF</p>
<p>[no] default-information <1-16777214> {<AS external metric type (1-2)>}</p> <p>Sets one default route among multiple choices in an area. Use none for no default.</p> <p>Command mode: Router OSPF</p>
<p>enable</p> <p>Enables OSPF on the CN4093.</p> <p>Command mode: Router OSPF</p>

Table 261. OSPF Configuration Commands (continued)

Command Syntax and Usage
<code>no enable</code> Disables OSPF on the CN4093. Command mode: Router OSPF
<code>show ip ospf</code> Displays the current OSPF configuration settings. Command mode: All

Area Index Configuration

Table 262. Area Index Configuration Commands

Command Syntax and Usage
<pre>area <0-2> area-id <IP address></pre> <p>Defines the IP address of the OSPF area number.</p> <p>Command mode: Router OSPF</p>
<pre>area <0-2> type {transit stub nssa}</pre> <p>Defines the type of area. For example, when a virtual link has to be established with the backbone, the area type must be defined as transit.</p> <p>Transit area: allows area summary information to be exchanged between routing devices. Any area that is not a stub area or NSSA is considered to be transit area.</p> <p>Stub area: is an area where external routing information is not distributed. Typically, a stub area is connected to only one other area.</p> <p>NSSA: Not-So-Stubby Area (NSSA) is similar to stub area with additional capabilities. For example, routes originating from within the NSSA can be propagated to adjacent transit and backbone areas.</p> <p>Command mode: Router OSPF</p>
<pre>area <0-2> stub-metric <1-65535></pre> <p>Configures a stub area to send a numeric metric value. All routes received via that stub area carry the configured metric to potentially influencing routing decisions.</p> <p>Metric value assigns the priority for choosing the switch for default route. Metric type determines the method for influencing routing decisions for external routes.</p> <p>Command mode: Router OSPF</p>
<pre>[no] area <0-2> authentication-type {password md5}</pre> <p>None: No authentication required.</p> <p>Password: Authenticates simple passwords so that only trusted routing devices can participate.</p> <p>MD5: This parameter is used when MD5 cryptographic authentication is required.</p> <p>Command mode: Router OSPF</p>
<pre>area <0-2> spf-interval <1-255></pre> <p>Configures the minimum time interval, in seconds, between two successive SPF (shortest path first) calculations of the shortest path tree using the Dijkstra's algorithm. The default value is 10 seconds.</p> <p>Command mode: Router OSPF</p>
<pre>area <0-2> enable</pre> <p>Enables the OSPF area.</p> <p>Command mode: Router OSPF</p>

Table 262. Area Index Configuration Commands (continued)

Command Syntax and Usage
<pre>no area <0-2> enable</pre> <p>Disables the OSPF area. Command mode: Router OSPF</p>
<pre>no area <0-2></pre> <p>Deletes the OSPF area. Command mode: Router OSPF</p>
<pre>show ip ospf area <0-2></pre> <p>Displays the current OSPF configuration. Command mode: All</p>

OSPF Summary Range Configuration

Table 263. OSPF Summary Range Configuration Commands

Command Syntax and Usage
<pre>area-range <1-16> address <IP address> <IP netmask></pre> <p>Displays the base IP address or the IP address mask for the range. Command mode: Router OSPF</p>
<pre>area-range <1-16> area <0-2></pre> <p>Displays the area index used by the CN4093. Command mode: Router OSPF</p>
<pre>[no] area-range <1-16> hide</pre> <p>Hides the OSPF summary range. Command mode: Router OSPF</p>
<pre>area-range <1-16> enable</pre> <p>Enables the OSPF summary range. Command mode: Router OSPF</p>
<pre>no area-range <1-16> enable</pre> <p>Disables the OSPF summary range. Command mode: Router OSPF</p>
<pre>no area-range <1-16></pre> <p>Deletes the OSPF summary range. Command mode: Router OSPF</p>
<pre>show ip ospf area-range <1-16></pre> <p>Displays the current OSPF summary range. Command mode: Router OSPF</p>

OSPF Interface Configuration

Table 264. OSPF Interface Configuration Commands

Command Syntax and Usage	
ip ospf area <0-2>	Configures the OSPF area index. Command mode: Interface IP
ip ospf priority <0-255>	Configures the priority value for the CN4093's OSPF interfaces. A priority value of 255 is the highest and 1 is the lowest. A priority value of 0 specifies that the interface cannot be used as Designated Router (DR) or Backup Designated Router (BDR). Command mode: Interface IP
ip ospf cost <1-65535>	Configures cost set for the selected path—preferred or backup. Usually the cost is inversely proportional to the bandwidth of the interface. Low cost indicates high bandwidth. Command mode: Interface IP
ip ospf hello-interval <1-65535> ip ospf hello-interval <50-65535ms>	Configures the interval, in seconds or milliseconds, between the hello packets for the interfaces. Command mode: Interface IP
ip ospf dead-interval <1-65535> ip ospf dead-interval <1000-65535ms>	Configures the health parameters of a hello packet, in seconds or milliseconds, before declaring a silent router to be down. Command mode: Interface IP
ip ospf transit-delay <1-3600>	Configures the transit delay in seconds. Command mode: Interface IP
ip ospf retransmit-interval <1-3600>	Configures the retransmit interval in seconds. Command mode: Interface IP
[no] ip ospf key <key string>	Sets the authentication key to clear the password. Command mode: Interface IP
[no] ip ospf message-digest-key <1-255>	Assigns an MD5 key to the interface. Command mode: Interface IP

Table 264. OSPF Interface Configuration Commands (continued)

Command Syntax and Usage	
[no] ip ospf passive-interface	<p>Sets the interface as passive. On a passive interface, you can disable OSPF protocol exchanges, but the router advertises the interface in its LSAs so that IP connectivity to the attached network segment will be established.</p> <p>Command mode: Interface IP</p>
[no] ip ospf point-to-point	<p>Sets the interface as point-to-point.</p> <p>Command mode: Interface IP</p>
ip ospf enable	<p>Enables OSPF interface.</p> <p>Command mode: Interface IP</p>
no ip ospf enable	<p>Disables OSPF interface.</p> <p>Command mode: Interface IP</p>
no ip ospf	<p>Deletes the OSPF interface.</p> <p>Command mode: Interface IP</p>
Show interface ip <interface number> ospf	<p>Displays the current settings for OSPF interface.</p> <p>Command mode: All</p>

OSPF Virtual Link Configuration

Table 265. OSPF Virtual Link Configuration Commands

Command Syntax and Usage
<pre>area-virtual-link <1-3> area <0-2></pre> <p>Configures the OSPF area index for the virtual link.</p> <p>Command mode: Router OSPF</p>
<pre>area-virtual-link <1-3> hello-interval <1-65535></pre> <pre>area-virtual-link <1-3> hello-interval <50-65535ms></pre> <p>Configures the authentication parameters of a hello packet, in seconds or milliseconds. The default value is 10 seconds.</p> <p>Command mode: Router OSPF</p>
<pre>area-virtual-link <1-3> dead-interval <1-65535></pre> <pre>area-virtual-link <1-3> dead-interval <1000-65535ms></pre> <p>Configures the health parameters of a hello packet, in seconds or milliseconds. The default value is 40 seconds.</p> <p>Command mode: Router OSPF</p>
<pre>area-virtual-link <1-3> transit-delay <1-3600></pre> <p>Configures the delay in transit, in seconds. The default value is one second.</p> <p>Command mode: Router OSPF</p>
<pre>area-virtual-link <1-3> retransmit-interval <1-3600></pre> <p>Configures the retransmit interval, in seconds. The default value is five seconds.</p> <p>Command mode: Router OSPF</p>
<pre>area-virtual-link <1-3> neighbor-router <IP address></pre> <p>Configures the router ID of the virtual neighbor. The default value is 0.0.0.0.</p> <p>Command mode: Router OSPF</p>
<pre>[no] area-virtual-link <1-3> key <password></pre> <p>Configures the password (up to eight characters) for each virtual link. The default setting is none.</p> <p>Command mode: Router OSPF</p>
<pre>area-virtual-link <1-3> message-digest-key <1-255></pre> <p>Sets MD5 key ID for each virtual link. The default setting is none.</p> <p>Command mode: Router OSPF</p>
<pre>area-virtual-link <1-3> enable</pre> <p>Enables OSPF virtual link.</p> <p>Command mode: Router OSPF</p>

Table 265. OSPF Virtual Link Configuration Commands (continued)

Command Syntax and Usage
<pre>no area-virtual-link <I-3> enable</pre> <p>Disables OSPF virtual link. Command mode: Router OSPF</p>
<pre>no area-virtual-link <I-3></pre> <p>Deletes OSPF virtual link. Command mode: Router OSPF</p>
<pre>show ip ospf area-virtual-link <I-3></pre> <p>Displays the current OSPF virtual link settings. Command mode: All</p>

OSPF Host Entry Configuration

Table 266. OSPF Host Entry Configuration Commands

Command Syntax and Usage
<pre>host <I-128> address <IP address></pre> <p>Configures the base IP address for the host entry. Command mode: Router OSPF</p>
<pre>host <I-128> area <0-2></pre> <p>Configures the area index of the host. Command mode: Router OSPF</p>
<pre>host <I-128> cost <I-65535></pre> <p>Configures the cost value of the host. Command mode: Router OSPF</p>
<pre>host <I-128> enable</pre> <p>Enables OSPF host entry. Command mode: Router OSPF</p>
<pre>no host <I-128> enable</pre> <p>Disables OSPF host entry. Command mode: Router OSPF</p>
<pre>no host <I-128></pre> <p>Deletes OSPF host entry. Command mode: Router OSPF</p>
<pre>show ip ospf host <I-128></pre> <p>Displays the current OSPF host entries. Command mode: All</p>

OSPF Route Redistribution Configuration.

Table 267. OSPF Route Redistribution Configuration Commands

Command Syntax and Usage
<pre>redistribute {fixed static rip ebgp ibgp} <rmap ID (1-32)></pre> <p>Adds selected routing map to the rmap list.</p> <p>This option adds a route map to the route redistribution list. The routes of the redistribution protocol matched by the route maps in the route redistribution list will be redistributed.</p> <p>Command mode: Router OSPF</p>
<pre>no redistribute {fixed static rip ebgp ibgp} <rmap ID (1-32)></pre> <p>Removes the route map from the route redistribution list.</p> <p>Removes routing maps from the rmap list.</p> <p>Command mode: Router OSPF</p>
<pre>[no] redistribute {fixed static rip ebgp ibgp} export metric <1-16777214> metric-type {type1 type2}</pre> <p>Exports the routes of this protocol as external OSPF AS-external LSAs in which the metric and metric type are specified. To remove a previous configuration and stop exporting the routes of the protocol, enter none.</p> <p>Command mode: Router OSPF</p>
<pre>show ip ospf redistribute</pre> <p>Displays the current route map settings.</p> <p>Command mode: All</p>

OSPF MD5 Key Configuration

Table 268. OSPF MD5 Key Commands

Command Syntax and Usage
<pre>message-digest-key <1-255> md5-key <1-16 characters></pre> <p>Sets the authentication key for this OSPF packet.</p> <p>Command mode: Router OSPF</p>
<pre>no message-digest-key <1-255></pre> <p>Deletes the authentication key for this OSPF packet.</p> <p>Command mode: Router OSPF</p>
<pre>show ip ospf message-digest-key <1-255></pre> <p>Displays the current MD5 key configuration.</p> <p>Command mode: All</p>

Border Gateway Protocol Configuration

Border Gateway Protocol (BGP) is an Internet protocol that enables routers on a network to share routing information with each other and advertise information about the segments of the IP address space they can access within their network with routers on external networks. BGP allows you to decide what is the “best” route for a packet to take from your network to a destination on another network, rather than simply setting a default route from your border router(s) to your upstream provider(s). You can configure BGP either within an autonomous system or between different autonomous systems. When run within an autonomous system, it's called internal BGP (iBGP). When run between different autonomous systems, it's called external BGP (eBGP). BGP is defined in RFC 1771.

BGP commands enable you to configure the switch to receive routes and to advertise static routes, fixed routes and virtual server IP addresses with other internal and external routers. In the current IBM Networking OS implementation, the CN4093 10Gb Converged Scalable Switch does not advertise BGP routes that are learned from one iBGP *speaker* to another iBGP *speaker*.

BGP is turned off by default.

Note: Fixed routes are subnet routes. There is one fixed route per IP interface.

Table 269. Border Gateway Protocol Commands

Command Syntax and Usage
<pre>router bgp</pre> <p>Enter Router BGP configuration mode.</p> <p>Command mode: Global configuration</p>
<pre>neighbor <I-I2></pre> <p>Configures each BGP <i>peer</i>. Each border router, within an autonomous system, exchanges routing information with routers on other external networks.</p> <p>To view command options, see page 394.</p> <p>Command mode: Router BGP</p>
<pre>as <0-65535></pre> <p>Set Autonomous System number.</p> <p>Command mode: Router BGP</p>
<pre>[no] asn4comp</pre> <p>Enables or disables ASN4 to ASN2 compatibility.</p> <p>Command mode: Router BGP</p>
<pre>local-preference <0-4294967294></pre> <p>Sets the local preference. The path with the higher value is preferred.</p> <p>When multiple peers advertise the same route, use the route with the shortest AS path as the preferred route if you are using eBGP, or use the local preference if you are using iBGP.</p> <p>Command mode: Router BGP</p>

Table 269. Border Gateway Protocol Commands (continued)

Command Syntax and Usage	
enable	Globally turns BGP on. Command mode: Router BGP
no enable	Globally turns BGP off. Command mode: Router BGP
show ip bgp	Displays the current BGP configuration. Command mode: All

BGP Peer Configuration

These commands are used to configure BGP peers, which are border routers that exchange routing information with routers on internal and external networks. The peer option is disabled by default.

Table 270. BGP Peer Configuration Commands

Command Syntax and Usage
<pre>neighbor <1-12> remote-address <IP address></pre> <p>Defines the IP address for the specified peer (border router), using dotted decimal notation. The default address is 0.0.0.0.</p> <p>Command mode: Router BGP</p>
<pre>neighbor <1-12> remote-as <1-65535></pre> <p>Sets the remote autonomous system number for the specified peer.</p> <p>Command mode: Router BGP</p>
<pre>neighbor <1-12> update-source {<interface number> loopback <1-5>}</pre> <p>Sets the source interface number for this peer.</p> <p>Command mode: Router BGP</p>
<pre>neighbor <1-12> timers hold-time <0, 3-65535></pre> <p>Sets the period of time, in seconds, that will elapse before the peer session is torn down because the switch hasn't received a "keep alive" message from the peer. The default value is 180 seconds.</p> <p>Command mode: Router BGP</p>
<pre>neighbor <1-12> timers keep-alive <0, 1-21845></pre> <p>Sets the keep-alive time for the specified peer, in seconds. The default value is 60 seconds.</p> <p>Command mode: Router BGP</p>
<pre>neighbor <1-12> advertisement-interval <1-65535></pre> <p>Sets time, in seconds, between advertisements. The default value is 60 seconds.</p> <p>Command mode: Router BGP</p>
<pre>neighbor <1-12> retry-interval <1-65535></pre> <p>Sets connection retry interval, in seconds. The default value is 120 seconds.</p> <p>Command mode: Router BGP</p>
<pre>neighbor <1-12> route-origination-interval <1-65535></pre> <p>Sets the minimum time between route originations, in seconds. The default value is 15 seconds.</p> <p>Command mode: Router BGP</p>

Table 270. BGP Peer Configuration Commands (continued)

Command Syntax and Usage	
neighbor <I-12> time-to-live <I-255>	<p>Time-to-live (TTL) is a value in an IP packet that tells a network router whether or not the packet has been in the network too long and should be discarded. TTL specifies a certain time span in seconds that, when exhausted, would cause the packet to be discarded. The TTL is determined by the number of router hops the packet is allowed before it must be discarded.</p> <p>This command specifies the number of router hops that the IP packet can make. This value is used to restrict the number of “hops” the advertisement makes. It is also used to support multi-hops, which allow BGP peers to talk across a routed network. The default number is set at 1.</p> <p>Note: The TTL value is significant only to eBGP peers, for iBGP peers the TTL value in the IP packets is always 255 (regardless of the configured value).</p> <p>Command mode: Router BGP</p>
neighbor <I-12> route-map in <I-32>	<p>Adds route map into in-route map list.</p> <p>Command mode: Router BGP</p>
neighbor <I-12> route-map out <I-32>	<p>Adds route map into out-route map list.</p> <p>Command mode: Router BGP</p>
no neighbor <I-12> route-map in <I-32>	<p>Removes route map from in-route map list.</p> <p>Command mode: Router BGP</p>
no neighbor <I-12> route-map out <I-32>	<p>Removes route map from out-route map list.</p> <p>Command mode: Router BGP</p>
no neighbor <I-12> shutdown	<p>Enables this peer configuration.</p> <p>Command mode: Router BGP</p>
neighbor <I-12> shutdown	<p>Disables this peer configuration.</p> <p>Command mode: Router BGP</p>
no neighbor <I-12>	<p>Deletes this peer configuration.</p> <p>Command mode: Router BGP</p>

Table 270. BGP Peer Configuration Commands (continued)

Command Syntax and Usage
<pre>[no] neighbor <1-12> password <1-16 characters></pre> <p>Configures the BGP peer password. Command mode: Router BGP</p>
<pre>show ip bgp neighbor [<1-12>]</pre> <p>Displays the current BGP peer configuration. Command mode: All</p>

BGP Redistribution Configuration

Table 271. BGP Redistribution Configuration Commands

Command Syntax and Usage
<pre>[no] neighbor <I-12> redistribute default-metric <I-4294967294></pre> <p>Sets default metric of advertised routes.</p> <p>Command mode: Router BGP</p>
<pre>[no] neighbor <I-12> redistribute default-action {import originate redistribute}</pre> <p>Sets default route action.</p> <p>Defaults routes can be configured as import, originate, redistribute, or none.</p> <p>None: No routes are configured</p> <p>Import: Import these routes.</p> <p>Originate: The switch sends a default route to peers if it does not have any default routes in its routing table.</p> <p>Redistribute: Default routes are either configured through default gateway or learned through other protocols and redistributed to peer. If the routes are learned from default gateway configuration, you have to enable static routes since the routes from default gateway are static routes. Similarly, if the routes are learned from a certain routing protocol, you have to enable that protocol.</p> <p>Command mode: Router BGP</p>
<pre>[no] neighbor <I-12> redistribute rip</pre> <p>Enables or disables advertising RIP routes.</p> <p>Command mode: Router BGP</p>
<pre>[no] neighbor <I-12> redistribute ospf</pre> <p>Enables or disables advertising OSPF routes.</p> <p>Command mode: Router BGP</p>
<pre>[no] neighbor <I-12> redistribute fixed</pre> <p>Enables or disables advertising fixed routes.</p> <p>Command mode: Router BGP</p>
<pre>[no] neighbor <I-12> redistribute static</pre> <p>Enables or disables advertising static routes.</p> <p>Command mode: Router BGP</p>
<pre>show ip bgp neighbor <I-12> redistribute</pre> <p>Displays current redistribution configuration.</p> <p>Command mode: All</p>

BGP Aggregation Configuration

These commands enable you to configure BGP aggregation to specify the routes/range of IP destinations a peer router accepts from other peers. All matched routes are aggregated to one route, to reduce the size of the routing table. By default, the first aggregation number is enabled and the rest are disabled.

Table 272. BGP Aggregation Configuration Commands

Command Syntax and Usage
<pre>aggregate-address <1-16> <IP address> <IP netmask></pre> <p>Defines the starting subnet IP address for this aggregation, using dotted decimal notation. The default address is 0.0.0.0.</p> <p>Command mode: Router BGP</p>
<pre>aggregate-address <1-16> enable</pre> <p>Enables this BGP aggregation.</p> <p>Command mode: Router BGP</p>
<pre>no aggregate-address <1-16> enable</pre> <p>Disables this BGP aggregation.</p> <p>Command mode: Router BGP</p>
<pre>no aggregate-address <1-16></pre> <p>Deletes this BGP aggregation.</p> <p>Command mode: Router BGP</p>
<pre>show ip bgp aggregate-address [<1-16>]</pre> <p>Displays the current BGP aggregation configuration.</p> <p>Command mode: All</p>

Multicast Listener Discovery Protocol Configuration

Table 273 describes the commands used to configure MLD parameters..

Table 273. MLD Protocol Configuration Commands

Command Syntax and Usage
<pre>ipv6 mld</pre> <p>Enter MLD global configuration mode. Command mode: Global configuration</p>
<pre>default</pre> <p>Resets MLD parameters to their default values. Command mode: MLD Configuration</p>
<pre>enable</pre> <p>Globally turns MLD on. Command mode: MLD Configuration</p>
<pre>no enable</pre> <p>Globally turns MLD off. Command mode: MLD Configuration</p>
<pre>exit</pre> <p>Exit from MLD configuration mode. Command mode: MLD Configuration</p>
<pre>show ipv6 mld</pre> <p>Displays the current MLD configuration parameters. Command mode: All</p>

MLD Interface Configuration

Table 274 describes the commands used to configure MLD parameters for an interface.

Table 274. MLD Interface Configuration Commands

Command Syntax and Usage
<pre>ipv6 mld default</pre> <p>Resets MLD parameters for the selected interface to their default values. Command mode: Interface IP</p>
<pre>ipv6 mld dmrtr enable disable</pre> <p>Enables or disables dynamic Mrouter learning on the interface. The default setting is disabled. Command mode: Interface IP</p>

Table 274. MLD Interface Configuration Commands (continued)

Command Syntax and Usage	
<pre>ipv6 mld enable</pre>	<p>Enables this MLD interface.</p> <p>Command mode: Interface IP</p>
<pre>no ipv6 mld enable</pre>	<p>Disables this MLD interface.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 mld llistnr <1-32></pre>	<p>Configures the Last Listener query interval. The default value is 1 second.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 mld qinterval <2-65535></pre>	<p>Configures the interval for MLD Query Reports. The default value is 125 seconds.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 mld qri <1000-65535></pre>	<p>Configures the interval for MLD Query Response Reports. The default value is 10,000 milliseconds.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 mld robust <2-10></pre>	<p>Configures the MLD Robustness variable, which allows you to tune the switch for expected packet loss on the subnet. If the subnet is expected to be lossy (high rate of packet loss), increase the value. The default value is 2.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 mld version <1-2></pre>	<p>Defines the MLD protocol version number.</p> <p>Command mode: Interface IP</p>
<pre>show ipv6 mld interface <interface number></pre>	<p>Displays the current MLD interface configuration.</p> <p>Command mode: All</p>

IGMP Configuration

[Table 275](#) describes the commands used to configure basic IGMP parameters.

Table 275. IGMP Configuration Commands

Command Syntax and Usage
<pre>[no] ip igmp aggregate</pre> <p>Enables or disables IGMP Membership Report aggregation. Command mode: Global configuration</p>
<pre>ip igmp enable</pre> <p>Globally turns IGMP on. Command mode: Global configuration</p>
<pre>no ip igmp enable</pre> <p>Globally turns IGMP off. Command mode: Global configuration</p>
<pre>show ip igmp</pre> <p>Displays the current IGMP configuration parameters. Command mode: All</p>

The following sections describe the IGMP configuration options.

- [“IGMP Snooping Configuration” on page 402](#)
- [“IGMPv3 Configuration” on page 403](#)
- [“IGMP Relay Configuration” on page 404](#)
- [“IGMP Relay Multicast Router Configuration” on page 405](#)
- [“IGMP Static Multicast Router Configuration” on page 406](#)
- [“IGMP Filtering Configuration” on page 407](#)
- [“IGMP Advanced Configuration” on page 410](#)
- [“IGMP Querier Configuration” on page 410](#)

IGMP Snooping Configuration

IGMP Snooping allows the switch to forward multicast traffic only to those ports that request it. IGMP Snooping prevents multicast traffic from being flooded to all ports. The switch learns which server hosts are interested in receiving multicast traffic, and forwards it only to ports connected to those servers.

[Table 276](#) describes the commands used to configure IGMP Snooping.

Table 276. IGMP Snooping Configuration Commands

Command Syntax and Usage
<pre>ip igmp snoop mrouter-timeout <1-600></pre> <p>Configures the timeout value for IGMP Membership Queries (mrouter). Once the timeout value is reached, the switch removes the multicast router from its IGMP table, if the proper conditions are met. The range is from 1 to 600 seconds. The default is 255 seconds.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp snoop source-ip <IP address></pre> <p>Configures the source IP address used as a proxy for IGMP Group Specific Queries.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp snoop vlan <VLAN number></pre> <p>Adds the selected VLAN(s) to IGMP Snooping.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp snoop vlan <VLAN number></pre> <p>Removes the selected VLAN(s) from IGMP Snooping.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp snoop vlan all</pre> <p>Removes all VLANs from IGMP Snooping.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp snoop enable</pre> <p>Enables IGMP Snooping.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp snoop enable</pre> <p>Disables IGMP Snooping.</p> <p>Command mode: Global configuration</p>
<pre>show ip igmp snoop</pre> <p>Displays the current IGMP Snooping parameters.</p> <p>Command mode: All</p>

IGMPv3 Configuration

Table 277 describes the commands used to configure IGMP version 3.

Table 277. IGMP version 3 Configuration Commands

Command Syntax and Usage	
<pre>ip igmp snoop igmpv3 sources <1-64></pre>	<p>Configures the maximum number of IGMP multicast sources to snoop from within the group record. Use this command to limit the number of IGMP sources to provide more refined control. The default value is 8.</p> <p>Command mode: Global configuration</p>
<pre>[no] ip igmp snoop igmpv3 v1v2</pre>	<p>Enables or disables snooping on IGMP version 1 and version 2 reports. When disabled, the switch drops IGMPv1 and IGMPv2 reports. The default value is enabled.</p> <p>Command mode: Global configuration</p>
<pre>[no] ip igmp snoop igmpv3 exclude</pre>	<p>Enables or disables snooping on IGMPv3 Exclude Reports. When disabled, the switch ignores Exclude Reports. The default value is enabled.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp snoop igmpv3 enable</pre>	<p>Enables IGMP version 3. The default value is disabled.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp snoop igmpv3 enable</pre>	<p>Disables IGMP version 3.</p> <p>Command mode: Global configuration</p>
<pre>show ip igmp snoop igmpv3</pre>	<p>Displays the current IGMP v3 Snooping configuration.</p> <p>Command mode: All</p>

IGMP Relay Configuration

When you configure IGMP Relay, also configure the IGMP Relay multicast routers.

[Table 278](#) describes the commands used to configure IGMP Relay.

Table 278. IGMP Relay Configuration Commands

Command Syntax and Usage
<pre>ip igmp relay vlan <VLAN number></pre> <p>Adds the VLAN to the list of IGMP Relay VLANs.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp relay vlan <VLAN number></pre> <p>Removes the VLAN from the list of IGMP Relay VLANs.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp relay report <0-150></pre> <p>Configures the interval between unsolicited Join reports sent by the switch, in seconds.</p> <p>The default value is 10.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp relay enable</pre> <p>Enables IGMP Relay.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp relay enable</pre> <p>Disables IGMP Relay.</p> <p>Command mode: Global configuration</p>
<pre>show ip igmp relay</pre> <p>Displays the current IGMP Relay configuration.</p> <p>Command mode: All</p>

IGMP Relay Multicast Router Configuration

Table 279 describes the commands used to configure multicast routers for IGMP Relay.

Table 279. IGMP Relay Mrouter Configuration Commands

Command Syntax and Usage	
ip igmp relay mrouter <1-2> address <IP address>	Configures the IP address of the IGMP multicast router used for IGMP Relay. Command mode: Global configuration
ip igmp relay mrouter <1-2> interval <1-60>	Configures the time interval between ping attempts to the upstream Mrouters, in seconds. The default value is 2. Command mode: Global configuration
ip igmp relay mrouter <1-2> retry <1-120>	Configures the number of failed ping attempts required before the switch declares this Mrouter is down. The default value is 4. Command mode: Global configuration
ip igmp relay mrouter <1-2> attempt <1-128>	Configures the number of successful ping attempts required before the switch declares this Mrouter is up. The default value is 5. Command mode: Global configuration
ip igmp relay mrouter <1-2> version <1-2>	Configures the IGMP version (1 or 2) of the multicast router. Command mode: Global configuration
ip igmp relay mrouter <1-2> enable	Enables the multicast router. Command mode: Global configuration
no ip igmp relay mrouter <1-2> enable	Disables the multicast router. Command mode: Global configuration
no ip igmp relay mrouter <1-2>	Deletes the multicast router from IGMP Relay. Command mode: Global configuration

IGMP Static Multicast Router Configuration

Table 280 describes the commands used to configure a static multicast router.

Note: When static Mrouters are used, the switch continues learning dynamic Mrouters via IGMP snooping. However, dynamic Mrouters may not replace static Mrouters. If a dynamic Mrouter has the same port and VLAN combination as a static Mrouter, the dynamic Mrouter is not learned.

Table 280. IGMP Static Multicast Router Configuration Commands

Command Syntax and Usage
<pre>ip igmp mrouter <port alias or number> <VLAN number> <version (1-3)></pre> <p>Selects a port/VLAN combination on which the static multicast router is connected, and configures the IGMP version (1, 2 or 3) of the multicast router.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp mrouter <port alias or number> <VLAN number> <version (1-3)></pre> <p>Removes a static multicast router from the selected port/VLAN combination.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp mrouter all</pre> <p>Removes all static multicast routers.</p> <p>Command mode: Global configuration</p>
<pre>clear ip igmp mrouter</pre> <p>Clears the Dynamic router port table.</p> <p>Command mode: Global configuration</p>
<pre>show ip igmp mrouter</pre> <p>Displays the current IGMP Static Multicast Router parameters.</p> <p>Command mode: All</p>

IGMP Filtering Configuration

[Table 281](#) describes the commands used to configure an IGMP filter.

Table 281. IGMP Filtering Configuration Commands

Command Syntax and Usage
<pre>ip igmp profile <1-16></pre> <p>Configures the IGMP filter. To view command options, see page 408.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp filtering</pre> <p>Enables IGMP filtering globally.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp filtering</pre> <p>Disables IGMP filtering globally.</p> <p>Command mode: Global configuration</p>
<pre>show ip igmp filtering</pre> <p>Displays the current IGMP Filtering parameters.</p> <p>Command mode: All</p>

IGMP Filter Definition

Table 282 describes the commands used to define an IGMP filter.

Table 282. IGMP Filter Definition Commands

Command Syntax and Usage
<pre>ip igmp profile <1-16> range <IP address 1> <IP address 2></pre> <p>Configures the range of IP multicast addresses for this filter. Command mode: Global configuration</p>
<pre>ip igmp profile <1-16> action {allow deny}</pre> <p>Allows or denies multicast traffic for the IP multicast addresses specified. The default action is deny. Command mode: Global configuration</p>
<pre>ip igmp profile <1-16> enable</pre> <p>Enables this IGMP filter. Command mode: Global configuration</p>
<pre>no ip igmp profile <1-16> enable</pre> <p>Disables this IGMP filter. Command mode: Global configuration</p>
<pre>no ip igmp profile <1-16></pre> <p>Deletes this filter's parameter definitions. Command mode: Global configuration</p>
<pre>show ip igmp profile <1-16></pre> <p>Displays the current IGMP filter. Command mode: All</p>

IGMP Filtering Port Configuration

Table 283 describes the commands used to configure a port for IGMP filtering.

Table 283. IGMP Filter Port Configuration Commands

Command Syntax and Usage
<pre>[no] ip igmp filtering</pre> <p>Enables or disables IGMP filtering on this port. Command mode: Interface port</p>
<pre>ip igmp profile <1-16></pre> <p>Adds an IGMP filter to this port. Command mode: Interface port</p>
<pre>no ip igmp profile <1-16></pre> <p>Removes an IGMP filter from this port. Command mode: Interface port</p>
<pre>show interface port <port alias or number> igmp-filtering</pre> <p>Displays the current IGMP filter parameters for this port. Command mode: All</p>

IGMP Advanced Configuration

Table 284 describes the commands used to configure advanced IGMP parameters.

Table 284. IGMP Advanced Configuration Commands

Command Syntax and Usage	
<pre>ip igmp query-interval <1-600></pre>	<p>Sets the IGMP router query interval, in seconds. The default value is 125.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp robust <1-10></pre>	<p>Configures the IGMP Robustness variable, which allows you to tune the switch for expected packet loss on the subnet. If you expect the subnet to have a high rate of packet loss, increase the value. The default value is 2.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp timeout <1-255></pre>	<p>Configures the Query Response Interval. This is a value used to determine the Group Membership Interval, together with the Robustness Variable and the Query Interval. The range is from 1 to 255 seconds. The default is 10 seconds.</p> <p>Command mode: Global configuration</p>
<pre>[no] ip igmp fastleave <VLAN number></pre>	<p>Enables or disables Fastleave processing. Fastleave lets the switch immediately remove a port from the IGMP port list if the host sends a Leave message and the proper conditions are met. This command is disabled by default.</p> <p>Command mode: Global configuration</p>
<pre>[no] ip igmp rtralert</pre>	<p>Enables or disables the Router Alert option in IGMP messages.</p> <p>Command mode: Global configuration</p>

IGMP Querier Configuration

Table 285. describes the commands used to configure IGMP Querier.

Table 285. IGMP Querier Configuration Options

Command Syntax and Usage	
<pre>[no] ip igmp querier vlan <VLAN number> enable</pre>	<p>Enables or disables the IGMP Querier globally.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier vlan <VLAN number> source-ip <IP address></pre>	<p>Configures the IGMP source IP address for the selected VLAN.</p> <p>Command mode: Global configuration</p>

Table 285. IGMP Querier Configuration Options (continued)

Command Syntax and Usage	
<pre>ip igmp querier vlan <VLAN number> max-response <1-256></pre>	<p>Configures the maximum time, in tenths of a second, allowed before responding to a Membership Query message. The default value is 100.</p> <p>By varying the Query Response Interval, an administrator may tune the burstiness of IGMP messages on the subnet; larger values make the traffic less bursty, as host responses are spread out over a larger interval.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier vlan <VLAN number> query-interval <1-608></pre>	<p>Configures the interval between IGMP Query broadcasts. The default value is 125 seconds.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier vlan <VLAN number> robustness <1-10></pre>	<p>Configures the IGMP Robustness variable, which is the number of times that the switch sends each IGMP message. The default value is 2.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier vlan <VLAN number> election-type [ipv4 mac]</pre>	<p>Sets the IGMP Querier election criteria as IP address or Mac address. The default setting is IPv4.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier vlan <VLAN number> startup-interval <1-608></pre>	<p>Configures the Startup Query Interval, which is the interval between General Queries sent out at startup.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier vlan <VLAN number> startup-count <1-10></pre>	<p>Configures the Startup Query Count, which is the number of IGMP Queries sent out at startup. Each Query is separated by the Startup Query Interval. The default value is 2.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier vlan <VLAN number> version [v1 v2 v3]</pre>	<p>Configures the IGMP version. The default version is v3.</p> <p>Command mode: Global configuration</p>
<pre>ip igmp querier enable</pre>	<p>Enables IGMP Querier.</p> <p>Command mode: Global configuration</p>
<pre>no ip igmp querier enable</pre>	<p>Disables IGMP Querier.</p> <p>Command mode: Global configuration</p>

Table 285. IGMP Querier Configuration Options (continued)

Command Syntax and Usage
<pre>show ip igmp querier vlan <VLAN number></pre> <p>Displays IGMP Querier information for the selected VLAN.</p> <p>Command mode: Global configuration</p>
<pre>show ip igmp querier</pre> <p>Displays the current IGMP Querier parameters.</p> <p>Command mode: All</p>

IKEv2 Configuration

Table 286 describes the commands used to configure IKEv2.

Table 286. IKEv2 Options

Command Syntax and Usage
<pre>ikev2 retransmit-interval <1-20></pre> <p>Sets the interval, in seconds, the timeout value in case a packet is not received by the peer and needs to be retransmitted. The default value is 20 seconds.</p> <p>Command mode: Global configuration</p>
<pre>[no] ikev2 cookie</pre> <p>Enables or disables cookie notification.</p> <p>Command mode: Global configuration</p>
<pre>show ikev2</pre> <p>Displays the current IKEv2 settings.</p> <p>Command mode: All</p>

IKEv2 Proposal Configuration

Table 287 describes the commands used to configure an IKEv2 proposal.

Table 287. IKEv2 Proposal Options

Command Syntax and Usage
<pre>ikev2 proposal</pre> <p>Enter IKEv2 proposal mode.</p> <p>Command mode: Global configuration</p>
<pre>encryption {3des aes-cbc}</pre> <p>Configures IKEv2 encryption mode. The default value is 3des.</p> <p>Command mode: IKEv2 proposal</p>
<pre>integrity {md5 sha1}</pre> <p>Configures the IKEv2 authentication algorithm type. The default value is sha1.</p> <p>Command mode: IKEv2 proposal</p>
<pre>group {1 2 5 14 24}</pre> <p>Configures the the DH group. The default group is 2.</p> <p>Command mode: IKEv2 proposal</p>

IKEv2 Preshare Key Configuration

Table 288 describes the commands used to configure IKEv2 preshare keys.

Table 288. IKEv2 Preshare Key Options

Command Syntax and Usage
<pre>ikev2 preshare-key local <1-32 characters></pre> <p>Configures the local preshare key. The default value is <code>ibm123</code>.</p> <p>Command mode: Global configuration</p>
<pre>ikev2 preshare-key remote <1-32 characters> <IPv6 address></pre> <p>Configures the remote preshare key for the IPv6 address.</p> <p>Command mode: Global configuration</p>
<pre>show ikev2 preshare-key</pre> <p>Displays the current IKEv2 Preshare key settings.</p> <p>Command mode: Global configuration</p>

IKEv2 Identification Configuration

Table 289 describes the commands used to configure IKEv2 identification.

Table 289. IKEv2 Identification Options

Command Syntax and Usage
<pre>ikev2 identity local address</pre> <p>Configures the switch to use the supplied IPv6 address as identification.</p> <p>Command mode: Global configuration</p>
<pre>ikev2 identity local fqdn <1-32 characters></pre> <p>Configures the switch to use the fully-qualified domain name (such as "example.com") as identification.</p> <p>Command mode: Global configuration</p>
<pre>ikev2 identity local email <1-32 characters></pre> <p>Configures the switch to use the supplied email address (such as "xyz@example.com") as identification.</p> <p>Command mode: Global configuration</p>
<pre>show ikev2 identity</pre> <p>Displays the current IKEv2 identification settings.</p> <p>Command mode: All</p>

IPsec Configuration

Table 290 describes the commands used to configure IPsec.

Table 290. IPsec Options

Command Syntax and Usage
<code>ipsec enable</code> Enables IPsec. Command mode: Global configuration
<code>no ipsec enable</code> Disables IPsec. Command mode: Global configuration
<code>show ipsec</code> Displays the current IPsec settings. Command mode: All

IPsec Transform Set Configuration

Table 291 describes the commands used to configure IPsec transforms.

Table 291. IPsec Transform Set Options

Command Syntax and Usage
<pre>ipsec transform-set <I-10> {ah-md5 ah-sha1 esp-3des esp-aes-cbc esp-md5 esp-null}</pre> <p>Sets the AH or ESP authentication, encryption, or integrity algorithm. The available algorithms are as follows:</p> <ul style="list-style-type: none"> - ah-md5 - ah-sha1 - esp-3des - esp-aes-cbc - esp-des - esp-md5 - esp-null - esp - sha1 <p>Command mode: Global configuration</p>
<pre>ipsec transform-set <I-10> transport {ah-md5 ah-sha1 esp-3des esp-aes-cbc esp-md5 esp-null}</pre> <p>Sets transport mode and the AH or ESP authentication, encryption, or integrity algorithm.</p> <p>Command mode: Global configuration</p>
<pre>ipsec transform-set <I-10> tunnel {ah-md5 ah-sha1 esp-3des esp-aes-cbc esp-md5 esp-null}</pre> <p>Sets tunnel mode and the AH or ESP authentication, encryption, or integrity algorithm.</p> <p>Command mode: Global configuration</p>
<pre>no ipsec transform <I-10></pre> <p>Deletes the transform set.</p> <p>Command mode: Global configuration</p>
<pre>show ipsec transform-set <I-10></pre> <p>Displays the current IPsec Transform Set settings.</p> <p>Command mode: All</p>

IPsec Traffic Selector Configuration

Table 292 describes the commands used to configure an IPsec traffic selector.

Table 292. IPsec Traffic Selector Options

Command Syntax and Usage
<pre>ipsec traffic-selector <1-10> action {permit deny} {any icmp tcp} {<IPv6 address> any}</pre> <p>Sets the traffic-selector to permit or deny the specified type of traffic. Command mode: Global configuration</p>
<pre>src <IPv6 address> any</pre> <p>Sets the source IPv6 address. Command mode: Global configuration</p>
<pre>prefix <1-128></pre> <p>Sets the destination IPv6 prefix length. Command mode: Global configuration</p>
<pre>dst <IPv6 address> any</pre> <p>Sets the destination IP address. Command mode: Global configuration</p>
<pre>del</pre> <p>Deletes the traffic selector. Command mode: Global configuration</p>
<pre>cur</pre> <p>Displays the current IPsec Traffic Selector settings. Command mode: All</p>

IPsec Dynamic Policy Configuration

Table 293 describes the commands used to configure an IPsec dynamic policy.

Table 293. IPsec Dynamic Policy Options

Command Syntax and Usage
<pre>ipsec dynamic-policy <I-10></pre> <p>Enter IPsec dynamic policy mode. Command mode: Global configuration</p>
<pre>peer <IPv6 address></pre> <p>Sets the remote peer IP address. Command mode: IPsec dynamic policy</p>
<pre>traffic-selector <I-10></pre> <p>Sets the traffic selector for the IPsec policy. Command mode: IPsec dynamic policy</p>
<pre>transform-set <I-10></pre> <p>Sets the transform set for the IPsec policy. Command mode: IPsec dynamic policy</p>
<pre>sa-lifetime <120-86400></pre> <p>Sets the IPsec SA lifetime in seconds. The default value is 86400 seconds. Command mode: IPsec dynamic policy</p>
<pre>pfs enable disable</pre> <p>Enables/disables perfect forward security. Command mode: IPsec dynamic policy</p>
<pre>show ipsec dynamic-policy <I-10></pre> <p>Displays the current IPsec dynamic policy settings. Command mode: All</p>

IPsec Manual Policy Configuration

Table 294 describes the commands used to configure an IPsec manual policy.

Table 294. IPsec Manual Policy Options

Command Syntax and Usage
<pre>ipsec manual-policy <I-10></pre> <p>Enter IPsec manual policy mode.</p> <p>Command mode: Global configuration</p>
<pre>in-ah auth-key <key code (hexadecimal)></pre> <p>Sets inbound Authentication Header (AH) authenticator key.</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 20 characters for SHA1 and 16 characters for MD5 encryption.</p> <p>Command mode: IPsec manual policy</p>
<pre>peer <IPv6 address></pre> <p>Sets the remote peer IP address.</p> <p>Command mode: IPsec manual policy</p>
<pre>traffic-selector <I-10></pre> <p>Sets the traffic selector for the IPsec policy.</p> <p>Command mode: IPsec manual policy</p>
<pre>transform-set <I-10></pre> <p>Sets the transform set for the IPsec policy.</p> <p>Command mode: IPsec manual policy</p>
<pre>in-ah spi <256-4294967295></pre> <p>Sets the inbound Authentication Header (AH) Security Parameter Index (SPI).</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 20 characters for SHA1 and 16 characters for MD5 encryption.</p> <p>Command mode: IPsec manual policy</p>
<pre>in-esp cipher-key <key code (hexadecimal)></pre> <p>Sets the inbound Encapsulating Security Payload (ESP) cipher key.</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 8 characters for DES and to 24 characters for 3DES and AES-CBC encryption.</p> <p>Command mode: IPsec manual policy</p>
<pre>in-esp auth-key <key code (hexadecimal)></pre> <p>Sets the inbound Encapsulating Security Payload (ESP) authenticator key.</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 8 characters for DES and to 24 characters for 3DES and AES-CBC encryption.</p> <p>Command mode: IPsec manual policy</p>

Table 294. IPsec Manual Policy Options (continued)

Command Syntax and Usage	
<code>in-esp auth-key spi <256-4294967295></code>	<p>Sets the inbound Encapsulating Security Payload (ESP) Security Parameter Index (SPI).</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 20 characters for SHA1 and 16 characters for MD5 encryption.</p> <p>Command mode: IPsec manual policy</p>
<code>out-ah auth-key <key code (hexadecimal)></code>	<p>Sets the outbound Authentication Header (AH) authenticator key.</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 20 characters for SHA1 and 16 characters for MD5 encryption.</p> <p>Command mode: IPsec manual policy</p>
<code>out-ah spi <256-4294967295></code>	<p>Sets the outbound Authentication Header (AH) Security Parameter Index (SPI).</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 20 characters for SHA1 and 16 characters for MD5 encryption.</p> <p>Command mode: IPsec manual policy</p>
<code>out-esp auth-key <key code (hexadecimal)></code>	<p>Sets the outbound Encapsulating Security Payload (ESP) authenticator key.</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 8 characters for DES and to 24 characters for 3DES and AES-CBC encryption.</p> <p>Command mode: IPsec manual policy</p>
<code>out-esp cipher-key <key code (hexadecimal)></code>	<p>Sets the outbound Encapsulating Security Payload (ESP) cipher key.</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 8 characters for DES and to 24 characters for 3DES and AES-CBC encryption.</p> <p>Command mode: IPsec manual policy</p>
<code>out-esp auth-key spi <256-4294967295></code>	<p>Sets the outbound Encapsulating Security Payload (ESP) Security Parameter Index (SPI).</p> <p>Note: For manual policies, when peering with a third-party device, key lengths are fixed to 20 characters for SHA1 and 16 characters for MD5 encryption.</p> <p>Command mode: IPsec manual policy</p>
<code>show ipsec manual-policy <1-10></code>	<p>Displays the current IPsec manual policy settings.</p> <p>Command mode: All</p>

Domain Name System Configuration

The Domain Name System (DNS) commands are used for defining the primary and secondary DNS servers on your local network, and for setting the default domain name served by the switch services. DNS parameters must be configured prior to using hostname parameters with the `ping`, `tracert`, and `tftp` commands.

Table 295. Domain Name Service Commands

Command Syntax and Usage	
<code>[no] ip dns primary-server <IP address></code>	<p>You are prompted to set the IPv4 address for your primary DNS server, using dotted decimal notation.</p> <p>Command mode: Global configuration</p>
<code>[no] ip dns secondary-server <IP address></code>	<p>You are prompted to set the IPv4 address for your secondary DNS server, using dotted decimal notation. If the primary DNS server fails, the configured secondary will be used instead.</p> <p>Command mode: Global configuration</p>
<code>[no] ip dns ipv6 primary-server <IP address></code>	<p>You are prompted to set the IPv6 address for your primary DNS server, using hexadecimal format with colons.</p> <p>Command mode: Global configuration</p>
<code>[no] ip dns ipv6 secondary-server <IP address></code>	<p>You are prompted to set the IPv6 address for your secondary DNS server, using hexadecimal format with colons. If the primary DNS server fails, the configured secondary will be used instead.</p> <p>Command mode: Global configuration</p>
<code>ip dns ipv6 request-version {ipv4 ipv6}</code>	<p>Sets the protocol used for the first request to the DNS server, as follows:</p> <ul style="list-style-type: none"> – IPv4 – IPv6 <p>Command mode: Global configuration</p>
<code>[no] ip dns domain-name <string></code>	<p>Sets the default domain name used by the switch. For example: <code>mycompany.com</code></p> <p>Command mode: Global configuration</p>
<code>show ip dns</code>	<p>Displays the current Domain Name System settings.</p> <p>Command mode: All</p>

Bootstrap Protocol Relay Configuration

The Bootstrap Protocol (BOOTP) Relay commands are used to let hosts get their configurations from a Dynamic Host Configuration Protocol (DHCP) server. The BOOTP configuration enables the switch to forward a client request for an IP address to two DHCP/BOOTP servers with IP addresses that have been configured on the CN4093.

BOOTP relay is turned off by default.

Table 296. Global BOOTP Relay Configuration Options

Command Syntax and Usage
<pre>[no] ip bootp-relay server <1-4> address <IP address></pre> <p>Sets the IP address of the selected global BOOTP server.</p> <p>Command mode: Global configuration</p>
<pre>ip bootp-relay enable</pre> <p>Globally turns on BOOTP relay.</p> <p>Command mode: Global configuration</p>
<pre>no ip bootp-relay enable</pre> <p>Globally turns off BOOTP relay.</p> <p>Command mode: Global configuration</p>

BOOTP Relay Broadcast Domain Configuration

These commands allow you to configure a BOOTP server for a specific broadcast domain, based on its associated VLAN.

Table 297. BOOTP Relay Broadcast Domain Configuration Options

Command Syntax and Usage
<pre>ip bootp-relay bcast-domain <1-10> vlan <VLAN number></pre> <p>Configures the VLAN of the broadcast domain. Each broadcast domain must have a unique VLAN.</p> <p>Command mode: Global configuration</p>
<pre>ip bootp-relay bcast-domain <1-10> server <1-4> address <IPv4 address></pre> <p>Sets the IP address of the BOOTP server.</p> <p>Command mode: Global configuration</p>
<pre>ip bootp-relay bcast-domain <1-10> enable</pre> <p>Enables BOOTP Relay for the broadcast domain.</p> <p>Command mode: Global configuration</p>
<pre>no ip bootp-relay bcast-domain <1-10> enable</pre> <p>Disables BOOTP Relay for the broadcast domain. When disabled, BOOTP Relay is performed by one of the global BOOTP servers.</p> <p>Command mode: Global configuration</p>

Table 297. BOOTP Relay Broadcast Domain Configuration Options

Command Syntax and Usage
<pre>no ip bootp-relay bcast-domain <1-10></pre> <p>Deletes the selected broadcast domain configuration.</p> <p>Command mode: Global configuration</p>
<pre>show ip bootp-relay</pre> <p>Displays the current parameters for the BOOTP Relay broadcast domain.</p> <p>Command mode: All</p>

VRRP Configuration

Virtual Router Redundancy Protocol (VRRP) support on the CN4093 provides redundancy between routers in a LAN. This is accomplished by configuring the same virtual router IP address and ID number on each participating VRRP-capable routing device. One of the virtual routers is then elected as the master, based on a number of priority criteria, and assumes control of the shared virtual router IP address. If the master fails, one of the backup virtual routers will assume routing authority and take control of the virtual router IP address.

By default, VRRP is disabled. IBM Networking OS has extended VRRP to include virtual servers as well, allowing for full active/active redundancy between switches. For more information on VRRP, see the “High Availability” chapter in the *IBM Networking OS 7.8 Application Guide*.

Table 298. Virtual Router Redundancy Protocol Commands

Command Syntax and Usage	
<code>router vrrp</code>	Enter Router VRRP configuration mode. Command mode: Global configuration
<code>holdoff <0-255></code>	Globally sets the time, in seconds, VRRP waits from when the master switch goes down until elevating a new switch to be the master switch. Command mode: Router VRRP
<code>[no] hot-standby</code>	Enables or disables hot standby processing, in which two or more switches provide redundancy for each other. By default, this option is disabled. Command mode: Router VRRP
<code>enable</code>	Globally enables VRRP on this switch. Command mode: Router VRRP
<code>no enable</code>	Globally disables VRRP on this switch. Command mode: Router VRRP
<code>show ip vrrp</code>	Displays the current VRRP parameters. Command mode: All

Virtual Router Configuration

These commands are used for configuring virtual routers for this switch. A virtual router is defined by its virtual router ID and an IP address. On each VRRP-capable routing device participating in redundancy for this virtual router, a virtual router will be configured to share the same virtual router ID and IP address.

Virtual routers are disabled by default.

Table 299. VRRP Virtual Router Configuration Commands

Command Syntax and Usage	
<pre>virtual-router <I-128> virtual-router-id <I-255></pre>	<p>Defines the virtual router ID (VRID). This is used in conjunction with the [no] virtual-router <VRID> address <IP address> command below to define a virtual router on this switch. To create a pool of VRRP-enabled routing devices which can provide redundancy to each other, each participating VRRP device must be configured with the same virtual router.</p> <p>The VRID for standard virtual routers (where the virtual router IP address is not the same as any virtual server) can be any integer between 1 and 255. The default value is 1.</p> <p>All VRID values must be unique within the VLAN to which the virtual router's IP interface belongs.</p> <p>Command mode: Router VRRP</p>
<pre>[no] virtual-router <I-128> address <IP address></pre>	<p>Defines the IP address for this virtual router using dotted decimal notation. This is used in conjunction with the VRID (above) to configure the same virtual router on each participating VRRP device. The default address is 0.0.0.0.</p> <p>Command mode: Router VRRP</p>
<pre>virtual-router <I-128> interface <interface number></pre>	<p>Selects a switch IP interface. If the IP interface has the same IP address as the addr option above, this switch is considered the "owner" of the defined virtual router. An owner has a special priority of 255 (highest) and will always assume the role of master router, even if it must pre-empt another virtual router which has assumed master routing authority. This pre-emption occurs even if the preem option below is disabled. The default value is 1.</p> <p>Command mode: Router VRRP</p>
<pre>virtual-router <I-128> priority <I-254></pre>	<p>Defines the election priority bias for this virtual server. The priority value can be any integer between 1 and 254. The default value is 100.</p> <p>During the master router election process, the routing device with the highest virtual router priority number wins. If there is a tie, the device with the highest IP interface address wins. If this virtual router's IP address is the same as the one used by the IP interface, the priority for this virtual router will automatically be set to 255 (highest).</p> <p>When priority tracking is used, this base priority value can be modified according to a number of performance and operational criteria.</p> <p>Command mode: Router VRRP</p>

Table 299. VRRP Virtual Router Configuration Commands (continued)

Command Syntax and Usage	
<pre>virtual-router <I-128> timers advertise <I-255></pre>	<p>Defines the time interval between VRRP master advertisements. This can be any integer between 1 and 255 seconds. The default value is 1.</p> <p>Command mode: Router VRRP</p>
<pre>[no] virtual-router <I-128> preemption</pre>	<p>Enables or disables master preemption. When enabled, if this virtual router is in backup mode but has a higher priority than the current master, this virtual router will preempt the lower priority master and assume control. Note that even when <code>preemption</code> is disabled, this virtual router will always pre-empt any other master if this switch is the owner (the IP interface address and virtual router <code>addr</code> are the same). By default, this option is enabled.</p> <p>Command mode: Router VRRP</p>
<pre>virtual-router <I-128> enable</pre>	<p>Enables this virtual router.</p> <p>Command mode: Router VRRP</p>
<pre>no virtual-router <I-128> enable</pre>	<p>Disables this virtual router.</p> <p>Command mode: Router VRRP</p>
<pre>no virtual-router <I-128></pre>	<p>Deletes this virtual router from the switch configuration.</p> <p>Command mode: Router VRRP</p>
<pre>show ip vrrp virtual-router <I-128></pre>	<p>Displays the current configuration information for this virtual router.</p> <p>Command mode: All</p>

Virtual Router Priority Tracking Configuration

These commands are used for modifying the priority system used when electing the master router from a pool of virtual routers. Various tracking criteria can be used to bias the election results. Each time one of the tracking criteria is met, the priority level for the virtual router is increased by an amount defined through the VRRP Tracking commands.

Criteria are tracked dynamically, continuously updating virtual router priority levels when enabled. If the virtual router preemption option is enabled, this virtual router can assume master routing authority when its priority level rises above that of the current master.

Some tracking criteria apply to standard virtual routers, otherwise called “virtual interface routers.” A virtual *server* router is defined as any virtual router whose IP address is the same as any configured virtual server IP address.

Table 300. VRRP Priority Tracking Configuration Commands

Command Syntax and Usage	
<pre>[no] virtual-router <1-128> track virtual-routers</pre>	<p>When enabled, the priority for this virtual router will be increased for each virtual router in master mode on this switch. This is useful for making sure that traffic for any particular client/server pairing are handled by the same switch, increasing routing and load balancing efficiency. This command is disabled by default.</p> <p>Command mode: Router VRRP</p>
<pre>[no] virtual-router <1-128> track interfaces</pre>	<p>When enabled, the priority for this virtual router will be increased for each other IP interface active on this switch. An IP interface is considered active when there is at least one active port on the same VLAN. This helps elect the virtual routers with the most available routes as the master. This command is disabled by default.</p> <p>Command mode: Router VRRP</p>
<pre>[no] virtual-router <1-128> track ports</pre>	<p>When enabled, the priority for this virtual router will be increased for each active port on the same VLAN. A port is considered “active” if it has a link and is forwarding traffic. This helps elect the virtual routers with the most available ports as the master. This command is disabled by default.</p> <p>Command mode: Router VRRP</p>
<pre>show ip vrrp virtual-router <1-128> track</pre>	<p>Displays the current configuration for priority tracking for this virtual router.</p> <p>Command mode: All</p>

Virtual Router Group Configuration

Virtual Router Group commands are used for associating all virtual routers into a single logical virtual router, which forces all virtual routers on the CN4093 to either be master or backup as a group. A virtual router is defined by its virtual router ID and an IP address. On each VRRP-capable routing device participating in redundancy for this virtual router, a virtual router will be configured to share the same virtual router ID and IP address.

Note: This option is required to be configured only when using at least two CN4093s in a hot-standby failover configuration, where only one switch is active at any time.

Table 301. VRRP Virtual Router Group Configuration Commands

Command Syntax and Usage
<pre>group virtual-router-id <1-255></pre> <p>Defines the virtual router ID (VRID).</p> <p>The VRID for standard virtual routers (where the virtual router IP address is not the same as any virtual server) can be any integer between 1 and 255. All VRID values must be unique within the VLAN to which the virtual router's IP interface (see <code>interface</code> below) belongs. The default virtual router ID is 1.</p> <p>Command mode: Router VRRP</p>
<pre>group interface <interface number></pre> <p>Selects a switch IP interface. The default switch IP interface number is 1.</p> <p>Command mode: Router VRRP</p>
<pre>group priority <1-254></pre> <p>Defines the election priority bias for this virtual router group. This can be any integer between 1 and 254. The default value is 100.</p> <p>During the master router election process, the routing device with the highest virtual router priority number wins.</p> <p>Each virtual router group is treated as one entity regardless of how many virtual routers are in the group. When the switch tracks the virtual router group, it measures the resources contained in the group (such as interfaces, VLAN ports, real servers). The priority is updated as a group. Every virtual router in the group has the same priority.</p> <p>The <i>owner</i> parameter does not apply to the virtual router group. The group itself cannot be an owner and therefore the priority is 1-254.</p> <p>Command mode: Router VRRP</p>
<pre>group advertisement <1-255></pre> <p>Defines the time interval between VRRP master advertisements. This can be any integer between 1 and 255 seconds. The default is 1.</p> <p>Command mode: Router VRRP</p>

Table 301. VRRP Virtual Router Group Configuration Commands (continued)

Command Syntax and Usage	
[no] group <code>preemption</code>	<p>Enables or disables master pre-emption. When enabled, if the virtual router group is in backup mode but has a higher priority than the current master, this virtual router will pre-empt the lower priority master and assume control. Note that even when <code>preemption</code> is disabled, this virtual router will always pre-empt any other master if this switch is the owner (the IP interface address and virtual router address are the same). By default, this option is enabled.</p> <p>Command mode: Router VRRP</p>
group <code>enable</code>	<p>Enables the virtual router group.</p> <p>Command mode: Router VRRP</p>
no group <code>enable</code>	<p>Disables the virtual router group.</p> <p>Command mode: Router VRRP</p>
no group	<p>Deletes the virtual router group from the switch configuration.</p> <p>Command mode: Router VRRP</p>
show ip vrrp group	<p>Displays the current configuration information for the virtual router group.</p> <p>Command mode: All</p>

Virtual Router Group Priority Tracking Configuration

Note: If *Virtual Router Group Tracking* is enabled, the tracking option will be available only under *group* option. The tracking setting for the other individual virtual routers will be ignored.

Table 302. *Virtual Router Group Priority Tracking Configuration Commands*

Command Syntax and Usage
<pre>[no] group track interfaces</pre> <p>When enabled, the priority for this virtual router will be increased for each other IP interface active on this switch. An IP interface is considered active when there is at least one active port on the same VLAN. This helps elect the virtual routers with the most available routes as the master. This command is disabled by default.</p> <p>Command mode: Router VRRP</p>
<pre>[no] group track ports</pre> <p>When enabled, the priority for this virtual router will be increased for each active port on the same VLAN. A port is considered “active” if it has a link and is forwarding traffic. This helps elect the virtual routers with the most available ports as the master. This command is disabled by default.</p> <p>Command mode: Router VRRP</p>
<pre>show ip vrrp group track</pre> <p>Displays the current configuration for priority tracking for this virtual router.</p> <p>Command mode: All</p>

VRRP Interface Configuration

Note: The *interface* represents the IP interface on which authentication parameters must be configured.

These commands are used for configuring VRRP authentication parameters for the IP interfaces used with the virtual routers.

Table 303. VRRP Interface Commands

Command Syntax and Usage
<pre>interface <interface number> authentication {password none}</pre> <p>Defines the type of authentication that will be used: <i>none</i> (no authentication) or <i>password</i> (password authentication).</p> <p>Command mode: Router VRRP</p>
<pre>[no] interface <interface number> password <password></pre> <p>Defines a plain text password up to eight characters long. This password will be added to each VRRP packet transmitted by this interface when password authentication is chosen (see <i>interface authentication</i> above).</p> <p>Command mode: Router VRRP</p>
<pre>no interface <interface number></pre> <p>Clears the authentication configuration parameters for this IP interface. The IP interface itself is not deleted.</p> <p>Command mode: Router VRRP</p>
<pre>show ip vrrp interface <interface number></pre> <p>Displays the current configuration for this IP interface's authentication parameters.</p> <p>Command mode: All</p>

VRRP Tracking Configuration

These commands are used for setting weights for the various criteria used to modify priority levels during the master router election process. Each time one of the tracking criteria is met (see “VRRP Virtual Router Priority Tracking Commands” on [page 427](#)), the priority level for the virtual router is increased by a defined amount.

Table 304. VRRP Tracking Configuration Commands

Command Syntax and Usage
<pre>tracking-priority-increment virtual-routers <0-254></pre> <p>Defines the priority increment value (0 through 254) for virtual routers in master mode detected on this switch. The default value is 2.</p> <p>Command mode: Router VRRP</p>
<pre>tracking-priority-increment interfaces <0-254></pre> <p>Defines the priority increment value for active IP interfaces detected on this switch. The default value is 2.</p> <p>Command mode: Router VRRP</p>
<pre>tracking-priority-increment ports <0-254></pre> <p>Defines the priority increment value for active ports on the virtual router's VLAN. The default value is 2.</p> <p>Command mode: Router VRRP</p>
<pre>show ip vrrp tracking-priority-increment</pre> <p>Displays the current configuration of priority tracking increment values.</p> <p>Command mode: All</p>

Note: These priority tracking options only define increment values. These options do not affect the VRRP master router election process until options under the VRRP Virtual Router Priority Tracking Commands (see [page 427](#)) are enabled.

Protocol Independent Multicast Configuration

Table 305. PIM Configuration Options

Command Syntax and Usage
<pre>ip pim component <I-2></pre> <p>Enter PIM component mode. See page 433 to view options. Command mode: Global configuration</p>
<pre>ip pim regstop-ratelimit-period <0-2147483647></pre> <p>Configures the register stop rate limit, in seconds. The default value is 5. Command mode: Global configuration</p>
<pre>[no] ip pim static-rp enable</pre> <p>Enables or disables static RP configuration. The default setting is disabled. Command mode: Global configuration</p>
<pre>[no] ip pim pmbr enable</pre> <p>Enables or disables PIM border router. The default setting is disabled. Command mode: Global configuration</p>
<pre>ip pim enable</pre> <p>Globally turns PIM on. Command mode: Global configuration</p>
<pre>no ip pim enable</pre> <p>Globally turns PIM off. Command mode: Global configuration</p>
<pre>clear ip pim mroute</pre> <p>Clears PIM multicast router entries. Command mode: Global configuration</p>

PIM Component Configuration

Table 306. PIM Component Configuration Options

Command Syntax and Usage
<pre>ip pim component <I-2></pre> <p>Enter PIM component mode. Command mode: Global configuration</p>
<pre>mode {dense sparse}</pre> <p>Configures the operational mode of the PIM router (dense or sparse). Command mode: PIM Component</p>
<pre>show ip pim component [<I-2>]</pre> <p>Displays the current PIM component configuration settings. Command mode: All</p>

RP Candidate Configuration

Use these commands to configure a PIM router Rendezvous Point (RP) candidate.

Table 307. RP Candidate Configuration Options

Command Syntax and Usage
<pre>rp-candidate rp-address <group multicast address> <group subnet mask> <IP address></pre> <p>Adds an RP candidate.</p> <p>Command mode: PIM Component</p>
<pre>no rp-candidate rp-address <group multicast address> <group subnet mask> <IP address></pre> <p>Removes the specified RP candidate.</p> <p>Command mode: PIM Component</p>
<pre>rp-candidate holdtime <0-255></pre> <p>Configures the hold time of the RP candidate, in seconds.</p> <p>Command mode: PIM Component</p>

RP Static Configuration

Use these commands to configure a static PIM router Rendezvous Point (RP).

Table 308. RP Static Configuration Options

Command Syntax and Usage
<pre>rp-static rp-address <group multicast address> <group subnet mask> <IP address></pre> <p>Adds a static RP.</p> <p>Command mode: PIM Component</p>
<pre>no rp-static rp-address <group multicast address> <group subnet mask> <IP address></pre> <p>Removes the specified static RP.</p> <p>Command mode: PIM Component</p>

PIM Interface Configuration

Table 309. PIM Interface Configuration Options

Command Syntax and Usage	
interface ip <interface number>	Enter Interface IP mode. Command mode: Global Configuration
ip pim hello-interval <0-65535>	Configures the time interval, in seconds, between PIM Hello packets. The default value is 30. Command mode: Interface IP
ip pim join-prune-interval <0-65535>	Configures the interval between Join Prune messages, in seconds. The default value is 60. Command mode: Interface IP
[no] ip pim cbsr-preference <0-255>	Configures the candidate bootstrap router preference. Command mode: Interface IP
ip pim component-id <1-2>	Defines the component ID for the interface. Command mode: Interface IP
ip pim hello-holdtime <1-65535>	Configures the time period for which a neighbor is to consider this switch to be operative (up). The default value is 105. Command mode: Interface IP
ip pim dr-priority <0-4294967294>	Configures the designated router priority. The default value is 1. Command mode: Interface IP
ip pim override-interval <0-65535>	Configures the override interval for the router interface, in seconds. Command mode: Interface IP
ip pim lan-delay <0-32767>	Configures the LAN delay value for the router interface, in seconds. Command mode: Interface IP
[no] ip pim border-bit	Enables or disables the interface as a border router. The default setting is disabled. Command mode: Interface IP

Table 309. PIM Interface Configuration Options (continued)

Command Syntax and Usage	
[no] ip pim lan-prune-delay	<p>Enables or disables LAN delay advertisements on the interface. The default setting is disabled.</p> <p>Command mode: Interface IP</p>
ip pim neighbor-addr <IP address> allow deny	<p>Allows or denies PIM access to the specified neighbor. You can configure a list of up to 72 neighbors that bypass the neighbor filter. Once you configure the interface to allow a neighbor, you can configure the interface to deny the neighbor.</p> <p>Command mode: Interface IP</p>
[no] ip pim neighbor-filter	<p>Enables or disables the PIM neighbor filter on the interface. When enabled, this interface does not accept any PIM neighbors, unless specifically permitted using the following command:</p> <p>ip pim neighbor-addr <IP address></p> <p>Command mode: Interface IP</p>
ip pim enable	<p>Enables PIM on the interface.</p> <p>Command mode: Interface IP</p>
no ip pim enable	<p>Disables PIM on the interface.</p> <p>Command mode: Interface IP</p>
show ip pim neighbor-filters	<p>Displays the configured PIM neighbor filters.</p> <p>Command mode: All</p>
show ip pim interface [<interface number> detail]	<p>Displays the current PIM interface parameters.</p> <p>Command mode: All</p>

IPv6 Default Gateway Configuration

The switch supports IPv6 default gateways.

- Gateway 1 is used for data traffic.
- Gateway 132 is reserved for management.

[Table 310](#) describes the IPv6 Default Gateway Configuration commands.

Table 310. IPv6 Default Gateway Configuration Commands

Command Syntax and Usage
<pre>ip gateway6 {<gateway number>} address <IPv6 address></pre> <p>Configures the IPv6 address of the default gateway, in hexadecimal format with colons (such as 3001:0:0:0:0:abcd:12).</p> <p>Command mode: Global configuration</p>
<pre>[no] ip gateway6 {<gateway number>} enable</pre> <p>Enables or disables the default gateway.</p> <p>Command mode: Global configuration</p>
<pre>no ip gateway6 {<gateway number>}</pre> <p>Deletes the default gateway.</p> <p>Command mode: Global configuration</p>
<pre>show ipv6 gateway6 {<gateway number>}</pre> <p>Displays the current IPv6 default gateway configuration.</p> <p>Command mode: All</p>

IPv6 Static Route Configuration

Table 311 describes the IPv6 static route configuration commands.

Table 311. IPv6 Static Route Configuration Commands

Command Syntax and Usage
<pre>ip route6 <IPv6 address> <prefix length> <IPv6 gateway address> [<interface number>]</pre> <p>Adds an IPv6 static route.</p> <p>Command mode: Global configuration</p>
<pre>no ip route6 <IPv6 address> <prefix length></pre> <p>Removes the selected route.</p> <p>Command mode: Global configuration</p>
<pre>no ip route6 [destination-address <IPv6 address> gateway <default gateway address> interface <I-128> all]</pre> <p>Clears IPv6 static routes. You are prompted to select the routes to clear, based on the following criteria:</p> <ul style="list-style-type: none"> – dest: Destination IPv6 address of the route – gw: Default gateway address used by the route – if: Interface used by the route – all: All IPv6 static routes <p>Command mode: Global configuration</p>
<pre>show ipv6 route static</pre> <p>Displays the current static route configuration.</p> <p>Command mode: All</p>

IPv6 Neighbor Discovery Cache Configuration

Table 312 describes the IPv6 Neighbor Discovery cache configuration commands.

Table 312. IPv6 Neighbor Discovery Cache Configuration Commands

Command Syntax and Usage
<pre>ip neighbors <IPv6 address> <MAC address> vlan <VLAN number> port <port number or alias></pre> <p>Adds a static entry to the Neighbor Discovery cache table.</p> <p>Command mode: Global configuration</p>
<pre>no ip neighbors {<IPv6 address> all}</pre> <p>Deletes the selected entry from the static Neighbor Discovery cache table.</p> <p>Command mode: Global configuration</p>
<pre>no ip neighbors [all if all interface port all vlan <VLAN number> all]</pre> <p>Clears the selected static entries in the Neighbor Discovery cache table.</p> <p>Command mode: Global configuration</p>

IPv6 Path MTU Configuration

The following table describes the configuration options for Path MTU (Maximum Transmission Unit). The Path MTU cache can consume system memory and affect performance. These commands allow you to manage the Path MTU cache.

Table 313. IPv6 Path MTU Commands

Command Syntax and Usage
<pre>ip pmtu6 timeout 0 <10-100></pre> <p>Sets the timeout value for Path MTU cache entries, in minutes. Enter 0 (zero) to set the timeout to infinity (no timeout). The default value is 10 minutes. Command mode: Global configuration</p>
<pre>clear ipv6 pmtu</pre> <p>Clears all entries in the Path MTU cache. Command mode: All Except User EXEC</p>
<pre>show ipv6 pmtu</pre> <p>Displays the current Path MTU configuration. Command mode: All</p>

IPv6 Neighbor Discovery Prefix Configuration

The following table describes the Neighbor Discovery prefix configuration options. These commands allow you to define a list of prefixes to be placed in Prefix Information options in Router Advertisement messages sent from an interface.

Table 314. IPv6 Neighbor Discovery Prefix Commands

Command Syntax and Usage
<pre>interface ip <1-127></pre> <p>Enters Interface IP mode. Command mode: Global configuration</p>
<pre>ipv6 nd prefix {<IPv6 prefix> <prefix length>} [no-advertise]</pre> <p>Adds a Neighbor Discovery prefix to the interface. The default setting is enabled. To disable the prefix and not advertise it in the Prefix Information options in Router Advertisement messages sent from the interface use the <code>no-advertise</code> option. Additional prefix options are listed in this table. Command mode: Interface IP</p>
<pre>no ipv6 nd prefix [<IPv6 prefix> <prefix length>] interface all</pre> <p>Removes the selected Neighbor Discovery prefix(es). If you specify an interface number, all prefixes for the interface are removed. Command mode: Interface IP</p>

Table 314. IPv6 Neighbor Discovery Prefix Commands (continued)

Command Syntax and Usage	
<pre> ipv6 nd prefix {<IPv6 prefix> <prefix length>} valid-lifetime <0-4294967295> [infinite variable] preferred-lifetime <0-4294967295> [infinite variable] </pre>	<p>Configures the Valid Lifetime and (optionally) the Preferred Lifetime of the prefix, in seconds.</p> <p>The Valid Lifetime is the length of time (relative to the time the packet is sent) that the prefix is valid for the purpose of on-link determination. The default value is 2592000.</p> <p>The Preferred Lifetime is the length of time (relative to the time the packet is sent) that addresses generated from the prefix via stateless address autoconfiguration remain preferred. The default value is 604800.</p> <p>Note: The Preferred Lifetime value must not exceed the Valid Lifetime value.</p> <p>Command mode: Interface IP</p>
<pre> ipv6 nd prefix {<IPv6 prefix> <prefix length>} off-link [no-autoconfig] </pre>	<p>Disables the on-link flag. When enabled, the on-link flag indicates that this prefix can be used for on-link determination. When disabled, the advertisement makes no statement about on-link or off-link properties of the prefix. The default setting is enabled.</p> <p>To clear the off-link flag, omit the off-link parameter when you issue this command.</p> <p>Command mode: Interface IP</p>
<pre> ipv6 nd prefix {<IPv6 prefix> <prefix length>} no-autoconfig </pre>	<p>Disables the autonomous flag. When enabled, the autonomous flag indicates that the prefix can be used for stateless address configuration. The default setting is enabled.</p> <p>Command mode: Interface IP</p>
<pre> show ipv6 prefix {<interface number>} </pre>	<p>Displays current Neighbor Discovery prefix parameters.</p> <p>Command mode: All</p>

IPv6 Prefix Policy Table Configuration

The following table describes the configuration options for the IPv6 Prefix Policy Table. The Prefix Policy Table allows you to override the default address selection criteria.

Table 315. IPv6 Prefix Policy Table Options

Command Syntax and Usage
<pre>ip prefix-policy <IPv6 prefix> <prefix length> <precedence (0-100)> <label (0-100)></pre> <p>Adds a Prefix Policy Table entry. Enter the following parameters:</p> <ul style="list-style-type: none"> – IPv6 address prefix – Prefix length – Precedence: The precedence is used to sort destination addresses. Prefixes with a higher precedence are sorted before those with a lower precedence. – Label: The label allows you to select prefixes based on matching labels. Source prefixes are coupled with destination prefixes if their labels match. <p>Command mode: Global configuration</p>
<pre>no ip prefix-policy <IPv6 prefix> <prefix length> <precedence (0-100)> <label (0-100)></pre> <p>Removes a prefix policy table entry.</p> <p>Command mode: Global configuration</p>
<pre>show ip prefix-policy</pre> <p>Displays the current Prefix Policy Table configuration.</p> <p>Command mode: All</p>

Open Shortest Path First Version 3 Configuration

Table 316. OSPFv3 Configuration Commands

Command Syntax and Usage
<pre>[no] ipv6 router ospf</pre> <p>Enter OSPFv3 configuration mode. Enables or disables OSPFv3 routing protocol.</p> <p>Command mode: Global configuration</p>
<pre>abr-type [standard cisco ibm]</pre> <p>Configures the Area Border Router (ABR) type, as follows:</p> <ul style="list-style-type: none"> – Standard – Cisco – IBM <p>The default setting is <code>standard</code>.</p> <p>Command mode: Router OSPF3</p>

Table 316. OSPFv3 Configuration Commands (continued)

Command Syntax and Usage
<p><code>as-external lsdB-limit <LSDB limit (0-2147483647, -1 for no limit)></code></p> <p>Sets the link state database limit.</p> <p>Command mode: Router OSPF3</p>
<p><code>exit-overflow-interval <0-4294967295></code></p> <p>Configures the number of seconds that a router takes to exit Overflow State. The default value is 0 (zero).</p> <p>Command mode: Router OSPF3</p>
<p><code>neighbor <1-256> {address <IPv6 address> enable interface <1-126> priority <0-255>}</code></p> <p>Configures directly reachable routers over non-broadcast networks. This is required for non-broadcast multiple access (NBMA) networks and optional for Point-to-Multipoint networks.</p> <ul style="list-style-type: none"> – <code>address</code> configures the neighbor's IPv6 address – <code>enable</code> activates a previously disabled neighbor – <code>interface</code> configures the OSPFv3 interface used for the neighbor entry – <code>priority</code> configures the priority value used for the neighbor entry. A priority value of 255 is the highest and 1 is the lowest. A priority value of 0 specifies that the neighbor cannot be used as Designated Router. The default value is 1. <p>Command mode: Router OSPF3</p>
<p><code>no neighbor <1-256> [enable]</code></p> <p>Deletes the neighbor entry.</p> <p>Using the <code>enable</code> option only disables the neighbor, while preserving its settings.</p> <p>Command mode: Router OSPF3</p>
<p><code>reference-bandwidth <0-4294967295></code></p> <p>Configures the reference bandwidth, in kilobits per second, used to calculate the default interface metric. The default value is 100,000.</p> <p>Command mode: Router OSPF3</p>
<p><code>timers spf {<SPF delay (0-65535)>} {<SPF hold time (0-65535)>}</code></p> <p>Configures the number of seconds that SPF calculation is delayed after a topology change message is received. The default value is 5.</p> <p>Configures the number of seconds between SPF calculations. The default value is 10.</p> <p>Command mode: Router OSPF3</p>
<p><code>router-id <IPv4 address></code></p> <p>Defines the router ID.</p> <p>Command mode: Router OSPF3</p>

Table 316. OSPFv3 Configuration Commands (continued)

Command Syntax and Usage	
[no] nssaAsbrDfRtTrans	<p>Enables or disables setting of the P-bit in the default Type 7 LSA generated by an NSSA internal ASBR. The default setting is disabled.</p> <p>Command mode: Router OSPF3</p>
enable	<p>Enables OSPFv3 on the switch.</p> <p>Command mode: Router OSPF3</p>
no enable	<p>Disables OSPFv3 on the switch.</p> <p>Command mode: Router OSPF3</p>
show ipv6 ospf	<p>Displays the current OSPF configuration settings.</p> <p>Command mode: All</p>

OSPFv3 Area Index Configuration

Table 317. OSPFv3 Area Index Configuration Options

Command Syntax and Usage	
area <area index> area-id <IP address>	<p>Defines the IP address of the OSPFv3 area number.</p> <p>Command mode: Router OSPF3</p>
area <area index> type {transit stub nssa} {no-summary}	<p>Defines the type of area. For example, when a virtual link has to be established with the backbone, the area type must be defined as transit.</p> <p>Transit area: allows area summary information to be exchanged between routing devices. Any area that is not a stub area or NSSA is considered to be transit area.</p> <p>Stub area: is an area where external routing information is not distributed. Typically, a stub area is connected to only one other area.</p> <p>NSSA: Not-So-Stubby Area (NSSA) is similar to stub area with additional capabilities. For example, routes originating from within the NSSA can be propagated to adjacent transit and backbone areas. External routes from outside the Autonomous System (AS) can be advertised within the NSSA but are not distributed into other areas.</p> <p>Enables or disables the no-summary option. When enabled, the area-border router neither originates nor propagates Inter-Area-Prefix LSAs into stub/NSSA areas. Instead it generates a default Inter-Area-Prefix LSA.</p> <p>The default setting is disabled.</p> <p>Command mode: Router OSPF3</p>

Table 317. OSPFv3 Area Index Configuration Options (continued)

Command Syntax and Usage	
<pre>area <area index> default-metric <metric value (1-16777215)></pre>	<p>Configures the cost for the default summary route in a stub area or NSSA.</p> <p>Command mode: Router OSPF3</p>
<pre>area <area index> default-metric type <1-3></pre>	<p>Configures the default metric type applied to the route.</p> <p>This command applies only to area type of Stub/NSSA.</p> <p>Command mode: Router OSPF3</p>
<pre>area <area index> stability-interval <1-255></pre>	<p>Configures the stability interval for an NSSA, in seconds. When the interval expires, an elected translator determines that its services are no longer required. The default value is 40.</p> <p>Command mode: Router OSPF3</p>
<pre>area <area index> translation-role always candidate</pre>	<p>Configures the translation role for an NSSA area, as follows:</p> <ul style="list-style-type: none"> – Always: Type 7 LSAs are always translated into Type 5 LSAs. – Candidate: An NSSA border router participates in the translator election process. <p>The default setting is candidate.</p> <p>Command mode: Router OSPF3</p>
<pre>area <area index> enable</pre>	<p>Enables the OSPF area.</p> <p>Command mode: Router OSPF3</p>
<pre>area <area index> no enable</pre>	<p>Disables the OSPF area.</p> <p>Command mode: Router OSPF3</p>
<pre>no area <area index></pre>	<p>Deletes the OSPF area.</p> <p>Command mode: Router OSPF3</p>
<pre>show ipv6 ospf areas</pre>	<p>Displays the current OSPFv3 area configuration.</p> <p>Command mode: All</p>

OSPFv3 Summary Range Configuration

Table 318. OSPFv3 Summary Range Configuration Options

Command Syntax and Usage	
area-range <1-16> address <IPv6 address> <prefix length (1-128)>	Configures the base IPv6 address and subnet prefix length for the range. Command mode: Router OSPF3
area-range <1-16> area <area index (0-2)>	Configures the area index used by the switch. Command mode: Router OSPF3
area-range <1-16> lsa-type summary Type7	Configures the LSA type, as follows: – Summary LSA – Type7 LSA Command mode: Router OSPF3
area-range <1-16> tag <0-4294967295>	Configures the route tag. Command mode: Router OSPF3
[no] area-range <1-16> hide	Hides the OSPFv3 summary range. Command mode: Router OSPF3
area-range <1-16> enable	Enables the OSPFv3 summary range. Command mode: Router OSPF3
area-range <1-16> no enable	Disables the OSPFv3 summary range. Command mode: Router OSPF3
no area-range <1-16>	Deletes the OSPFv3 summary range. Command mode: Router OSPF3
show ipv6 ospf area-range	Displays the current OSPFv3 summary range. Command mode: All

OSPFv3 AS-External Range Configuration

Table 319. OSPFv3 AS-External Range Configuration Options

Command Syntax and Usage
<pre>summary-prefix <1-16> address <IPv6 address> <IPv6 prefix length (1-128)></pre> <p>Configures the base IPv6 address and the subnet prefix length for the range. Command mode: Router OSPF3</p>
<pre>summary-prefix <1-16> area <area index (0-2)></pre> <p>Configures the area index used by the switch. Command mode: Router OSPF3</p>
<pre>summary-prefix <1-16> aggregation-effect {allowAll denyAll advertise not-advertise}</pre> <p>Configures the aggregation effect, as follows:</p> <ul style="list-style-type: none"> – allowAll: If the area ID is 0.0.0.0, aggregated Type-5 LSAs are generated. Aggregated Type-7 LSAs are generated in all the attached NSSAs for the range. – denyAll: Type-5 and Type-7 LSAs are not generated. – advertise: If the area ID is 0.0.0.0, aggregated Type-5 LSAs are generated. For other area IDs, aggregated Type-7 LSAs are generated in the NSSA area. – not-advertise: If the area ID is 0.0.0.0, Type-5 LSAs are not generated, while all NSSA LSAs within the range are cleared and aggregated Type-7 LSAs are generated for all NSSAs. For other area IDs, aggregated Type-7 LSAs are not generated in the NSSA area. <p>Command mode: Router OSPF3</p>
<pre>[no] summary-prefix <1-16> translation</pre> <p>When enabled, the P-bit is set in the generated Type-7 LSA. When disabled, the P-bit is cleared. The default setting is disabled. Command mode: Router OSPF3</p>
<pre>summary-prefix <1-16> enable</pre> <p>Enables the OSPFv3 AS-external range. Command mode: Router OSPF3</p>
<pre>summary-prefix <1-16> no enable</pre> <p>Disables the OSPFv3 AS-external range. Command mode: Router OSPF3</p>
<pre>no summary-prefix <1-16></pre> <p>Deletes the OSPFv3 AS-external range. Command mode: Router OSPF3</p>
<pre>show ipv6 ospf summary-prefix <1-16></pre> <p>Displays the current OSPFv3 AS-external range. Command mode: All</p>

OSPFv3 Interface Configuration

Table 320. OSPFv3 Interface Configuration Options

Command Syntax and Usage
<pre>interface ip <interface number></pre> <p>Enter Interface IP mode, from Global Configuration mode. Command mode: Global configuration</p>
<pre>ipv6 ospf area <area index (0-2)></pre> <p>Configures the OSPFv3 area index. Command mode: Interface IP</p>
<pre>[no] ipsec dynamic-policy <1-10></pre> <p>Adds an IP security dynamic policy to the OSPFv3 interface. Command mode: Interface IP</p>
<pre>ipsec manual-policy <1-10></pre> <p>Adds an IP security manual policy to the OSPFv3 interface. Command mode: Interface IP</p>
<pre>ipv6 ospf area <area index (0-2)> instance <0-255></pre> <p>Configures the instance ID for the interface. Command mode: Interface IP</p>
<pre>[no] ipv6 ospf priority <priority value (0-255)></pre> <p>Configures the priority value for the switch's OSPFv3 interface. A priority value of 255 is the highest and 1 is the lowest. A priority value of 0 specifies that the interface cannot be used as Designated Router (DR). Command mode: Interface IP</p>
<pre>[no] ipv6 ospf cost <1-65535></pre> <p>Configures the metric value for sending a packet on the interface. Command mode: Interface IP</p>
<pre>[no] ipv6 ospf hello-interval <1-65535></pre> <p>Configures the indicated interval, in seconds, between the hello packets, that the router sends on the interface. Command mode: Interface IP</p>
<pre>[no] ipv6 ospf linklsasuppress</pre> <p>Enables or disables Link LSA suppression. When suppressed, no Link LSAs are originated. Default setting is disabled. Command mode: Interface IP</p>

Table 320. OSPFv3 Interface Configuration Options (continued)

Command Syntax and Usage	
<pre>ipv6 ospf network {broadcast non-broadcast point-to-multipoint point-to-point}</pre>	<p>Configures the network type for the OSPFv3 interface:</p> <ul style="list-style-type: none"> – broadcast: network where all routers use the broadcast capability – non-broadcast: non-broadcast multiple access (NBMA) network supporting pseudo-broadcast (multicast and broadcast traffic is configured manually) – point-to-multipoint: network where multiple point-to-point links are set up on the same interface – point-to-point: network that joins a single pair of routers <p>The default value is broadcast.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 ospf poll-interval <0-4294967295></pre>	<p>Configures the poll interval in seconds for neighbors in NBMA networks. Default value is 120.</p> <p>Command mode: Interface IP</p>
<pre>no ipv6 ospf poll-interval</pre>	<p>Configures the poll interval in seconds for neighbors in NBMA and point-to-multipoint networks to its default 120 seconds value.</p> <p>Command mode: Interface IP</p>
<pre>[no] ipv6 ospf dead-interval <1-65535></pre>	<p>Configures the health parameters of a hello packet, in seconds, before declaring a silent router to be down.</p> <p>Command mode: Interface IP</p>
<pre>[no] ipv6 ospf transmit-delay <1-1800></pre>	<p>Configures the estimated time, in seconds, taken to transmit LS update packet over this interface.</p> <p>Command mode: Interface IP</p>
<pre>[no] ipv6 ospf retransmit-interval <1-1800></pre>	<p>Configures the interval in seconds, between LSA retransmissions for adjacencies belonging to interface.</p> <p>Command mode: Interface IP</p>
<pre>[no] ipv6 ospf passive-interface</pre>	<p>Enables or disables the passive setting on the interface. On a passive interface, OSPFv3 protocol packets are suppressed.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 ospf enable</pre>	<p>Enables OSPFv3 on the interface.</p> <p>Command mode: Interface IP</p>

Table 320. OSPFv3 Interface Configuration Options (continued)

Command Syntax and Usage
<pre>ipv6 ospf no enable</pre> <p>Disables OSPFv3 on the interface. Command mode: Interface IP</p>
<pre>no ipv6 ospf</pre> <p>Deletes OSPFv3 from interface. Command mode: Interface IP</p>
<pre>show ipv6 ospf interface</pre> <p>Displays the current settings for OSPFv3 interface. Command mode: Interface IP</p>

OSPFv3 over IPsec Configuration

The following table describes the OSPFv3 over IPsec Configuration commands.

Table 321. Layer 3 IPsec Configuration Options

Command Syntax and Usage
<pre>ipv6 ospf authentication ipsec spi <256-4294967295> {md5 sha1} <authentication key (hexadecimal)></pre> <p>Configures the Security Parameters Index (SPI), algorithm, and authentication key for the Authentication Header (AH). The algorithms supported are:</p> <ul style="list-style-type: none"> – MD5 (hexadecimal key length is 32) – SHA1 (hexadecimal key length is 40) <p>Command mode: Interface IP</p>
<pre>[no] ipv6 ospf authentication ipsec enable</pre> <p>Enables or disables IPsec. Command mode: Interface IP</p>
<pre>no ipv6 ospf authentication ipsec spi <256-4294967295></pre> <p>Disables the specified Authentication Header (AH) SPI. Command mode: Interface IP</p>
<pre>ipv6 ospf authentication ipsec default</pre> <p>Resets the Authentication Header (AH) configuration to default values. Command mode: Interface IP</p>

Table 321. Layer 3 IPsec Configuration Options (continued)

Command Syntax and Usage	
<pre>ipv6 ospf encryption ipsec spi <256-4294967295> esp {3des aes-cbc des null} <encryption key (hexadecimal)>[null] {md5 sha1 none} <authentication key (hexadecimal)></pre>	<p>Configures the Security Parameters Index (SPI), encryption algorithm, authentication algorithm, and authentication key for the Encapsulating Security Payload (ESP). The ESP algorithms supported are:</p> <ul style="list-style-type: none"> – 3DES (hexadecimal key length is 48) – AES-CBC (hexadecimal key length is 32) – DES (hexadecimal key length is 16) <p>The authentication algorithms supported are:</p> <ul style="list-style-type: none"> – MD5 (hexadecimal key length is 32) – SHA1 (hexadecimal key length is 40) – none <p>Note: If the encryption algorithm is null, the authentication algorithm must be either MD5 or SHA1. (hexadecimal key length is 40). If an encryption algorithm is specified (3DES, AES-CBC, or DES), the authentication algorithm can be none.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 ospf encryption ipsec enable</pre>	<p>Enables OSPFv3 encryption for this interface.</p> <p>Command mode: Interface IP</p>
<pre>no ipv6 ospf encryption ipsec spi <256-4294967295></pre>	<p>Disables the specified Encapsulating Security Payload (ESP) SPI.</p> <p>Command mode: Interface IP</p>
<pre>ipv6 ospf encryption ipsec default</pre>	<p>Resets the Encapsulating Security Payload (ESP) configuration to default values.</p> <p>Command mode: Interface IP</p>

OSPFv3 Virtual Link Configuration

Table 322. OSPFv3 Virtual Link Configuration Options

Command Syntax and Usage	
area-virtual-link <1-3> area <area index (0-2)>	Configures the OSPF area index. Command mode: Router OSPF3
area-virtual-link <1-3> hello-interval <1-65535>	Configures the indicated interval, in seconds, between the hello packets, that the router sends on the interface. Command mode: Router OSPF3
area-virtual-link <1-3> dead-interval <1-65535>	Configures the time period, in seconds, for which the router waits for hello packet from the neighbor before declaring this neighbor down. Command mode: Router OSPF3
area-virtual-link <1-3> transmit-delay <1-1800>	Configures the estimated time, in seconds, taken to transmit LS update packet over this interface. Command mode: Router OSPF3
area-virtual-link <1-3> retransmit-interval <1-1800>	Configures the interval, in seconds, between link-state advertisement (LSA) retransmissions for adjacencies belonging to the OSPFv3 virtual link interface. The default value is five seconds. Command mode: Router OSPF3
area-virtual-link <1-3> neighbor-router <NBR router ID (IP address)>	Configures the router ID of the virtual neighbor. The default setting is 0.0.0.0 Command mode: Router OSPF3
area-virtual-link <1-3> enable	Enables OSPF virtual link. Command mode: Router OSPF3
area-virtual-link <1-3> no enable	Disables OSPF virtual link. Command mode: Router OSPF3
no area-virtual-link <1-3>	Deletes OSPF virtual link. Command mode: Router OSPF3
show ipv6 ospf area-virtual-link	Displays the current OSPFv3 virtual link settings. Command mode: All

OSPFv3 Host Entry Configuration

Table 323. OSPFv3 Host Entry Configuration Options

Command Syntax and Usage
<pre>host <1-128> address <IPv6 address> <prefix length (1-128)></pre> <p>Configures the base IPv6 address and the subnet prefix length for the host entry.</p> <p>Command mode: Router OSPF3</p>
<pre>host <1-128> area <area index (0-2)></pre> <p>Configures the area index of the host.</p> <p>Command mode: Router OSPF3</p>
<pre>host <1-128> cost <1-65535></pre> <p>Configures the cost value of the host.</p> <p>Command mode: Router OSPF3</p>
<pre>host <1-128> enable</pre> <p>Enables the host entry.</p> <p>Command mode: Router OSPF3</p>
<pre>no host <1-128> enable</pre> <p>Disables the host entry.</p> <p>Command mode: Router OSPF3</p>
<pre>no host <1-128></pre> <p>Deletes the host entry.</p> <p>Command mode: Router OSPF3</p>
<pre>show ipv6 ospf host [<1-128>]</pre> <p>Displays the current OSPFv3 host entries.</p> <p>Command mode: All</p>

OSPFv3 Redist Entry Configuration

Table 324. OSPFv3 Redist Entry Configuration Options

Command Syntax and Usage	
<pre>redist-config <1-128> address <IPv6 address> <IPv6 prefix length (1-128)></pre>	<p>Configures the base IPv6 address and the subnet prefix length for the redistribution entry.</p> <p>Command mode: Router OSPF3</p>
<pre>redist-config <1-128> metric-value <1-16777215></pre>	<p>Configures the route metric value applied to the route before it is advertised into the OSPFv3 domain.</p> <p>Command mode: Router OSPF3</p>
<pre>redist-config <1-128> metric-type asExtttype1 asExtttype2</pre>	<p>Configures the metric type applied to the route before it is advertised into the OSPFv3 domain.</p> <p>Command mode: Router OSPF3</p>
<pre>[no] redist-config <1-128> tag <0-4294967295></pre>	<p>Configures the route tag.</p> <p>Command mode: Router OSPF3</p>
<pre>redist-config <1-128> enable</pre>	<p>Enables the OSPFv3 redistribution entry.</p> <p>Command mode: Router OSPF3</p>
<pre>no redist-config <1-128> enable</pre>	<p>Disables the OSPFv3 redistribution entry.</p> <p>Command mode: Router OSPF3</p>
<pre>no redist-config <1-128></pre>	<p>Deletes the OSPFv3 redistribution entry.</p> <p>Command mode: Router OSPF3</p>
<pre>show ipv6 ospf redist-config</pre>	<p>Displays the current OSPFv3 redistribution configuration entries.</p> <p>Command mode: Router OSPF3</p>

OSPFv3 Redistribute Configuration

Table 325. OSPFv3 Redistribute Configuration Options

Command Syntax and Usage
<pre>[no] redistribute {connected static} export <metric value (1-16777215)> <metric type (1-2)> <tag (0-4294967295)></pre> <p>Exports the routes of this protocol as external OSPFv3 AS-external LSAs in which the metric, metric type, and route tag are specified. To remove a previous configuration and stop exporting the routes of the protocol, use the <code>no</code> form of the command.</p> <p>Command mode: Router OSPF3</p>
<pre>show ipv6 ospf</pre> <p>Displays the current OSPFv3 route redistribution settings.</p> <p>Command mode: All</p>

IP Loopback Interface Configuration

An IP loopback interface is not connected to any physical port. A loopback interface is always accessible over the network.

Table 326. IP Loopback Interface Commands

Command Syntax and Usage	
<code>interface loopback <1-5></code>	Enter Interface Loopback mode. Command mode: Global configuration
<code>no interface loopback <1-5></code>	Deletes the selected loopback interface. Command mode: Global configuration
<code>ip address <IP address></code>	Defines the loopback interface IP address. Command mode: Interface loopback
<code>ip netmask <subnet mask></code>	Defines the loopback interface subnet mask. Command mode: Interface loopback
<code>ip ospf area <area number></code>	Configures the OSPF area index used by the loopback interface. Command mode: Interface loopback
<code>[no] ip ospf enable</code>	Enables or disables OSPF for the loopback interface. Command mode: Interface loopback
<code>enable</code>	Enables the loopback interface. Command mode: Interface loopback
<code>no enable</code>	Disables the loopback interface. Command mode: Interface loopback
<code>show interface loopback <1-5></code>	Displays the current IP loopback interface parameters. Command mode: All

Converged Enhanced Ethernet Configuration

Table 327 describes the Converged Enhanced Ethernet (CEE) configuration commands.

Table 327. CEE Commands

Command Syntax and Usage
<code>cee enable</code> Globally turns CEE on. Command mode: Global configuration
<code>no cee enable</code> Globally turns CEE off. Command mode: Global configuration
<code>cee iscsi enable</code> Enables or disables ISCSI TLV advertisements. Command mode: Global configuration
<code>show cee iscsi</code> Displays the current ISCSI TLV parameters. Command mode: All
<code>show cee</code> Displays the current CEE parameters. Command mode: All

ETS Global Configuration

Enhanced Transmission Selection (ETS) allows you to allocate bandwidth to different traffic types, based on 802.1p priority.

Note: ETS configuration supersedes the QoS 802.1p menu. When ETS is enabled, you cannot configure the 802.1p menu options.

ETS Global Priority Group Configuration

[Table 328](#) describes the global ETS Priority Group configuration options.

Table 328. Global ETS Priority Group Commands

Command Syntax and Usage
<pre>cee global ets priority-group pgid <0-7, 15> bandwidth <802.1p priority (0-7)> <bandwidth percentage (0, 10-100)></pre> <p>Allows you to configure Priority Group parameters. You can enter the link bandwidth percentage allocated to the Priority Group, and also assign one or more 802.1p values to the Priority Group.</p> <p>Command mode: Global configuration</p>
<pre>cee global ets priority-group pgid <0-7, 15> description <1-31 characters></pre> <p>Enter text that describes this Priority Group.</p> <p>Command mode: Global configuration</p>
<pre>no cee global ets priority-group <0-7, 15> description</pre> <p>Removes the description for the specified Priority Group.</p> <p>Command mode: Global configuration</p>
<pre>[no] cee global ets mcast-priority-group mcpgid <0-3> [bandwidth percentage <0, 10-100>] [priority <0-7>]</pre> <p>Configures Multicast Priority Group parameters. You can enter the link bandwidth percentage allocated to the Multicast Priority Group, and assign one or more 802.1p values to the Multicast Priority Group.</p> <p>Command mode: Global configuration</p>
<pre>cee global ets mcast-priority-group mcpgid <0-3> description <1-31 characters></pre> <p>Enter text that describes the multicast priority group.</p> <p>Command mode: Global configuration</p>
<pre>no cee global ets mcast-priority-group mcpgid <0-3> description</pre> <p>Removes the description for the specified multicast priority group.</p> <p>Command mode: Global configuration</p>
<pre>cee global ets priority-group pgid <0-7, 15> priority <0-7></pre> <p>Adds one or more 802.1p priority values to the Priority Group. Enter one value per line, null to end.</p> <p>Command mode: Global configuration</p>

Table 328. Global ETS Priority Group Commands

Command Syntax and Usage
<pre>show cee global ets priority-group <0-7, 15></pre> <p>Displays the current global ETS Priority Group parameters. Command mode: All</p>
<pre>show cee global ets</pre> <p>Displays the current global ETS Priority Group parameters. Command mode: All</p>
<pre>show cee global ets mcast-priority-group <0-3></pre> <p>Displays the current global ETS Multicast Priority Group parameters. Command mode: All</p>

Priority Flow Control Configuration

Priority-based Flow Control (PFC) enhances flow control by allowing the switch to pause traffic based on its 802.1p priority value, while allowing traffic at other priority levels to continue.

Port-level 802.1p PFC Configuration

Table 329 describes the 802.1p Priority Flow Control (PFC) configuration options for the selected port.

Table 329. Port 802.1p PFC Options

Command Syntax and Usage
<pre>cee port <port alias or number> pfc enable</pre> <p>Enables Priority Flow Control on the selected port. Command mode: Global configuration</p>
<pre>no cee port <port alias or number> pfc enable</pre> <p>Disables Priority Flow Control on the selected port. Command mode: Global configuration</p>
<pre>cee port <port alias or number> pfc priority <0-7> enable</pre> <p>Enables Priority Flow Control on the selected 802.1p priority. Note: PFC can be enabled on 802.1p priority 3 and one other priority only. Command mode: Global configuration</p>
<pre>no cee port <port alias or number> pfc priority <0-7> enable</pre> <p>Disables Priority Flow Control on the selected 802.1p priority. Command mode: Global configuration</p>
<pre>[no] cee port <port alias or number> pfc priority <0-7> description <1-31 characters></pre> <p>Enter text to describe the priority value. Command mode: Global configuration</p>

Table 329. Port 802.1p PFC Options (continued)

Command Syntax and Usage
<pre>show cee port <port alias or number> pfc priority <0-7></pre> <p>Displays the current 802.1p PFC parameters for the selected port.</p> <p>Command mode: All</p>
<pre>show cee port <port alias or number> pfc</pre> <p>Displays the current PFC parameters for the selected port.</p> <p>Command mode: All</p>

DCBX Port Configuration

Table 330 describes the port DCB Capability Exchange Protocol (DCBX) configuration options.

Table 330. Port DCBX Commands

Command Syntax and Usage
<pre>[no] cee port <port alias or number> dcbx app_proto advertise</pre> <p>Enables or disables DCBX Application Protocol advertisements of configuration data. When enabled, the Advertisement flag is set to 1 (advertise data to the peer device).</p> <p>Command mode: Global configuration</p>
<pre>[no] cee port <port alias or number> dcbx app_proto willing</pre> <p>Enables or disables Application Protocol willingness to accept configuration data from the peer device. When enabled, the Willing flag is set to 1 (willing to accept data).</p> <p>Command mode: Global configuration</p>
<pre>[no] cee port <port alias or number> dcbx ets advertise</pre> <p>Enables or disables DCBX ETS advertisements of configuration data. When enabled, the Advertisement flag is set to 1 (advertise data to the peer device).</p> <p>Command mode: Global configuration</p>
<pre>[no] cee port <port alias or number> dcbx ets willing</pre> <p>Enables or disables ETS willingness to accept configuration data from the peer device. When enabled, the Willing flag is set to 1 (willing to accept data).</p> <p>Command mode: Global configuration</p>
<pre>[no] cee port <port alias or number> dcbx pfc advertise</pre> <p>Enables or disables DCBX PFC advertisements of configuration data. When enabled, the Advertisement flag is set to 1 (advertise data to the peer device).</p> <p>Command mode: Global configuration</p>
<pre>[no] cee port <port alias or number> dcbx pfc willing</pre> <p>Enables or disables PFC willingness to accept configuration data from the peer device. When enabled, the Willing flag is set to 1 (willing to accept data).</p> <p>Command mode: Global configuration</p>

Table 330. Port DCBX Commands (continued)

Command Syntax and Usage
<pre>no cee port <port alias or number> dcbx enable</pre> <p>Disables DCBX on the port.</p> <p>Command mode: Global configuration</p>
<pre>cee port <port alias or number> dcbx enable</pre> <p>Enables DCBX on the port.</p> <p>Command mode: Global configuration</p>
<pre>show cee port <port alias or number> dcbx</pre> <p>Displays the current port DCBX parameters.</p> <p>Command mode: All</p>

Fibre Channel Configuration

As a converged switch, the CN4093 provides combined support for Ethernet and Fibre Channel (FC) networks. Ports EXT11-EXT16 are hybrid, allowing them to operate in either Ethernet mode (the default), or in Fibre Channel mode for direct connection to Fibre Channel devices.

The CN4093 can be used in the following Fibre Channel applications:

- As an FCoE gateway for bridging FCoE and Fibre Channel networks
- As a Node Port Virtualized (NPV) Gateway for uplinking multiple Fibre Channel nodes to a full fabric switch
- As a Full-Fabric Switch — a central element of a Fibre Channel network

[Table 336](#) describes generic Fibre Channel configuration options.

Table 331. Fibre Channel Configuration Commands

Command Syntax and Usage
<pre>[no] system port <low port>-<high port> type fc</pre> <p>Enables or disables Fibre Channel mode on the specified port range. Fibre Channel can be enabled only for port pairs, specifically for: EXT11-EXT12, EXT13-EXT14 and EXT15-EXT16. Default setting is disabled (ports are in Ethernet mode).</p> <p>Note: VLAN tagging is automatically enabled on any ports placed in Fibre Channel mode.</p> <p>Command mode: Global configuration</p>
<pre>[no] fcalias <1-64 characters> wwn <port World Wide Name> <VLAN number></pre> <p>Configures or removes an FC alias name for the specified port World Wide Name.</p> <p>Command mode: Global configuration</p>

Table 331. Fibre Channel Configuration Commands (continued)

Command Syntax and Usage
<pre>fcdomain domain <0-239> {preferred static} <VLAN number></pre> <p>Configures the domain type for the specified FC domain ID:</p> <ul style="list-style-type: none"> – <u>preferred</u> allows the domain ID to be re-assigned. If the switch does not get its requested domain ID, it accepts any assigned domain ID. – <u>static</u> does not allow the domain ID to be re-assigned. If the switch does not get that domain ID, it does not join the fabric. <p>Default setting is preferred.</p> <p>Command mode: Global configuration</p>
<pre>clear zone database <VLAN number></pre> <p>Erases all FC zones and zonesets.</p> <p>Command mode: Global configuration</p>

FC Port Configuration

Use the following commands to configure Fibre Channel ports.

Table 332. Fibre Channel Port Configuration Commands

Command Syntax and Usage
<pre>interface fc <FC port alias or number></pre> <p>Enter Fibre Channel port configuration mode.</p> <p>Command mode: Global configuration</p>
<pre>[no] shutdown</pre> <p>Disables or enables the FC port. Default setting is enabled (no shutdown)</p> <p>Command mode: FC Port configuration</p>
<pre>fc-speed {2 4 8 auto}</pre> <p>Configures the Fibre Channel port speed in Gbps or allows the port to negotiate its speed automatically. Default setting is auto.</p> <p>Command mode: FC Port configuration</p>
<pre>[no] type e</pre> <p>Enable the FC port to type E or disable the E port.</p> <p>Command mode: FC Port configuration</p>

FC VLAN Configuration

Use the following commands to configure the Fibre Channel Forwarding VLAN.

Table 333. FCF VLAN Configuration Commands

Command Syntax and Usage
<p><code>vlan <VLAN number></code></p> <p>Enter VLAN configuration mode.</p> <p>Command mode: Global configuration</p>
<p><code>[no] fcf enable</code></p> <p>Enables or disables the VLAN as Fibre Channel Forwarding VLAN. Default setting is disabled.</p> <p>Command mode: VLAN configuration</p>
<p><code>[no] npv enable</code></p> <p>Enables or disables NPV gateway functionality for the VLAN. Default setting is disabled.</p> <p>Command mode: VLAN configuration</p>
<p><code>[no] npv traffic-map external-interface <port no.></code></p> <p>Enables or disables the selected ports as NP (external uplink) ports.</p> <p>Command mode: VLAN configuration</p>
<p><code>fcoe fcmmap <fabric map ID></code></p> <p>Configures the global FC-map that identifies the FC fabric used by the switch. The switch will discard MAC addresses that are not part of the current fabric, which avoids cross-fabric talk.</p> <p>The FC-map is a 24-bit hexadecimal value. The default value is 0x0efc00.</p> <p>Command mode: VLAN configuration</p>
<p><code>no fcoe fcmmap</code></p> <p>Resets the FC-map to the default 0x0efc00 value.</p> <p>Command mode: VLAN configuration</p>
<p><code>fcoe fcf-priority <0-255></code></p> <p>Configures the FCF priority. When an FC initiator sends login requests to multiple FCFs, it selects the one with the highest priority value.</p> <p>The default value is 128.</p> <p>Command mode: VLAN configuration</p>
<p><code>no fcoe fcf-priority</code></p> <p>Resets the FCF priority to the default 128 value.</p> <p>Command mode: VLAN configuration</p>
<p><code>fcoe fka-adv-period <8-90></code></p> <p>Configures the FIP Keep Alive advertising period, in seconds.</p> <p>Command mode: VLAN configuration</p>

FC Zone Configuration

Use the following commands to configure Fibre Channel zones.

Table 334. Fibre Channel Zone Configuration Commands

Command Syntax and Usage
<pre>[no] zone name <1-64 characters> <VLAN number></pre> <p>Enter FC Zone configuration mode for the specified zone. If the zone doesn't exist, it is created. The <code>no</code> form of the command erases the zone.</p> <p>Command mode: Global configuration</p>
<pre>zone clone <selected_zone_name> <new_zone_name> <VLAN number></pre> <p>Creates a new zone with the attributes of the selected zone.</p> <p>Command mode: Global configuration</p>
<pre>zone rename <current_name> <new_name> <VLAN number></pre> <p>Renames the FC zone.</p> <p>Command mode: Global configuration</p>
<pre>[no] zone default-zone permit <VLAN number></pre> <p>Permits or denies traffic flow to default zone members.</p> <p>Command mode: Global configuration</p>
<pre>[no] member {pwwn <pwwn> fcid <ID number> fcalias <alias ID>}</pre> <p>Adds or removes zone members based on:</p> <ul style="list-style-type: none"> – <code>pwwn</code>: Port World Wide Number – <code>fcid</code>: FC ID of the port, in hex format (for example, 0xce00d1). – <code>fcalias</code>: Alias name of the FC device. <p>Command mode: FC Zone configuration</p>

FC Zoneset Configuration

Use the following commands to configure Fibre Channel zonesets.

Table 335. Fibre Channel Zoneset Configuration Commands

Command Syntax and Usage
<pre>[no] zoneset name <1-64 characters> <VLAN number></pre> <p>Enter FC Zoneset configuration mode for the specified zone. If the zoneset doesn't exist, it is created. The <code>no</code> form of the command erases the zoneset.</p> <p>Command mode: Global configuration</p>
<pre>[no] zoneset activate name <1-64 characters> <VLAN number></pre> <p>Activates or deactivates the zoneset. Only one zoneset can be active at any point in time. Activating a zoneset automatically deactivates any other zoneset currently active.</p> <p>Command mode: Global configuration</p>

Table 335. Fibre Channel Zoneset Configuration Commands

Command Syntax and Usage
<p><code>zoneset clone <selected_zoneset_name> <new_zoneset_name> <VLAN number></code> Creates a new zoneset with the attributes of the selected zoneset. Command mode: Global configuration</p>
<p><code>zone copy active-zoneset running-config <VLAN number></code> Copies the active zoneset database to the running configuration. Command mode: Global configuration</p>
<p><code>zoneset rename <current_name> <new_name> <VLAN number></code> Renames the FC zoneset. Command mode: Global configuration</p>
<p><code>[no] member <1-64 characters></code> Adds or removes a zone from the zoneset. Command mode: FC Zoneset configuration</p>

Fibre Channel over Ethernet Configuration

Fibre Channel over Ethernet (FCoE) transports Fibre Channel frames over an Ethernet fabric. The CEE features and FCoE features allow you to create a lossless Ethernet transport mechanism.

[Table 336](#) describes the FCoE configuration options.

Table 336. FCoE Configuration Commands

Command Syntax and Usage
<code>fcoe fips enable</code> Globally turns FIP Snooping on. Command mode: Global configuration
<code>no fcoe fips enable</code> Globally turns FIP Snooping off. Command mode: Global configuration
<code>[no] fcoe fips timeout-acl</code> Enables or disables ACL time-out removal. When enabled, ACLs associated with expired FCFs and FCoE connections are removed from the system. Command mode: Global configuration
<code>show fcoe information</code> Displays the current FCoE parameters. Command mode: All
<code>[no] fcoe optimized-forwarding enable</code> Enables or disables QLogic Fibre Channel optimized forwarding. The default value is enabled. Command mode: Global configuration
<code>show fcoe optimized-acl vlan <1-4095></code> Displays optimized ACLs used for a specific VLAN. Command mode: All
<code>show fcoe optimized-forwarding status</code> Displays whether QLogic Fibre Channel optimized forwarding is enabled or not.. Command mode: All

FIPS Port Configuration

FIP Snooping allows the switch to monitor FCoE Initialization Protocol (FIP) frames to gather discovery, initialization, and maintenance data. This data is used to automatically configure ACLs that provide FCoE connections and data security.

[Table 337](#) describes the port Fibre Channel over Ethernet Initialization Protocol (FIP) Snooping configuration options.

Table 337. Port FIP Snooping Commands

Command Syntax and Usage
<pre>fcoe fips port <port alias or number> fcf-mode [auto on off]</pre> <p>Configures FCoE Forwarding (FCF) on the port, as follows:</p> <ul style="list-style-type: none">– on: Configures the port as a Fibre Channel Forwarding (FCF) port.– off: Configures the port as an FCoE node (ENode).– auto: Automatically detect the configuration of the connected device, and configure this port to match. <p>Command mode: Global configuration</p>
<pre>fcoe fips port <port alias or number> enable</pre> <p>Enables FIP Snooping on the port. The default setting is enabled.</p> <p>Note: If IPv6 ACLs are assigned to the port, you cannot enable FCoE.</p> <p>Command mode: Global configuration</p>
<pre>no fcoe fips port <port alias or number> enable</pre> <p>Disables FIP Snooping on the port.</p> <p>Command mode: Global configuration</p>

Remote Monitoring Configuration

Remote Monitoring (RMON) allows you to monitor traffic flowing through the switch. The RMON MIB is described in RFC 1757.

The following sections describe the Remote Monitoring (RMON) configuration options.

- [“RMON History Configuration” on page 467](#)
- [“RMON Event Configuration” on page 468](#)
- [“RMON Alarm Configuration” on page 469](#)

RMON History Configuration

[Table 338](#) describes the RMON History commands.

Table 338. RMON History Commands

Command Syntax and Usage
<pre>rmon history <I-65535> interface-oid <I-127 characters></pre> <p>Configures the interface MIB Object Identifier. The IFOID must correspond to the standard interface OID, as follows:</p> <pre>1.3.6.1.2.1.2.2.1.1.x</pre> <p>where x is the ifIndex</p> <p>Command mode: Global configuration</p>
<pre>rmon history <I-65535> requested-buckets <I-65535></pre> <p>Configures the requested number of buckets, which is the number of discrete time intervals over which data is to be saved. The default value is 30.</p> <p>The maximum number of buckets that can be granted is 50.</p> <p>Command mode: Global configuration</p>
<pre>rmon history <I-65535> polling-interval <I-3600></pre> <p>Configures the time interval over which the data is sampled for each bucket.</p> <p>The default value is 1800.</p> <p>Command mode: Global configuration</p>
<pre>rmon history <I-65535> owner <I-127 characters></pre> <p>Enter a text string that identifies the person or entity that uses this History index.</p> <p>Command mode: Global configuration</p>
<pre>no rmon history <I-65535></pre> <p>Deletes the selected History index.</p> <p>Command mode: Global configuration</p>
<pre>show rmon history</pre> <p>Displays the current RMON History parameters.</p> <p>Command mode: All</p>

RMON Event Configuration

Table 339 describes the RMON Event commands.

Table 339. RMON Event Commands

Command Syntax and Usage
<pre>rmon event <1-65535> description <1-127 characters></pre> <p>Enter a text string to describe the event. Command mode: Global configuration</p>
<pre>[no] rmon event <1-65535> type log trap both</pre> <p>Selects the type of notification provided for this event. For log events, an entry is made in the log table and sent to the configured syslog host. For trap events, an SNMP trap is sent to the management station. Command mode: Global configuration</p>
<pre>rmon event <1-65535> owner <1-127 characters></pre> <p>Enter a text string that identifies the person or entity that uses this event index. Command mode: Global configuration</p>
<pre>no rmon event <1-65535></pre> <p>Deletes the selected RMON Event index. Command mode: Global configuration</p>
<pre>show rmon event</pre> <p>Displays the current RMON Event parameters. Command mode: All</p>

RMON Alarm Configuration

The Alarm RMON group can track rising or falling values for a MIB object. The MIB object must be a counter, gauge, integer, or time interval. Each alarm index must correspond to an event index that triggers once the alarm threshold is crossed.

Table 340 describes the RMON Alarm commands.

Table 340. RMON Alarm Commands

Command Syntax and Usage	
<code>rmon alarm <I-65535> oid <I-127 characters></code>	Configures an alarm MIB Object Identifier. Command mode: Global configuration
<code>rmon alarm <I-65535> interval <I-65535></code>	Configures the time interval over which data is sampled and compared with the rising and falling thresholds. The default value is 1800. Command mode: Global configuration
<code>rmon alarm <I-65535> sample abs delta</code>	Configures the method of sampling the selected variable and calculating the value to be compared against the thresholds, as follows: <ul style="list-style-type: none"> – <code>abs</code>—absolute value, the value of the selected variable is compared directly with the thresholds at the end of the sampling interval. – <code>delta</code>—delta value, the value of the selected variable at the last sample is subtracted from the current value, and the difference compared with the thresholds. Command mode: Global configuration
<code>rmon alarm <I-65535> alarm-type rising falling either</code>	Configures the alarm type as rising, falling, or either (rising or falling). Command mode: Global configuration
<code>rmon alarm <I-65535> rising-limit <-2147483647 - 2147483647></code>	Configures the rising threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single event is generated. Command mode: Global configuration
<code>rmon alarm <I-65535> falling-limit <-2147483647 - 2147483647></code>	Configures the falling threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single event is generated. Command mode: Global configuration
<code>rmon alarm <I-65535> rising-crossing-index <I-65535></code>	Configures the rising alarm event index that is triggered when a rising threshold is crossed. Command mode: Global configuration

Table 340. RMON Alarm Commands (continued)

Command Syntax and Usage	
<pre>rmon alarm <1-65535> falling-crossing-index <1-65535></pre>	<p>Configures the falling alarm event index that is triggered when a falling threshold is crossed.</p> <p>Command mode: Global configuration</p>
<pre>rmon alarm <1-65535> owner <1-127 characters></pre>	<p>Enter a text string that identifies the person or entity that uses this alarm index.</p> <p>Command mode: Global configuration</p>
<pre>no rmon alarm <1-65535></pre>	<p>Deletes the selected RMON Alarm index.</p> <p>Command mode: Global configuration</p>
<pre>show rmon alarm</pre>	<p>Displays the current RMON Alarm parameters.</p> <p>Command mode: All</p>

Virtualization Configuration

Table 341 describes the virtualization configuration options.

Table 341. Virtualization Configurations Options

Command Syntax and Usage
<pre>virt enable</pre> <p>Enables VMready. Command mode: Global configuration</p>
<pre>no virt enable</pre> <p>Disables VMready. Note: This command deletes all configured VM groups. Command mode: Global configuration</p>
<pre>show virt</pre> <p>Displays the current virtualization parameters. Command mode: All</p>

VM Policy Bandwidth Management

Table 342 describes the bandwidth management options for the selected VM. Use these commands to limit the bandwidth used by each VM.

Table 342. VM Bandwidth Management Options

Command Syntax and Usage
<pre>virt vmpolicy vmbwidth [<MAC address> <UUID> <name> <IP address> <index number>] txrate <64-10000000> <max. burst (32-4096)> <ACL number></pre> <p>The first value configures Committed Rate—the amount of bandwidth available to traffic transmitted from the VM to the switch, in kilobits per second. Enter the value in multiples of 64.</p> <p>The second values configures the maximum burst size, in kilobits. Enter one of the following values: 32, 64, 128, 256, 512, 1024, 2048, 4096.</p> <p>The third value represents the ACL assigned to the transmission rate. The ACL is automatically, in sequential order, if not specified by the user. If there are no available ACLs, the TXrate cannot be configured. Each TXrate configuration reduces the number of available ACLs by one.</p> <p>Command mode: Global configuration</p>
<pre>[no] virt vmpolicy vmbwidth [<MAC address> <UUID> <name> <IP address> <index number>] bwctrl</pre> <p>Enables or disables bandwidth control on the VM policy. Command mode: Global configuration</p>

Table 342. VM Bandwidth Management Options (continued)

Command Syntax and Usage
<pre>no virt vmpolicy vmbwidth [<MAC address> <UUID> <name> <IP address> <index number>]</pre> <p>Deletes the bandwidth management settings from this VM policy.</p> <p>Command mode: Global configuration</p>
<pre>show virt vmpolicy vmbandwidth [<MAC address> <UUID> <name> <IP address> <index number>]</pre> <p>Displays the current VM bandwidth management parameters.</p> <p>Command mode: All</p>

Virtual NIC Configuration

Table 343 describes the Virtual NIC (vNIC) configuration options.

Table 343. Virtual NIC options

Command Syntax and Usage
<pre>vnic enable</pre> <p>Globally turns vNIC on.</p> <p>Command mode: Global configuration</p>
<pre>no vnic enable</pre> <p>Globally turns vNIC off.</p> <p>Command mode: Global configuration</p>
<pre>[no] vnic egress-bw-meter</pre> <p>Enables or disables vNIC bandwidth metering. When enabled, any bandwidth which is not used by the vNIC to which it is allocated is shared with other vNICs. In all cases, the configured values for minimum bandwidth are honored. Only the excess bandwidth is shared.</p> <p>Command mode: Global configuration</p>
<pre>[no] vnic uplink-share</pre> <p>Enable or disable vNIC shared mode. When enabled, multiple vNIC groups can be assigned to the same uplink port.</p> <p>Command mode: Global configuration</p>
<pre>show vnic</pre> <p>Displays the current vNIC parameters.</p> <p>Command mode: All</p>

vNIC Port Configuration

Table 344 describes the Virtual NIC (vNIC) port configuration options.

Table 344. vNIC Port Commands

Command Syntax and Usage
<pre>vnic port <port alias or number> index <1-4></pre> <p>Enters vNIC Configuration mode.</p> <p>Note: This command is valid for internal server ports only.</p> <p>Command mode: Global configuration</p>
<pre>bandwidth <1-100></pre> <p>Configures the maximum bandwidth allocated to this vNIC, in increments of 100 Mbps. For example:</p> <ul style="list-style-type: none"> – 1 = 100 Mbps – 10 = 1000 Mbps <p>Command mode: vNIC configuration</p>
<pre>enable</pre> <p>Enables the vNIC.</p> <p>Command mode: vNIC configuration</p>
<pre>no enable</pre> <p>Disables the vNIC.</p> <p>Command mode: vNIC configuration</p>

Virtual NIC Group Configuration

Table 345 describes the Virtual NIC (vNIC) Group configuration options.

Table 345. vNIC Group Commands

Command Syntax and Usage
<pre>vnic vnicgroup <1-32></pre> <p>Enters vNIC Group Configuration mode.</p> <p>Command mode: Global Configuration</p>
<pre>vlan <VLAN number></pre> <p>Assigns a VLAN to the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
<pre>[no] failover</pre> <p>Enables or disables uplink failover for the vNIC Group. Uplink Failover for the vNIC Group will disable all vNIC and non-vNIC ports in the group. Other port functions continue to operate normally.</p> <p>The default setting is disabled.</p> <p>Command mode: vNIC Group configuration</p>

Table 345. vNIC Group Commands (continued)

Command Syntax and Usage	
member <vNIC number>	<p>Adds a vNIC to the vNIC Group. The vNIC ID is comprised of the port number and the vNIC number. For example: 1 . 1</p> <p>Command mode: vNIC Group configuration</p>
no member <vNIC number>	<p>Removes the selected vNIC from the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
port <port number or alias>	<p>Adds the non-vNIC port or uplink port to the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
no port <port number or alias>	<p>Removes the non-vNIC port or uplink port from the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
trunk <trunk number>	<p>Adds the uplink trunk group to the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
no trunk <trunk number>	<p>Removes the uplink trunk group from the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
key <trunk number>	<p>Adds the uplink LACP trunk to the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
no key <trunk number>	<p>Removes the uplink LACP trunk from the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
enable	<p>Enables the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
no enable	<p>Disables the vNIC Group.</p> <p>Command mode: vNIC Group configuration</p>
no vnic vnicgroup <1-32>	<p>Deletes the selected vNIC Group.</p> <p>Command mode: Global configuration</p>
show vnicgroup	<p>Displays the current vNIC Group parameters.</p> <p>Command mode: All</p>

UFP Configuration

[Table 346](#) describes the Unified Fabric Port (UFP) configuration options. UFP allows defining up to 4 virtual ports per physical port. Each virtual port can be set up to operate in a specific mode (access, trunk, tunnel, FCoE) and within predefined bandwidth limits.

Note: vNIC and UFP are mutually exclusive. Only one of them can be globally enabled at any point in time.

Table 346. UFP Commands

Command Syntax and Usage
<pre>[no] ufp enable</pre> <p>Globally enables or disables UFP. Command mode: Global configuration</p>
<pre>[no] ufp port <port_no.> enable</pre> <p>Enables or disables UFP on the specified physical ports. Command mode: Global configuration</p>
<pre>ufp port <port_no.> vport <1-4></pre> <p>Enters UFP Virtual Port Configuration mode. Command mode: Global configuration</p>
<pre>no ufp port <port_no.> [vport <1-4>]</pre> <p>Disables UFP settings on the specified physical or virtual port. Command mode: Global configuration</p>
<pre>[no] enable</pre> <p>Enables or disables the virtual port. Command mode: UFP Virtual Port Configuration</p>
<pre>evb profile <1-16></pre> <p>Applies the specified EVB profile for the port. Command mode: UFP Virtual Port Configuration</p>

Table 346. UFP Commands (continued)

Command Syntax and Usage
<pre>network {mode [access trunk tunnel fcoe auto] default-vlan <2-4094> default-tag}</pre> <p>Configures the virtual port network configuration settings:</p> <ul style="list-style-type: none"> – mode configures the virtual port’s operating mode: <ul style="list-style-type: none"> • access allows the virtual port to associate only with the default customer VLAN, as defined by the default-vlan option. • trunk allows the virtual port to associate with up to 256 customer VLANs. • tunnel makes the virtual port VLAN agnostic. This is the default setting. • fcoe configures the virtual port to carry Fibre Channel over Ethernet traffic when linked to a Fibre Channel virtual Host Bus Adapter. Setting a virtual port in fcoe mode enables Priority Flow Control on the physical port. • auto integrates UFP with VMReady/802.1qbg. This mode allows dynamic vlan creation for the vport. – default-vlan configures the default VLAN ID for the virtual port. – default-tag enables tagging egress frames with the default VLAN ID when the virtual port is in access or trunk mode and default-vlan is defined. Default setting is disabled. <p>Note: VLANs 4002-4005 cannot be used as customer VLANs</p> <p>Note: A customer VLAN cannot be configured on multiple virtual ports of the same physical port.</p> <p>Command mode: UFP Virtual Port Configuration</p>
<pre>no network default-tag</pre> <p>Disables default VLAN ID tagging on the virtual port.</p> <p>Command mode: UFP Virtual Port Configuration</p>
<pre>qos bandwidth {max <10-100> min <10-100>}</pre> <p>Configures bandwidth allocation for the virtual port:</p> <ul style="list-style-type: none"> – Configures the minimum bandwidth guaranteed for the virtual port as a percentage of the physical port’s bandwidth. The default value is 25. – Configures the maximum bandwidth allowed for this virtual port as a percentage of the physical port’s bandwidth. The default value is 100. <p>Note: The aggregated minimum bandwidth guaranteed for all the virtual ports within a physical port cannot exceed 100.</p> <p>Command mode: UFP Virtual Port Configuration</p>

VM Group Configuration

[Table 347](#) describes the VM group configuration options. A VM group is a collection of members, such as VMs, ports, or trunk groups. Members of a VM group share certain properties, including VLAN membership, ACLs (VMAP), and VM profiles.

Table 347. VM Group Commands

Command Syntax and Usage
<pre>virt vmgroup <I-4096> cpu</pre> <p>Enables or disables sending unregistered IPMC to CPU.</p> <p>Command mode: Global configuration</p>
<pre>virt vmgroup <I-4096> flood</pre> <p>Enables or disables flooding unregistered IPMC.</p> <p>Command mode: Global configuration</p>
<pre>virt vmgroup <I-4096> optflood</pre> <p>Enables or disables optimized flooding.</p> <p>Command mode: Global configuration</p>
<pre>virt vmgroup <I-4096> vlan <VLAN number></pre> <p>Assigns a VLAN to this VM group. If you do not assign a VLAN to the VM group, the switch automatically assigns an unused VLAN when adding a port or a VM to the VM Group.</p> <p>Note: If you add a VM profile to this group, the group will use the VLAN assigned to the profile.</p> <p>Command mode: Global configuration</p>
<pre>[no] virt vmgroup <I-4096> vmap <VMAP number> intports extports</pre> <p>Assigns the selected VLAN Map to this group. You can choose to limit operation of the VLAN Map to internal ports only or external ports only. If you do not select a port type, the VMAP is applied to the entire VM Group.</p> <p>For more information about configuring VLAN Maps, see “VMAP Configuration” on page 308.</p> <p>Command mode: Global configuration</p>
<pre>[no] virt vmgroup <I-4096> tag</pre> <p>Enables or disables VLAN tagging on ports in this VM group.</p> <p>Command mode: Global configuration</p>
<pre>virt vmgroup <I-4096> vm [<MAC address> <UUID> <name> <IP address> <index number>]</pre> <p>Adds a VM to the VM group. Enter a unique identifier to select a VM. The UUID and name parameters apply only if Virtual Center information is configured (virt vmware vcspec).</p> <p>The VM index number is found in the VM information dump (show virt vm).</p> <p>Note: If the VM is connected to a port that is contained within the VM group, do not add the VM to the VM group.</p> <p>Command mode: Global configuration</p>

Table 347. VM Group Commands (continued)

Command Syntax and Usage	
<pre>no virt vmggroup <1-4096> vm [<MAC address> <UUID> <name> <IP address> <index number>]</pre>	<p>Removes a VM from the VM group. Enter a unique identifier to select a VM. The UUID and name parameters apply only if Virtual Center information is configured (<code>virt vmware vcspec</code>). The VM index number is found in the VM information dump (<code>show virt vm</code>).</p> <p>Command mode: Global configuration</p>
<pre>virt vmggroup <1-4096> profile <profile name (1-39 characters)></pre>	<p>Adds the selected VM profile to the VM group.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmggroup <1-4096> profile</pre>	<p>Removes the VM profile assigned to the VM group.</p> <p>Note: This command can only be used if the VM group is empty (only has the profile assigned).</p> <p>Command mode: Global configuration</p>
<pre>virt vmggroup <1-4096> port <port number or alias></pre>	<p>Adds the selected port to the VM group.</p> <p>Note: A port can be added to a VM group only if no VMs on that port are members of the VM group.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmggroup <1-4096> port <port number or alias></pre>	<p>Removes the selected port from the VM group.</p> <p>Command mode: Global configuration</p>
<pre>virt vmggroup <1-4096> vport <port alias or number></pre>	<p>Adds the selected virtual port to the VM group.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmggroup <1-4096> vport <port alias or number></pre>	<p>Removes the selected virtual port from the VM group.</p> <p>Command mode: Global configuration</p>
<pre>virt vmggroup <1-4096> portchannel <trunk number></pre>	<p>Adds the selected trunk group to the VM group.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmggroup <1-4096> portchannel <trunk number></pre>	<p>Removes the selected trunk group from the VM group.</p> <p>Command mode: Global configuration</p>

Table 347. VM Group Commands (continued)

Command Syntax and Usage	
<pre>virt vmgroup <I-4096> key <I-65535></pre>	<p>Adds an LACP <i>admin key</i> to the VM group. LACP trunks formed with this <i>admin key</i> will be included in the VM group.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmgroup <I-4096> key <I-65535></pre>	<p>Removes an LACP <i>admin key</i> from the VM group.</p> <p>Command mode: Global configuration</p>
<pre>virt vmgroup <I-4096> stg <STG number></pre>	<p>Assigns the VM group VLAN to a Spanning Tree Group (STG).</p> <p>Command mode: Global configuration</p>
<pre>virt vmgroup <I-4096> validate [basic advanced]</pre>	<p>Enables MAC address spoof prevention for the specified VM group. Default setting is disabled.</p> <ul style="list-style-type: none"> – <i>basic</i> validation ensures lightweight port-based protection by cross-checking the VM MAC address, switch port and switch ID between the switch and the hypervisor. Applicable for “trusted” hypervisors, which are not susceptible to duplicating or reusing MAC addresses on virtual machines. – <i>advanced</i> validation ensures heavyweight VM-based protection by cross-checking the VM MAC address, VM UUID, switch port and switch ID between the switch and the hypervisor. Applicable for “untrusted” hypervisors, which are susceptible to duplicating or reusing MAC addresses on virtual machines. <p>Command mode: Global configuration</p>
<pre>no virt vmgroup <I-4096> validate</pre>	<p>Disables MAC address spoof prevention for the specified VM group.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmgroup <I-4096></pre>	<p>Deletes the VM group.</p> <p>Command mode: Global configuration</p>
<pre>show virt vmgroup <I-4096></pre>	<p>Displays the current VM group parameters.</p> <p>Command mode: All</p>

VM Check Configuration

[Table 348](#) describes the VM Check validation options used for MAC address spoof prevention.

Table 348. VM Check Configuration Options

Command Syntax and Usage
<pre>virt vmcheck acls max <1-256></pre> <p>Configures the maximum number of ACLs that can be set up for MAC address spoofing prevention in advanced validation mode. Default value is 50.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmcheck acls</pre> <p>Disables ACL-based MAC address spoofing prevention in advanced validation mode.</p> <p>Command mode: Global configuration</p>
<pre>virt vmcheck action basic {link log}</pre> <p>Sets up action taken when detecting MAC address spoofing in basic validation mode:</p> <ul style="list-style-type: none">– <code>link</code> registers a syslog entry and disables the corresponding switch port– <code>log</code> registers a syslog entry <p>Default setting is <code>link</code>.</p> <p>Command mode: Global configuration</p>
<pre>virt vmcheck action advanced {acl link log}</pre> <p>Sets up action taken when detecting MAC address spoofing in advanced validation mode:</p> <ul style="list-style-type: none">– <code>acl</code> registers a syslog entry and installs an ACL to drop traffic incoming on the corresponding switch port originating from the spoofed MAC address– <code>link</code> registers a syslog entry and disables the corresponding switch port– <code>log</code> registers a syslog entry <p>Default setting is <code>acl</code>.</p> <p>Command mode: Global configuration</p>
<pre>[no] virt vmcheck trust <ports></pre> <p>Enables or disables trusted ports for VM communication. By default, all ports are disabled.</p> <p>Command mode: Global configuration</p>
<pre>show virt vmcheck</pre> <p>Displays the current VM Check settings. See page 113 for sample output.</p> <p>Command mode: Global configuration</p>

VM Profile Configuration

Table 349 describes the VM Profiles configuration options.

Table 349. VM Profiles Commands

Command Syntax and Usage
<pre>virt vmprofile <profile name (1-39 characters)></pre> <p>Defines a name for the VM profile.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmprofile <profile name (1-39 characters)></pre> <p>Deletes the selected VM profile.</p> <p>Command mode: Global configuration</p>
<pre>virt vmprofile edit <profile name (1-39 characters)> vlan <VLAN number></pre> <p>Assigns a VLAN to the VM profile.</p> <p>Command mode: Global configuration</p>
<pre>[no] virt vmprofile edit <profile name (1-39 characters)> shaping [<average (1-1000000000)> <burst (1-1000000000)> <peak (1-1000000000)>]</pre> <p>Configures traffic shaping parameters implemented in the hypervisor, as follows:</p> <ul style="list-style-type: none"> – Average traffic, in Kilobits per second – Maximum burst size, in Kilobytes – Peak traffic, in Kilobits per second – Delete traffic shaping parameters. <p>Command mode: Global configuration</p>
<pre>[no] virt vmprofile edit <profile name (1-39 characters)> eshaping [<average (1-1000000000)> <burst (1-1000000000)> <peak (1-1000000000)>]</pre> <p>Configures traffic egress shaping parameters implemented in the hypervisor, as follows:</p> <ul style="list-style-type: none"> – Average traffic, in Kilobits per second – Maximum burst size, in Kilobytes – Peak traffic, in Kilobits per second – Delete traffic shaping parameters. <p>Command mode: Global configuration</p>
<pre>show virt vmprofile [<profile name>]</pre> <p>Displays the current VM Profile parameters.</p> <p>Command mode: All</p>

VMWare Configuration

Table 350 describes the VMware configuration options. When the user configures the VMware Virtual Center, the VM Agent module in the switch can perform advanced functionality by communicating with the VMware management console. The Virtual Center provides VM and Host names, IP addresses, Virtual Switch and port group information. The VM Agent on the switch communicates with the Virtual Center to synchronize VM profiles between the switch and the VMware virtual switch.

Note: VM Profiles and Hello cannot be configured or enabled unless the Virtual Center is configured.

Table 350. VM Ware Commands

Command Syntax and Usage
<pre>virt vmware hbport <I-65535></pre> <p>Configures the UDP port number used for heartbeat communication from the VM host to the Virtual Center. The default value is port 902.</p> <p>Command mode: Global configuration</p>
<pre>[no] virt vmware vcspec [<IP address> [<username> noauth]</pre> <p>Defines the Virtual Center credentials on the switch. Once you configure the Virtual Center, VM Agent functionality is enabled across the system. You are prompted for the following information:</p> <ul style="list-style-type: none"> – IP address of the Virtual Center – User name and password for the Virtual Center – Whether to authenticate the SSL security certificate (yes or no) <p>Command mode: Global configuration</p>
<pre>virt vmware hello [enable haddr <IP_address> hport <port_no> htimer <I-60>]</pre> <p>Configures CDP (Cisco Discovery Protocol) advertisements sent periodically to VMware ESX hypervisors. Exchanging CDP message with ESX hypervisors facilitates MAC address spoof prevention. Default setting is disabled.</p> <ul style="list-style-type: none"> – <code>enable</code> enables CDP advertisements transmission. – <code>haddr</code> advertises a specific IP address instead of the default management IP. – <code>hport</code> enables ports on which CDP advertisements are sent. – <code>htimer</code> sets the number of seconds between successive CDP advertisements. Default value is 30. <p>Command mode: Global configuration</p>
<pre>no virt vmware hello [enable hport <port_no>]</pre> <p>Disables CDP advertisement transmissions completely or only on specific ports.</p> <p>Command mode: Global configuration</p>
<pre>show virt vmware</pre> <p>Displays the current VMware parameters.</p> <p>Command mode: All</p>

Miscellaneous VMready Configuration

You can pre-configure MAC addresses as VM Organization Unique Identifiers (OUIs). These configuration commands are only available using the IBM Networking OS CLI, ISCLI and the Miscellaneous VMready Configuration Menu. [Table 350](#) describes the VMready configuration options.

Table 351. VMware Miscellaneous Options

Command Syntax and Usage	
<pre>virt vmrmisc oui < 3 byte VM MAC OUI> <Vendor Name></pre>	<p>Adds a MAC OUI.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmrmisc oui < 3 byte VM MAC OUI></pre>	<p>Removes a MAC OUI.</p> <p>Command mode: Global configuration</p>
<pre>show virt oui</pre>	<p>Displays all the configured MAC OUIs.</p> <p>Command mode: All</p>
<pre>virt vmrmisc lmac</pre>	<p>Enables the switch to treat locally administered MAC addresses as VMs.</p> <p>Command mode: Global configuration</p>
<pre>no virt vmrmisc lmac</pre>	<p>Disables the switch from treating locally administered MAC addresses as VMs.</p> <p>Command mode: Global configuration</p>

Edge Virtual Bridge Configuration

You can configure your switch to use Edge Virtual Bridging (EVB). [Table 352](#) describes the EVB configuration options.

Table 352. Edge Virtual Bridge Configuration Options

Command Syntax and Usage
<pre>virt evb vsidb <VSIDB_number></pre> <p>Enter Virtual Station Interface Database configuration mode.</p> <p>Command mode: Global configuration</p>
<pre>virt evb update vsidb <VSIDB_number></pre> <p>Update VSI types from the VSI database.</p> <p>Command mode: All</p>
<pre>clear virt evb vsidb [mgrid <0-255> typeid <1-16777215> version <0-255>]</pre> <p>Clears local VSI types cache.</p> <p>Command mode: All</p>
<pre>clear virt evb vsi [mac-address port <port alias or number> type-id <1-16777215> vlan <1-4094>]</pre> <p>Clears VSI database associations.</p> <p>Command mode: All</p>
<pre>host <IP address> [mgt-port extm-port data-port]</pre> <p>Sets the Virtual Station Interface Type database manager IPv4/IPv6 address and the port used for the connection. By default, the management port is used.</p> <p>Command mode: VSI Database</p>
<pre>port <1-65534></pre> <p>Sets the Virtual Station Interface Type database manager port.</p> <p>Command mode: VSI Database</p>
<pre>filename <File name></pre> <p>Sets the Virtual Station Interface Type database document name.</p> <p>Command mode: VSI Database</p>
<pre>filepath <File path></pre> <p>Sets the Virtual Station Interface Type database document path.</p> <p>Command mode: VSI Database</p>
<pre>protocol {http https}</pre> <p>Sets the Virtual Station Interface Type database transport protocol. The default setting is HTTP.</p> <p>Command mode: VSI Database</p>

Table 352. Edge Virtual Bridge Configuration Options

Command Syntax and Usage
<pre>update-interval <5-300></pre> <p>Sets the Virtual Station Interface Type database update interval in seconds. A value of "0" disables periodic updates.</p> <p>Command mode: VSI Database</p>
<pre>show virt evb vsitypes [mgrid <0-255> typeid <1-16777215> version <0-255></pre> <p>Displays the current Virtual Station Interface Type database parameters.</p> <p>Command mode: All</p>
<pre>show virt evb vsidb <VSIDB_number></pre> <p>Displays the current Virtual Station Interface database information.</p> <p>Command mode: All</p>
<pre>no virt evb vsidb <VSIDB_number></pre> <p>Resets the Virtual Station Interface Type database information to the default values.</p> <p>Command mode: Global configuration</p>

Edge Virtual Bridge Profile Configuration

[Table 353](#) describes the Edge Virtual Bridge profile configuration options.

Table 353. Edge Virtual Bridge VSI Type Profile Configuration Options

Command Syntax and Usage
<pre>virt evb profile <profile_number></pre> <p>Enter Virtual Station Interface type profile configuration mode.</p> <p>Command mode: Global configuration</p>
<pre>[no] reflective-relay</pre> <p>Enables or disables VEPA mode (Reflective Relay capability).</p> <p>Command mode: EVB Profile</p>
<pre>[no] vsi-discovery</pre> <p>Enables or disables VSI Discovery (ECP and VDP).</p> <p>Command mode: EVB Profile</p>
<pre>no virt evb profile <profile_number></pre> <p>Deletes the specified EVB profile.</p> <p>Command mode: Global configuration</p>
<pre>show virt evb profile [<1-16>]</pre> <p>Displays the current EVB profile parameters.</p> <p>Command mode: All</p>

Table 353. Edge Virtual Bridge VSI Type Profile Configuration Options

Command Syntax and Usage
<pre>evb profile <1-16></pre> <p>Applies the specified EVB profile for the port. Automatically enables LLDP EVB TLV on the corresponding port.</p> <p>Command mode: Interface port/UFP Virtual port</p>
<pre>no evb profile</pre> <p>Resets EVB profile for the port. Automatically disables LLDP, EVB, and TLV on the corresponding port.</p> <p>Command mode: Interface port/UFP Virtual port</p>

Switch Partition (SPAR) Configuration

Switch partitions (SPARs) divide the data plane inside a physical switch into independent switching domains. Switch partitions do not communicate with each other, forcing hosts on different SPARs to bridge traffic over an upstream link, even if they belong to the same VLAN.

Up to 8 SPARs can be defined on a switch. Each SPAR supports up to 32 local VLANs, for further partitioning flexibility

Table 354. SPAR Configuration Options

Command Syntax and Usage	
spar <1-8>	Enters SPAR Configuration mode Command mode: Global configuration
no spar <1-8>	Deletes the specified SPAR. Command mode: Global configuration
[no] enable	Enables or disables the SPAR. Command mode: SPAR Configuration
name	Configures the SPAR name. Command mode: SPAR Configuration
[no] uplink {port <port no.> portchannel <1-64> adminkey <1-65535>}	Enables or disables uplink connectivity for the SPAR. A single external port, portchannel, or LACP channel can be used for uplink. All uplinks within a SPAR are automatically assigned to the SPAR domain's default VLAN and to any SPAR local VLANs. Command mode: SPAR Configuration
domain default {vlan <2-4094> member <port no.>}	Configures the SPAR's default domain settings: <ul style="list-style-type: none"> – vlan configures the default SPAR VLAN ID. A unique factory default VLAN ID is assigned to each SPAR as "408x", where x is the SPAR ID <1-8>. This option provides an override if conflicts arise with a customer VLAN ID on the upstream network. – member adds server ports to the SPAR. Command mode: SPAR Configuration
no domain default member <port no.>	Removes server ports from the SPAR. Command mode: SPAR Configuration

Table 354. SPAR Configuration Options (continued)

Command Syntax and Usage
<pre>domain local <1-32> {enable member <port no.> name <text> vlan <2-4094>}</pre> <p>Configures the SPAR's local domains:</p> <ul style="list-style-type: none"> – enable enables the SPAR local domains – member adds server ports to the SPAR local domains – name configures the SPAR local domains names – vlan applies a VLAN ID to the SPAR local domains. The default value is 0. <p>Command mode: SPAR Configuration</p>
<pre>no domain local <1-32> [enable member <port no.> vlan]</pre> <p>Deletes the SPAR local VLAN domains:</p> <ul style="list-style-type: none"> – enable disables the SPAR local domains – member deletes SPAR local domains server ports – vlan deletes SPAR local domains vlan. <p>Command mode: SPAR Configuration</p>
<pre>domain mode {passthrough local}</pre> <p>Configures the SPAR domain mode:</p> <ul style="list-style-type: none"> – passthrough references member ports only by the SPAR default VLAN. This provides VLAN-unaware uplink connectivity via pass-through tunnel domain switching for SPAR member ports. The default value is passthrough. – local references member ports by both SPAR default VLAN and SPAR local domain VLANs. This provides VLAN-aware uplink connectivity via local domain switching for SPAR member ports <p>Command mode: SPAR Configuration</p>
<pre>show spar <1-8> [domain [default local <1-32>] uplink]</pre> <p>Displays the SPAR settings:</p> <ul style="list-style-type: none"> – domain filters only the SPAR domain related settings <ul style="list-style-type: none"> • default filters only SPAR default domain settings • local <1-32> filters only SPAR local domains settings – uplink filters only SPAR uplink settings <p>Command mode: All</p>

Service Location Protocol Configuration

Service Location Protocol (SLP) enables networked devices to request/announce services over a local area network without prior configuration. In an SLP environment, devices may have the following roles:

- User Agents (UA) are devices requesting services.
- Service Agents (SA) are devices providing services.

- Directory Agents (DA) are devices caching services provided by SAs. When present in an SLA setup, DAs mediate all communication between UAs and SAs.

When SLP is enabled, the CN4093 10Gb Converged Scalable Switch behaves as a Service Agent providing systems management services.

Table 355. Service Location Protocol

Command Syntax and Usage	
<code>[no] ip slp enable</code>	Enables or disables SLP. Default value is disabled. Command mode: Global configuration
<code>[no] ip slp active-da-discovery enable</code>	Enables or disables active directory agent discovery. Default value is disabled. Command mode: Global configuration
<code>ip slp active-da-discovery-start-wait-time <1-10></code>	Number of seconds to wait after enabling SLP before attempting active DA discovery, if active DA discovery is enabled. Default value is 3. Command mode: Global configuration
<code>clear ip slp directory-agents</code>	Clears directory agents discovered. Command mode: Privileged EXEC

Configuration Dump

The dump program writes the current switch configuration to the terminal screen. To start the dump program, at the prompt, enter:

```
Router(config)# show running-config
```

The configuration is displayed with parameters that have been changed from the default values. The screen display can be captured, edited, and placed in a script file, which can be used to configure other switches through a Telnet connection. When using Telnet to configure a new switch, paste the configuration commands from the script file at the command line prompt of the switch. The active configuration can also be saved or loaded via FTP/TFTP, as described on [page 492](#).

Saving the Active Switch Configuration

When the `copy running-config {ftp|tftp|sftp}` command is used, the switch's active configuration commands (as displayed using `show running-config`) will be uploaded to the specified script configuration file on the FTP/TFTP/SFTP server. To start the switch configuration upload, at the prompt, enter:

```
Router(config)# copy running-config ftp [data-port|extm-port|mgt-port]
    or
Router(config)# copy running-config tftp [data-port|extm-port|mgt-port]
    or
Router(config)# copy running-config sftp [data-port|extm-port|mgt-port]
```

Select a port, or press **Enter** to use the default (management port). The switch prompts you for the server address and filename.

Notes:

- The output file is formatted with line-breaks but no carriage returns—the file cannot be viewed with editors that require carriage returns (such as Microsoft Notepad).
- If the FTP/TFTP server is running SunOS or the Solaris operating system, the specified configuration file must exist prior to executing the `copy running-config` command and must be writable (set with proper permission, and not locked by any application). The contents of the specified file will be replaced with the current configuration data.

Restoring the Active Switch Configuration

When the `copy {ftp|tftp|sftp} running-config` command is used, the active configuration will be replaced with the commands found in the specified configuration file. The file can contain a full switch configuration or a partial switch configuration.

To start the switch configuration download, at the prompt, enter:

```
Router(config)# copy ftp running-config [extm-port|mgt-port|data-port]
    or
Router(config)# copy tftp running-config [extm-port|mgt-port|data-port]
    or
Router(config)# copy sftp running-config [extm-port|mgt-port|data-port]
```

Select a port, or press **Enter** to use the default (management port). The switch prompts you for the server address and filename.

Chapter 5. Operations Commands

Operations commands generally affect switch performance immediately, but do not alter permanent switch configurations. For example, you can use Operations commands to immediately disable a port (without the need to apply or save the change), with the understanding that when the switch is reset, the port returns to its normally configured operation.

These commands enable you to alter switch operational characteristics without affecting switch configuration.

Table 356. General Operations Commands

Command Syntax and Usage
<pre>password <1-128 characters></pre> <p>Allows the user to change the password. You must enter the current password in use for validation. The switch prompts for a new password between 1-128 characters.</p> <p>Command Mode: Privileged EXEC</p>
<pre>clear logging</pre> <p>Clears all Syslog messages.</p> <p>Command Mode: Privileged EXEC</p>
<pre>ntp send</pre> <p>Allows the user to send requests to the NTP server.</p> <p>Command Mode: Privileged EXEC</p>

Operations-Level Port Commands

Operations-level port options are used for temporarily disabling or enabling a port, and for re-setting the port.

Table 357. Port Operations Commands

Command Syntax and Usage
<pre>no interface port <port number or alias> shutdown</pre> <p>Temporarily enables the port. The port will be returned to its configured operation mode when the switch is reset.</p> <p>Command Mode: Privileged EXEC</p>
<pre>interface port <port number or alias> shutdown</pre> <p>Temporarily disables the port. The port will be returned to its configured operation mode when the switch is reset.</p> <p>Command Mode: Privileged EXEC</p>
<pre>[no] interface portchannel <1-52> shutdown</pre> <p>Temporarily enables or disables the specified port channel. The port channel will be returned to its configured operation mode when the switch is reset.</p> <p>Command Mode: Privileged EXEC</p>
<pre>[no] interface portchannel lacp <1-65535> shutdown</pre> <p>Temporarily enables or disables specified LACP trunk groups.</p> <p>Command Mode: Privileged EXEC</p>
<pre>show interface port <port number or alias> operation</pre> <p>Displays the port interface operational state.</p> <p>Command Mode: Privileged EXEC</p>

Operations-Level Port 802.1X Commands

Operations-level port 802.1X options are used to temporarily set 802.1X parameters for a port.

Table 358. 802.1X Operations Commands

Command Syntax and Usage
<pre>interface port <port number or alias> dot1x init</pre> <p>Re-initializes the 802.1X access-control parameters for the port. The following actions take place, depending on the 802.1X port configuration:</p> <ul style="list-style-type: none">– <code>force unauth</code>: the port is placed in unauthorized state, and traffic is blocked.– <code>auto</code>: the port is placed in unauthorized state, then authentication is initiated.– <code>force auth</code>: the port is placed in authorized state, and authentication is not required. <p>Command Mode: Privileged EXEC</p>
<pre>interface port <port number or alias> dot1x re-authenticate</pre> <p>Re-authenticates the supplicant (client) attached to the port. This command only applies if the port's 802.1X mode is configured as <code>auto</code>.</p> <p>Command Mode: Privileged EXEC</p>

Operations-Level FCoE Commands

Fibre Channel over Ethernet (FCoE) operations commands are listed in the following table.

Table 359. FCoE Operations Commands

Command Syntax and Usage
<pre>no fcoe fips fcf <MAC address></pre> <p>Deletes the selected FCoE Forwarder (FCF), and any associated ACLs.</p> <p>Command Mode: Privileged EXEC</p>

Operations-Level VRRP Commands

Table 360. Virtual Router Redundancy Operations Commands

Command Syntax and Usage
<pre>router vrrp backup <virtual router number (1-255)></pre> <p>Forces the specified master virtual router on this switch into backup mode. This is generally used for passing master control back to a preferred switch once the preferred switch has been returned to service after a failure. When this command is executed, the current master gives up control and initiates a new election by temporarily advertising its own priority level as 0 (lowest). After the new election, the virtual router forced into backup mode by this command will resume master control in the following cases:</p> <ul style="list-style-type: none">– This switch owns the virtual router (the IP addresses of the virtual router and its IP interface are the same)– This switch's virtual router has a higher priority and preemption is enabled.– There are no other virtual routers available to take master control. <p>Command Mode: Privileged EXEC</p>

Operations-Level BGP Commands

Table 361. IP BGP Operations Commands

Command Syntax and Usage
<pre>router bgp start <1-12></pre> <p>Starts the peer session.</p> <p>Command Mode: Privileged EXEC</p>
<pre>router bgp stop <1-12></pre> <p>Stops the peer session.</p> <p>Command Mode: Privileged EXEC</p>
<pre>show ip bgp state</pre> <p>Displays the current BGP operational state.</p> <p>Command Mode: Privileged EXEC</p>

Protected Mode Options

Protected Mode is used to secure certain switch management options, so they cannot be changed by the management module.

Table 362. Protected Mode Options

Command Syntax and Usage
<pre>[no] protected-mode external-management</pre> <p>Enables exclusive local control of switch management. When Protected Mode is set to <code>on</code>, the management module cannot be used to disable external management on the switch. The default value is <code>enabled</code>.</p> <p>Note: Due to current management module implementation, this setting cannot be disabled.</p> <p>Command Mode: Global Configuration</p>
<pre>[no] protected-mode external-ports</pre> <p>Enables exclusive local control of external ports. When Protected Mode is set to <code>on</code>, the management module cannot be used to disable external ports on the switch. The default value is <code>enabled</code>.</p> <p>Note: Due to current management module implementation, this setting cannot be disabled.</p> <p>Command Mode: Global Configuration</p>
<pre>[no] protected-mode factory-default</pre> <p>Enables exclusive local control of factory default resets. When Protected Mode is set to <code>on</code>, the management module cannot be used to reset the switch software to factory default values. The default value is <code>enabled</code>.</p> <p>Note: Due to current management module implementation, this setting cannot be disabled.</p> <p>Command Mode: Global Configuration</p>
<pre>[no] protected-mode management-vlan-interface</pre> <p>Enables exclusive local control of the management interface. When Protected Mode is set to <code>on</code>, the management module cannot be used to configure parameters for the management interface. The default value is <code>enabled</code>.</p> <p>Note: Due to current management module implementation, this setting cannot be disabled.</p> <p>Command Mode: Global Configuration</p>
<pre>protected-mode enable</pre> <p>Turns Protected Mode <code>on</code>. When Protected Mode is turned on, the switch takes exclusive local control of all enabled options.</p> <p>Command Mode: Global Configuration</p>

Table 362. Protected Mode Options (continued)

Command Syntax and Usage
<pre>no protected-mode enable</pre> <p>Turns Protected Mode <code>off</code>. When Protected Mode is turned off, the switch relinquishes exclusive local control of all enabled options.</p> <p>Command Mode: Global Configuration</p>
<pre>show protected-mode</pre> <p>Displays the current Protected Mode configuration.</p> <p>Command Mode: Global Configuration</p>

VMware Operations

Use these commands to perform minor adjustments to the VMware operation. Use these commands to perform Virtual Switch operations directly from the switch. Note that these commands require the configuration of Virtual Center access information (`virt vmware vcspec`).

Table 363. VMware Operations Commands

Command Syntax and Usage
<pre>virt vmware pg [<Port Group name> <host ID> <VSwitch name> <VLAN number> <shaping-enabled> <average-Kbps> <burst-KB> <peak-Kbps>]</pre> <p>Adds a Port Group to a VMware host. You are prompted for the following information:</p> <ul style="list-style-type: none"> – Port Group name – VMware host ID (Use host UUID, host IP address, or host name.) – Virtual Switch name – VLAN ID of the Port Group – Whether to enable the traffic-shaping profile (1 or 0). If you choose 1 (yes), you are prompted to enter the traffic shaping parameters. <p>Command Mode: All</p>
<pre>virt vmware vsw <host ID> <Virtual Switch name></pre> <p>Adds a Virtual Switch to a VMware host. Use one of the following identifiers to specify the host:</p> <ul style="list-style-type: none"> – UUID – IP address – Host name <p>Command Mode: All</p>
<pre>no virt vmware pg <Port Group name> <host ID></pre> <p>Removes a Port Group from a VMware host. Use one of the following identifiers to specify the host:</p> <ul style="list-style-type: none"> – UUID – IP address – Host name <p>Command Mode: All</p>
<pre>no virt vmware vsw <host ID> <Virtual Switch name></pre> <p>Removes a Virtual Switch from a VMware host. Use one of the following identifiers to specify the host:</p> <ul style="list-style-type: none"> – UUID – IP address – Host name <p>Command Mode: All</p>

Table 363. VMware Operations Commands (continued)

Command Syntax and Usage
<pre>virt vmware export <VM profile name> <VMware host ID> <Virtual Switch name></pre> <p>Exports a VM Profile to a VMware host.</p> <p>Use one of the following identifiers to specify each host:</p> <ul style="list-style-type: none"> – UUID – IP address – Host name <p>You may enter a Virtual Switch name, or enter a new name to create a new Virtual Switch.</p> <p>Command Mode: All</p>
<pre>virt vmware scan</pre> <p>Performs a scan of the VM Agent, and updates VM information.</p> <p>Command Mode: All</p>
<pre>virt vmware vmacpg <MAC address> <Port Group name></pre> <p>Changes a VM NIC's configured Port Group.</p> <p>Command Mode: All</p>
<pre>virt vmware updpg <Port Group name> <host ID> <VLAN number> [<shaping enabled> <average Kbps> <burst KB> <peak Kbps>]</pre> <p>Updates a VMware host's Port Group parameters.</p> <p>Command Mode: All</p>

VMware Distributed Virtual Switch Operations

Use these commands to administer a VMware Distributed Virtual Switch (dvSwitch).

Table 364. VMware dvSwitch Operations (/oper/virt/vmware/dvswitch)

Command Syntax and Usage
<pre>virt vmware dvswitch add <datacenter name> <dvSwitch name> <dvSwitch version></pre> <p>Adds the specified dvSwitch to the specified DataCenter.</p> <p>Command Mode: All</p>
<pre>virt vmware dvswitch del <datacenter name> <dvSwitch name></pre> <p>Removes the specified dvSwitch from the specified DataCenter.</p> <p>Command Mode: All</p>
<pre>virt vmware dvswitch addhost <dvSwitch name> <host UUID IP address host name></pre> <p>Adds the specified host to the specified dvSwitch. Use one of the following identifiers to specify the host:</p> <ul style="list-style-type: none"> – UUID – IP address – Host name <p>Command Mode: All</p>
<pre>virt vmware dvswitch remhost <dvSwitch name> <host UUID IP address host name></pre> <p>Removes the specified host from the specified dvSwitch. Use one of the following identifiers to specify the host:</p> <ul style="list-style-type: none"> – UUID – IP address – Host name <p>Command Mode: All</p>
<pre>virt vmware dvswitch addUplink <dvSwitch name> <host ID> <uplink name></pre> <p>Adds the specified physical NIC to the specified dvSwitch uplink ports.</p> <p>Command Mode: All</p>
<pre>virt vmware dvswitch remUplink <dvSwitch name> <host ID> <uplink name></pre> <p>Removes the specified physical NIC from the specified dvSwitch uplink ports.</p> <p>Command Mode: All</p>

VMware Distributed Port Group Operations

Use these commands to administer a VMware distributed port group.

Table 365. VMware Distributed Port Group Operations (/oper/virt/vmware/dpg)

Command Syntax and Usage
<pre>virt vmware dpg add <port group name> <dvSwitch name> <VLAN ID> [ishaping <bandwidth> <burst size> <peak bandwidth>] [eshaping <bandwidth> <burst size> <peak bandwidth>]</pre> <p>Adds the specified port group to the specified dvSwitch. You may enter the following parameters:</p> <ul style="list-style-type: none">– <code>ishaping</code>: Enables ingress shaping. Supply the following information:<ul style="list-style-type: none">• average bandwidth in KB per second• burst size in KB• peak bandwidth in KB per second– <code>eshaping</code>: Enables egress shaping. Supply the following information:<ul style="list-style-type: none">• average bandwidth in KB per second• burst size in KB• peak bandwidth in KB per second <p>Command Mode: All</p>
<pre>virt vmware dpg vmac <VNIC MAC> <port group name></pre> <p>Adds the specified VM NIC to the specified port group.</p> <p>Command Mode: All</p>
<pre>virt vmware dpg update <port group name> <dvSwitch name> <VLAN ID (1-4094)> [ishaping <bandwidth> <burst size> <peak bandwidth>] [eshaping <bandwidth> <burst size> <peak bandwidth>]</pre> <p>Updates the specified port group on the specified dvSwitch. You may enter the following parameters:</p> <ul style="list-style-type: none">– <code>ishaping</code>: Enables ingress shaping. Supply the following information:<ul style="list-style-type: none">• average bandwidth in KB per second• burst size in KB• peak bandwidth in KB per second– <code>eshaping</code>: Enables egress shaping. Supply the following information:<ul style="list-style-type: none">• average bandwidth in KB per second• burst size in KB• peak bandwidth in KB per second <p>Command Mode: All</p>
<pre>virt vmware dpg del <port group name> <dvSwitch name></pre> <p>Removes the specified port group from the specified dvSwitch.</p> <p>Command Mode: All</p>

Feature on Demand Key Options

Use the license key to upgrade the port mode. Base port mode is the default. To upgrade the port mode, you must obtain a software license key.

After selecting a port mode, you must reset the switch for the change to take affect. Use the following command to verify the port configuration:
show interface information

Table 366. Feature on Demand Key Options

Command Syntax and Usage
<pre>software-key</pre> <p>Enter FOD Key mode.</p> <p>Command mode: Privileged EXEC</p>
<pre>enakey address <hostname or IP address> keyfile <file name> protocol tftp sftp mgt</pre> <p>Unlocks the software port expansion feature. You are prompted to enter the host name or IP address of the server where the license key is stored, and the license key file name, as follows:</p> <ul style="list-style-type: none"> - 46Port - 64Port <p>Note: You must upgrade to 46Port port mode before you can upgrade to 64Port port mode.</p> <p>Command mode: FOD Key mode</p> <p>Use the following command to perform the same action, regardless the command mode:</p> <pre>copy tftp software-key address <hostname or IP address> keyfile <file name> mgt</pre>
<pre>ptkey address <hostname or IP address> key <feature name> protocol tftp sftp file <file name> mgt</pre> <p>Loads the specified key file to a server.</p> <p>Command mode: FOD Key mode</p> <p>Use the following command to perform the same action, regardless the command mode:</p> <pre>copy software-key address <hostname or IP address> key <file name> protocol tftp sftp file <file name> mgt</pre>
<pre>invkeys address <hostname or IP address> invfile <file name> protocol tftp sftp mgt</pre> <p>Loads key code inventory information to a server.</p> <p>Command mode: FOD Key mode</p> <p>Use the following command to perform the same action, regardless the command mode:</p> <pre>copy invkeys address <hostname or IP address> invfile <file name> protocol tftp sftp mgt</pre>

Table 366. Feature on Demand Key Options

Command Syntax and Usage
<pre>rmkey key <feature name></pre> <p>Removes the specified software feature. Command mode: FOD Key mode</p>
<pre>show software-key</pre> <p>Removes the specified software feature. Command mode: All</p>
<pre>exit</pre> <p>Exit from Feature on Demand Key mode. Command mode: FOD Key mode</p>

Edge Virtual Bridge Operations

Edge Virtual Bridge operations commands are listed in the following table:

Table 367. Edge Virtual Bridge Operations Commands

Command Syntax and Usage
<pre>virt evb update vsidb <VSIDB_number></pre> <p>Update VSI types from the VSI database.</p> <p>Command mode: All</p>
<pre>clear virt evb vsidb [mgrid <0-255> typeid <1-16777215> version <0-255>]</pre> <p>Clears local VSI types cache.</p> <p>Command mode: Privileged EXEC</p>
<pre>clear virt evb vsi [mac-address port <port alias or number> type-id <1-16777215> vlan <1-4094>]</pre> <p>Clears VSI database associations.</p> <p>Command mode: Privileged EXEC</p>

Chapter 6. Boot Options

To use the Boot Options commands, you must be logged in to the switch as the administrator. The Boot Options commands provide options for:

- Selecting a switch software image to be used when the switch is next reset
- Selecting a configuration block to be used when the switch is next reset
- Downloading or uploading a new software image to the switch via FTP/TFTP

In addition to the Boot commands, you can use a Web browser or SNMP to work with switch image and configuration files. To use SNMP, refer to “Working with Switch Images and Configuration Files” in the *Command Reference*.

The boot options are discussed in the following sections.

Stacking Boot Options

The Stacking Boot options are used to define the role of the switch in a stack: either as the Master that controls the stack, or as a participating Member switch. Options are available for loading stack software to individual Member switches, and to configure the VLAN that is reserved for inter-switch stacking communications.

You must enable Stacking and reset the switch to enter Stacking mode. When the switch enters Stacking mode, the Stacking configuration menu appears. For more information, see “Stacking Configuration” on page 290.

Table 368 lists the Boot Stacking command options.

Table 368. Boot Stacking Options

Command Syntax and Usage
<pre>boot stack mode [master member] [<1-16> all backup master]</pre> <p>Configures the Stacking mode for the selected switch. This can be applied for:</p> <ul style="list-style-type: none">– a specific unit <1-16>– all units– backup unit– master unit <p>Command mode: Global configuration</p>
<pre>boot stack higr-trunk <list of ports></pre> <p>Configures the ports used to connect the switch to the stack.</p> <p>Command mode: Global configuration</p>
<pre>boot stack vlan <VLAN number></pre> <p>Configures the VLAN used for Stacking control communication.</p> <p>Command mode: Global configuration</p>
<pre>default boot stack [master backup <asnum (1-16)> all]</pre> <p>Resets the Stacking boot parameters to their default values.</p> <p>Command mode: Global configuration</p>

Table 368. Boot Stacking Options (continued)

Command Syntax and Usage	
<code>boot stack push-image {image1 image2 boot} <asnum (1-16)></code>	Pushes the selected software file from the master to the selected switch. Command mode: Global configuration
<code>boot stack enable</code>	Enables the switch stack. Command mode: Global configuration
<code>no boot stack enable</code>	Disables the switch stack. Command mode: Global configuration
<code>show boot stack [master backup <asnum (1-16)> all]</code>	Displays current Stacking boot parameters. Command mode: All

When in stacking mode, the following stand-alone features are not supported:

- Active Multi-Path Protocol (AMP)
- SFD
- sFlow port monitoring
- Uni-Directional Link Detection (UDLD)
- Port flood blocking
- BCM rate control
- Private VLANs
- RIP
- OSPF and OSPFv3
- IPv6
- Virtual Router Redundancy Protocol (VRRP)
- Loopback Interfaces
- Router IDs
- Route maps
- Border Gateway Protocol (BGP)
- MAC address notification
- Static MAC address adding
- Static multicast
- MSTP and RSTP settings for CIST, Name, Rev, and Maxhop
- IGMP Relay and IGMPv3
- Static multicast routes
- IGMP Querier
- Microburst detection

Switch menus and commands for unsupported features may be unavailable, or may have no effect on switch operation.

Scheduled Reboot

This feature allows you to schedule a reboot to occur at a particular time in the future. This feature is particularly helpful if the user needs to perform switch upgrades during off-peak hours. You can set the reboot time, cancel a previously scheduled reboot, and check the time of the currently set reboot schedule.

Table 369. Boot Scheduling Options

Command Syntax and Usage	
<code>boot schedule <day of week> <time of day></code>	Defines the reboot schedule. Enter the day of the week, followed by the time of day (in hh:mm format). For example: <code>boot schedule monday 11:30</code> Command mode: Global configuration
<code>no boot schedule</code>	Cancels the next pending scheduled reboot. Command mode: Global configuration
<code>show boot</code>	Displays the current reboot scheduling parameters. Command mode: All

Netboot Configuration

Netboot allows the switch to automatically download its configuration file over the network during switch reboot, and apply the new configuration. Upon reboot, the switch includes the following options in its DHCP requests:

- Option 66 (TFTP server address)
- Option 67 (file path)

If the DHCP server returns the information, the switch initiates a TFTP file transfer, and loads the configuration file into the active configuration block. As the switch boots up, it applies the new configuration file. Note that the option 66 TFTP server address must be specified in IP-address format (host name is not supported).

If DHCP is not enabled, or the DHCP server does not return the required information, the switch uses the manually-configured TFTP server address and file path.

Table 370. Netboot Options (/boot/netboot)

Command Syntax and Usage	
<code>boot netboot enable</code>	Enables Netboot. When enabled, the switch boots into factory-default configuration, and attempts to download a new configuration file. Command mode: Global configuration
<code>no boot netboot enable</code>	Disables Netboot. Command mode: Global configuration
<code>[no] boot netboot tftp <IP address></code>	Configures the IP address of the TFTP server used for manual configuration. This server is used if DHCP is not enabled, or if the DHCP server does not return the required information. Command mode: Global configuration
<code>[no] boot netboot cfgfile <1-31 characters></code>	Defines the file path for the configuration file on the TFTP server. For example: <code>/directory/sub/config.cfg</code> Command mode: Global configuration
<code>show boot</code>	Displays the current Netboot parameters. Command mode: All

Flexible Port Mapping

Depending on the license keys installed on the switch, only a limited number of physical ports might be active. Flexible Port Mapping allows you to alter the default configuration set up by the license, by manually setting up which ports are active or inactive.

Active ports may not collectively exceed the bandwidth limit imposed by the current license level.

Table 195 lists the Flexible Port Mapping command options.

Table 371. Flexible Port Mapping Options

Command Syntax and Usage	
<code>[no] boot port-map <port no.></code>	Enables or disables the specified ports. Command mode: Global configuration
<code>default boot port-map</code>	Reverts the port mapping to the default licensed configuration. Command mode: Global configuration
<code>show boot port-map</code>	Displays the total bandwidth available, current port mapping and configured port mapping. Command mode: All

The switch must be reset for port mapping changes to take effect.

QSFP Port Configuration

Quad Small Form-factor Pluggable Plus (QSFP+) ports are designed to handle high-intensity traffic. Use the following commands to configure QSFP+ ports.

Table 372. Netboot Options (/boot/qsfp-40Gports)

Command Syntax and Usage
<pre>[no] boot qsfp-40Gports <ports></pre> <p>Enables or disables 40GbE mode on the selected QSFP+ ports. When enabled, each QSFP+ port is set as a single 40GbE port. When disabled, each QSFP+ port is configured to breakout into four 10GbE ports.</p> <p>You must reboot the switch for this change to take effect.</p> <p>Command mode: Global configuration</p>
<pre>show boot qsfp-port-modes</pre> <p>Displays the current QSFP port settings.</p> <p>Command mode: All</p>

Updating the Switch Software Image

The switch software image is the executable code running on the CN4093 10Gb Converged Scalable Switch. A version of the image ships with the switch, and comes pre-installed on the device. As new versions of the image are released, you can upgrade the software running on your switch. To get the latest version of software available for your CN4093, go to:

<http://www-304.ibm.com/jct01004c/systems/support>

Click on software updates. Use the following command to determine the current software version: `show boot`

Upgrading the software image on your switch requires the following:

- Loading the new image onto a FTP or TFTP server on your network
- Transferring the new image from the FTP or TFTP server to your switch
- Selecting the new software image to be loaded into switch memory the next time the switch is reset

Loading New Software to Your Switch

The switch can store up to two different software images, called `image1` and `image2`, as well as boot software, called `boot`. When you load new software, you must specify where it should be placed: either into `image1`, `image2`, or `boot`.

For example, if your active image is currently loaded into `image1`, you would probably load the new image software into `image2`. This lets you test the new software and reload the original active image (stored in `image1`), if needed.

To load a new software image to your switch, you need the following:

- The image or boot software loaded on an FTP/TFTP server on your network
- The hostname or IP address of the FTP/TFTP server
- The name of the new software image or boot file

Note: The DNS parameters must be configured if specifying hostnames.

When the above requirements are met, use the following procedure to download the new software to your switch.

1. In Privileged EXEC mode, enter the following command:

```
Router# copy {ftp|tftp} {image1|image2|boot-image[extm-port|  
mgt-port|data-port]}
```

Select a port, or press <Enter> to use the default (management port).

2. Enter the hostname or IP address of the FTP or TFTP server.

```
Address or name of remote host: <IP address or hostname>
```

3. Enter the name of the new software file on the server.

```
Source file name: <filename>
```

The exact form of the name will vary by server. However, the file location is normally relative to the FTP or TFTP directory (usually `tftpboot`).

4. Enter your username and password for the server, if applicable.

```
User name: {<username> | <Enter>}
```

5. The system prompts you to confirm your request.

Next, select a software image to run, as described in the following section.

Selecting a Software Image to Run

You can select which software image (`image1` or `image2`) you want to run in switch memory for the next reboot.

1. In Global Configuration mode, enter:

```
Router(config)# boot image {image1 | image2}
```

2. Enter the name of the image you want the switch to use upon the next boot.
The system informs you of which image set to be loaded at the next reset:

```
Next boot will use switch software image1 instead of image2.
```

Uploading a Software Image from Your Switch

You can upload a software image from the switch to a FTP or TFTP server.

1. In Privileged EXEC mode, enter:

```
Router# copy {image1 | image2 | boot-image} {ftp | tftp [extm-port |  
mgt-port | data-port]}
```

Select a port, or press `<Enter>` to use the default (management port).

2. Enter the name or the IP address of the FTP or TFTP server:

```
Address or name of remote host: <IP address or hostname>
```

3. Enter the name of the file into which the image will be uploaded on the FTP or TFTP server:

```
Destination file name: <filename>
```

4. Enter your username and password for the server, if applicable.

```
User name: {<username> | <Enter>}
```

5. The system then requests confirmation of what you have entered. To have the file uploaded, enter `Y`.

```
image2 currently contains Software Version 6.5.0
that was downloaded at 0:23:39 Thu Jan 1, 2010
Upload will transfer image2 (2788535 bytes) to file "image1"
on FTP/TFTP server 1.90.90.95.
Confirm upload operation (y/n) ? y
```

Selecting a Configuration Block

When you make configuration changes to the CN4093 10Gb Converged Scalable Switch, you must save the changes so that they are retained beyond the next time the switch is reset. When you perform a save operation (`copy running-config startup-config`), your new configuration changes are placed in the *active* configuration block. The previous configuration is copied into the *backup* configuration block.

There is also a *factory* configuration block. This holds the default configuration set by the factory when your CN4093 10Gb Converged Scalable Switch was manufactured. Under certain circumstances, it may be desirable to reset the switch configuration to the default. This can be useful when a custom-configured CN4093 10Gb Converged Scalable Switch is moved to a network environment where it will be re-configured for a different purpose.

In Global Configuration mode, use the following command to set which configuration block you want the switch to load the next time it is reset:

```
Router (config)# boot configuration-block {active | backup | factory}
```

Resetting the Switch

You can reset the switch to make your software image file and configuration block changes occur.

Note: Resetting the switch causes the Spanning Tree Group to restart. This process can be lengthy, depending on the topology of your network.

Enter the following command to reset (reload) the switch:

```
>> Router# reload
```

You are prompted to confirm your request.

```
Reset will use software "image2" and the active config block.  
>> Note that this will RESTART the Spanning Tree,  
>> which will likely cause an interruption in network service.  
Confirm reload (y/n) ?
```

Accessing the IBM Networking OS CLI

To access the IBM Networking OS CLI, enter the following command from the ISCLI:

```
Router(config)# boot cli-mode ibmnos-cli
```

The default command-line interface for the CN4093 is the IBM Networking OS CLI. To access the ISCLI, enter the following command and reset the CN4093:

```
Main# boot/mode iscli
```

Users can select the CLI mode upon login, if the following ISCLI command is enabled:

```
Router(config)# boot cli-mode prompt
```

Only an administrator connected through the CLI can view and enable the `prompt` command. When `prompt` is enabled, the first user to log in can select the CLI mode. Subsequent users must use the selected CLI mode, until all users have logged out.

Changing the Switch Profile

The IBM Networking OS software for the CN4093 can be configured to operate in different modes for different deployment scenarios. The deployment profile changes some of the basic switch behavior, shifting switch resources to optimize capacity levels to meet the needs of different types of networks. For more information about deployment profiles, see the IBM Networking OS 7.8 *Application Guide*.

To change the deployment profile, select the new profile and reset the CN4093. Use the following command to select a new profile:

```
Router(config)# boot profile {default | acl | ipmc-opt}
```

Using the Boot Management Menu

The Boot Management menu allows you to switch the software image, reset the switch to factory defaults, or to recover from a failed software download.

You can interrupt the boot process and enter the Boot Management menu from the serial console port. When the system displays Memory Test, press **<Shift B>**. The Boot Management menu appears.

```
Resetting the System ...
Memory Test .....

Boot Management Menu
1 - Change booting image
2 - Change configuration block
3 - Xmodem download
4 - Exit

Please choose your menu option: 1
Current boot image is 1. Enter image to boot: 1 or 2: 2
Booting from image 2
```

The Boot Management menu allows you to perform the following actions:

- To change the booting image, press 1 and follow the screen prompts.
- To change the configuration block, press 2, and follow the screen prompts.
- To perform an Xmodem download, press 3 and follow the screen prompts.
- To exit the Boot Management menu, press 4. The booting process continues.

Recovering from a Failed Software Upgrade

Use the following procedure to recover from a failed software upgrade.

1. Connect a PC to the serial port of the switch.
2. Open a terminal emulator program that supports XModem Download (for example, HyperTerminal, CRT, PuTTY) and select the following serial port characteristics:
 - Speed: 9600 bps
 - Data Bits: 8
 - Stop Bits: 1
 - Parity: None
 - Flow Control: None
3. Boot the switch and access the Boot Management menu by pressing **<Shift B>** while the Memory Test is in progress and the dots are being displayed.
4. Select **3** for **Xmodem download**. When you see the following message, change the Serial Port characteristics to 115200 bps:

```
## Switch baudrate to 115200 bps and press ENTER ...
```

5. Press **<Enter>** to set the system into download accept mode. When the readiness meter displays (a series of "C" characters), start XModem on your terminal emulator.

6. Select the Boot Image to download. The XModem initiates the file transfer. When the download is complete, a message similar to the following is displayed:

```
yzModem - CRC mode, 62494 (SOH)/0 (STX)/0 (CAN) packets, 6 retries
Extracting images ... Do *NOT* power cycle the switch.
**** VMLINUX ****
Un-Protected 10 sectors
Erasing Flash..... done
Writing to Flash.....done
Protected 10 sectors
**** RAMDISK ****
Un-Protected 44 sectors
Erasing Flash..... done
Writing to Flash.....done
Protected 44 sectors
**** BOOT CODE ****
Un-Protected 8 sectors
Erasing Flash..... done
Writing to Flash.....done
Protected 8 sectors
```

7. When you see the following message, change the Serial Port characteristics to 9600 bps:

```
## Switch baudrate to 9600 bps and press ESC ...
```

8. Press the Escape key (<Esc>) to re-display the Boot Management menu.
9. Select **3** to start a new **XModem Download**. When you see the following message, change the Serial Port characteristics to 115200 bps:

```
## Switch baudrate to 115200 bps and press ENTER ...
```

10. Press <Enter> to continue the download.

11. Select the OS Image to download. The XModem initiates the file transfer. When the download is complete, a message similar to the following is displayed:

```
yzModem - CRC mode, 27186(SOH)/0(STX)/0(CAN) packets, 6 retries

Extracting images ... Do *NOT* power cycle the switch.

**** Switch OS ****

Please choose the Switch OS Image to upgrade [1|2|n] :
```

12. Select the image number to load the new image (1 or 2). It is recommended that you select 1. A message similar to the following is displayed:

```
Switch OS Image 1 ...

Un-Protected 27 sectors

Erasing Flash..... done

Writing to Flash.....done

Protected 27 sectors
```

13. When you see the following message, change the Serial Port characteristics to 9600 bps:

```
## Switch baudrate to 9600 bps and press ESC ...
```

14. Press the Escape key (<Esc>) to re-display the Boot Management menu.

Select 4 to exit and boot the new image.

Recovering a Failed Boot Image

Use the following procedure to recover from a failed boot image upgrade.

1. Connect a PC to the serial port of the switch.
2. Open a terminal emulator program that supports Xmodem download (for example, HyperTerminal, CRT, PuTTY) and select the following serial port characteristics:
 - Speed: 9600 bps
 - Data Bits: 8
 - Stop Bits: 1
 - Parity: None
 - Flow Control: None
3. Boot the switch and access the Boot Management menu by pressing <Shift B> while the Memory Test is in progress and the dots are being displayed.
4. Select 4 for **Xmodem download**. You will see the following display:

```
Perform xmodem download

To download an image use 1K Xmodem at 115200 bps.
```

5. When you see the following message, change the Serial Port characteristics to 115200 bps:

```
Change the baud rate to 115200 bps and hit the <ENTER> key before
initiating the download.
```

- a. Press **<Enter>** to set the system into download accept mode. When the readiness meter displays (a series of "C" characters), start Xmodem on your terminal emulator. You will see a display similar to the following:

```
Extracting images ... Do *NOT* power cycle the switch.
**** RAMDISK ****
Un-Protected 38 sectors
Erasing Flash...
..... done
Erased 38 sectors
Writing to
Flash...9...8...7...6...5...4...3...2...1... done
Protected 38 sectors
**** KERNEL ****
Un-Protected 24 sectors
Erasing Flash...
..... done
Erased 24 sectors
Writing to Flash...9...8...7...6...5...4...3...2...1...
```

- b. When you see the following message, change the Serial Port characteristics to 9600 bps:

```
Change the baud rate back to 9600 bps, hit the <ESC> key.
```

Boot image recovery is complete.

Chapter 7. Maintenance Commands

The maintenance commands are used to manage dump information and forward database information. They also include debugging commands to help with troubleshooting.

Dump information contains internal switch state data that is written to flash memory on the CN4093 10Gb Converged Scalable Switch after any one of the following occurs:

- The watchdog timer forces a switch reset. The purpose of the watchdog timer is to reboot the switch if the switch software freezes.
- The switch detects a hardware or software problem that requires a reboot.

To use the maintenance commands, you must be logged in to the switch as the administrator.

Table 373. General Maintenance Commands

Command Syntax and Usage
<pre>show flash-dump-uuencode</pre> <p>Displays dump information in uuencoded format. For details, see page 542.</p> <p>Command mode: All</p>
<pre>copy flash-dump tftp</pre> <p>Saves the system dump information via TFTP. For details, see page 543.</p> <p>Command mode: All except User EXEC</p>
<pre>copy flash-dump ftp</pre> <p>Saves the system dump information via FTP. For details, see page 543.</p> <p>Command mode: All except User EXEC</p>
<pre>copy flash-dump sftp</pre> <p>Saves the system dump information via SFTP. For details, see page 543.</p> <p>Command mode: All except User EXEC</p>
<pre>clear flash-dump</pre> <p>Clears dump information from flash memory.</p> <p>Command mode: All except User EXEC</p>
<pre>show tech-support [l2 l3 link port]</pre> <p>Dumps all CN4093 information, statistics, and configuration. You can log the output (<code>tsdmp</code>) into a file. To filter the information, use the following options:</p> <ul style="list-style-type: none">– <code>l2</code> displays only Layer 2-related information– <code>l3</code> displays only Layer 3-related information– <code>link</code> displays only link status-related information– <code>port</code> displays only port-related information <p>Command mode: All except User EXEC</p>

Table 373. General Maintenance Commands

Command Syntax and Usage
<pre>copy tech-support tftp</pre> <p>Redirects the technical support dump (tsdmp) to an external TFTP server.</p> <p>Command mode: All except User EXEC</p>
<pre>copy tech-support ftp</pre> <p>Redirects the technical support dump (tsdmp) to an external FTP server.</p> <p>Command mode: All except User EXEC</p>

Forwarding Database Maintenance

The Forwarding Database commands can be used to view information and to delete a MAC address from the forwarding database or to clear the entire forwarding database. This is helpful in identifying problems associated with MAC address learning and packet forwarding decisions.

Table 374. FDB Manipulation Commands

Command Syntax and Usage
<pre>show mac-address-table address <MAC address></pre> <p>Displays a single database entry by its MAC address. If not specified, you are prompted for the MAC address of the device. Enter the MAC address using one of the following formats:</p> <ul style="list-style-type: none"> – xx:xx:xx:xx:xx:xx (such as 08:00:20:12:34:56) – xxxxxxxxxxxxxx (such as 080020123456) <p>Command mode: All except User EXEC</p>
<pre>show mac-address-table interface port <port number or alias></pre> <p>Displays all FDB entries for a particular port.</p> <p>Command mode: All except User EXEC</p>
<pre>show mac-address-table portchannel <trunk group number></pre> <p>Displays all FDB entries for a particular trunk group.</p> <p>Command mode: All</p>
<pre>show mac-address-table private-vlan <VLAN number></pre> <p>Displays all FDB entries on a single private VLAN.</p> <p>Command mode: All</p>
<pre>show mac-address-table vlan <VLAN number></pre> <p>Displays all FDB entries on a single VLAN.</p> <p>Command mode: All except User EXEC</p>
<pre>show mac-address-table state {forward trunk unknown}</pre> <p>Displays all FDB entries of a particular state.</p> <p>Command mode: All except User EXEC</p>
<pre>show mac-address-table static</pre> <p>Displays static entries in the FDB.</p> <p>Command mode: All except User EXEC</p>
<pre>no mac-address-table static {<MAC address> all}</pre> <p>Removes static FDB entries.</p> <p>Command mode: All except User EXEC</p>
<pre>no mac-address-table multicast {<MAC address> all}</pre> <p>Removes static multicast FDB entries.</p> <p>Command mode: All except User EXEC</p>

Table 374. FDB Manipulation Commands (continued)

Command Syntax and Usage
<pre>clear mac-address-table static</pre> <p>Clears all static entries from the Forwarding Database.</p> <p>Command mode: All except User EXEC</p>
<pre>clear mac-address-table</pre> <p>Clears the entire Forwarding Database from switch memory.</p> <p>Command mode: All except User EXEC</p>

Debugging Commands

The Miscellaneous Debug Commands display trace buffer information about events that can be helpful in understanding switch operation. You can view the following information using the debug commands:

- Events traced by the Management Processor (MP)
- Events traced to a buffer area when a reset occurs

Note: IBM Networking OS debug commands are intended for advanced users. Use debug commands with caution as they can disrupt the operation of the switch under high load conditions. When debug is running under high load conditions, the CLI prompt may appear unresponsive. Before debugging, check the MP utilization to verify there is sufficient processing capacity available to perform the debug operation.

If the switch resets for any reason, the MP trace buffer is saved into the snap trace buffer area. The output from these commands can be interpreted by Technical Support personnel.

Table 375. Miscellaneous Debug Commands

Command Syntax and Usage
<code>debug debug-flags</code> This command sets the flags that are used for debugging purposes. Command mode: All except User EXEC
<code>debug mp-trace</code> Displays the Management Processor trace buffer. Header information similar to the following is shown: MP trace buffer at 13:28:15 Fri May 25, 2001; mask: 0x2ffdf748 The buffer information is displayed after the header. Command mode: All except User EXEC
<code>debug dumpbt</code> Displays the backtrace log. Command mode: All except User EXEC
<code>debug mp-snap</code> Displays the Management Processor snap (or post-mortem) trace buffer. This buffer contains information traced at the time that a reset occurred. Command mode: All except User EXEC
<code>clear flash-config</code> Deletes all flash configuration blocks. Command mode: All except User EXEC

Table 375. Miscellaneous Debug Commands

Command Syntax and Usage
<p>[no] debug lacp packet [receive transmit both] [port <port numbers>]</p> <p>Enables/disables debugging for Link Aggregation Control Protocol (LACP) packets on all ports running LACP.</p> <p>The following parameters are available:</p> <ul style="list-style-type: none"> – receive filters only LACP packets received – transmit filters only LACP packets sent – both filters LACP packets either sent or received – port filters LACP packets sent/received on specific ports <p>By default, LACP debugging is disabled.</p> <p>Command mode: Privileged EXEC</p>
<p>[no] debug spanning-tree bpdu [receive transmit]</p> <p>Enables/disables debugging for Spanning Tree Protocol (STP) Bridge Protocol Data Unit (BPDU) frames sent or received.</p> <p>The following parameters are available:</p> <ul style="list-style-type: none"> – receive filters only BPDU frames received – transmit filters only BPDU frames sent <p>By default, STP BPDU debugging is disabled.</p> <p>Command mode: Privileged EXEC</p>

IP Security Debugging

The following table describes the options available.

Table 376. IP Security Debug Options

Command Syntax and Usage
<p>[no] debug sec all</p> <p>Enables or disables all IP security debug messages.</p>
<p>[no] debug sec crypto</p> <p>Enables or disables all IP security cryptographic debug messages.</p>
<p>[no] debug sec ike</p> <p>Enables or disables all IP security IKEv2 debug messages.</p>
<p>[no] debug sec ipsec</p> <p>Enables or disables all IPsec debug messages.</p>
<p>[no] debug sec info</p> <p>Displays the current security debug settings.</p>

DCBX Debugging Commands

Table 377. DCBX Maintenance Commands

Command Syntax and Usage
<pre>show dcbx transmit <port alias or number></pre> <p>Displays the Type-Length-Value (TLV) list transmitted in the DCBX TLV.</p> <p>Command mode: All except User EXEC</p>
<pre>show dcbx receive <port alias or number></pre> <p>Displays the Type-Length-Value (TLV) list received in the DCBX TLV.</p> <p>Command mode: All except User EXEC</p>

ARP Cache Maintenance

Table 378. Address Resolution Protocol Maintenance Commands

Command Syntax and Usage
<pre>show ip arp find <IP address></pre> <p>Shows a single ARP entry by IP address. Command mode: All except User EXEC</p>
<pre>show ip arp interface port <port number or alias></pre> <p>Shows ARP entries on selected ports. Command mode: All except User EXEC</p>
<pre>show ip arp vlan <VLAN number></pre> <p>Shows ARP entries on a single VLAN. Command mode: All except User EXEC</p>
<pre>show ip arp reply</pre> <p>Shows the list of IP addresses which the switch will respond to for ARP requests. Command mode: All except User EXEC</p>
<pre>show ip arp</pre> <p>Shows all ARP entries. Command mode: All except User EXEC</p>
<pre>clear arp</pre> <p>Clears the entire ARP list from switch memory. Command mode: All except User EXEC</p>

Note: To display all or a portion of ARP entries currently held in the switch, you can also refer to “ARP Information” on [page 63](#).

IP Route Manipulation

Table 379. IP Route Manipulation Commands

Command Syntax and Usage
<pre>show ip route address <IP address></pre> <p>Shows a single route by destination IP address. Command mode: All except User EXEC</p>
<pre>show ip route gateway <IP address></pre> <p>Shows routes to a default gateway. Command mode: All except User EXEC</p>
<pre>show ip route type {indirect direct local broadcast martian multicast}</pre> <p>Shows routes of a single type. Command mode: All except User EXEC For a description of IP routing types, see Table 37 on page 62</p>
<pre>show ip route tag {fixed static address rip ospf bgp broadcast martian multicast}</pre> <p>Shows routes of a single tag. Command mode: All except User EXEC For a description of IP routing tags, see Table 38 on page 62</p>
<pre>show ip route interface <IP interface></pre> <p>Shows routes on a single interface. Command mode: All except User EXEC</p>
<pre>show ip route</pre> <p>Shows all routes. Command mode: All except User EXEC</p>
<pre>clear ip route</pre> <p>Clears the route table from switch memory. Command mode: All except User EXEC</p>

Note: To display all routes, you can also refer to [“IP Routing Information” on page 61](#).

LLDP Cache Manipulation

[Table 380](#) describes the LLDP cache manipulation commands.

Table 380. LLDP Cache Manipulation commands

Command Syntax and Usage
<pre>show lldp port <port alias or number></pre> <p>Displays Link Layer Discovery Protocol (LLDP) port information.</p> <p>Command mode: All</p>
<pre>show lldp receive</pre> <p>Displays information about the LLDP receive state machine.</p> <p>Command mode: All</p>
<pre>show lldp transmit</pre> <p>Displays information about the LLDP transmit state machine.</p> <p>Command mode: All</p>
<pre>show lldp remote-device [<I-256> detail]</pre> <p>Displays information received from LLDP -capable devices. For more information, see page 45.</p> <p>Command mode: All</p>
<pre>show lldp</pre> <p>Displays all LLDP information.</p> <p>Command mode: All</p>
<pre>clear lldp</pre> <p>Clears the LLDP cache.</p> <p>Command mode: All</p>

IGMP Group Maintenance

Table 381 describes the IGMP group maintenance commands.

Table 381. IGMP Multicast Group Maintenance Commands

Command Syntax and Usage
<pre>show ip igmp groups address <IP address></pre> <p>Displays a single IGMP multicast group by its IP address.</p> <p>Command mode: All</p>
<pre>show ip igmp groups vlan <VLAN number></pre> <p>Displays all IGMP multicast groups on a single VLAN.</p> <p>Command mode: All</p>
<pre>show ip igmp groups interface port <port number or alias></pre> <p>Displays all IGMP multicast groups on selected ports.</p> <p>Command mode: All</p>
<pre>show ip igmp groups portchannel <trunk number></pre> <p>Displays all IGMP multicast groups on a single trunk group.</p> <p>Command mode: All</p>
<pre>show ip igmp groups detail <IP address></pre> <p>Displays detailed information about a single IGMP multicast group.</p> <p>Command mode: All</p>
<pre>show ip igmp groups</pre> <p>Displays information for all multicast groups.</p> <p>Command mode: All</p>
<pre>clear ip igmp groups</pre> <p>Clears the IGMP group table.</p> <p>Command mode: All except User EXEC</p>

IGMP Multicast Routers Maintenance

The following table describes the maintenance commands for IGMP multicast routers (Mrouters).

Table 382. IGMP Multicast Router Maintenance Commands

Command Syntax and Usage
<pre>show ip igmp mrouter vlan <VLAN number></pre> <p>Displays IGMP Mrouter information for a single VLAN.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter</pre> <p>Displays information for all Mrouters.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter dynamic</pre> <p>Displays all dynamic multicast router ports installed.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter static</pre> <p>Displays all static multicast router ports installed.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter interface port <port alias or number></pre> <p>Displays all multicast router ports installed on a specific port.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter portchannel <trunk number></pre> <p>Displays all multicast router ports installed on a specific portchannel group.</p> <p>Command mode: All</p>
<pre>show ip igmp mrouter information</pre> <p>Displays IGMP snooping information for all Mrouters.</p> <p>Command mode: All</p>
<pre>show ip igmp snoop igmpv3</pre> <p>Displays IGMPv3 snooping information.</p> <p>Command mode: All</p>
<pre>show ip igmp relay</pre> <p>Displays IGMP relay information.</p> <p>Command mode: All</p>
<pre>clear ip igmp mrouter</pre> <p>Clears the IGMP Mrouter port table.</p> <p>Command mode: All except User EXEC</p>

MLD Multicast Group Manipulation

Table 383 describes the Multicast Listener Discovery (MLD) manipulation options.

Table 383. MLD Maintenance

Command Syntax and Usage
<pre>show ipv6 mld groups</pre> <p>Shows all MLD groups. Command mode: All</p>
<pre>show ipv6 mld interface <interface number></pre> <p>Shows MLD groups on the specified interface. Command mode: All</p>
<pre>clear ipv6 mld mrouter</pre> <p>Clears all dynamic MLD multicast router group tables. Command mode: All except User EXEC</p>
<pre>clear ipv6 mld groups</pre> <p>Clears all dynamic MLD registered group tables. Command mode: All except User EXEC</p>
<pre>clear ipv6 mld dynamic</pre> <p>Clears all dynamic MLD group tables. Command mode: All except User EXEC</p>

IPv6 Neighbor Discovery Cache Manipulation

Table 384 describes the IPv6 Neighbor Discovery cache manipulation commands.

Table 384. IPv6 Neighbor Discovery cache manipulation commands

Command Syntax and Usage
<pre>show ipv6 neighbors find <IPv6 address></pre> <p>Shows a single IPv6 Neighbor Discovery cache entry by IP address.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors interface port <port number or alias></pre> <p>Shows IPv6 Neighbor Discovery cache entries on a single port.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors vlan <VLAN number></pre> <p>Shows IPv6 Neighbor Discovery cache entries on a single VLAN.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors static</pre> <p>Shows static IPv6 Neighbor Discovery cache entries.</p> <p>Command mode: All</p>
<pre>show ipv6 neighbors</pre> <p>Shows all IPv6 Neighbor Discovery cache entries.</p> <p>Command mode: All</p>
<pre>clear ipv6 neighbors</pre> <p>Clears all IPv6 Neighbor Discovery cache entries from switch memory.</p> <p>Command mode: All except User EXEC</p>

IPv6 Route Maintenance

Table 385 describes the IPv6 route maintenance commands.

Table 385. IPv6 Route Maintenance Options

Command Syntax and Usage
<pre>show ipv6 route address <IPv6 address></pre> <p>Show a single route by destination IP address. Command mode: All</p>
<pre>show ipv6 route gateway <IPv6 gateway number></pre> <p>Show routes to a single gateway. Command mode: All</p>
<pre>show ipv6 route interface <interface number></pre> <p>Show routes on a single IP interface. Command mode: All</p>
<pre>show ipv6 route type {connected static ospf}</pre> <p>Show routes of a single type. Command mode: All</p>
<pre>show ipv6 route static</pre> <p>Show static IPv6 routes. Command mode: All</p>
<pre>show ipv6 route summary</pre> <p>Shows a summary of IPv6 route information. Command mode: All</p>
<pre>show ipv6 route</pre> <p>Shows all IPv6 routes. Command mode: All</p>
<pre>clear ipv6 route</pre> <p>Clears all IPv6 routes. Command mode: Privileged EXEC</p>

Uuencode Flash Dump

Using this command, dump information is presented in uuencoded format. This format makes it easy to capture the dump information as a file or a string of characters.

If you want to capture dump information to a file, set your communication software on your workstation to capture session data prior to issuing the `show flash-dump-uuencode` command. This will ensure that you do not lose any information. Once entered, the `show flash-dump-uuencode` command will cause approximately 23,300 lines of data to be displayed on your screen and copied into the file.

Using the `show flash-dump-uuencode` command, dump information can be read multiple times. The command does not cause the information to be updated or cleared from flash memory.

Note: Dump information is not cleared automatically. In order for any subsequent dump information to be written to flash memory, you must manually clear the dump region. For more information on clearing the dump region, see [page 544](#).

To access dump information, enter:

```
Router# show flash-dump-uuencode
```

The dump information is displayed on your screen and, if you have configured your communication software to do so, captured to a file. If the dump region is empty, the following appears:

```
No FLASH dump available.
```

TFTP, SFTP or FTP System Dump Put

Use these commands to put (save) the system dump to a TFTP or FTP server.

Note: If the TFTP/FTP server is running SunOS or the Solaris operating system, the specified `copy flash-dump tftp` (or `ftp`) file must exist *prior* to executing the `copy flash-dump tftp` command (or `copy flash-dump ftp`), and must be writable (set with proper permission, and not locked by any application). The contents of the specified file will be replaced with the current dump data.

To save dump information via TFTP, enter:

```
Router# copy flash-dump tftp [data-port|extm-port|mgt-port] <server filename>
```

You are prompted for the TFTP server IP address or hostname, and the *filename* of the target dump file.

To save dump information via SFTP, enter:

```
Router# copy flash-dump sftp [data-port|extm-port|mgt-port] <server filename>
```

You are prompted for the SFTP server IP address or hostname, your *username* and *password*, and the *filename* of the target dump file.

To save dump information via FTP, enter:

```
Router# copy flash-dump ftp [data-port|extm-port|mgt-port] <server filename>
```

You are prompted for the FTP server IP address or hostname, your *username* and *password*, and the *filename* of the target dump file.

Clearing Dump Information

To clear dump information from flash memory, enter:

```
Router# clear flash-dump
```

The switch clears the dump region of flash memory and displays the following message:

```
FLASH dump region cleared.
```

If the flash dump region is already clear, the switch displays the following message:

```
FLASH dump region is already clear.
```

Unscheduled System Dumps

If there is an unscheduled system dump to flash memory, the following message is displayed when you log on to the switch:

```
Note: A system dump exists in FLASH. The dump was saved
      at 13:43:22 Wednesday January 30, 2010. Use show flash-dump
      uuencode to
      extract the dump for analysis and clear flash-dump to
      clear the FLASH region. The region must be cleared
      before another dump can be saved.
```

Appendix A. IBM Networking OS System Log Messages

The CN4093 10Gb Converged Scalable Switch (CN4093) uses the following syntax when outputting system log (syslog) messages:

<Time stamp> <IP/Hostname><Log Label>IBMOS<Thread ID> : <Message>

The following parameters are used:

- *<Timestamp>*

The time of the message event is displayed in the following format:

<month (3 characters)> <day> <hour (1-24)> : <minute> : <second>

For example: Aug 19 14 : 20 : 30

- *<IP/Hostname>*

The hostname is displayed when configured.

For example: 1.1.1.1

- *<Log Label>*

The following types of log messages are recorded: LOG_CRIT, LOG_WARNING, LOG_ALERT, LOG_ERR, LOG_NOTICE, and LOG_INFO

- *<Thread ID>*

This is the software thread that reports the log message. For example:

stg, ip, console, telnet, vrrp, system, web server, ssh, bgp

- *<Message>*: The log message

Following is a list of potential syslog messages. To keep this list as short as possible, only the *<Thread ID>* and *<Message>* are shown. The messages are sorted by *<Log Label>*.

Where the *<Thread ID>* is listed as `mgmt`, one of the following may be shown: `console`, `telnet`, `web server`, or `ssh`.

LOG_ALERT

Thread	LOG_ALERT Message
	Possible buffer overrun attack detected!
BGP	session with <IP address> failed (bad event:<event>)
BGP	session with <IP address> failed <reason> Reasons: <ul style="list-style-type: none"> • Connect Retry Expire • Holdtime Expire • Invalid • Keepalive Expire • Receive KEEPALIVE • Receive NOTIFICATION • Receive OPEN • Receive UPDATE • Start • Stop • Transport Conn Closed • Transport Conn Failed • Transport Conn Open • Transport Fatal Error
HOTLINKS	LACP trunk <trunk ID> and <trunk ID> formed with admin key <key>
IP	cannot contact default gateway <IP address>
IP	Route table full
MGMT	Maximum number of login failures (<threshold>) has been exceeded.
OSPF	Interface IP <IP address>, Interface State {Down Loopback Waiting P To P DR BackupDR DR Other}: Interface down detached
OSPF	LS Database full: likely incorrect/missing routes or failed neighbors
OSPF	Neighbor Router ID <router ID>, Neighbor State {Down Attempt Init 2 Way ExStart Exchange Loading Full Loopback Waiting P To P DR BackupDR DR Other}
OSPF	OSPF Route table full: likely incorrect/missing routes
STP	CIST new root bridge
STP	CIST topology change detected
STP	own BPDU received from port <port>
STP	Port <port>, putting port into blocking state
STP	STG <STG>, new root bridge
STP	STG <STG>, topology change detected
SYSTEM	LACP trunk <trunk ID> and <trunk ID> formed with admin key <key>
VRRP	Received <x> virtual routers instead of <y>

Thread	LOG_ALERT Message (continued)
VRRP	received errored advertisement from <IP address>
VRRP	received incorrect addresses from <IP address>
VRRP	received incorrect advertisement interval <interval> from <IP address>
VRRP	received incorrect VRRP authentication type from <IP address>
VRRP	received incorrect VRRP password from <IP address>
VRRP	VRRP : received incorrect IP addresses list from <IP address>

LOG_CRIT

Thread	LOG_CRIT Message
SSH	can't allocate memory in load_MP_INT()
SSH	currently not enough resource for loading RSA {private public key}
SYSTEM	System memory is at <n> percent

LOG_ERR

Thread	LOG_ERR Message
CFG	Configuration file is EMPTY
CFG	Configuration is too large
CFG	Default VLAN cannot be a private-VLAN.
CFG	Error writing active config to FLASH! Configuration is too large
CFG	Error writing active config to FLASH! Unknown error
CFG	TFTP {Copy cfgRcv} attempting to redirect a previously redirected output
MGMT	Apply is issued by another user. Try later
MGMT	Critical Error. Failed to add Interface <interface>
MGMT	Diff is issued by another user. Try later
MGMT	Dump is issued by another user. Try later
MGMT	Error: Apply not done
MGMT	Error: Save not done.
MGMT	Firmware download failed (insufficient memory
MGMT	Revert Apply is issued by another user. Try later
MGMT	Revert is issued by another user. Try later.
MGMT	Save is issued by another user. Try later
NTP	unable to listen to NTP port
STP	Cannot set "{Hello Time Max Age Forward Delay Aging}" (Switch is in MSTP mode)
SYSTEM	Error: BOOTP Offer was found incompatible with the other IP interfaces
SYSTEM	I2C device <ID> <description> set to access state <state> [from CLI]
SYSTEM	Not enough memory!

LOG_INFO

Thread	LOG_INFO Message
	System log cleared by user <i><username></i> .
	System log cleared via SNMP.
HOTLINKS	"Error" is set to "{Active Standby}"
HOTLINKS	"Learning" is set to "{Active Standby}"
HOTLINKS	"None" is set to "{Active Standby}"
HOTLINKS	"Side Max" is set to "{Active Standby}"
HOTLINKS	has no "{Side Max None Learning Error}" interface
MGMT	/* Config changes at <i><time></i> by <i><username></i> */ <i><config diff></i> /* Done */
MGMT	<i><username></i> ejected from BBI
MGMT	<i><username></i> (<i><user type></i>) {logout ejected idle timeout connection closed} from {Console Telnet/SSH}
MGMT	<i><username></i> (<i><user type></i>) login {on Console from host <i><IP address></i> }
MGMT	boot kernel download completed. Now writing to flash.
MGMT	boot kernel downloaded {from host <i><hostname></i> via browser}, filename too long to be displayed, software version <i><version></i>
MGMT	boot kernel downloaded from host <i><hostname></i> , file ' <i><filename></i> ', software version <i><version></i>
MGMT	Can't downgrade to image with only single flash support
MGMT	Could not revert unsaved changes
MGMT	Download already currently in progress. Try again later via {Browser BBI}
MGMT	Error in setting the new config
MGMT	Failed to allocate buffer for diff track.
MGMT	Firmware download failed to {invalid image image1 image2 boot kernel undefined SP boot kernel}
MGMT	Firmware downloaded to {invalid image image1 image2 boot kernel undefined SP boot kernel}.
MGMT	Flash dump successfully tftp'd to <i><hostname></i> : <i><filename></i>
MGMT	FLASH ERROR - invalid address used
MGMT	Flash Read Error. Failed to read flash into holding structure. Quitting

Thread	LOG_INFO Message (continued)
MGMT	Flash Write Error
MGMT	Flash Write Error. Failed to allocate buffer. Quitting
MGMT	Flash Write Error. Trying again
MGMT	image1 2 download completed. Now writing to flash.
MGMT	image1 2 downloaded {from host <hostname> via browser}, filename too long to be displayed, software version <version>
MGMT	image1 2 downloaded from host <hostname>, file '<filename>', software version <version>
MGMT	Incorrect image being loaded
MGMT	Invalid diff track address. Continuing with apply()
MGMT	Invalid image being loaded for this switch type
MGMT	invalid image download completed. Now writing to flash.
MGMT	invalid image downloaded {from host <hostname> via browser}, filename too long to be displayed, software version <version>
MGMT	invalid image downloaded from host <hostname>, file '<filename>', software version <version>
MGMT	New config set
MGMT	new configuration applied [from BBI EM SCP SNMP Stacking Master]
MGMT	new configuration saved from {BBI ISCLI SNMP}
MGMT	scp<username>(<user type>) {logout ejected idle timeout connection closed} from {Console Telnet/SSH}
MGMT	scp<username>(<user type>) login {on Console from host <IP address>}
MGMT	SP boot kernel download completed. Now writing to flash.
MGMT	SP boot kernel downloaded {from host <hostname> via browser}, filename too long to be displayed, software version <version>
MGMT	SP boot kernel downloaded from host <hostname>, file '<filename>', software version <version>
MGMT	Starting Firmware download for {invalid image image1 image2 boot kernel undefined SP boot kernel}.
MGMT	Static FDB entry on disabled VLAN
MGMT	Tech support dump failed
MGMT	Tech support dump successfully tftp'd to <hostname>:<filename>
MGMT	Two Phase Apply Failed in Creating Backup Config Block.

Thread	LOG_INFO Message (continued)
MGMT	undefined download completed. Now writing to flash.
MGMT	undefined downloaded {from host <hostname> via browser}, filename too long to be displayed, software version <version>
MGMT	undefined downloaded from host <hostname>, file '<filename>', software version <version>
MGMT	unsaved changes reverted [from BBI from SNMP]
MGMT	Unsupported GBIC {accepted refused}
MGMT	user {SNMP user <username>} ejected from BBI
MGMT	Watchdog has been {enabled disabled}
MGMT	Watchdog timeout interval is now <seconds> seconds)
MGMT	Wrong config file type
SSH	<username>(<user type>) {logout ejected idle timeout connection closed} from {Console Telnet/SSH}
SSH	<username>(<user type>) login {on Console from host <IP address>}
SSH	Error in setting the new config
SSH	New config set
SSH	scp<username>(<user type>) {logout ejected idle timeout connection closed} from {Console Telnet/SSH}
SSH	scp<username>(<user type>) login {on Console from host <IP address>}
SSH	server key autogen {starts completes}
SSH	Wrong config file type
SYSTEM	booted version <version> from Flash image <image>, {active backup factory} config block

LOG_NOTICE

Thread	LOG_NOTICE Message
	ARP table is full.
	Current config successfully tftp'd <filename> from <hostname>
	Current config successfully tftp'd to <hostname>: <filename>
	Port <port> mode is changed to full duplex for 1000 Mbps operation.
CONSOLE	RADIUS: authentication timeout. Retrying...
CONSOLE	RADIUS: failed to contact primary secondary server
CONSOLE	RADIUS: No configured RADIUS server
CONSOLE	RADIUS: trying alternate server...
HOTLINKS	"Error" is set to "Standby Active"
HOTLINKS	"Learning" is set to "Standby Active"
HOTLINKS	"None" is set to "Standby Active"
HOTLINKS	"Side Max" is set to "Standby Active"
HOTLINKS	has no "{Side Max None Learning Error}" interface
MGMT	<username> automatically logged out from BBI because changing of authentication type
MGMT	<username>(<user type>) {logout ejected idle timeout connection closed} from {BBI Console Telnet/SSH}
MGMT	<username>(<user type>) login {on Console from host <IP address> from BBI}
MGMT	Authentication failed for backdoor.
MGMT	Authentication failed for backdoor. Password incorrect!
MGMT	Authentication failed for backdoor. Telnet disabled!
MGMT	boot config block changed
MGMT	boot image changed
MGMT	boot mode changed
MGMT	enable password changed
MGMT	Error in setting the new config
MGMT	Failed login attempt via {BBI TELNET} from host <IP address>.
MGMT	Failed login attempt via the CONSOLE
MGMT	FLASH Dump cleared from BBI

Thread	LOG_NOTICE Message (continued)
MGMT	New config set
MGMT	packet-buffer statistics cleared
MGMT	PANIC command from CLI
MGMT	PASSWORD FIX-UP MODE IN USE
MGMT	Password for {oper operator} changed by {SNMP user <username>}, notifying admin to save.
MGMT	QSFP: Port <port> changed to {10G 40G}, from {BBI SNMP CLI}.
MGMT	RADIUS server timeouts
MGMT	RADIUS: authentication timeout. Retrying...
MGMT	RADIUS: failed to contact {primary secondary} server
MGMT	RADIUS: No configured RADIUS server
MGMT	RADIUS: trying alternate server...
MGMT	scp<username>(<user type>) {logout ejected idle timeout connection closed} from {Console Telnet/SSH}
MGMT	scp<username>(<user type>) login {on Console from host <IP address>}
MGMT	second syslog host changed to {this host <IP address>}
MGMT	selectable [boot] mode changed
MGMT	STP BPDU statistics cleared
MGMT	switch reset from CLI
MGMT	syslog host changed to {this host <IP address>}
MGMT	System clock set to <time>.
MGMT	System date set to <date>.
MGMT	Terminating BBI connection from host <IP address>
MGMT	User <username> deleted by {SNMP user <username>}.
MGMT	User <username> is {deleted disabled} and will be ejected by {SNMP user <username>}
MGMT	User {oper operator} is disabled and will be ejected by {SNMP user <username>}.
MGMT	Wrong config file type
NTP	System clock updated
OSPF	Neighbor Router ID <router ID>, Neighbor State {Down Loopback Waiting P To P DR BackupDR DR Other Attempt Init 2 Way ExStart Exchange Loading Full}

Thread	LOG_NOTICE Message (continued)		
SERVER	link {down up} on port <port>		
SSH	(remote disconnect msg)		
SSH	<username>(<user type>) {logout ejected idle timeout connection closed} from {Console Telnet/SSH}		
SSH	<username>(<user type>) login {on Console from host <IP address>}		
SSH	Error in setting the new config		
SSH	Failed login attempt via SSH		
SSH	New config set		
SSH	scp<username>(<user type>) {logout ejected idle timeout connection closed} from {Console Telnet/SSH}		
SSH	scp<username>(<user type>) login {on Console from host <IP address>}		
SSH	Wrong config file type		
SYSTEM	Change fiber GIG port <port> mode to full duplex		
SYSTEM	Change fiber GIG port <port> speed to 1000		
SYSTEM	Changed ARP entry for IP <IP address> to: MAC <MAC address>, Port <port>, VLAN <VLAN>		
SYSTEM	Enable auto negotiation for copper GIG port: <port>		
SYSTEM	I2C device <ID> <description> set to access state <state> [from CLI]		
SYSTEM	Port <port> disabled		
SYSTEM	Port <port> disabled due to reason code <reason code>		
SYSTEM	rebooted (<reason>)[, administrator logged in] Reason: <table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top; width: 50%;"> <ul style="list-style-type: none"> • Boot watchdog reset • console PANIC command • console RESET KEY • hard reset by SNMP • hard reset by WEB-UI • hard reset from console • hard reset from Telnet • low memory • MM Cycled Power Domain • power cycle • Reset Button was pushed • reset by SNMP • reset by WEB-UI </td> <td style="vertical-align: top; width: 50%;"> <ul style="list-style-type: none"> • reset from console • reset from EM • reset from Telnet/SSH • scheduled reboot • SMS-64 found an over-voltage • SMS-64 found an under-voltage • software ASSERT • software PANIC • software VERIFY • Telnet PANIC command • unknown reason • watchdog timer </td> </tr> </table>	<ul style="list-style-type: none"> • Boot watchdog reset • console PANIC command • console RESET KEY • hard reset by SNMP • hard reset by WEB-UI • hard reset from console • hard reset from Telnet • low memory • MM Cycled Power Domain • power cycle • Reset Button was pushed • reset by SNMP • reset by WEB-UI 	<ul style="list-style-type: none"> • reset from console • reset from EM • reset from Telnet/SSH • scheduled reboot • SMS-64 found an over-voltage • SMS-64 found an under-voltage • software ASSERT • software PANIC • software VERIFY • Telnet PANIC command • unknown reason • watchdog timer
<ul style="list-style-type: none"> • Boot watchdog reset • console PANIC command • console RESET KEY • hard reset by SNMP • hard reset by WEB-UI • hard reset from console • hard reset from Telnet • low memory • MM Cycled Power Domain • power cycle • Reset Button was pushed • reset by SNMP • reset by WEB-UI 	<ul style="list-style-type: none"> • reset from console • reset from EM • reset from Telnet/SSH • scheduled reboot • SMS-64 found an over-voltage • SMS-64 found an under-voltage • software ASSERT • software PANIC • software VERIFY • Telnet PANIC command • unknown reason • watchdog timer 		

Thread	LOG_NOTICE Message (continued)
SYSTEM	Received BOOTP Offer: IP: <IP address>, Mask: <netmask>, Broadcast <IP address>, GW: <IP address>
SYSTEM	Watchdog threshold changed from <old value> to <new value> seconds
SYSTEM	Watchdog timer has been enabled
TEAMING	error, action is undefined
TEAMING	is down, but teardown is blocked
TEAMING	is down, control ports are auto disabled
TEAMING	is up, control ports are auto controlled
VLAN	Default VLAN can not be deleted
VRRP	virtual router <IP address> is now {BACKUP MASTER}
WEB	<username> ejected from BBI
WEB	RSA host key is being saved to Flash ROM, please don't reboot the box immediately.

LOG_WARNING

Thread	LOG_WARNING Message
CFG	Authentication should be disabled to run RIPv2 in RIPv1 compatibility mode on interface <i><interface></i> .
CFG	Multicast should be disabled to run RIPv2 in RIPv1 compatibility mode on interface <i><interface></i> .
HOTLINKS	"Error" is set to "Standby Active"
HOTLINKS	"Learning" is set to "Standby Active"
HOTLINKS	"None" is set to "Standby Active"
HOTLINKS	"Side Max" is set to "Standby Active"
HOTLINKS	has no "{Side Max None Learning Error}" interface
MGMT	The software demo license for Upgrade2 will expire in 10 days. The switch will automatically reset to the factory configuration after the license expires. Please backup your configuration or enter a valid license key so the configuration will not be lost.
NTP	cannot contact [primary secondary] NTP server <i><IP address></i>
SYSTEM	I2C device <i><ID></i> <i><description></i> set to access state <i><state></i> [from CLI]
TEAMING	error, action is undefined
TEAMING	is down, but teardown is blocked
TEAMING	is down, control ports are auto disabled
TEAMING	is up, control ports are auto controlled

Appendix B. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you. This section contains information about where to go for additional information about IBM and IBM products, what to do if you experience a problem with your system, and whom to call for service, if it is necessary.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools that come with your system. Information about diagnostic tools is in the *Problem Determination and Service Guide* on the *IBM Documentation CD* that comes with your system.
- Go to the IBM support website at <http://www.ibm.com/systems/support/> to check for technical information, hints, tips, and new device drivers or to submit a request for information.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

Using the documentation

Information about your IBM system and pre-installed software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, ReadMe files, and Help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/systems/support/> and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

Getting help and information on the World Wide Web

On the World Wide Web, the IBM website has up-to-date information about IBM systems, optional devices, services, and support. The address for IBM System x[®] and xSeries[®] information is <http://www.ibm.com/systems/x/>. The address for IBM BladeCenter information is <http://www.ibm.com/systems/bladecenter/>. The address for IBM IntelliStation[®] information is <http://www.ibm.com/intellistation/>.

You can find service information for IBM systems and optional devices at <http://www.ibm.com/systems/support/>.

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with System x and x Series servers, BladeCenter products, IntelliStation workstations, and appliances. For information about which products are supported by Support Line in your country or region, see <http://www.ibm.com/services/sl/products/>.

For more information about Support Line and other IBM services, see <http://www.ibm.com/services/>, or see <http://www.ibm.com/planetwide/> for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services. To locate a reseller authorized by IBM to provide warranty service, go to <http://www.ibm.com/partnerworld/> and click **Find Business Partners** on the right side of the page. For IBM support telephone numbers, see <http://www.ibm.com/planetwide/>. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

IBM Taiwan product service

台灣 IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

IBM Taiwan product service contact information:

IBM Taiwan Corporation
3F, No 7, Song Ren Rd.
Taipei, Taiwan
Telephone: 0800-016-888

Index

Numerics

- 802.1p
 - and ETS 457
 - configuration 293, 314
 - DCBX PFC information 129
 - information 98, 99, 132
 - PFC configuration 458
 - Priority Group mapping 132
 - priority level 279, 299, 308
 - IPv6 303
 - priority value 316
 - re-marking the value (IPv6) 306
 - 802.1X
 - configuration 321
 - guest VLAN 323
 - information 35, 49
 - operations-level commands 495
 - port configuration 324
- ## A
- abbreviating commands (CLI) 9
 - access control
 - switch 271
 - user 273
 - Access Control List (see ACL) 100
 - ACL
 - add group 286
 - and VMAP 308
 - configuration 298
 - delete 496
 - Ethernet matching criteria 300
 - filtering criteria 299
 - groups 298
 - information 100, 101
 - IPv4 matching criteria 301
 - IPv6 303
 - list of FIPS ACLs 134, 135
 - metering configuration 313
 - Packet Format matching criteria 303
 - port ACL configuration 286
 - port configuration commands 286
 - QoS parameters 286
 - re-marking 314
 - re-marking (IPv6) 306, 307, 316
 - remove group 286
 - statistics 224, 225
 - TCP matching criteria 302
 - UDP matching criteria 302
 - active
 - configuration block 239, 518
 - IP interface 430
 - switch configuration
 - ptcfg 491
 - restoring 492

- saving and loading 492
- VLAN port 430
- addr (IP route tag) 62
- administrator account 10
- aging (STP information) 52
- asnum (attached switch number) 291
- autonomous system filter path
 - action 377
 - as 377
 - aspath 377

B

- backup configuration block 518
- bandwidth allocation, Priority Groups 457
- BGP 62
 - aggregation configuration 398
 - configuration 392
 - eBGP 392
 - filters, aggregation configuration 398
 - iBGP 392
 - in route 395
 - IP address, border router 394
 - keep-alive time 394
 - operations-level commands 498
 - peer 392
 - peer configuration 394
 - redistribution configuration 397
 - remote autonomous system 394
 - router hops 395
- bgp (IP route tag) 62
- boot
 - options 509 to 524
- Boot Management menu 522
- BOOTP
 - configuration 422
 - relay broadcast domain configuration 422
- Bootstrap Protocol (see BOOTP) 422
- Border Gateway Protocol (see BGP) 4
- bridge priority 53
- Bridge Protocol Data Unit (BPDU) 53, 333
- Bridge Spanning-Tree parameters 333
- broadcast (IP route tag) 63
- broadcast (IP route type) 62

C

- capture dump information to a file 542
- CEE
 - configuration 456
 - DCBX 533
 - information 125
- Cisco Ether Channel 342
- CIST information 53
- clear

- ACL statistics 224
- all defined management networks 272
- all IP statistics 174
- all IPv4 statistics 172, 175
- all IPv6 statistics 178
- ARP statistics 173
- DNS statistics 174
- dump information 544
- FCoE statistics 226
- Hot Links statistics 165
- ICMP statistics 174
- IGMP statistics 174
- LACP statistics 165
- MLD statistics 192
- OSPF statistics 174
- RIP statistics 174
- static route 368
- statistics for specific ports 145
- statistics on a specific trunk group 164
- TCP statistics 174
- UDP statistics 174
- VRRP statistics 174
- commands
 - abbreviations 9
 - conventions used in this manual xvi
 - help with 7
 - shortcuts 9
 - tab completion 9
- configuration
 - 802.1X 321
 - commands 237 to 492
 - default gateway interval, for health checks 367
 - default gateway IP address 367
 - dump command 490
 - failover 350
 - flow control 284, 288
 - IGMP 401
 - IP static route 368
 - port link speed 283
 - port mirroring 318
 - port trunking 342
 - RIP 378
 - RIP commands 379
 - save changes 239
 - SNMP 257
 - switch IP address 365
 - TACACS+ 249
 - VLAN default (PVID) 280
 - VLAN IP interface 365
 - VLAN tagging 280
 - VMware 482
 - VRRP 424
- configuration block
 - active 518
 - backup 518
 - factory 518
 - selection 518
- Control Plane Protection, configuration 295

- Converged Enhanced Ethernet (see CEE) 125
- COPP, configuration 295
- COS queue information 99
- cost
 - STP information 52
- cost (STP information) 54
- CPU use
 - history 223
 - statistics 220, 223
- D**
- daylight saving time 240
- DCB Capability Exchange Protocol (see DCBX) 125
- DCBX
 - Application Protocol information 130
 - configuration 459
 - control information 126
 - debugging 533
 - ETS information 127
 - feature information 127
 - information 125
 - PFC information 129
- debugging 527
- default gateway
 - information 59
 - interval, for health checks 367
 - IPv6 437
- default password 10
- delete
 - ACL statistics 224
 - all defined management networks 272
 - all IP statistics 174
 - all IPv4 statistics 172, 175
 - all IPv6 statistics 178
 - ARP statistics 173
 - DNS statistics 174
 - dump information 544
 - Hot Links statistics 165
 - ICMP statistics 174
 - IGMP statistics 174
 - LACP statistics 165
 - MLD statistics 192
 - OSPF statistics 174
 - RIP statistics 174
 - static route 368
 - statistics for specific ports 145
 - statistics on a specific trunk group 164
 - TCP statistics 174
 - UDP statistics 174
 - VRRP statistics 174
- DHCP
 - and BOOTP commands 422
 - and Netboot configuration 512
 - packets logged 216
- DiffServ Code Point (see DSCP) 294
- direct (IP route type) 62
- directed broadcasts 372

- disconnect idle timeout 11
- downloading software 515
- DSCP
 - configuration 294
 - disable for in-profile traffic 315
 - disable for out-profile traffic 315
 - re-mark for in-profile traffic 317
 - re-marking configuration 279, 294
 - set value of in-profile packets 315
 - set value of out-profile packets 315
- dump
 - configuration command 490
 - maintenance 527
- duplex mode
 - interface status 13
 - link status 107
- Dynamic Host Configuration Protocol (see DHCP) 422
- dynamic routes 535

E

- ECMP route information 79
- ECN (Explicit Congestion Notification) 296
- ECP
 - configuration 337
- Edge Virtual Bridging, configuration 484
- Enhanced Transmission Selection (see ETS) 132
- ENode 466
- Error Disable and Recovery
 - port 283
 - system 243
- EtherChannel, and port trunking 342
- ETS
 - configuration 457
 - information 125, 127, 132
 - Priority Group configuration 457
- EVB
 - configuration 484
 - configuration mode 5
 - information 115
- Explicit Congestion Notification (ECN) 296

F

- factory configuration block 518
- failover
 - auto monitor configuration 351
 - configuration 350
 - Layer 2 configuration 350
 - Layer 2 information 36, 41
 - manual monitor port configuration 352
 - trigger configuration 351
 - uplink, for vNIC group 473
- FCF port 466
- FCoE
 - configuration 465
 - FIPS port configuration 466
 - forwarding 466

- information 134
- Initialization Protocol (see FIP) 466
- statistics 226

FDB

- configuration 335
- configuring static entries 337
- hot links update 354
- information 37
- learning 281
- maintenance 527, 529
- troubleshooting 527, 529
- Fiber Channel Initialization Protocol (see FIP) 134
- Fibre Channel
 - configuration 6, 460
 - information 135
- Fibre Channel over Ethernet (see FCoE) 134
- FIP
 - Snooping (see FIPS) 466
 - snooping information 134

FIPS

- list of ACLs 134
- port configuration 466
- fixed (IP route tag) 62
- flag field 64
- flow control
 - configuring 284, 288
 - configuring for port link 283
 - configuring management port 288
 - information 13, 107
 - Ingress Back Pressure 156
 - pause packets 154, 155
 - priority (see PFC) 129
- Forwarding Database (see FDB) 37
- forwarding state
 - (FWD) 54
- forwarding state (FWD) 38, 55
- FWD (port state) 38
- fwd (STP bridge option) 333
- FwdDel (forward delay), bridge port 52, 54

G

- getting help 561
- gtcfg (TFTP load command) 492

H

- hardware service and support 566
- health checks
 - default gateway interval, retries 367
 - retry, number of failed health checks 367
- hello (STP information) 51, 53
- help
 - getting 561
 - online 7
- Hot Links configuration 354
- hot-standby failover 428
- http

- controlling access 269
 - port 269
- HTTPS 276

I

- IBM support line 565
- ICMP statistics 186
- idle timeout, setting 11
- IEEE standards
 - 802.1p 293
 - 802.1X 49
- IGMP
 - advanced parameters 410
 - configuration 401
 - filter definition commands 408
 - filtering configuration 407
 - filtering port configuration 409
 - group information 82
 - group maintenance 537
 - mrouter maintenance commands 538
 - multicast group information 80
 - multicast
 - group information 80
 - multicast router information 82
 - relay configuration 404
 - relay mrouter configuration 405
 - snooping configuration 402
 - static mrouter configuration 406
 - statistics 190
- IGMPv3
 - and stacking mode 510
 - configuration 403
 - information 82
 - snooping information 538
 - statistics 190
- IKEv2
 - configuration 413
 - configuration mode 5
 - debugging 532
 - identification configuration 414
 - information 59, 91
 - information commands 90
 - preshare key configuration 414
 - proposal configuration 413
- image
 - downloading 515
 - software, selecting 516
- indirect (IP route type) 62
- information
 - VMware 113
- Information Commands 13 to 142
- Interface change stats 202
- IP address
 - ARP information 63
 - configuring default gateway 367
- IP forwarding
 - configuration 372

- directed broadcasts 372
 - information 59
- IP Information 59, 89
- IP interfaces 62
 - active 430
 - configuring address 365
 - configuring VLANs 365
 - information 59
 - IP route tag 62
 - priority increment value (ifs) for VRRP 432
- IP network filter configuration 373
- IP route
 - manipulation 535
 - tag parameters 62
- IP Static Route commands 368
- IP statistics 175
- IPMC group information 83
- IPsec
 - configuration 415
 - debugging 532
 - dynamic policy configuration 418
 - information 92
 - Layer 3 configuration 449
 - manual policy configuration 419
 - manual policy information 93
 - traffic selector configuration 417
 - transform set configuration 416
- IPv6
 - ACL configuration 303
 - default gateway configuration 437
 - interface information 87
 - Neighbor Discovery
 - cache configuration 438
 - cache information 78
 - cache information commands 78
 - cache manipulation 540
 - prefix configuration 439
 - prefix information 79
 - Path MTU
 - configuration 439
 - information 88
 - re-mark configuration 306, 307
 - re-marking
 - configuration 316
 - in-profile configuration 317
 - routing information 77
 - static route 438
 - statistics 178
- IPv6 route 184
- ISCLI command modes 3

L

- LACP
 - add trunk to vNIC Group 474
 - admin key
 - add to Auto Monitor 351
 - add to Backup interface 357

- add to Manual Monitor Control 353
- add to Manual Monitor Port 352
- add to Master interface 356
- add to VM group 479
- remove from Auto Monitor 351
- remove from Manual Monitor Control 353
- remove from Manual Monitor Port 352
- remove from VM group 479
- aggregator information 40
- and trunk hash configuration 343
- configuration 348
- information 40
- port configuration 349
- port status information 40
- remove trunk from vNIC group 474
- show trunk groups 36
- statistics 165, 166
- virtual (see vLAG) 345
- Layer 2 commands 35
- Layer 3 commands 58
- LDAP server configuration 252
- Lightweight Directory Access Protocol (see LDAP) 252
- Link Aggregation Control Protocol (see LACP) 36
- Link Layer Discovery Protocol (see LLDP) 44
- link speed, configuring 283
- link status 13
 - command 107
 - duplex mode 13, 107
 - information 106
 - port speed 13, 107
- linkt (SNMP option) 258
- LLDP
 - cache manipulation commands 536
 - configuration 338
 - disable 338
 - enable 338
 - information 44
 - packets received 211
 - PDU's logged 217
 - remote device information 45
 - statistics 165, 168
 - TLV configuration 340
- local (IP route type) 62
- log, syslog messaging options 245
- LRN (port state) 54

M

- MAC address
 - ARP information 63
 - display 14
 - FDB information 37
 - FDB maintenance 529
 - multicast, configuring 336
 - switch management processor 26
- MAC address spoof prevention 480
- Maintenance commands 527
- Management Processor (see MP) 14

- manual style conventions xvi
- martian
 - IP route tag (filtered) 63
 - IP route type (filtered out) 62
- MaxAge (STP information) 52, 54
- MD5
 - cryptographic authentication 384
 - key 387
 - key configuration, OSPF 391
- meter
 - ACL
 - configuring 313
 - current parameters 313
 - delete 313
 - log, configuring 313
 - port metering 309
 - configuring vNIC bandwidth 472
 - readiness 522
- Miscellaneous Debug commands 531
- MLD
 - configuration 399
 - configuration mode 5
 - global statistics 193
 - information 59, 84
 - mrouter information 85
 - statistics 192
- monitor port 318
- MP
 - display MAC address 14, 26
 - packet statistics 207
 - snap trace buffer 531
 - statistics 206
 - trace buffer 531
- Mrouter information 82
- MST
 - configuration mode 5
- MTU 439
- multicast
 - IP route type 62
 - router information 82
 - static MAC configuration 336
- Multicast Listener Discovery protocol (see MLD) 5
- multiple management VLANs 358
- mxage (STP bridge option) 333

N

- nbr change statistics 201
- Neighbor Discovery
 - cache configuration, IPv6 438
 - cache manipulation, IPv6 540
 - prefix 439
- Neighbor Discovery prefix 439
- notice 241
- NTP synchronization 256

O

OAM

- information 47
- statistics 144, 165, 169

online help 7

Operations commands 493

operations-level

- 802.1X port commands 495
- BGP commands 498
- port commands 494
- VRRP options 497

OSPF

- and stacking mode 510
 - area index 384
 - authentication key 387
 - configuration 382
 - host entry 390
 - interface 387
 - MD5 key 391
 - route redistribution 391
 - summary range 386
 - virtual link 389
 - cost of the selected path 387
 - cost value of the host 390
 - dead
 - declaring a silent router to be down 387
 - health parameter of a hello packet 389
 - export 391
 - fixed routes 392
 - general information 69
 - hello, authentication parameter of a hello packet 389
 - host routes 382
 - information
 - commands 67
 - database 70
 - general 68
 - interface 69
 - interface loopback 69
 - route 71
 - interface 382
 - link state database 382, 442
 - Not-So-Stubby Area 384, 443
 - priority value of the switch interface 387
 - range number 382
 - SPF, shortest path first 384
 - statistics
 - commands 195
 - delete 174
 - global 196
 - stub area 384, 443
 - transit area 384, 443
 - transit delay 387
 - type 384
 - virtual link 382
 - virtual neighbor, router ID 389
- ospf (IP route tag) 62
- OSPFv3
- and stacking mode 510

- configuration 441
 - area index 443
 - interface 447
 - virtual link 451
- dead
 - declaring a silent router to be down 448
 - health parameter of a hello packet 451
- hello, authentication parameter of a hello packet 451
- information
 - commands 72
 - database 74
 - dump of 73
 - interface 74
 - route 75
- statistics
 - commands 199
 - global 200
- type 443
- virtual neighbor, router ID 451

P

- parameters
- tag 62
 - type 62
- passwords 10
- administrator account 10
 - changing 273
 - default 10
 - user account 10
- Path MTU 439
- path-cost (STP port option) 334
- PFC configuration 458
- PIM mode 433
- ping 7
- poisoned reverse, as used with split horizon 379
- port
- ACL configuration 286
 - configuration 279
 - disabling temporarily 284
 - Error Disable and Recovery 283
 - failover manual monitor configuration 352
 - FIPS configuration 466
 - HTTP 269
 - IGMP filtering configuration 409
 - information 109
 - LACP
 - configuration 349
 - status information 40
 - link configuration 283
 - link speed, configuring 283
 - management, configuring 288
 - membership of the VLAN 36, 57
 - mirroring, configuring 318
 - number 107
 - priority 54
 - reference 38
 - speed 13, 107

- state information 38
- telnet 270
- TFTP 270
- trunking
 - configuration 342
 - description 342
- VLAN ID 13, 109
- port ECN configuration 287
- port WRED configuration 287
- preemption
 - assuming VRRP master routing authority 427
 - hot links trigger, configuring 355
 - virtual router, configuring 426
 - VRRP, configuring 429
- Priority Flow Control 458
- Priority Groups
 - 802.1p mapping to 132
 - configuration 457
 - information 127
- Private VLAN 362
- Protected Mode 499
- Protocol-based VLAN (see PVLAN) 360
- ptcfg (TFTP save command) 491
- PVID (port VLAN ID) 13, 109
- PVLAN
 - configuration 358, 360
 - current parameters 361

Q

- QoS
 - ACL parameters 286
 - configuration 286, 293
 - control plane protection 295
 - DSCP configuration 294
 - ECN information 99
 - information 98
 - transmit-queue information 98
 - WRED information 99

R

- RADIUS server
 - 802.1X response timeout, setting 322
 - and 802.1X configuration 321
 - configuration commands 247
 - current parameters 248
 - packets logged 216
 - primary 247
 - shared secret 247
- receive flow control 284, 288
- reference ports 38
- re-mark
 - ACL
 - configuration 311, 314
 - parameters 101
 - DSCP
 - configuration 279

- global configuration 294
- in-profile
 - configuration 315
 - settings 311
- IPv6 ACL 306, 307
 - configuration 316
 - in-profile configuration 317
- out-of-profile
 - configuration 315
 - settings 311
- TOS precedence, configuring 311
- user update priority 311
- Remote Monitoring (RMON) 467
- Rendezvous Point (RP) 434
- retries
 - health checks for default gateway 367
 - radius server 247
- RIP
 - and stacking mode 510
 - configuration 378, 379
 - BGP redistribution 397
 - route redistribution 381
 - configuration mode 4, 378
 - information 76
 - interface 76
 - routes 76
 - user configuration 58, 76
 - IPv4 route statistics 183
 - packets logged 217
 - poisoned reverse 379
 - split horizon 379
 - statistics 173, 174, 205
 - version 379
- rip (IP route tag) 62
- RMON
 - configuration 467
 - information 102
- route statistics
 - IPv4 183
 - IPv6 184
- router hops 395
- Routing Information Protocol (see RIP) 4
- RSTP information 50
- Rx/Tx statistics 196, 200

S

- save (global command) 239
- secret, RADIUS server 247
- Secure Shell 246
- service and support 566
- shortcuts (CLI) 9
- SLP
 - configuration 488
 - information 118
 - statistics 233
- snap trace buffer 531
- SNMP

- configuration
 - commands 257
 - current 258
 - link traps 258
 - location 257
 - read community string 257
 - source interface for traps 258
 - system authentication trap 258
 - system contact 257
 - timeout 258
 - trap host server 258
 - version 260
 - write community string 258
- options 257
- statistics 228
- SNMPv3
 - configuration
 - access rights 259
 - commands 259
 - community table 259, 265
 - destination 260
 - display 260
 - group 259, 264
 - MIB views 259
 - Notify table 268
 - parameters 260
 - target address table 266
 - target parameters 267
 - user access 263
 - user security 261
 - USM 259, 261
 - version 260
 - view 262
 - information 24
 - access 20
 - commands 17
 - community table 21
 - group 20
 - Notify table 23
 - target address table 21
 - target parameters table 23
 - USM user table 18
 - View Table 19
- software
 - image 515
 - image file and version 14, 26
 - service and support 565
 - upgrade recovery 522
- SPAR. *See* Switch Partition.
- split horizon 379
- Stacking
 - boot options 509
 - configuration 290
- state (STP information) 52, 54
- static (IP route tag) 62
- static multicast MAC 336
- static route
 - add 368
 - delete 368
 - IPv6 438
- statistics
 - 184
 - 802.1X 146
 - ACL 224
 - ARP 184
 - bridging 150
 - commands 143 to 235
 - CPU 220
 - DNS 185
 - ethernet 151
 - FCoE 226
 - hot links 167
 - ICMP 186
 - IGMP 190
 - interface 154
 - interface protocol 157
 - IPv4 175
 - IPv4 route 183
 - IPv6 178
 - LACP 166
 - Layer 2 165
 - Layer 3 172
 - link 157
 - LLDP 168
 - logged packet 215
 - management processor 206
 - MLD 192
 - NTP 232
 - OAM 169
 - OSPF 195
 - OSPFv3 199
 - port 144
 - RIP 205
 - RMON 158
 - SNMP 228
 - TCP 188, 219
 - trunk group 164
 - UDP 189, 220
 - VMAP 225
 - VRRP 203
- STG
 - information 35
- STP
 - and trunk groups 55
 - bridge parameters 333
 - bridge priority 53
 - configuration 326
 - information 328
 - path-cost option 334
 - root bridge 53, 333
 - RSTP/PVRST 332
 - switch reset effect 519
- support
 - line 565
 - Web site 565
- switch

- name and location 14, 26
- resetting 519
- Switch Partition (SPAR)
 - configuration 487
- Switch Partition (SPAR)
 - configuration 6
- system
 - date and time 14, 26
 - information 14, 26
- System Error Disable and Recovery 243

T

- tab completion (CLI) 9
- TACACS+ 249
- TCP statistics 188, 219
- technical assistance 561
- telephone assistance 565
- telephone numbers 567
- telnet
 - configuring switches using 490
 - controlling access 270
 - port 270
 - radius server 247, 248, 252
- text conventions xvi
- TFTP 515
 - port 270
 - PUT and GET commands 491
 - server 491
- timeout
 - idle connection 11
 - radius server 247
- timers kickoff 199, 202
- TLV 340
- trace buffer 531
- traceroute 8
- transceiver status 110
- transmit flow control 284, 288
- Trunk group information 54
- trunk hash algorithm 343
- type of area
 - OSPF 384
 - OSPFv3 443
- type parameters 62
- typographic conventions, manual xvi

U

- UCB statistics 220
- UDLD
 - configuration 285
 - information 46
 - statistics 210, 215
- UDP statistics 189
- UFP. See Unified Fabric Port.
- UFP. See Universal Fabric Port.
- Unified Fabric Port (UFP)
 - configuration 475

- Universal Fabric Port (UFP)
 - configuration 6
- unknown (UNK) port state 38
- Unscheduled System Dump 545
- upgrade
 - recover from failure 522
 - switch software 515
- user access control configuration 273
- user account 10
- Uuencode Flash Dump 542

V

- Virtual Link Aggregation Control protocol (see vLAG) 345
- virtual router
 - description 425
 - increasing priority level of 427
 - priority increment values (vrs) for VRRP 432
 - tracking criteria 427
- virtual router group
 - configuration 428
 - priority tracking 430
- Virtual Router Redundancy Protocol (see VRRP) 5
- virtualization
 - configuration 471
 - information 112
- vLAG
 - configuration 345
 - information 346
- VLAN
 - active port 430
 - ARP entry information 63
 - configuration 358
 - information 57
 - name 36
 - Number 57
 - port membership 36, 57
 - setting access VLAN 280
 - setting default number (PVID) 280
 - tagging 109
 - port configuration 280
 - port restrictions 359
 - port use of 13
 - Type 57
- VLAN Map (see VMAP) 308
- VM
 - bandwidth management 471
 - Distributed Virtual Switch 503
 - Edge Virtual Bridge configuration 484
 - group configuration 477
 - information 112
 - policy configuration 471
 - profile configuration 481
 - VMready configuration 483
 - VMware
 - configuration 482
 - dvSwitch operations 503, 504

- information 113
- operations 501
- VM Check
 - configuration 479, 480, 482
 - information 113
- VMAP
 - configuration 308
 - definition 308
 - information 56, 100
 - statistics 225
- VMware
 - configuration 482
 - distributed port group operations 504
 - dvSwitch administration 503
 - information 113
 - operations 501
- VNIC
 - configuration 472
 - group configuration 473
 - information 116
- VRRP
 - authentication parameters for IP interfaces 431
 - configuration 424
 - configuration mode 5
 - information 86
 - interface configuration 431
 - master advertisements 426
 - master advertisements, time interval 428
 - operations-level options 497
 - priority tracking options 394, 427
 - statistics 203
 - tracking configuration 432
- VSI
 - configuration mode 5

W

- watchdog timer 527
- Web site
 - ordering publications 563
 - support 565
 - telephone support numbers 566
- weight
 - COS queue 98, 293
 - COS scheduling 99
 - route map 375
 - setting virtual router priority values 432
 - VRRP priority 432
- Weighted Random Early Detection (WRED) 296
- WRED (Weighted Random Early Detection) 296



Part Number: 00CG953

Printed in USA

(IP) P/N: 00CG965